사용설명서 Operating Instructions

CRP-M1059F Series

1.8L(2~10 Persons) / 1.8L(2~10인분)



happiness

NO.1 CUCKOO Electric Pressure Rice cooker/warmer



love

lesign

CUCKOO ELECTRONICS CO., LTD.

CONTENTS

Thank you very much for purchasing "CUCKOO" Electric Rice cooker/warmer

Read the following instruction manual before use. Save this instruction manual for future reference. This manual will be useful if you have any questions or have problems operating the rice cooker.

저희 쿠쿠 압력보온밥솥을 애용해 주셔서 대단히 감사 드립니다.

이 사용설명서는 잘 보관하여 주십시오. 사용 중에 모르는 사항이 있을 때나 기능이 제대로 발휘되지 않을 때 많은 도움이 될 것입니다.

CONTENTS

BEFORE USING

Cooking Guide

----- 68~69

Important safeguards 3~4 Important safeguards 3 제품규격5 Mesures de protection importantes ----- 4 Specifications / Spécifications ----- 5 안전상의 경고 ……………………… 39~42 43 각 부분이 이름 Mesures de sécurité ------ 35~38 제품 손질 방법 44~46 기능 조작부의 이름과 역할47 How to clean 11~13 기능 표시부의 이상점검 기능47 WHEN USING 시용할 때 현재시각의 설정 48 음성안내 기능의 설정과 해제48 취사전 준비사항 49 Before cooking rice16 맛있는 밥을 드시려면 ······ 50 For the best taste of rice ------ 17 취사는 이렇게 하십시오 ………………… 51~52 쿠쿠 맞춤밥맛 기능은 이렇게 하십시오 53~55 MY MODE (Cuckoo Customized Taste Function) ... 20~22 현미발아는 이렇게 하십시오 56~57 How to use "GABA (Brown rice)" ----- 23~24 만능찜 누룽지는 이렇게 하십시오58 How to cook using MULTI-COOK and NU RUNG JI 25 예약 취사는 이렇게 하십시오59~60 밥을 맛있게 보온하려면 61~63 To keep cooked rice warm and tasty 28~30 버튼잠금 기능은 이렇게 하십시오 ······ 64 이간 음성 볼륨 줄임 기능은 이렇게 하십시오 64 BEFORE ASKING FOR SERVICE 고장 신고 전에 고장신고 전에 확인 하십시오65~67 Check before asking for service 32~34 COOKING GUIDE 요리안내

요리안내

목 차

시용하기전에

IMPORTANT SAFEGUARDS

- 1. Read all instructions before using this appliance.
- 2. Do not touch hot surfaces. Use handles or knobs.
- 3. To protect against fire, electric shock and / or injury to persons do not immerse cord, plugs, or Pressure Cooker Body in water or any other liquid.
- 4. Close supervision is necessary when this appliance is used by or near children. This appliance is not intended for use by young children without supervision.
- 5. Unplug cord from outlet when not in use and before cleaning.
 - Allow appliance to cool before putting on or taking off parts, and before cleaning the appliance.
- 6. Do not operate any appliance with a damaged cord or plug, after the appliance malfunctions, or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
- 7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, and / or injury to persons.
- 8. If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or your service agent.
- 9. Do not use outdoors.
- 10. Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- 11. Do not place on or near a hot gas, electric burner, or in a heated oven.
- 12. Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, or set all control to "off", then remove the plug from the wall outlet.
- 13. Do not use this appliance for other than its intended use.
- 14. Extreme caution must be used when moving an appliance containing hot oil or any hot liquids.
- 15. Oversized foods, metal foil packages, or utensils must not be inserted into the appliance as they are a risk of fire or electric shock.
- Fire may occur if the appliance is covered or touching flammable material, including curtains, draperies, walls, etc while in operation.
- 17. To reduce the risk of electric shock, cook only in the provided removable container.
- 18. This appliance cooks under pressure. Improper use may result in scalding injury. Before operating the unit, properly secure and close the unit. See "Operating Instructions."
- 19. Do not cook foods such as applesauce, cranberries, cereals, macaroni, spaghetti, or other foods. These foods tend to foam, froth, and sputter, and may block the pressure releasing device
- 20. Before use always check the pressure releasing device for clogging.
- 21. Do not open the pressure cooker until the unit has cooled and internal pressure has been reduced. See "Operating Instructions."
- 22. Do not use this pressure cooker to fry in oil.

SAVE THESE INSTRUCTIONS THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

ADDITIONAL IMPORTANT SAFEGUARDS

WARNING: This appliance generates heat and releases steam during use. Use proper precaution to prevent risk of burns, fires, other injuries, or damage to property.

- 1. Keep hands and face away from the Pressure Release Valve when releasing pressure.
- 2. Take extreme caution when opening the Lid after cooking. Severe burns can result from steam inside.
- 3. Never open the Lid while the unit is in operation.
- 4. Do not use without the inner Pot in place.
- 5. Do not cover the Pressure Valve with anything as an explosion may occur.
- Do not touch the inner pot nor any heating parts, immediately after use.Allow the unit to cool down completely first.

This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments.

MESURES DE PROTECTION IMPORTANTES

- 1. Lisez toutes les instructions avant d'utiliser cet appareil.
- 2. Ne touchez pas les surfaces chaudes. Utilisez les poignées ou les boutons.
- 3. Pour prévenir les risques d'incendie, les chocs électriques et/ou les blessures, ne plongez pas le cordon, les prises ou le corps autocuiseur dans l'eau ou tout autre liquide.
- 4. Une surveillance étroite est nécessaire quand cet appareil est utilisé par des enfants ou qu'il se situe à leur portée. Cet appareil n'est pas prévu pour être utilisé par de jeunes enfants sans surveillance.
- 5. Débranchez le cordon de la prise lorsque vous ne vous servez pas de l'appareil et avant de le nettoyer. Laissez l'appareil refroidir avant de remettre en place ou de retirer des pièces, et avant de le nettoyer.
- 6. Nutilisez aucun appareil si le cordon ou la fiche est endommagé, s'il ne fonctionne pas correctement ou s'il est endommagé de quelque facon que ce soit. Renvoyez l'appareil à un centre technique agréé le plus proche pour le faire examiner, réparer ou régler.
- 7. L'utilisation d'accessoires non recommandés par le fabricant peut causer un incendie, un choc électrique et/ou des blessures
- 8. Si le cordon d'alimentation est endommagé, il doit être remplacé par un cordon ou ensemble prévu à cet effet. disponible auprès du fabricant ou de réparateurs agréés.
- 9. N'utilisez pas l'appareil à l'extérieur.
- 10. Ne laissez pas le cordon pendre d'une table ou d'un comptoir. Ne le laissez pas non plus en contact avec une surface chaude.
- 11. Ne placez pas l'appareil au-dessus ou près d'un brûleur à gaz, sur une plaque électrique ou dans un four chaud.
- 12. Branchez toujours la fiche sur l'appareil en premier, puis branchez le cordon dans la prise murale. Pour débrancher, ou désactiver toutes les commandes, retirez la fiche de la prise murale.
- 13. N'utilisez pas cet appareil à des fins autres que celles pour lesquelles il a été concu.
- 14. Une prudence extrême est requise lorsque vous déplacez l'appareil contenant de l'huile chaude ou tout autre liquide chaud.
- 15. Des denrées alimentaires de taille excessive, les emballages sous feuille métallique, ou les ustensiles ne doivent pas être insérés dans l'appareil car ils constituent un risque d'incendie ou de choc électrique.
- 16. Un incendie peut se déclarer si l'appareil est couvert ou en contact avec des matériaux inflammables, y compris des rideaux ou des draperies, des murs, etc durant son fonctionnement.
- 17. Afin de réduire le risque de choc électrique, faites cuire uniquement dans le récipient amovible fourni.
- 18. Cet appareil cuit sous pression. Un mauvais usage peut entraîner des brûlures. Avant d'utiliser l'appareil, mettez l'appareil bien en place et fermez-le. Reportez-vous à la section « Instructions d'utilisation ».
- 19. Ne cuisinez pas des aliments tels que compotes de pommes, canneberges, céréales, macaronis, spaghettis ou autres. Ces aliments ont tendance à mousser, écumer et à crépiter et peuvent obstruer le dispositif de relâchement de la pression.
- 20. Avant toute utilisation, vérifiez toujours si le dispositif de relâchement de la pression est obstrué.
- 21. N'ouvrez pas l'autocuiseur jusqu'à ce que l'appareil ait refroidi et que la pression interne ait diminué. Reportez-vous à la section « Instructions d'utilisation ».
- 22. N'utilisez pas cet autocuiseur pour faire frire dans de l'huile.

CONSERVEZ CES INSTRUCTIONS

CET APPAREIL EST DESTINÉ À UN USAGE DOMESTIQUE UNIQUEMENT

MESURES DE PROTECTION SUPPLÉMENTAIRES

- AVERTISSEMENT : Cet appareil génère de la chaleur et libère de la vapeur durant son fonctionnement. Utilisez les protections appropriées pour prévenir le risque de brûlures, d'incendies, de blessures ou de dégâts matériels.
- 1. Gardez vos mains et votre visage à l'écart de la soupape de décharge lors du relâchement de la pression.
- 2. Faites extrêmement attention lors de l'ouverture du couvercle après la cuisson. La vapeur à l'intérieur peut provoquer des brûlures graves.
- 3. N'ouvrez jamais le couvercle lorsque l'appareil est en fonctionnement.
- 4. N'utilisez pas l'appareil sans la cuve de cuisson à sa place.
- 5. Ne recouvrez pas la soupape de pression par un objet quelconque, une explosion pourrait survenir.
- 6. Ne touchez pas la cuve de cuisson ni les éléments chauffants immédiatement après utilisation. Laissez tout d'abord l'appareil refroidir complètement. Cet appareil est prévu pour être utilisé à la maison à des fins telles que :
- la cuisine pour le personnel dans des magasins, des bureaux et d'autres environnements de travail;
- les fermes:
- par des clients dans des hôtels, des motels et autres environnements de type résidentiel;
- des environnements de type chambres d'hôtes.

HOW TO USE EXTENSION CORD / COMMENT UTILISER UNE RALLONGE

Note:

- A. A short power-supply cord (or cord set) is provided to reduce the hazards from entanglement by a longer cord.
- **B.** Extension cord should be used properly.
- C. Extension cord usage for the rice cooker:
 - (1) The correct rated voltage should be used for the rice cooker.
 - (2) If the appliance is set on the ground, the extension cord should also be set on the ground.
 - (3) The cord wires and extension cord should always be arranged to prevent hazards to children.

This appliance has a polarized plug: (one blade is wider than the other).

As a safety feature, this plug will fit in a polarized outlet only one way.

If the plug does not properly fit in the outlet, turn the plug over.

If it still does not fit, contact a qualified electrician.

Please, keep this safety feature.

Remarque:

- A. Un cordon d'alimentation court (ou câble) est fourni pour réduire les dangers d'emmêlement causés par un cordon plus long.
- B. La rallonge doit être utilisée correctement.
- C. L'utilisation de la rallonge pour le cuiseur à riz :
 - (1) La tension nominale correcte doit être utilisée pour le cuiseur à riz.
 - (2) Si l'appareil est installé sur le sol, la rallonge doit aussi être installée sur le sol.
 - (3) Les câbles et la rallonge doivent toujours être disposés dans le but d'éviter les dangers pour les enfants.

Cet appareil dispose d'une fiche polarisée : (une broche est plus large que l'autre).

Par mesure de sécurité, cette fiche ne peut s'enfoncer dans une prise polarisée que dans un seul sens.

Si la fiche ne s'enfonce pas correctement dans la prise, retournez-la.

Si elle ne s'enfonce toujours pas, contactez un électricien qualifié.

Veuillez respecter cette mesure de sécurité.

SPECIFICATIONS / 제품규격 / SPÉCIFICATIONS

Model Name / NOM D	U MODÈLE (모델명)	CRP-M10 Fuzzy Series		
Power Supply / CORDON	D'ALIMENTATION(전원)	AC120V, 60Hz		
Power Consumption / CONSOMI	MATION D'ÉNERGIE(소비전력)	1150W		
	Glutinous Rice(백미)	0.36~1.8L (2~10cups)		
	Sushi(김초밥)	0.36~1.44L (2~8cups)		
Cooking Capacity	Mixed Ricce(잡곡)	0.50~1.44L (2~0cups)		
CAPACITÉ DE CUISSON	GABA(현□/발())			
(취사용량)	Old Rice(묵은쌀)	0.36~1.08L (2~6cups)		
	Turbo Glutinous Rice(백미댊속)			
	Nu Rung Ji(누룽지)	0.36~0.72L (2~4cups)		
	Porridge(至)	0.18~0.36L (1~2cups)		
Power Cord Length/LONGUEUR DU COR	DON D'ALIMENTATION(전면 코드길이)	1.0m		
Pressure / PRESS	SION (사용압력)	78.4KPa(0.8kgf/cm ²)		
Weight / PC)IDS(중량)	6.9kg		
	Width/LARGEUR(폭)	29.4cm		
Dimension/DIMENSION(치수)	Length/LONGUEUR(길이)	39.5cm		
	Height/HAUTEUR(높())	29cm		

HOW SERVICE IS HANDLED / MISE EN OEUVRE DU SERVICE

USA The East and the Central Districts

Tel. No. 718 888 9144

The West and the Central Districts Tel. No. 323 780 8808 Canada TOF

TORONTO Tel. No. 905 707 8224

VANCOUVER Tel. No. 604 540 1004



- Read the following product safety guide carefully to prevent any accidents and/or serious danger.
- Warning' and 'Caution' are different as follows.

Warning

This means that the action it describes may result in death or severe injury.



Caution

This means that the action it describes may result in injury or property damage.



- This sign is intended to remind and alert that something may cause problems under the certain situation.
- · Please read and follow the instruction to avoid any harmful situation.
- Indicates a prohibition
- - Indicates an instruction



Do not

Do not cover the automatic steam outlet or pressure weight with your hand or face.

- . It can cause burns.
- · Especially be careful to keep it out of children's reach.



Please pay careful attention against water and chemicals

 It can cause an electric shock or fire.

materials nearby a product.

• It can cause explosion or fire.

power cord, plug, or loose

Do not use damaged

socket.



Do not use the cooker near hot things such as stove, gas stove or direct ray of light.



 It can cause an electric shock. fire, deformation, malfunction, or discoloration. Please check the power cord and plug frequectly.

Do not alter, reassemble, disassemble or repair.

- . It can cause fire, electric shock or injury.
- · For repair, contact dealer or the service center.



Serious damage can cause electric shock or fire.

- Please check the power cord frequently for damage.
- If the plug is damaged, contact the dealer or a service center.

Do not use a rice cooker at a place where dust

is trapped or chemical material is located.

Do not use any combustible gas or flammable

Use a single socket with the rated current above 15A.

- · Using several lines in one socket can cause overheating or fire. Please check the power cord and plug frequently.
- · Use an extension cord with the rated current above 15A



- It can cause an electric shock or fire.
- . If it contacts water, please separate power cord and contact dealer and service center.





Warning

Do not

Do not cover the automatic steam outlet or pressure weight with a duster, a towel, or apron, etc.



- It can cause deformation or a breakdown.
- It can cause an explosion by pressure.

Do not use pots that are not designed for the cooker.

Do not use abnormal pot and do not use without the inner pot.



. It can cause an electric shock or fire.

Do not use it without the inner pot.

- · It can cause electric shock or malfunction.
- Do not pour rice or water without the inner pot.
- If rice or water gets in then do not turn the product over or shake it, please contact the dealer or service center.

Do not turn the Lock/Unlock Handle to "Unlock" while cooking.

- The hot steam or any hot content within the cooker can cause burns.
- After you finish the cooking do not try to open the cooker by force until the steam is completely exhausted.

Do not over unplug and plug the power cord over and over.

• It can cause an electric shock or fire.

Do not insert metal objects such as pins and wires or any other external substances in the automatic steam exhaust outlet or any other slot.




- It can cause an electric shock or fire.
- Especially be careful to keep it out of reach of children.

Keep the cooker out of reach of children.

· It can cause burns, electric shock or injury.

Don't spray or put any insecticides or chemicals.

- It can cause an electric shock or fire.
- If cockroaches or any insects get inside the cooker, please call a dealer or a service center.



- It can cause an electric shock or fire.
- Do not put a cleaning pin in a gap or a hole of the product except when dearing a steam outlet.

Do not open the top cover while in heating and cooking.

- · It can cause burns.
- If you need to open the lid while cooking, keep pressing the cancel button for 2 seconds and confirm internal steam released completely turning the pressure weight over.

Do not bend, tie, or pull the power cord by force.

 It can cause an electric shock or short circuit resulting in fire. Please check the power cord and plug frequently.

Do not pull out the clean steam vent by force.


• When separated it, the steam control vent can be damaged.

Please make sure you clean and check the assembly condition of the clean steam vent before and after use.

- If you have any problem with assembly and cleaning of the clean steam vent, please call a dealer or service center.
- . Keep clean the product before and after use.

Be careful that both the plug and power cord are not to be shocked by animal attack or sharp metal materials.

- Damages by impact can cause an electric shock or fire.
- Please check the power cord and plug frequently.



• It can cause fire. Please check the power cord and plug frequently.









Remember

Do not use it on a rice chest or a shelf.

- Do not place the power cord
 between furniture. It can cause
 an electric shock resulting in fire.

 Please check the power cord and plud frequently.
- When using on furniture be cautious of steam release As it can cause damage, fire and and/or electric shock.

Do not press heavy things on the power cord.

- . It can cause an electric shock or fire.
- Please check the power cord and plug frequently

Do not change, extend or connect the power cord without the advice of a technical expert

• It can cause an electric shock or fire.

Clean any dust or external substances off the temperature sensor and inner pot.

· It can cause a system malfunction or fire.

Do not plug or pull out the power cord with wet hands.

· It can cause an electric shock.

Do not move the product by pulling or using the power cord.

· Electric short might cause fire.



Do not

Please contact a dealer or service center when there is a strange smell or smoke.

• First pull out the power cord.

And contact dealer or the service center.

Do not use over the maximum capacity.

- · It can cause overflow or breakdown.
- Do not cook over stated capacity for cooking of chicken soup and congee.

Do not touch the metallic surface of the inner pot and pressure weight after cooking or warming.

- · It can cause burns.
- Remaining hot steam can cause burns when you tilt the pressure weight while and right after the cooking.

Don't use the cooker near a magnetic field.

• It can cause burns or breakdown.



Do not drop or impact the cooker.

· It can cause a safety problem.

Please surely pull out the plug when not in use.

- . It can cause electric shocks or fire.
- Use AC 120V only.

Use product on a flat surface. Do not use on a cushion. Please avoid using it on an unstable location prone to falling down.

It can cause malfunction or a fire. Please check the power cord and plug frequently.

Don't use for various purpose for inner pot. And do not heat up the inner pot on the gas stove.

- It can cause deformation of the inner pot.
- It can cause to spill the inner coating.

Please pull out the plug when not in use.

It can cause electric shocks or fire.



Please use the cooker for it's intended purpose.

. It can cause malfunction or smell.





Do not

After you finish cooking, do not try to open the cooker by force until the steam is completely exhausted.



- The hot steam or any hot content within the cooker can cause burns.
- · Cautiously open the top cover after cooking is done to avoid dangerous steam and burns.

Do not place on rough top or tilted top.

- It can cause burns or breakdowns.
- Be careful to install the power cord to pass without disruption.



Please call customer service if the inner pot coating peels off.

- . Inner pot coating may wear away after long use.
- . When cleaning the inner pot. do not use tough scrubber, metallic scrubber, brush, abrasive metallic etc.



Do not hold the cooker by the inner pot handle.


. It can cause problems and danger. There are portable handles on the bottom right and left side of the cooker. Hold the handles with both hands and move it carefully.



Remember

Always turn the Lock/Unlock Handle to "Lock" when not

in use.



• It can cause deformation by remaining pressure.

. It can cause odor and discoloration. Wipe off water that is left behind from dew.

Please contact dealer or service center when either a button of a product or a product itself is not working properly.



In case of a blackout during cooking, steam from a rice cooker will be released automatically. Thus, the quality of rice is lower than normal.

- Please start cooking with an indicated amount of rice and water.
- · Water can overflow if the amount of water in a pot exceeds the indicated level of water usage.
- Please start cooking in a status that steam control cap is installed completely.

Please clean the body and other parts after cooking.

- . After cooking chicken soup, multi cook dishes, and etc., the smell may be absorbed.
- . Clean the oven packing, top heater plate, and inner pot every time you cook any of those.
- . It can cause alteration or smell.
- . Use dry kitchen cleaner or sponge to clean the inner pot, since rough scrub or metallic ones are abrasive to the coating.
- Depending on the using methods or user's circumstances inner pot coating might rise.
 - Please call the customer service for those cases.
- . Please, do not pull out the clean steam vent by force.

Be cautious when steam is being released.

- When the steam is released don't be surprised.
- . Please keep the cooker out of reach of children

If possible, only use warming function when cooking white rice. Other foods are easily discolored.

When you pull out the power plug, don't pull the power cord. Please, safely pull out the power plug.

. If you inflict impact on power cord, it can cause an electric shock or fire.





NAME OF EACH PART

Name of each part

Soft Steam Cap

Pressure Weight

Always keep the pressure weight horizontal. It stabilizes steam inside the oven. When the pressure weight is twisted it releases steam.

Automatic Steam Exhaust Outlet (Solenoid valve)

When finished cooking or during warming, steam is automatically released.

Lock/Unlock Handle (Set the handle to lock when cooking or warming the rice)

The handle has to turn to 'Lock' for operation.

Clamp Knob

Turn handle to 'Unlock', and then press Clamp knob to open.

Control Panel

Name of each part



Sensor

Top Cover Assy



Detachable Cover Inner Pot(Oven)

Place the inner pot Into the body property.

Clean Steam Vent Handle

Dew Dish

Empty the water out of the dew dish after cooking or keeping warm. Leaving water inside the dew dish car result on odor.

Rice Scoop holder

Power Cord

Power Plug

The plug type may differ from the actual. (This is only to explain about how it works.)

Accessories



Manual & Cooking Guide



Rice Scoop



Rice Measuring Cup



Steam Plate



Cleaning Pin (Attached on the bottom of the unit)



Detachable cover & Pressure packing


After cleaning detachable cover, put it back on the lid

Unless detachable cover is mounted, preset cooking cannot be done. (Alarm may sound while keeping warm.)

- -Clean the detachable cover to prevent odor.
- -Clean the body and cover with a dry dish towel. Do not use bentol while using the rice cooker. Starch may be remain, however there is no health risks.
- -Do not put materials like screws into holes on the detachable cover. Check the back cover and front cover.



(1) If you pull out the detachable cover indicated by the arrow, it can be easily separated.




(2) When cleaning the detachable cover, hold and pull out the both side wing of the cover, then separate the handle and the rubber packing.




Frequetly clean the cover with a sponge using with a neutral detergent.



② Please put the detachable cover.



(5) When you fix the rubber packing to the detachable cover, hold it between and put it in the edge of the detachable cover by turning it.



When putting the cover into the lid, press the cover handle after fitting the handle into the groove indicated by the arrow.

Correct example



the front of packing



the front of handle



projection presentina the front



the back of packing



the back of handle



no projection



* Look in the back cover and the front cover.

www.cuckoo.co.kr



HOW TO CLEAN



Wipe the inner, upper, outer parts of the inner pot of any alien substances. Do not use abrasive materials such as rough scrubbers or metallic scrubbers.



Check if there is any rice or foreign substances on the oven packing.



Wipe the top cover with a damp cloth. Be careful when cleaning the top heater



Make sure you clean the steam vent before and after use. When cleaning the steam vent, Use extra care; do not pull on the vent. Make sure the steam vent is in place before and after use. If the clean steam vent is not assembled correctly or falls out please call a dealer or service center.



Wipe the main unit with a damp cloth.



Make sure to clean the steam control vent before and after use



In case the cauldron is stained with cooked rice broth or foreign matter, wipe the cauldron with a damp dish cloth. Using a rough scouring pad or brush etc may damage cauldron surface. If the buttons are functioning correctly please contact our customer care service.

How to clean dew dish



Separate the dew



Separate the drain ditch cap by pushing



Clean the drain ditch cap and dew dish with a neutral detergent.



Securely put in the dew dish after cleaning.



in direction of the arrow.

How to clean the pressure weight nozzle.

If the valve hole of the pressure weight part is clogged, puncture it with the cleaning pin

• The valve hole of the pressure weight allows steam to release. Check regularly to ensure that it is not blocked. If the valve hole of the pressure weight is blocked, the hot steam and hot content within the cooker can cause serious injury.

** Do not use the cleaning pin for any other use except to clean the valve hole of the pressure weight.







Substance

Pressure Weight

How to disassemble the pressure weight

- ▶ Under the Lock/Unlock handle is locked(located on "Lock") turn the pressure weight counterclockwise while pulling it up, and pull it out.
- ▶ Puncture the clogged valve hole with the cleaning pin and reassemble it by turning it clockwise. ▶ When the pressure weight is properly assembled, it can freely be turned.

HOW TO CLEAN



How to clean the soft steam cap

* Do not touch the surface of the soft steam cap right after cooking. You can get burned.



♠ Take out soft steam cap
♠ Disassemble soft steam cap as in the figure.



in the rear by pressing the hook in direction, at the arrow and wash it frequently with an neutral detergent and sponge.



Disassemble the rubber packing in the direction of the arrow.




When fitting the rubber packing into the plate. please make sure the packing is facing the correct direction.



steam cap, match the sill of the below and insert the cap firmly by pressing it in the direction of the arrow.



a When assembling the soft a When installing the soft steam cap, insert the cap firmly by pressing in the direction of the arrow indicated in the figure.



How to use handle

- Handle must be turned to "Lock" during Cooking. When the lamp is turned on it means that it is ready to cook.
- 2. After cooking, turn the handle from "Lock" to "Unlock" turn the handle to open.
 - If there is unreleased steam in the Inner pot it might be hard to turn the handle. In this case twist the pressure weight and let the excess steam out. Do not open by force.
- 3. Handle must be turned to "Unlock" when opening and closing.

· If the lamp does not turn on, it would not operate the "Cook" and "Preset" buttons. Make sure the handle is located in "Lock".



When top cover does not close perfectly

Do not try to close the top cover by force. It can cause problems.



1. Check to make sure the inner pot is place correctly inside the main body.

picture on the right.






3. If there is excess steam inside the inner pot it might be difficult to lock the handle. Twist the pressure weight and allow the excess steam to release. Then try to turn the handle again.



FUNCTION OPERATING PART



HOW TO SET CURRENT TIME / HOW TO SET OR CANCEL VOICE GUIDE FUNCTION



<Standby mode>

How to set current time

ex) 8:25am now

- Press mode button once.
 - ▶ Press mode button for more than 1sec.
 - "Current time mode press yes button" after setting current time with selection button Menu/Selection button blinks and Mode, Set and Cancel buttons turn ON.
 - ► Colon mark (:) on the sec. screen is blinking once per second.
- 2 set 8 o'clock and 25 minutes by pressing the menu/selection button.
 - ▶ 1 min up " ▷" button 1 min down " ⓓ " button
 - ▶ 10 min up or down "() ", "() " keep pressing.
 - ► Careful of setting am,pm.
 - ▶ In case of 12:00 it is 12:00 pm.
- 3 When you finish setting the time you want the press "Set" button.
 - If it is over 7 sec without yes button, setting time will be canceled with voice. "it is canceled due to exceeded time limit".



About Lithium battery

- This product contains lithium battery for improving blackout compensation and time. Lithium battery lasts for 3 years.
- When current time is not displayed on the screen, it means the battery is exhausted. It should be replaced.

What is blackout compensation


- This product remembers and maintains previous condition and processes. After finishing a blackout, it operates immediately.
- If blackout happens during cooking, the cooking time will be delayed depending on blackout time.
- If the rice became cold because of blackout, warming will be cancelled

■ How to set current time during keep warming mode

- Press Cancel button to cancel keep warm and then press Mode button over 1 time to set current time.
- 2. After setting time, press keep warm button to re-start keep warm.

Voice guide volume control (The function which can control volume and cancel)

First hold the mode button for more than 1sec. Then enter this function, press Mode button 2 times.



'3' sign is displayed when entered volume control mode by pressing Mode button 2 times.

If set value became ' Π ' by pressing button, voice guide function is off.


Press button to set '5', that is the maximum volume sound. When finish setting desired volume, press Mode button to store.

▶ Set to desired voice volume, and press Set button.



BEFORE COOKING RICE

- Clean the inner pot with a dry cloth.
 - ▶ Use the soft cloth to wash the inner pot.
 - ▶ Tough scrubber can make the coating come off.




- ▶ Make the rice flat to the top of measuring cup and it is serving for 1 person. (ex: for 3 servings 3 cups, for 6 servings 6 cups)
- Wash the rice with another container until the water becomes clear.
- Put the rinsed rice into the inner pot.
- According to the menu, adjust the water amount.
 - ▶ For measuring, place the inner pot on a leveled surface and adjust the amount of water.
 - ► The marked line of the inner pot indicates water level when putting the rice and water into the inner pot together.
 - ▶ About water scale
 - Glutinous rice, mixed rice, nutritious rice and nu rung ji, Rince free:
 Adjust water level to the water scale for 'glutinous rice and mixed rice'.
 Glutinous rice can be cooked to max 10 servings, mixed rice to max 8 servings, nutritious rice to max 6 servings and nu rung ji to max 4 servings.
 - Sushi, Old rice: Adjust water level to the water scale for 'sushi'. Sushi can be cooked to max 8 servings, old rice to max 6 servings.
 - GABA: Adjust water level to the water scale for 'GABA'.
 Can be cooked to max6 servings.
 - Nutritious porridge : Adjust water level to the water scale for 'nutritious porridge'.
 Nutritious porridge can be cooked to max 2 servings
 - Mixed Brown Rice: When cooking use a 5:5 ration of Brown and White Rice.
 Use the "Mixed Rice" gradient lines when pouring water.
 For Mixed Rice mode it will only cook up to a maximum of 8 servings.
 - Cook in cereals menu, hard cereals like red-bean can be half-cooked depeding on the kind of cereal.
- Put the inner pot into the main body and close the topcover.

 Put the inner pot correctly.
 - ▶ If there is any external substance on the temperature sensor or the bottom of the inner pot, wipe it off before putting the pot into the main unit.
 - ▶ Top cover will not close if the inner pot is not placed correctly in the main body (Place the inner pot to the corresponding parts of the main body)
- Connect power plug and turn the handle to "Lock"
 - ▶ The lamp turning on means closed perfectly.
 - ▶ If you press the cook button without setting the Lock/Unlock handle to "Lock", the cooker will not operate. You will hear "beep beep beep" sound and "F∏ [" is shown in the LCD.
 - * If you want to select another function while cooking, push cancel button.
 - ▶ If "£ d_G" shows up in other instances, turn cover handle to "Open" direction, and turn it toward "Lock". Then the cooker will work normally. (The operation of cover lock sensing device can be checked.)
 - Note: This instruction is not applicable if cover handle is turned toward "Open" direction once or more after cooking was completed in previous cooking.







- When you want to cook the old rice or want the soft rice : pour more water than the measured scale
- ❸ Glutinous Rice for 6 persons (6 cups): Set the water to scale 6 of "GLUTINOUS"
- S For overcooked rice: pour less water than the measured scale





FOR THE BEST TASTE OF RICE



Cook tasty rice with Cuckoo pressure rice cooker

For the best taste of rice, check the following points carefully.

,								
Use the measuring cup! Pour the water until water level marking in the inner pot!	 When measuring the rice, Use the measuring cup. (The amount of the rice may vary depending on the quality of the rice.) Place the inner pot on a flat surface and adjust the water to water level in the inner pot. 	If amount of water and amount of rice is different, rice can be crisp or hard.						
How to store rice	 If possible, buy a small amount of rice and keep the rice some place where it ventilates well and avoids a direct ray of light. It can prevent evaporation of rice moisture. If the rice has been unsealed for long, rice can be dry and stale. In this case, you should pour the half of water more. It's tastier. 	If the rice is too dry, rice can be crisp even though it is measured properly.						
Shorten the duration of the "Present" time for better cooking.	If possible, do not use the preset time function when rice is too dry and pour the half of water more.	If you set "Preset" over the 10 hours or "Preset" dried rice, rice can be crisp or half cooked. Even worse condition, rice can be cooked different tastes each level. If the preset time is longer, the melanoizing effect could be increased.						
It's better to set the "warm" time shortly.	It's better to set "warm" less than 12 hours.	If rice is kept warm for a long period of time, rice color will change, as well as odor.						
Keep the product clean.	Clean the product often. (Especially clean the top of the cover for external substance.)	Wipe the top cover heating part well for any rice or external substance.						




HOW TO COOK



Choose menu with menu selection button.

- Select button
- Each time "Menu" button is pressed, the selection switches in the sequential order, glutinous rice → turbo glutinous rice → sushi → GABA → old rice → mixed rice → nutritious rice → RIURUNG JI → porridge → chicken soup → multi cook → automatic Sterilization
- · If the button is pressed, repeatedly, the menu switches continuously in sequential order.
- In the cases of sushi, mixed rice, GABA and old rice, the menu remains memorized once each cooking is completed, so for continuous use of the same menu, no selection of menu is required.



ex)In case of selecting Sushi.


You can hear a voice, Sushi. when you cook Sushi, automatic steam outlet operates while cooking.



Start cooking by pressing Pressure Cook button.

- You must turn lid handle to lock before cooking. Then press the pressure Cook/Turbo
- · Unless lid handle is not turned to close, you get alarm with " £ [] !", and sound "turn lid handle to lock".





ex)In case of cooking Glutinous.




Cooking thoroughly

The cooktime remaining on the display is shown from cooking thoroughly. The cook time is different according to the menu.

Be careful not to burn yourself from the automatic steam outlet.

ex)In case of 14minutes left.







- When cooking is completed, warming will start with the voice "cuckoo completed alutinous".
- When cooking ends, stir rice equally and immediately. If you don't stir rice at once and keep it stagnant, rice will go bad and smell bad.
- If the lid handle is not working well, take out the steam completely out of inner pot by turning over pressure weight.
- While cooking, do not press cancel button.





Cooking time for each menu

Menu Class	Glutinous	Turbo Glutinous rice	Sushi	Mixed	GABA	Nutritious Porridge	Old Rice	Chicken Soup	Nu Rung Ji	Nutritious rice	Multi Cook	Rince free	Automatic Sterilization (Steam Cleaning)
Cooking Capacity								1 chicken	2servings~ 4servings		See detailed quide to	2servings~ 8servings	Up to water scale 2
Cooking Time		About 17 min~ About 27 min						About 64 minutes	About 39 min~ About 44 min				About 23 minutes

^{3%} After cooking chicken soup and multi cook etc, the smell may permeate into the unit, use the Unit after cleaning the rubber packing and lid part according to page 11~13.

^{*}Cooking time by menus may vary to some degree depending on the using environment of the product.

HOW TO COOK

How to use the cooking menu

Glutinous	When you want to have sticky and nutritious white rice.	Sushi	When you want to have a little more sticky and nutritious white rice than Glutinous rice.				
Mixed /Brown	This menu is used to cook by mixing glutinous rice in cereals.	GABA	For cooking germinated brown rice.				
Porridge	This menu is used to cook porridge.	Old Rice	For cooking old rice.				
Chicken Soup	This menu cooks samgyetang automatically.	Nu Rung Ji (Scorched rice)	Have scorched rice when cooking done.				
Nutritious Rice	This menu is used to cook nutritious rice.	Multi cook	This menu is used to cook various dishes by setting a time mannually.				
Rince free	This menu is used to cook Rince free. Automatic Sterilization (Steam Cleaning) This menu is used to eliminate smell soaked after cooking or warming.						
Turbo function	Press Pressure Cooking/White Rice Turbo button twice after selecting "White Rice" menu, and the cooker will go for white rice turbo cooking, which will cut rice cooking time. (Two servings of white rice normally takes 17 minutes or so.)						

- Gluttingus The mode of white rice turbo does not produce cooked rice as good as normal cooking mode. Use white rice turbo mode only for 6 servings or less.
 - For better taste of cooked rice, cook rice in white rice turbo mode after macerating rice for 20 minutes or so before cooking.
- * After cooking in white rice turbo mode or cooking of small serving, discard water. In case of small servings white rice turbo cooking, more water may be required than other menu.
- Please refer to the cooking guide.

HOW TO USE AUTOMATIC STERILIZATION (STEAM CLEANING)



Put water until water scale 2, make sure to close and lock the cover. Method 1, After choosing automatic cleaning menu by pressing "Menu/Select" button, and then press "Pressure cook/turbo" button. Method 2. After choosing automatic cleaning function by pressing "Preset" button twice in standby mode, press "Pressure Cook/turbo" button.

How to cook with Rince free

- 1. Put desired amount of Rince free into the cooker body by measuring it with measuring cup, and pour water to meet glutinous water scale. (Rince free can be cooked to min 2 servings to max 10 servings.)
- 2. Stir evenly with scoop so Rince free and water may mix properly, lock the cover, and after selecting Rince free menu with Menu/Selection button, press Pressure Cook button.
- Note: Rince free is cooked only with water poured with no separate washing, so they may experience the fine scorching. phenomenon(melanoizing).
- ** Note: Do not store Rince free in a humid place as it is vulnerable to humidity. In summer or rainy seasons, the rice may go bad or be inhabited by beetles, so when purchasing Rince free in the market, buy it by units of small pack.

Melanoizing effect

The cooked rice can be light yellow at the bottom of the oven, because this product is designed to improve pleasant flavor and taste. Especially, melanoizing is more serious at the "Preset cooking" than just "Cooking".

It does not mean malfunction.

* When mixing other rice with Glutinous, Melanoizing effect could increase more than 'Glutinous cook' setting.

Old rice cook function

- If you cook long stored rice or dried rice, they could be half-cooked. If using the old rice menu, you can get better taste.
- The taste of rice will be different depending on storage of rice and water state.
- * You can add the soaking or heating time through setting MY MODE.

COOKING NUTRITIOUS COOKED RICE

- When cooking nutritious cooked rice, the degree of melanoizing, a phenomenon of finely scorched rice, may vary depending on the amount or condition of used materials like juilbe or fresh ginseng etc. Adjust the amount of material depending on the preference of melanoized degree.





MY MODE (Cuckoo Customized Taste Function)

What is "MY MODE"?

Cuckoo's patented technology based on variable circuit design. User can select the degree of "softness" and "glutinosity & tastiness" to meet a user's desire.

MY MODE Function

- ▶ Longer "SOFT" Time: rice becomes soft and glutinous. (selectable in 4 steps)
- ▶ Longer "SWEET" Time: rice becomes tastier(selectable in 4 steps) [melanoizing will occur]
- ▶ Both functions above can be selected simultaneously or separatetly

How to Use "MY MODE"

To enter "Customized Rice Taste Setting Mode", select the menu in which Customized Rice Taste is supported such as glutinous rice, mixed rice, GABA, old rice, nurungij and Rince free, and press and hold the mode button for 1second or longer. Then, you are going to enter "Customized Rice Taste Setting Mode. Select the welling and heating stage with the Selection button, and press the Set button".

** The setting of figure below is based onalutinous rice menu.



Select menu you want with menu/selection button and press the set button.

2 "MY MODE" setting screen



To enter Customized Rice Taste Setting Mode, select desire menu and hold the Mode button once for 1 second or longer. Soft time control mode



Select the desiring level of soft rice by pressing left side of Menu/Selection button.

8-2 Sweet time control mode



 Select the desiring level of sweet rice by pressing right side of Menu/Selection button.
 For 16 customized rice tastes, refer to the graph for 6 rice tastes. (See page 21) Setting the completed screen after



Set up desired customized rice taste. And press Pressure Cook. (If you press cancel or do not press a button within 7 seconds, the function will deactivate and return to the standby mode.)

How to Use "MY MODE" II

You can customize your preference for cooked rice by selecting Customized Cooked Rice Taste mode or mode button. Each time you press Mode button, the major cooked rice taste will show up in the sequential order 'Sticky Cooked Rice Taste-> Soft Cooked Rice Taste -> Soft Cooked Rice Taste -> Soft and Soothing Cooked Rice Taste'.

** The setting in the figure below is based on glutinous rice menu.

♠ "MENU" setting screen



Select the menu you want with the menu/selection button and press the set button

"MY MODE" setting screen



To enter Customized Rice Taste etting Mode, select desire menu and press Mode button once for 1 second or longer Soft time control mode



Press Mode button once, and the display will change as shown in the figure. At this time, Soft Cooked Rice Taste 4th Step will be selected.

Sweet time control mode



Press Mode button two times, and the display will change as in the figure. At this time, Soothing Cooked Rice Taste 4th Step will be selected.

➡∃ Soft and Sweet Rice Mode



Press Mode button three times, and the display will change as in the figure. At this time, Soft, Soothing Cooked Rice Taste will be selected.

Setting completed screen after



Set up desired customized rice taste. And press Pressure Cook. (If you press cancel or do not press a button within 7 seconds, the function will deactivate and return to the standby mode.)

MY MODE (Cuckoo Customized Taste Function)



The display for My Mode










This is a graph that shows the flavors of 16 types of cuckoo custom-made rice



- *1. The rice becomes solid and glutinous.
- *2. The rice becomes soft and well-raised rice.
- *3. The rice becomes soft and alutinous.
- * Note: Rice taste number from 1 to 16 will be displayed on the display window.

Shown in the tigure above, the stage mark will show up on the display during setting swelling time, heating, and maintenance time. The mark will continue to show up during cooking, reservation, keeping warm, and reheating as well.

- Cuckoo customized taste function is applied to glutinous, mixed, GABA, old rice, Nu Rung ji.
- Set-up times is stored until the next reset. No need to set-up at every cooking. During cooking, warming and preset time cooking modes, "soft" and "sweet" time cannot be readjusted.

Cautions 1. 'MY MODE' function may influence scorching or cooking quality. Ensure that cooking time is not changed, by children.

- Default setting are "SOFT" Time 0 min, "SWEET" Time 0 min.
- 2. 'MY MODE' function may elongate cooking time according to the set-up time.
- 3. Scorching of rice may occur by longer "SWEET" Time.

Cuckoo customized cooking function

While cooking you can control the heating temperature (both high an low) depending on, your prefenence. Initialization is set up " get step by step as the case may be.

- High step: for cooking cereals, old rice and soft-boiled rice.
- Low step: for cooking the year's crop of rice.

How to use Cuckoo Customized cooking function


If you press the mode button 5times, customized cooking function is setup. Select heating power by selection button. You can see all means with cuckoo customized cooking function on the display.

The display Cuckoo customized cooking function



If the push the button 5 times, the display for customized cooking function will be set up. Initiation is like above picture.

▶ Menu/selection button will blink. and mode, seland Cancel buttons will turn ON.



Press the "set" button to complete your customized cooking. (If you press cancel or do not press a button within 7 seconds, the function will deactivate and return to the

standby mode.)

Setting completed

screen after

Press the "menu" button to select the desired level or low level mode.

- ▶ Continuously press the "menu" button
- 1. 'Cuckoo customized cooking function' applies to Glutinous, Turbo cooking, Sushi, Mixed rice/Brown rice, GABA, Nutrition rice, OLDRICE collectively
- 2. Set up the step of customized cooking function to taste. The scorch can occur when cooking in high level mode.
- 3. Cook is subject to be set differently depending on the percentage of water content and the condition of rice.









MY MODE (Cuckoo Customized Taste Function)

How to set up the function for burning nu rung ji

- ▶ When cooking nu rung ji, please set it up for your taste with function which controls the level of burning nu rung ji.
- ▶ How to set up the enhanced burning nu rung ji (for enhanced burning nu rung ji).



- 1. If you push mode button 7 times at the waiting state, enhanced burning nu rung ji mode will be set up when pushing mode button more than it will be possible to set up.
- 2. When enhanced burning nu rung ji mode is set up, it says "after removed or selection of enhanced burning nu rung ji, push the yes button". At this time, Menu/Selection button will blink, and Mode, Set and Cancel buttons will turn ON.
- 3. If you push the menu/selection button it says "enhanced burning nu rung ji chosen press the yes button after choosing a mode you want. press the yes button".
- Without any button within 7 seconds or cancel button, enhanced burning nu rung ji mode will be canceled and returned to waiting state.
- ▶ How to cancel the enhanced burning nu rung ji



- 1. If you push mode button 7 times at the waiting state, enhanced burning nu rung ji mode will be set up when pushing mode button more than it will be possible to set up.
- When enhanced burning nu rung ji mode is set up, it says "after removed or selection of enhanced burning nu rung ji, push the set button". At this time, Menu/Selection button will blink, and Mode, Set and Cancel buttons will turn ON.
- 3. If you push the menu/selection button it says, "enhanced burning nu rung ji chosen press the yes button after choosing a mode you want. press the set button".
- Without any button within 7 seconds or cancel button, enhanced burning nu rung ji mode will be canceled and returned to waiting state.
 - ▶ Set up this function as occasion demands because this function is on the condition of cancel for enriched saorch at the first use.



What is Germinated Brown rice?

▶ Brown rice has richer nutrients than polished rice. However, brown rice is rather tough and hard to be digested. By germination, the enzymes in the brown rice are activated, generating nutrients and become more digestible.

Tips to Buy Quality Brown Rice








- Check the dates of harvest and pounding.
- ▶ The dates should be within 1 year from harvest, 3 months from pounding.
- 2 Inspect rice with your eyes.
 - · Check too see if the embryo is alive
 - Rice surface should be light yellow and glazing. Whitely stirred up surface, or darkish colored Brown rice is not suitable for a germination
 - Avoid fractured, not fully corned, or empty ear's. Empty ear's may generate odors during germination and and be bluish- nor corned Brown rice cannot be germinated.

Features of Germinated Brown rice

Germinated Brown rice increases nutrients and enhances taste which is a weak point of brown rice. Germinated Brown rice also improves digestion.

- ▶ Taste will be greatly enhanced.
- ▶Digestive and rich in nutrients.
- Diabetic hormone is generated improving digestion.
- ▶Good as a health food for children or adults.
 - Rich with dietary fiber.
- ▶ Germinated brown rice has rich GABA (Gamma Aminobutryc Acid)
 - GABA promotes metabolism in liver and kidneys, suppresses neutral fat, lowers blood pressure, promotes metabolism in brain cells - these effects have been proven by medical science.



- < Comparison of Germinated brown rice's nutrition and Glutinous rice's (6 hours) nutrition. >
 - Phytic acid 10.3Times
 - ► Ferulic acid 1.4Times
 - Gamma-orizanol 23.9Times
 - ▶ Gammma-aminobutyric 5Times
 - ▶ Inositol 10Times
 - ▶ Food fiber 4.3Times



HOW TO USE "GABA (Brown rice)"

Using "GABA" Menu

In order to promote germination, soak brown rice for 16 hours in water.

Method of Pre-germination

- ▶ Put washed brown rice in an appropriate container, pour sufficient water to soak the rice.
- ► Pre-germination shall not exceed 16 hours. Make sure to wash rice clean with flowing water before using "GABA" menu. Be careful that hard washing may take off embryos which generate the germination.
- ▶ Unique smell may be generated according to the soaking time of pre-germination.
- ▶ When pre-germination has been completed, wash the rice and put in inner pot (Oven). Pour appropriated volume of water, and use "GABA" menu.
- ▶ In summer or hot temperature environment odor may be generated. Reduce germination time and wash clean when cooking.
- Set the Lock/Unlock handle at Lock, press Menu button to select "GABA".



First setting time 0H (0Hours)

- ▶ When the "GABA" is selected, "["]-|" is indicated in the display.
- ► Set button will blink, and Mode, Menu/Selection, Cancel, and Pressure Cook buttons will turn ON.

Press "Set" and Menu Selection buttons to set time.

- Menu/Selection button will blink, and Mode, Cancel and Pressure Cook buttons will turn ON.
- Pressing "Menu Selection" button increases germination time by 3hours.
- 2. Pressing "Menu Selection" button decreases germination time by 3hours.
- 3. "GABA" time can be set up by 0, 3 hours.
- If GABA time is set "0"hours, pressing "Pressure Cook" button will start cooking immediately. To cook without germinated Brown rice, set the time at "0".

Press Pressure Cook button.





2 more hours for germination

- Pressing Pressure Cook button will being the GABA process, after which. cooking will begin immediately.
- ▶ During GABA mode, "EIJ" indicator will show the remaining time and will be displayed in minutes with the 2H mark going around clockwise.

Precautions for "GABA" Cooking

- If smaller germ is preferred, omit pre-germination process. Select "GABA" menu, set-up appropriate germination time, and start cooking (nutrient ingredients do not vary significantly by the size of germ).
- During hot seasons, longer germination time may generate odor. Reduce germination time.
- A GABA cooking is allowed up to 6 persons.
- Ocity water can be used for germination. However, spring water is recommended. Germination may not be properly performed in hot or boiled water even after cooling.
- Germination rate, germ growth may differ by the Brown rice type, condition or period of storing, etc.
 - Germinated brown rice is sprouted brown rice. Germination rate and growth may differ by the Brown rice type. The brown rice should be within 1 year from harvest, and not long since pounded.
- and In GABA mode, preset on 3H may not be possible. If you want to preset the GABA, set up '!!!+!' (See the page 26)
- The taste of rice could be different as depending on a kind of brown rice. Use customized taste function or control the amount of water for your taste. (Refer to page 20~22)

HOW TO COOK USING MULTI COOK AND NU RUNG JI



How to use Multi-Cook and preset time







Turn the top handle to "Lock," press menu to select the Multi-cook.

When selecting Multi-cook, the display indicates cooking time to be 20 minutes.

- 2 Press "Set", "Menu/Selection" button to set up the time.
 - ▶ The Menu/Selection button will blink, and the Cancel and Pressure Cooking buttons will turn ON.



Each time you press "Selection" button, the time increases 5 minutes.
▶ Press Menu/Selection to choose desired Menu.



Menu.

Each time you press "Menu" button, the time decreases 5 minutes.

Press Menu/Selection to choose desired

- Available setting time is
 10 ~ 90 minutes.
 (Please refer to cooking guide for time setting of each menu.)
- 4. If you press the set button after choosing the time you want, then it says "press cook/Turbo button."





Press "Pressure cook/turbo" button.

- Pressure Cook button will blink, and Menu/Selection and Cancel buttons will turn ON. Press the Pressure Cook/Turbo button and the Multi-cook will start.If the Multi-cook starts, the display shows the 'cooking mark' and remaining minutes.
- Use the preset time of Multi -cook as following instruction.
 - Check the present time.

2. Turn the Lock/Unlock handle to 'Lock" and press the "Preset" button.



















How to make Nu rung ji

- 1. Turn the Lock/Unlock handle to "Lock" and press menu to select the "Nu Rung Ji.' Refer to page 22
- 2. Press the "Pressure Cook/Turbo" button to start cooking.
- When cooking is completed, scoop out the boiled rice. The "Nu Rung Ji" on the bottom of the jar can be prepared for your taste (e.g. scorched rice tea)
- ► "Nu Rung Ji" can be prepared for up to 4 people
- ▶ For "Nu Rung Ji" cooking, set the water volume at "Glutinous" level.
- Not too much washing rice.
- lf you want enhanced burning nu rung ji, cook after soaking rice in water for 30minutes.




HOW TO PRESET TIMER FOR COOKING

How to preset timer for cooking

How to use timer function

- Check if the current time and the menu are correct.
 - ▶ Refer to page 15 for the time setting.
 - If the current time is not set correctly, the presetting time will also be incorrect.
 - ▶ Make sure not to confuse AM and PM.



- ►To activate Preset 1, press the "preset" button once.
 To activate Preset 2, press the "preset/timer" button twice.
- ► Factory Set Configurations- Preset 1: Preset at 6:30am, Preset 2: Preset at 7:00pm. If you want to use these times, select Preset 1 or Preset 2
- ►If the lock/unlock handle is not in the locked position then you will not be able to program or use the preset function
- ►When you press the "preset" button, the preset time will be displayed, and the Preset 1 & Preset 2 signs will be blinking.
- Gaba menu, you have to select "0H" in order to use the preset timer function.
- * When it is in keep warm mode, press cancel to exit keep warm mode, then select your desired preset time.




- ► In case of setting up timer while warming, increases by 10min when you press " ▷ "button
- Please set up timer after canceling warming, decreases by 10min when you press " () "button.

If you keep on pressing either button, It can be changed continually.

- * Please be careful not to change from AM to PM.
- ▶ Then press the "Set"button to program your desired time.











When preset time is set to AM07:40





- It says that preset cook for glutinous is booked Preset cook will be completed at the timer
- Once cook is completed with preset time, preset time is stored in the memory.
- ▶ Don't need to set up time again.
- * If a small amount of rice is cooked, it could be finished earlier than time you programmed it.





HOW TO PRESET TIMER FOR COOKING



Precautions for preset cooking

- In case of preset cooking
 - ▶ If the rice is old and dry, the result may not be good
 - ▶ If the rice is not well cooked, add more water by about half-scale.
 - ▶ If the preset time is longer, melanization could be increased.
 - Rinsed rice adds precipitated starch, Preset Cook may cause scorching To reduce scorching, cook Rince free by rinsing it in running water or reduce cooking amount.
- The change of preset time
 - ▶ Press "cancel" button for more than 2 seconds and restart it to change the preset time.
- If the preset time is shorter than cooking time, cooking will immediately begin.
 - ▶ If set time is shorter than preset time, cooking will immediately begin.
- 4 In case the preset time is over 13 hours.
 - ► " 13 H₀ " will be displayed and the preset time will be changed to 13 hours automatically.
 ex) If cooking is preset to AM07:00 of the following day at PM5:00 of the day, where preset time is 14 hours,
 " 13 H₀ " will be displayed, and preset time automatically changes to AM06:00. (Preset time is 13 hours)
 - If the preset time is over 13 hours, it can cause bad smell. The limited preset time is set up less than 13 hours because the rice spoils easily during the summer time
 - When you want to finish presetting PM 12:00, preset PM 12:00
 - * Use this function when you want to finish cooking between 1 hour to 13 hours based on the preset time
 - If you press the set button to check the present time during the preset cooking function, the preset time will be displayed for 2 second.











	Possible time setting for each menu												
Menu Class	Glutinous	Turbo Glutinous Rice	Sushi	Mixed	GABA	nutritious rice	nutritious Porridge	Nu Rung ji	Old Rice	Multi Cook	Automatic Sterilization (Steam Cleaning)	Chicken soup	Rince free
Possible time Setting	From (41minutes + My mode) to 13 hours	From 27minutes to 13 hours	From 49minutes to 13 hours	From (57minutes + My mode) to 13 hours		+ My mode)	From 93minutes to 13 hours	From (44minutes + My mode) to 13 hours	From (48minutes + My mode) to 13 hours		From 23minutes to 13 hours	From 64minutes to 13 hours	From (38minutes + My mode) to 13 hours



HOW TO PRESET TIMER FOR COOKING

Having a meal

- ▶ If you want to have warm rice, press the "Reheat/keep" warm. Then "Reheat/Keep" warm function will be started and you can eat fresh rice in 9 minutes.
- ► To use reheating in standby status after power is applied, turn lid combining hand grip to Locked" location, press Reheat/Keep button, and the cooker will convert to Heat Preservation mode. Here press Reheat/Keep warm button once more.

<Keep warming>



The '3H' of function display indicates 3 hours has passed in heat preservation mode. One press of 'Set' button during heat preservation displays present heat

<Reheating>



The lamp blinks and indicator will shows the reheat remaining time will be displayed in minutes with the mark going around clockwise.

<Finishing reheat>



When the reheat finishes with the beep sound, keep warming function will be operated and, the elasped time will be shown.

press of 'Set' button present time. <Present morning temperature>

preservation temperature, and another



If you push the "set" button present warming temperature is displayed and push "set" button again. The current time is displayed during warming. Moreover, when you push the button once more, the time elapsed of warming is displayed

- There is a difference between the outer temperature and inner temperature because it operates with various users and environment.
- * After cooking rice, temperature is much higher than the warming temperature programmed.

- ▶ The frequent use of the "Reheat" function may cause the cooked rice to be discolored or dried. Use it once or twice per day.
- ▶ After 24 hours of heat preservation, the lamp of heat preservation time lapse blinks, indicating that long time has passed in heat preservation condition.
- ▶ In case the lid combining hand grip is in open status during heat preservation, the cooker does not go for reheating. For reheating, lock the lid combining hand grip to (Locked) position, and then press Keep warm/reheat button.
- ▶ If the lid combining hand grip is turned to open status during reheating, function display will show " ₹ 1". At this time, reheating will be cancelled, and heat preservation will proceed.

Cautions for Keeping Warm

It will be hard to open the lid during warming, or right after it has finished cooking, So push the pressure weight to the side and allow the steam to release.

Make sure the handle is in the "Lock" position during warming or reheating.

It is recommended to evenly stir the cooked rice after cooking.

The rice taste is improved. (For a small quantity of rice, pile up the rice on the center area of the inner pot to keep warm)

It is recommended to evenly stir the cooked rice after cooking. The rice taste is improved. (For a small quantity of rice, pile up the rice on the center area of the inner pot to keep warm)

Do not keep the scoop inside the pot while warming the rice. When using a wooden scoop it can create serious bacteria and odors.

It would be better to warm the rice for less than 12 hours because of odors and color change.

The cooked rice, which cooked by pressure cooker is more prone to changing color than the rice cooked by general cooker. During warm mode, the rice can arise and turn white and rise. In this case, mix the rice.

The mixed and brown rice cannot be in such good condition as white rice while in warm function due to their characteristics. Therefore do not keep mixed and brown rice in function for a long period of time.

Do not mix small amount of rice or leftovers with the rice under keeping warm. Doing so may cause an odor. (Use a microwave oven for the cold rice.)

TO KEEP COOKED RICE WARM AND TASTY




Controlling method of warming temperature

If the temperature in the oven is not proper, it smells bad and changes rice color even though it is cleaned frequently and boiled up. Temperature needs to be set.



- ♠ Hold the "Mode" button for 1sec during keep warming, stage It display a picture with a buzzer sound. At the time. 74° means current warming temperature.
- * Note: The reference temperature programmed when the product is shipped may differ from the Instruction.



- 2-1 Press "Selection" button to increase
- After setting the temperature, press the "Set" button. Preset temperature will be stored with buzzer sound. (It will be cancelled once press "Cancel" button or after 7 seconds without pressing any button.)



Press "Menu" button to decrease the temperature as 74° → 73° → 72° → $7.1^{\circ} \Rightarrow 70^{\circ} \Rightarrow 59^{\circ}$

Device Temperature Control


- 1. When you smell bad odors and the rice is too watery: The keep warm temperature is too low. In this case, increase the "Keep Warm" temperature by 1~2°C.
- 2. When the rice has a vellowish color or is too dry: The keep warm temp is too high. In this case decrease the "Keep Warm" temperature by 1~2°C.

How to operate My Mode function.

Use it while opening the lid when there is too much water or rice becomes too soft.



Hold on to the "Mode" button for 1sec, then push the "mode" button 4times. The voice says that it is programmed warming mode, control the temperature you want.



- A –1 Press "Selection" button to change as the picture(up)
- Select the menu you want, then the press the "My Mode" button and set-up time will be automatically entered with a buzzer. (If you press the "Cancel" button or do not press a button within 7 seconds, the function will be cancelled and returned to standby mode.)



- 2 Press "Menu" button as the picture(down)
- 1. If too much water is spilled out when you open the lid: Press "Menu/Selection" button to raise the setting mode.
- 2. If the edge of rice is too soft: Press "Menu/Selection" button to reduce the setting mode.



TO KEEP COOKED RICE WARM AND TASTY

How to activate "Sleeping" mode.

▶ When keeping rice warm for a long time, set up the temperature low to prevent the following quality of rice: smelly, dry, change of color; from PM10:00 ~ AM 04:00.

▶ How to set up



- Hold "the mode" button for one second, then press the "mode" button 6times to set up sleeping mode.
 If sleeping mode is not shown, keep on pressing the "mode" button until it is heard or displayed.
- When you are in sleeping mode, it says "After selecting or canceling sleeping mode, press the set button." At this time, Menu/Selection will blink, and the Mode, Set, and Cancel will turn on.
- 3. Press the "Menu/Selection" button until you hear or see "Sleeping mode", then Press set. You will see nothing surrounding the rice cooker on the screen.
- 4. This function must be activated by the user depending on necessity.

How to release



- 1. Hold "the mode" button for one second, then press the "mode" button 6times to set up sleeping mode. If sleeping mode is not shown, keep on pressing the "mode" button until it is heard or displayed.
- When you are in sleeping mode, it says "After selecting or canceling sleeping mode, press the set button." At this time, Menu/Selection will blink, and the Mode, Set, and Cancel will turn on.
- Press the "Menu/Selection" button until you hear "Sleeping mode has been canceled", then Press set. You will see rings around the rice cooker on the screen.
 - ▶ If you need to keep the rice warm during sleeping, do not use this function. This function makes the rice cooler than normal. In summer, the rice can be spoiled and may smell bad because of high temperature. If possible, do not use the "Custom-made warming" mode while sleeping.
 - ▶ This function is set up as cancel state.

When odors are rising during the warming mode

- ▶ Clean the lid frequently. It can cause bacteria and odors.
- ► Even though exterior looks clean, there might be germs and it can cause odor so please be sure to use automatic sterilization (steam cleaning) menu for cleaning. Clean the inner pot completely after automatic cleaning function is done. (refer to 19)
- ▶ After you cook soups and steamed dishes, clean the inner pot properly to prevent rice from smelling.

For button locking or night voice volume reduction, proceed with the following procedure



How to set Lock buttons

Lock can be set for touch button to prevent malfuncion during cleaning with touch button or by children touch.

▶ Setting Method



- Button will be locked if "Set" button is pressed for 3 seconds or longer during cooking, presetting, warming, reheating, or in standby stage.
- When button is locked, a voice will sound saying "Button lock is selected." At this time, button lock is displayed on the screen.

▶ Cancelling Method



- To cancel button lock, press "Set" button for 3 seconds or longer on locked the button.
- "Lock" sign on the display disappears when button lock is cancelled, a voice will be saying "Button lock is cancelled."
- Note: Any button other than "Set" button is pressed while button lock is set, buzzer will sound.
- Mote: Desired function can be set after cancelling button lock by pressing "Set" button for 3 seconds or longer.
- Note: Button lock function is cancelled automatically when the power is off even though the button lock function is already set.

Night Voice Volume Reduction function

Night Voice Volume Reduction is the function of reducing voice volume during night hours 10:00PM ~ 05:59AM. Activate this function when necessary. This function works only during night hours.

▶ How to activate or inactivate the function of Night Voice Volume Reduction



1st step 20% of daytime voice volume
2st step 40% of daytime voice volume
3st step 60% of daytime voice volume
4st step 80% of daytime voice volume
5st step In case Night Voice Volume Reduction function is inactivated

No voice

Marking of process progress bar by the activation of Night Voice Volume Reduction function.

- 60% of day time voice volume
- Press 'Mode' button 8 times in standby status, and the system will enter night voice volume reduction mode.
 When pressing 'Mode' button for the first time, press the button for 1 second or longer to enter the function.
- 2. Upon entering the mode of activating 'Night Voice Volume Reduction', you will hear a voice saying "You have entered the Night Voice Volume Reduction Activation mode. Select or inactivate the Night Voice Volume Reduction function with 'Select' button, and press 'Confirm' button."
- Press Menu/Select button, and as process progress bar changes, voice volume will change. Select the desired volume of voice, and press 'Confirm' button.
- 4. If you press 'Inactivate' button or no button is pressed for 7 seconds after process progress bar reaches 5th step through adjustment of Menu/Select button, the function will be inactivated while you hear a voice saying "Specified time has passed and the function is inactivated", and the system will return to standby mode.
 - ▶ This function remains inactivated when the product is shipped. Activate this function when necessary.

CHECK BEFORE ASKING FOR SERVICE

▼ If there is a problem with your cooker, check the following details before requesting service to your dealer. Sometimes the cooker may not operate as desired if used incorrectly.

Case	Check points	Do the following
When the rice is not cooked.	Pressure "Cook/Turbo" button is pressed?	• Press the "Pressure Cook" button once. And check " [] "sign on the display.
	Is there power cut while in cooking?	Blackout backup power source for the Rice Cooker, see page 15.
When the rice is not cooked well.	Did you use the measuring cup for the rice? Did you put proper amount of water? Did you rinse the rice before cooking? Did you put rice in water for a long time? Is the rice old or dry?	 Refer to page 16~17 Add water about half the notch and then cook.
Rice is too watery or stiff.	• Is the menu selected correctly?	Select the correct menu.
	Did you properly measure water?Did you open the top cover before	Properly measure water.Open the top cover after cooking finished.
	cooking was finished?	,
When the water overflows.	Did you use the measuring cup? Did you use proper amount of water? Is it the menu selected correctly?	• Refer to page 16~17
When you smell odors while warming.	Did you close the top cover? Please check it the power cord is plugged. Did it warm over 12 hours? Is there any other substance such as rice scoop or cold rice?	Close the top cover perfectly. Always keep the power on while warming. As possible, keep warming time within 12 hours. Don't warm rice with other substance.
"£" signs show up.	Temperature sensor does not work properly.	Unplug the power cord and call the Service center.
Warming passed time mark blinks during keeping warm	• 24 hours has not passed yet after keeping warm	•This function alarms if the rice remained warm for more than 24 hours.
Rice has gotten cold or a lot of water flow during keeping warm	Keeping warm was set in "Sleeping" mode	Keep warm after cancelling or setting "Sleep Keeping Warm" mode depending on the necessity
If " <i>E do</i> " sign appears.	• It shows on the display when pressing "Start" button again, or when the cooking has finished and you've never turned the handle to 'Unlock'.	It can be solved by turning handle to 'Unlock' and then turn to 'Lock'.

CHECK BEFORE ASKING FOR SERVICE

▼ If there is a problem with your cooker, check the following details before requesting service to your dealer. Sometimes the cooker may not operate as desired if used incorrectly.

Case	Check points	Do the following
When the button cannot operate with " []"	▶ Is the inner pot inserted? ▶ Check the rated voltage?	 Please insert inner pot. This product is AC 120V only.
When the Pressure "Cook/Turbo" Timer button does not operate with " E [] "	Did you turn the Lock/Unlock Handle to "Lock" Is "pressure" lamp on? Is "pressure" lamp on?	Please turn the "Lock/Unlock" handle to "Lock".
When the rice is badly sticky.	Is there any rice or any other alien substance on the temperature sensor or the bottom surface of the inner pot?	Clean all the alien substance on the temperature sensor or the bottom surface of the inner pot.
When " ₣ ਜ਼ " is showed on the LCD	Check the rated Voltage?	• Cut the power and contact customer service. • It is normal to get " ₣ ਜ਼ ȝ " when putting only water. • This is only for AC 120V.
When the time cannot be preset.	 Is the current time correct? Is AM or PM set properly? Did you set the reservation time over 13 hours? 	Set the current time. (Refer to page 14) Check the AM and PM. Maximum reservation time is 13 hours. (Refer to page 26~27)
When you smell after and before cooking?	Did you clean it after cooking?	Please clean it after cooking.
When the top cover cannot be closed.	Is the inner pot correctly inserted in the main body? Is the Lock/Unlock handle on the top cover set to "Lock"? Is there hot food in the inner pot?	 Please put in the inner pot perfectly. Please turn the "Lock/Unlock" handle to "Lock". Pull the pressure handle to aside once.
When "tick, tick" sounds occurs while cooking and warming.	Is it the sound of cooking relay? Did you wipe the moisture of bottom of inner pot?	It is normal that the "tick, tick" sound of relay is an on and off operation. The moisture of the bottom of the inner pot may cause "tick, tick" sound. Please wipe the moisture.

CHECK BEFORE ASKING FOR SERVICE

▼ If there is a problem with your cooker, check the following details before requesting service to your dealer. Sometimes the cooker may not operate as desired if used incorrectly.

Case	Check points	Do the following
When cannot turn to "Unlock".	Did you turn the "Lock/Unlock" handle while cooking? Did you turn the "Lock/Unlock" handle before exhausting steam perfectly?	Don't open the top cover while cooking. If you want to open top cover while cooking, press the "Cancel" button more than 2 seconds and exhaust the steam. Pull the pressure handle to aside once and exhaust the steam perfectly.
When the top cover cannot open although the Lock/Unlock handle is turned to "Unlock".		Because of the pressure. Pull the pressure handle to aside once and exhaust the steam perfectly.
When the steam exhausted between the top cover.	 Is there an external substance on the packing? Is packing too old? 	Clean the packing throughly. Keep the packing clean. If the steam is exhausted through the top cover, please power off and contact the service center and dealer. Packing life cycle is 12 months, please replace the packing per 1 year.
When the "Cancel" button does not operate while cooking.	• Is the inner pot hot?	Keep pressing the "Cancel" button for 2 seconds for safety reason if you want to cancel while cooking. Be careful of hot steam emission or hot contents spattered from the automatic steam outlet during cancellation.
When you hear weird noises during cooking and warming	Is there a wind blowing sound when cooking the rice? Is there a "Chi" sound when warming the rice?	This is the sound of the fan motor to cool the internal parts. This is normal. The "Chi" sound during the warming process is the sound of IH cooker operating. This is normal.
Bean(other grains) is half cooked.	→ Is bean (other grains) too dry?	Soak or steam beans and other grains before cooking in the pressure cooker in order to avoid partially cooked beans or grains. Beans should be soaked for-2-minutes or steamed for-2-minutes prior to cooking, depending on your taste.



COOKING GUIDE

Tasty Rice

Boiled Rice

Pea Rice



Ingredients

Rice 6 cups

*The "cup" in ingredients means a measuring cup in the rice cooker. 1 cup (180cc) is for one person.

Recipe

- Put clean-washed rice in the inner pot and pour water by water gradation 6.
- Firstly, lock the cover, and select [Glutinous Rice] in the menu, and then push the [Pressure Cook/Turbo] button.
- Mix rice when cooking is finished.

Reference

According to gradation on the inside of inner pot, when cooking with newly harvested rice the amount of water should be less than the gradation, and when cooking with old rice the amount of water should be more than gradation. (Control the amount of water according to preference of each family)

Ingredients

Recipe

- As for peas, add salt into them, wash them clean and extract water from them.
- Put cleanly washed rice into My Caldron, season them with sake and salt, and pour water up to white rice water graduation 3.
- Place peas on top of them, press MENU button after locking the lid, select [Glutinous Rice], and press [Pressure Cook/Turbo] button.
- When the cooker comes to Heat Preservation mode, mix the cooked grains properly.

Store peas as follows

If peas and kidney beans etc are stored in the refrigerator, they change in color and decrease in freshness fast. Therefore, immediately after retting the materials from the market, blanch them slightly, place them in the refrigerator, and whenever they are needed, take them out to use them in natural color and freshness.

Boiled Barley



Ingredients

2 cups of rice, a cup of barley

Recipe

- Prepare boiled barley with a cup of barley.
- Wash rice clean, and after putting it in My Caldron along with boiled barley, pour water up to white rice water graduation 3.
- Lock the lid, press MENU button, and after selecting [Mixed Rice], press [Pressure
- Once the cooker comes to Heat Preservation mode, mix the cooked grains properly.

Mixed Rice

: Five-grain Rice



Ingredients

Rice 1.5cup, millet1/3cup, glutinous rice1/2cup, red beans 1/3cup, sorghum1/3cup and salt 1 teaspoon

Recipe

- The Uppe Mash rice, glutinous rice, millet and sorghum clean and scoop them with a landing net. Boil red beans on high heat, and then put only water in which red beans were boiled in
- Boil red beans on high heat, and then put only water in which red beans were boiled in another bowl.
- Put rice, glutinous rice, millet and sorghum on a landing net into the inner pot and pour water in which red beans were boiled and water by white rice water gradation 3.
- Put the boiled red beans, and then lock the cover. After select [Mixed Rice] in the menu, push the [Pressure Cook/Turbo] button.
- Mix rice when cooking is finished.

Reference

Oriental medicine calls red beans as Jeoksodu which holds moisture, removes steam and discharges accumulated pus as well as relieving edema by making thirst and diarrhea stopped and bladder empty.

COOKING GUIDE



Mixed Rice

Boiled Fresh Germinated Brown Rice



Ingredients

Brown rice 4 cups


Recipe

- Put washed brown rice into the inner pot, and then put it into the inner pot and pour water by
- After locking the cover and choosing [GABA Rice] in the menu, push the button of [Pressure button after setting up the time of germinated brown rice for four hours.
- Mix rice when cooking is finished.

Reference

- Control the time of germinated brown rice according to each preference.
 - When cooking with germinated brown rice, set up germinating time for 0 hour if you want to have 100% boiled brown rice without germination.

Boiled Brown Rice with Red Beans



Ingredients

Brown rice 1 cup, rice 2 cups and red beans 1/3 cup

Recipe

- Boil red beans until it become soft, but not to break the shape of red beans and separate it from water
- Wash brown rice clean and put it in the inner pot. Put the boiled red beans after pouring water by germinated brown rice water "scale 3".
- After locking the cover and choosing [GABA Rice] in the menu, push [Pressure button after setting up the time of germinated brown rice for four hours.
- Mix rice when cooking is finished.


Well-being Boiled Rice

Green Tea Rice Blended

with Chicken Chest Flesh

Ingredients

2 cups of brown rice, 3g of green tea leaf, 10g of green tea powder, 4 nuggets of chicken chest flesh, a little bit of olive oil, a little bit of salt, a little bit of pepper, 5g of celery, a little bit of lime, a little bit of rosemary



Lock the lid, press MENU button, and after selecting and setting Germinated Brown Rice Time to 3 hours, press button.


Pickle chicken chest flesh in salt and pepper for 1 hour or so, put olive oil in the pan, and after frying the flesh in the pan, slice it thin.

Prepare lime by slicing it in half moon shape, and prepare shredded celery.

When the cooker comes to heat preservation mode, mix the cooked grains properly, and after placing germinated brown rice and chicken chest flesh in the vessel, add lime and celery.

10 Long Points of Green Tea

Anticarcinogenic property, anti-aging effect, prevention of lifestyle disease, prevention of obesity and diet, detoxication of heavy metals and nicotine, recovery from fatigue and removal of hangover, treatment of constipation, prevention of caries, prevention of acidification of constitution, inhibition of inflammation and bacterial contagion.





Ingredients

2 cups of brown rice and some sprouts and vegetables

Seasoning red pepper paste: Red pepper paste 1/2cup, beef (crushed) 40g, sesame oil 1 tablespoon, honey 1 tablespoon and sugar 1 tablespoon

Recipe

- Wash brown rice clean, put it into the inner pot and pour water by germinated brown rice water "scale 2".
- After locking the cover and choosing [in the menu, push [Pres setting up the time of germinated brown rice for 3 hours.
- Pour sesame oil in a pot and stir-fry the crushed beef. Stir-fry it a little more after stirring up it with red pepper paste and 1/3cup of water in order to be thick put sugar, honey and sesame oil.
- After stirring up rice when it is changes to heating mode, put the prepared sprouts and vegetables on
- germinated brown rice.

 Put red pepper paste so that sprouts may not cause a mess.
- Broccoli sprout: Prevention of cancer.
- Chinese cabbage sprout: Good for stomach and improve constipation
- Turnip sprout : improve hepatitis and jaundice,
- Cabbage sprout: include selenium, preventing aging and cancer
- Daikon sprout: Lowers body heat heat and makes swelling subside
- Wheat sprout : purify blood



CUCKOO ELECTRIC RICE COOKER/WARMER LIMITED WARRANTY

KEY Company, P&K USA TRADING CORP and Cuckoo Trading Canada will repair at its option replace. without charge, your product which proves to be defective in material or workmanship under normal use, during the warranty period listed below from the date of original purchase. This warranty is good only to the original purchaser of the product during the warranty period. P&K USA TRADING CORP, covers the east and the central districts. KEY Company covers the west and the central districts. Cuckoo Trading Canada covers the whole Canada.

MODEL# #LABOR PARTS CRP-M10 1YFAR 1YFAR

WARRANTY PERIOD HOW SERVICE IS HANDLED

The Fast and the Central Districts

Call: 718 888 9144

Address: 129-04 14th Avenue College Point, NY 11356, USA

The West and the Central Districts.

Call: 323 780 8808

Address: 1137 E. 1st Street, L.A. CA 90033, USA

Canada (TORONTO) Call: 905 707 8224

Address: #D8-7398 Yonge Street Thornhill Ontario Canada L4J 8J2

Canada (VANCOUVER) Call: 604 540 1004

Address: 945 Lougheed Hwy Coguitlam BC Canada V3K 3T4

No other express warranty is applicable to this product. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY. IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. CUCKOO ELECTRONICS CO.,LTD. SHALL NOT BE LIABLE FOR THE LOSS, THE USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSEQUENTIAL. ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY APPLICABLE TO THIS PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts: so these limitations or exclusions may apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

THE ABOVE WARRANTY DOES NOT APPLY IN THESE CASES:

- * To damages problems which result from delivery or improper installation.
- * To damages problems which result from misuse, abuse, accident, alteration, or incorrect electrical current or voltage.
- * To serve call which do not involve defective workmanship or material and explaining the operation of the unit.

Therefore, these costs are paid by the consumer, Customer assistance numbers:

- To Prove warranty Coverage: Retain your Sales Receipt to prove date of purchase
 - ▶ Copy of your Sales Receipt must submitted at the time warranty service is provided.

To Obtain Product, Customer, or Service Assistance and Nearest Authorized service center. Parts Distributor or Sales Dealer:

The East and the Central Districts Call: 718 888 9144 Address:129-04 14th Avenue College Point, NY 11356, USA The West and the Central Districts. Call : 323 780 8808

Address: 1137 E. 1st Street, L.A. CA 90033, USA

Canada (Toronto) Call: 905 707 8224 Address: #D8-7398 Yonge Street Thomhill Ontario Canada L4J 8J2

Canada (Vancouver) Call: 604 540 1004 Address: 103-4501 North Road Burnaby BC Canada V3R 4R7