

EG4® 12kPV HYBRID INVERTER

QUICK-START GUIDE

This guide has been created to give the end-user a simple and efficient way to install and commission the 12kPV hybrid inverter.



TABLE OF CONTENTS

1.	TECHNICAL SPECIFICATIONS	1
2.	ABBREVIATIONS	3
3.	INVERTER SAFETY PRECAUTIONS	4
3.1	SAFETY INSTRUCTIONS.....	4
3.2	IMPORTANT SAFETY NOTIFICATIONS	4
4.	PACKING LISTS.....	6
5.	LOCATION SELECTION AND INSTALLATION TOOLS	7
5.1	REQUIREMENTS FOR INSTALLATION LOCATION.....	7
5.2	TOOLS NEEDED FOR INSTALLATION.....	7
5.3	INSTALLING THE INVERTER	8
5.3.1	MOUNTING STEPS.....	8
6.	PRE-WIRE STEPS AND WIRING (BATT, PV, AC).....	8
6.1	WIRE SIZING	8
6.1.1	BATTERY WIRE SIZING.....	8
6.1.2	PV WIRE SIZING.....	8
6.1.3	AC WIRE SIZING.....	8
6.2	MULTIMETER TESTING.....	9
6.3	BATTERY TO INVERTER CONNECTION FOR NON-SERVER RACK BATTERIES.....	9
6.4	BATTERY TO INVERTER CONNECTION FOR SERVER RACK BATTERIES.....	9
6.5	BMS COMMUNICATIONS.....	9
6.5.1	CLOSED LOOP COMMUNICATIONS: WALLMOUNT, LL-S & LL-V2	10
6.5.2	CLOSED LOOP COMMUNICATIONS: LIFEPOWER4	10
6.6	PV CONNECTION	10
6.7	AC CONNECTION.....	11
7.	SYSTEM START-UP SEQUENCE FOR COMMISSIONING.....	11
8.	ACCOUNT REGISTRATION	11
9.	FIRMWARE UPDATES.....	12
9.1	INVERTER UPDATE VIA EG4 APP	12
9.2	INVERTER UPDATE VIA MONITOR CENTER.....	12
9.3	BATTERY UPDATE.....	13
10.	OPERATION GUIDE	13
10.1	OPERATION MODE AND FUNCTION	13
10.1.1	SELF-USAGE MODE.....	13
10.1.2	CHARGE FIRST MODE	14
10.1.3	AC CHARGER MODE	15
10.1.4	GRID PEAK-SHAVING FUNCTION	15
10.1.5	SMART LOAD FUNCTION	15
10.2	RAPID SHUTDOWN (RSD)	16
10.2.1	EXTERNAL RSD WIRING INSTRUCTIONS.....	16
10.3	LCD DISPLAY AND SETTINGS	17
10.3.1	VIEWING INFORMATION AND ALARM FAULT/RECORD	17
10.3.2	SETTING PARAMETERS	18
11.	OPERATING MODE DESCRIPTION	22
11.1	SELF-CONSUMPTION MODE	23

11.2	BATTERY BACKUP MODE	24
11.3	GRID SELL BACK WITH AC COUPLE	26
12.	DOUBLE CHECK ALL WIRING/VOLTAGES/AMPS	27
13.	FULL SYSTEM START-UP	27
14.	FULL SYSTEM SHUTDOWN.....	27
15.	INVERTER TROUBLESHOOTING.....	28
15.1	VIEWING INFORMATION AND ALARM FAULT/RECORD	28
15.2	REGULAR MAINTENANCE	29
15.3	TROUBLESHOOTING BASED ON LCD SCREEN	29
15.3.1	FAULTS ON THE LCD AND FAULT LIST	29
15.3.2	ALARM ON THE LCD AND ALARM LIST	32
16.	TROUBLESHOOTING WI-FI MODULE.....	34
16.1	CENTER LIGHT FLASHING	34
16.2	DONGLE RECOVERY	34
17.	BATTERY TROUBLESHOOTING	38
17.1	BMS TOOLS.....	38
17.2	BMS TEST.....	38
17.3	WARNING/PROTECTION CODES TABLES (LL-S, V2 AND WALLMOUNT)	39

1. TECHNICAL SPECIFICATIONS

AC INPUT DATA				
NOMINAL AC VOLTAGE	120/240VAC; 120/208VAC (L1/L2/N required)			
FREQUENCY	50/60Hz			
MAX. AC INPUT POWER	12000W			
MIN. GENERATOR SIZE	>5000W			
MAX. GEN GRID PASSTHROUGH CURRENT	80A 80A			
AC GRID OUTPUT DATA				
MAX. OUTPUT CURRENT	33.3A@240VAC 38.5A @208VAC			
OUTPUT VOLTAGE	120/240VAC; 120/208VAC			
NOMINAL POWER OUTPUT	8000W			
OUTPUT FREQUENCY	50/60Hz			
POWER FACTOR	0.99 @ Full Load			
REACTIVE POWER ADJUST RANGE	±0.8			
MAX CONT. LINE WATTAGE	4000W			
PEAK POWER	0.5 s	1 s	1 min	12 min
	16kW	12kW	10kW	8.8kW
OPERATING FREQUENCY	50/60Hz			
THD (V) @FULL LOAD	<3%			
TRANSFER TIME	Single			Parallel
	20 ms – Default, 10 ms – Selectable			20 ms
PV INPUT DATA				
NUMBER OF MPPTS	2			
INPUTS PER MPPT	2			
MAX. USABLE INPUT CURRENT	25/25A			
	25A per MPPT 41.6A in total			
MAX. SHORT CIRCUIT INPUT CURRENT	31/31A			
DC INPUT VOLTAGE RANGE	100-600 VDC			
UNIT STARTUP VOLTAGE	100 VDC			
MPPT OPERATING VOLTAGE RANGE	120-500 VDC			
NOMINAL MPPT VOLTAGE	360 VDC			
MAXIMUM UTILIZED SOLAR POWER	12000W			
RECOMMENDED MAXIMUM SOLAR INPUT	15000W			
EFFICIENCY				
MAXIMUM EFFICIENCY (PV TO GRID)	97.5%			
MAXIMUM EFFICIENCY (BATTERY TO GRID)	94%			
CEC WEIGHTED EFFICIENCY	96.4%			
MAXIMUM EFFICIENCY (PV TO BATTERY)	94.5%			
IDLE CONSUMPTION (STANDBY MODE)	<55W			
BATTERY DATA				
COMPATIBLE BATTERY TYPES	Lead-Acid/Lithium			
MAX. CHARGE/DISCHARGE CURRENT	167A @ 48 VDC			
NOMINAL VOLTAGE	48 VDC			
VOLTAGE RANGE	40-60 VDC (Lithium); 40-60 VDC (Lead-Acid)			
RECOMMENDED BATTERY CAPACITY PER INVERTER	>200Ah			

GENERAL DATA

MAX. UNITS IN PARALLEL	10
PRODUCT DIMENSIONS (H×W×D)	29.5×20.5×11.2 in (750×520×285 mm)
UNIT WEIGHT	110 lbs. (50 kg)
DESIGN TOPOLOGY	High Frequency - Transformerless
RELATIVE HUMIDITY	0-100%
OPERATING ALTITUDE	<2000 m (<6561 ft)
OPERATING AMBIENT TEMPERATURE RANGE	-13°F – 140°F, >113°F Derating (-25°C – 60°C, >45°C Derating)
STORAGE AMBIENT TEMPERATURE RANGE	-13°F – 140°F (-25°C – 60°C)
NOISE EMISSION (TYPICAL)	<50 dB @ 3 ft
COMMUNICATION INTERFACE	RS485/Wi-Fi/CAN
STANDARD WARRANTY	10-year standard warranty**
INGRESS PROTECTION RATING	IP65
SAFETY FEATURES	PV Arc Fault Protection, PV Ground Fault Protection, PV Reverse Polarity Protection, Pole Sensitive Leakage Current Monitoring Unit, Surge Protection Device, Integrated PV Disconnect

STANDARDS AND CERTIFICATIONS

UL1741 SB

CSA C22.2#107.1:2016

CSA C22.2#330:2017 ED 1

HECO SRD-IEEE-1547.1:2020 ED 2

RAPID SHUT DOWN (RSD) NEC 2020:690.12

FCC PART 15, CLASS B (PENDING)

***See EG4 Warranty Registration for terms and conditions**

2. ABBREVIATIONS

- AWG – American Wire Gauge
- A – Amps
- Ah – Amp hour(s)
- AC – Alternating Current
- AFCI – Arc-Fault Circuit Interrupter
- AHJ – Authority Having Jurisdiction
- kAIC – kilo-Amp Interrupting Capability
- ANSI – American National Standards Institute
- BAT – Battery
- BMS – Battery Management System
- COM – Communication
- CT – Current Transformer
- DC – Direct Current
- DIP – Dual In-line Package
- DOD – Depth of Discharge
- EG – Equipment Ground
- EGS – Equipment Grounding System
- EMC – Electromagnetic Compatibility
- EPS – Emergency Power System
- ESS – Energy Storage System
- E-Stop – Emergency Stop
- FCC – Federal Communication Commission
- GE – Grounding Electrode
- GEC – Grounding Electrode Conductor
- GFCI – Ground Fault Circuit Interrupter
- GFDI – Ground Fault Detector/Interrupter
- Imp – Maximum Power Point Current
- IEEE – Institute of Electrical and Electronic Engineers
- IP – Ingress Protection
- Isc – Short-Circuit Current
- In-lbs. – Inch Pounds
- kW – Kilowatt
- kWh – Kilowatt-hour
- LCD – Liquid Crystal Display
- LFP – Lithium Iron Phosphate
- L1 – Line 1
- L2 – Line 2
- mm – Millimeters
- MPPT – Maximum Power Point Tracking
- mV – Millivolt
- N – Neutral
- NEC – National Electric Code
- NEMA – National Electrical Manufacturers Association
- NFPA – National Fire Prevention Association
- Nm – Newton Meters
- NOCT – Normal Operating Cell Temperature
- PC – Personal Computer
- PCB – Printed Circuit Board
- PE – Protective Earth
- PPE – Personal Protective Equipment
- PV – Photovoltaic
- RSD – Rapid Shut Down
- SCC – Standards Council of Canada
- SOC – State of Charge
- STC – Standard Testing Conditions
- UL – Underwriters Laboratories
- UPS – Uninterrupted Power Supply
- V – Volts
- VOC – Open-Circuit Voltage
- VMP – Voltage Maximum Power

3. INVERTER SAFETY PRECAUTIONS



DANGER!

AVERTISSEMENT!

Hazardous Voltage Circuits!

Circuits à tension élevée!

3.1 SAFETY INSTRUCTIONS

International safety regulations have been strictly observed in the design and testing of the inverter. Before beginning any work, carefully read all safety instructions, and always observe them when working on or with the inverter. The installation must follow all applicable national or local standards and regulations.

Incorrect installation may cause:

- Injury or death to the installer, operator or third party
- Damage to the inverter or other attached equipment

3.2 IMPORTANT SAFETY NOTIFICATIONS

There are various safety concerns that must be carefully observed before, during, and after the installation, as well as during future operation and maintenance. The following are important safety notifications for the installer and any end users of this product under normal operating conditions.

1. **Beware of high PV voltage.** Please install an external DC disconnect switch or breaker and ensure it is in the “off” or “open” position before installing or working on the inverter. Use a voltmeter to confirm there is no DC voltage present to avoid electric shock.
2. **Beware of high grid voltage.** Please ensure the AC switch and/or AC breaker are in the “off” or “open” position before installing or working on the inverter. Use a voltmeter to confirm there is no voltage present to avoid electric shock.
3. **Beware of high battery current.** Please ensure that the battery module breakers and/or on/off switches are in the “open” or “off” position before installing or working on the inverter. Use a voltmeter to confirm there is no DC voltage present to avoid electric shock.
4. **Do not open the inverter while it is operating** to avoid electric shock and damage from live voltage and current within the system.
5. **Do not make any connections or disconnections (PV, battery, grid, communication, etc.) while the inverter is operating.**
6. An installer should make sure to be well protected by reasonable and professional insulative equipment [e.g., personal protective equipment (PPE)].
7. Before installing, operating, or maintaining the system, it is important to inspect all existing wiring to ensure that it meets the appropriate specifications and conditions for use.
8. Some components of the system can be very heavy. Please use the team lift technique or other safe lifting practices when performing the installation.
9. Ensure that the PV, battery, and grid connections to the inverter are secure and proper to prevent damage or injuries caused by improper installation.



WARNING: *To reduce the risk of injury, read all instructions!*

All work on this product (system design, installation, operation, setting, configuration, and maintenance) must be carried out by qualified personnel. To reduce the risk of electric shock, do not perform any servicing other than those specified in the operating instructions unless you are qualified to do so.

1. Read all instructions before installing. For electrical work, follow all local and national wiring standards, regulations, and these installation instructions.
2. Make sure the inverter is properly grounded. All wiring should be in accordance with the National Electrical Code (NEC), ANSI/NFPA 70.
3. The inverter and system can inter-connect with the utility grid only if the utility provider permits. Consult with the local AHJ (Authority Having Jurisdiction) before installing this product for any additional regulations and requirements for the area.
4. All warning labels and nameplates on this inverter should be clearly visible and must not be removed or covered.
5. The installer should consider the safety of future users when choosing the inverter's correct position and location as specified in this manual.
6. Please keep children away from touching or misusing the inverter and relevant systems.




CAUTION: The inverter and some parts of the system can be hot when in use. Please do not touch the inverter's surface or most of the parts when they are operating. During operation, only the LCD and buttons should be touched.


4. PACKING LISTS

The items listed below will arrive with each product shipment (purchased separately):


12kPV:




LL-S/V2:



LifePower4:



WallMount All-Weather:



5. LOCATION SELECTION AND INSTALLATION TOOLS

5.1 REQUIREMENTS FOR INSTALLATION LOCATION

1. The mounting wall must be strong enough to bear the weight of the inverter.
2. Maintain the minimum clearance of 7.9 in. (200mm) between the inverter and other components of the system to allow adequate heat dissipation.
3. Never position the inverter in direct sunlight. Ensure the site is well shaded or placed in a shed to protect the inverter and LCD from excessive UV exposure.
4. Ensure the inverter is mounted upright. Do not mount the inverter at a $>90^\circ$ angle, or upside down.

5.2 TOOLS NEEDED FOR INSTALLATION

The following list of tools are not included with purchase, but may be required to complete the installation process:

- Hand truck with all terrain tires
- Tape measure
- Drill and drill bits (5/16")
- M8 Hex wrench/socket
- M5 Hex wrench/socket
- Torque wrench
- Multimeter
- Lineman pliers, rabbit ears or side cutters
- Wire strippers
- Channel locks
- Medium Phillips head screwdriver
- 13 mm or 1/2" socket for lag screws
- 14 mm or 9/16" socket for anchors

5.3 INSTALLING THE INVERTER

The 12kPV is designed to be wall mounted. The mounting location must be a vertical, solid mounting surface, such as concrete or brick, and be able to withstand the weight of the unit. The surface must be made of non-combustible material.

5.3.1 MOUNTING STEPS

Follow the steps below if mounting on brick or concrete:

1. Mark the drill hole positions using the included mounting bracket.
2. Drill four 5/16 in. diameter holes, ensuring the holes are deeper than 2 in.
3. Insert the expansion bolts into the drilled holes and tighten.
4. Use the included nuts and washers packaged together with the expansion bolts to secure the wall-mount bracket to the wall.
5. Using the team-lift technique, hang the inverter on the wall-mount bracket and lock the inverter on the wall using two self-tapping screws (not included) on the top of the inverter. Lock the safety screws on the left and right sides of the inverter.

For installation on concrete board with wooden studs:

- Fasten the mounting bracket to the studs with four heavy duty wood screws. Hang the inverter on the bracket and lock it to the wall with two self-tapping screws (not included).



NOTE: Wood screws and self-tapping screws are not included in the shipment. Installers will need to acquire all necessary screws before installation.

6. PRE-WIRE STEPS AND WIRING (BATT, PV, AC)

6.1 WIRE SIZING

Reference the tables below for wire size and torque recommendations depending on the type of wire and connection.

6.1.1 BATTERY WIRE SIZING

CABLE SIZE	MAX. DISTANCE	TORQUE VALUES
4/0 AWG (107 mm ²)	10 ft.	Max. 22.9 ft-lbs. (31.1Nm)
250 Kcmil (127 mm ²)	20 ft.	Max. 22.9 ft-lbs. (31.1Nm)

6.1.2 PV WIRE SIZING

CABLE SIZE	MINIMUM INSULATOR VOLTAGE
10 AWG – 6 AWG (Max.) (6 mm ² – 16 mm ²)	600V

6.1.3 AC WIRE SIZING

TERMINAL CONNECTION	CABLE SIZE	TORQUE VALUES
GRID	Max. 4 AWG (21.2 mm ²)	17.7 in-lbs. (2Nm)
GEN	Max. 4 AWG (21.2 mm ²)	17.7 in-lbs. (2Nm)
LOAD	Max. 4 AWG (21.2 mm ²)	17.7 in-lbs. (2Nm)

6.2 MULTIMETER TESTING

Follow the steps outlined below to both test the inputs and wire the system.

Ensure all circuit breakers are open (off). Using a multimeter, check voltages at all available disconnects and lines. Once 0V on all disconnects/lines are confirmed, proceed.

6.3 BATTERY TO INVERTER CONNECTION FOR NON-SERVER RACK BATTERIES

1. Ensure all circuit breakers are open (off). Use a multimeter to test the wires and terminals for voltage. If no voltage is present, proceed to the next step.
2. Route the battery power cables, ensuring cables are long enough to span the distance between battery and inverter terminals, without making any connections.
3. Secure a conduit fitting to the enclosure using a counter nut.



NOTE: Conduit fittings and counter nuts are not included with purchase. Installers will need to acquire all necessary conduit accessories before installation.

4. Connect the battery positive and negative cables to the inverter's mechanical terminals using an M8 hex wrench, torquing to a maximum value of 22.9 ft-lbs. (31.1 Nm).

6.4 BATTERY TO INVERTER CONNECTION FOR SERVER RACK BATTERIES

The recommended installation practice with server rack batteries requires the use of external busbars or battery cabinets with busbars. Follow the steps below to install the batteries to an external busbar.

1. Identify the positive and negative terminals of the battery. Red=positive and black=negative.
2. Remove the M8 terminal bolts. Install the power cables (positive and negative) to the battery terminals. Reseat the M8 bolts once the cables are in place, torquing to a maximum value of 70 in-lbs. (7.9Nm)
3. Install the power cables to the external busbar torquing to a maximum value of 15 ft-lbs. (20.3Nm)
4. Install the power cables from the external busbar to the inverter, torquing to a maximum value of 22.9 ft-lbs. (31.1Nm)



IMPORTANT! Size the battery cables going from external busbar to inverter accordingly! Refer to an NEC ampacity chart for further information.

6.5 BMS COMMUNICATIONS

EG4 batteries interface with an inverter by designating a "Master" battery (DIP switch ID No. 1).


Depending on the model of battery, the available ID codes range from 1–64 (1-16 for LifePower4). The battery will connect directly to the inverter via an RS485 battery communications cable (see pin-out in Section 3.5.2) or a standard CAT 5, CAT 5e, or CAT 6 cable for closed loop communications with supported non-EG4 inverters using CAN bus protocol.


6.5.1 CLOSED LOOP COMMUNICATIONS: WALLMOUNT, LL-S & LL-V2



IMPORTANT: Only the master battery (Address 1) must be set to the inverter protocol; all other batteries must have unique addresses starting at address 2 and ascending in chronological order. The CAN port of the master battery must be connected to the inverter's (or communication device's) BMS communication port.

CAN PROTOCOL LIST	
PROTOCOL #	MANUFACTURER
P01-EG4/LUX	EG4/LUX
P02-GRW	Growatt
P03-SLK	Sol-Ark
P04-DY	Deye
P05-MGR	Megarevo
P06-VCT	Victron
P07-LUX	Luxpower
P08-SMA	SMA

1. Power off all battery DC breakers and BMS power buttons.
2. The inverter protocol can only be changed with the master battery temporarily set to address 64 (all switches ON.) (See image) 

After the dipswitch is changed, reset the battery using the BMS power button for the settings to take effect.
3. On the master battery, press and hold the “Return”  key for 5 seconds and release to enter the “Protocol Setting” menu.
4. Select the CAN Protocol. Select EG4/LUX for closed loop communications.
5. Change the master DIP switch back to address 1 for inverter communications. Reset the BMS to register the change. (See image) 

6.5.2 CLOSED LOOP COMMUNICATIONS: LIFEPOWER4



NOTE: To achieve closed loop communications between LifePower4 batteries and the 12kPV inverter, a battery firmware update is required. Navigate to eg4electronics.com or contact the distributor to locate this file.

1. Set the dipswitches on the master battery to address “0.” (See image) 
2. Set the following battery dipswitches in ascending order to ensure there are no matching addresses.
3. Reset the battery BMS using the built-in circuit breaker.

6.6 PV CONNECTION

1. Ensure all circuit breakers are open (off). Use a multimeter to test the wires and terminals for voltage. If no voltage is present, proceed to the next step.
2. Strip 1/4 in. – 5/16 in. (6 – 8 mm) insulation from the PV wires. (If using stranded wire, use wire ferrules.)
3. Insert the conduit fitting into the opening for the PV connection and tighten it from the inside using a counter nut.
4. Route the PV wires through the conduit fitting and into the inverter.
5. Secure the PV wires into the terminals. Verify the connection by lightly tugging on the wires.

6.7 AC CONNECTION

1. Ensure all circuit breakers are open (off). Use a multimeter to test the wires and terminals for voltage. If no voltage is present, proceed to the next step.
2. Strip 5/16 – 3/8 in. (8-10 mm) insulation from cables. (If using stranded wire, use wire ferrules.)
3. Secure a conduit fitting to the enclosure using the counter nut of the fitting.
4. Fasten the GRID and LOAD cables to the respective terminals (GRID = AC Input, LOAD = AC Output) using a Phillips head screwdriver, torquing to 17.7 in-lbs. (2Nm).
5. Secure conduit to the conduit fitting.

7. SYSTEM START-UP SEQUENCE FOR COMMISSIONING

Follow the steps below to turn the system on to disable output while finishing commissioning:

1. Ensure the LOAD breaker is open (off)
2. If equipped, close (turn on) the external DC breaker between the battery and inverter. Turn on the “BAT” breaker located in the cable box of the inverter and then power on the battery system.
3. Ensure the PV string voltages are within the operating parameters using a multimeter. Upon confirmation, turn on (close) the PV isolator switch between the inverter and the panel array.
4. Turn on (close) the PV isolator switch on the side of the unit.
5. Make sure Steps 1 and 2 are accomplished before turning on the grid power or generator breaker.
6. Ensure the LOAD breaker is open (off) before proceeding to account registration.

Once the steps above are completed, the system will be in the proper state allowing for registry changes.

8. ACCOUNT REGISTRATION

Before using the EG4 Monitoring System, an account must be registered. Follow the steps outlined below for account creating and linking

1. Register the account:
2. When registering the account, provide the following information:
 - a. Customer code: This is the code for a distributor or installer. Please contact the distributor or installer to obtain this code.
 - b. Dongle SN: The serial number is attached to the shell on the sticker.
 - c. Dongle PIN: The PIN is attached to the shell on the sticker.
3. Set the Wi-Fi Password:
 - a. Ensure the inverter is powered on and plug in the Wi-Fi dongle into the dongle port.
 - b. Wait until the “INV” LED on the module is solid. Once solid, connect the mobile device to the dongle’s Wi-Fi hotspot. The hotspot will be named the same as the SN of the module.
 - c. Open the app and click “DONGLE CONNECT.”
Select the yellow “Refresh” button to display a full list of available networks. Select the home Wi-Fi network and enter the password.

- d. After selecting “Home Wi-Fi Connect,” the dongle will reset. Once all three LED lights are solid the inverter has successfully connected to the network.

9. FIRMWARE UPDATES

Before commissioning the system, please ensure all components' firmware is fully up to date. There are two different methods for updating the inverter's firmware. These two methods are listed below:



NOTE! Contact the distributor to ensure the latest firmware files are applied.

9.1 INVERTER UPDATE VIA EG4 APP

1. Open the EG4 Electronics app on a mobile device and select the “DOWNLOAD FIRMWARE” button.
2. Select the correct inverter model, then select “DOWNLOAD” on the right-hand side to download the file to a mobile device.
3. With the app still running, go to the mobile device’s Wi-Fi settings. Connect the mobile device to the Wi-Fi dongle’s network. The dongle’s network ID will be the same as the dongle’s Serial Number.
4. Return to the home screen of the app and select “LOCAL CONNECT.” Select the “Set” button on the right-hand side of the app and proceed to the next step.
5. Swipe upward on the phone screen until the “Update Firmware” button is visible at the bottom of the app’s display.
6. Choose the correct installation package in the dropdown box and click “UPDATE FIRMWARE” to begin the update process.

9.2 INVERTER UPDATE VIA MONITOR CENTER

1. Log in to the EG4 Monitor System. Select “Maintenance” and then select “Remote Update.”
2. Choose the inverter needing the update by SN and select “Standard Update.” The Monitor Center will begin updating both firmware files for the inverter. The latest version of the firmware will be displayed in the bottom-right window.

EG4 ELECTRONICS

Monitor Data Configuration Overview Maintenance

Remote Set Station Serial number Online Device Auto Reload

Weather Optimize Remote Update

Serial number	Dongle	Firmware version	Connect Status	Action	Serial number	Mode	Firmware	Start Time	Update Status	Rate of Progress	Stop Time
1		FAAB-0E0E	Lost	Standard Update							
2		fAAB-1A1A	Connected	Standard Update							
3		fAAB-1B1B	Lost	Standard Update							
4		fAAB-1B1A	Connected	Standard Update							
5		cCaa-175F66	Lost	Standard Update							
6		cCaa-186169	Lost	Standard Update							
7		ccaa-160B0B	Lost	Standard Update							
8		cCaa-18626B	Connected	Standard Update							
9		eAAB-1919	Connected	Standard Update							



NOTE! While performing the update, make sure the inverter stays powered on throughout the entire process to ensure the update goes through successfully.

9.3 BATTERY UPDATE

To update the firmware on the battery, please navigate to EG4electronics.com to find the latest files. Included in the downloaded file are two guides in PDF format to walk through the steps of each update. **Follow the guides to avoid soft-bricking the battery BMS!**

10. OPERATION GUIDE

10.1 OPERATION MODE AND FUNCTION

10.1.1 SELF-USAGE MODE



In this mode, the order of priority for powering loads is Solar>Battery>Grid. The order of priority for solar power usage is Load>Battery.

Application Scenarios

Self-usage mode will increase the self-consumption rate of solar power and reduce energy bills.

Related Settings

Effective when Charge Priority, AC Charge, and Forced Discharge are disabled.




10.1.2 CHARGE FIRST MODE

The order of priority for solar power usage will be Battery>Load>Grid. During the **charge first** period, loads are first supplied power from the grid. If there is excess solar power after charging batteries, the excess solar will power the loads along with grid power.


Application Scenarios:

When users want solar power to charge batteries and the grid is used to power loads.

Related Settings:



Example



10.1.3 AC CHARGER MODE

Basic | Operating Mode | Use SOC % | Use Bat V | Set

Charge | Bat charge current limit(A) | Set

Discharge | AC charge | According to SOC/Volt | Set

Advanced | AC charge power(kW) | Start AC charge SOC(%) | Set

Debug | Time 1 | Start AC charge Volt (V) | Set

Device info. | Time 2 | Stop AC charge SOC(%) | Set

Time 3 | Stop AC charge Volt (V) | Set

10.1.4 GRID PEAK-SHAVING FUNCTION

Basic | Grid peak-shaving | Peak-shaving power(kW) | Set

Charge | Time 1 | Start SOC1 | Start Volt1 | Set

Discharge | Time 2 | Start SOC2 | Start Volt2 | Set

Advanced | Smart load | Set

Debug | Start PV power (kW) | On Grid always on | Set

Device info. | Smart load start Volt(V) | Smart load start SOC(%) | Set

Smart load end Volt(V) | Smart load end SOC(%) | Set

10.1.5 SMART LOAD FUNCTION

Basic | Grid peak-shaving | Peak-shaving power(kW) | Set

Charge | Time 1 | Start SOC1 | Start Volt1 | Set

Discharge | Time 2 | Start SOC2 | Start Volt2 | Set

Advanced | Smart load | Set

Debug | Start PV power (kW) | On Grid always on | Set

Device info. | Smart load start Volt(V) | Smart load start SOC(%) | Set

Smart load end Volt(V) | Smart load end SOC(%) | Set

Basic | PV input | Meter or CT | Set

Charge | MODBUS addr | Meter type | Set

Discharge | Vpv start (V) | CT ratio | Set

Advanced | Offgrid output | CT direction reversed | Set

Debug | Seamless switch | Charge last | RSD disable | Set

Device info. | AC couple | No Battery | Micro-grid | Set

Smart load | Run without grid | Set

PV Arc | PV Arc fault clear | Set

AC charger mode

Users can charge batteries with grid power when electricity prices are low, then use battery power run loads or export to the grid when electricity prices are high.

Application Scenarios

When users have a Time of Use (TOU) rate plan.

Related Settings (see image to left)

Grid peak-shaving and peak-shaving power (kW):

Used to set the maximum power that the inverter will draw from the grid. The minimum setting value is 0.2kW.

Smart Load: This function will make the GEN input connection point to a load connection point. If enabled, the inverter will supply power to this load when the battery SOC and PV power are above user set values.

For Example: Smart load start SOC=90% Smart load end SOC=85%

Start PV power=1kW means: When the PV power exceeds 1000W, and the battery system SOC gets to 90%, the Smart Load Port (GEN) will automatically switch on to power the connected load. When the battery reaches SOC<85% or PV power<1000W, the Smart Load Port automatically switches off.

Important Note:

*If the smart load function is enabled, a generator **cannot** be connected at the same time; otherwise, the device will be damaged!*

10.2 RAPID SHUTDOWN (RSD)

The inverter includes a rapid shutdown system that complies with 2017 and 2020 NEC 690.12 requirements. A rapid shutdown switch should be connected to the RSD terminals on the master inverter and mounted in a readily accessible location outdoors (check with the AHJ for specific requirements). For paralleled systems, the RSD needs only to connect to the master inverter. When the switch is engaged, it will shut down all inverters in parallel.



NOTE: When using supported EG4 batteries in closed-loop communications with the inverter, the RSD also initiates ESS Disconnect.


The system can utilize an External E-Stop Switch if the AHJ deems it necessary.

Type of External E-Stop Switch for RSD Requirements:

The external switch must have normally closed contact type for emergency shutdown.


10.2.1 EXTERNAL RSD WIRING INSTRUCTIONS


The inverter includes a rapid shutdown system that complies with 2017 and 2020 NEC 690.12 requirements. A rapid shutdown switch should be connected to the RSD terminals on the inverter and mounted in a readily accessible location outdoors (check with the AHJ for requirements).



10.3 LCD DISPLAY AND SETTINGS

Users can wake up the LCD screen by simply pressing the Enter button. System status, real-time power, and daily/accumulated energy information can all be conveniently viewed on the inverter's LCD screen. Additionally, users can also check the alarm and fault record on the display for troubleshooting.

LED	Display	Description	Action
Green LED	Solid lit 	Working normally	No action needed
	Flashing 	Firmware upgrading	Wait until update is complete
Yellow LED	Solid lit 	Warning, inverter may stop working	Needs troubleshooting
Red LED	Solid lit 	Fault, inverter will stop working	Needs troubleshooting



10.3.1 VIEWING INFORMATION AND ALARM FAULT/RECORD

Home Screen

Touch the LCD screen to light it up if in sleep mode. The home page will appear on the display. Users will see a system overview diagram along with real-time information of each component such as battery SOC, battery charging/discharging power, grid import/export power, load power, etc. On the right side of the screen, users can check daily and accumulated solar energy, battery charge/discharge energy, grid import/export energy, as well as load consumption.

Connect in: xxx S

PV Energy	
Today:	
Total:	
Charge Energy	
Today:	
Total:	
Export	
Today:	
Total:	
Consumption	
Today:	
Total:	






LCD Version :

Detailed System Information

Click on the pie icon at the bottom of the screen to view the detailed real-time solar information, battery information, grid information, and load output information.

Solar	Vpv1	Ppv1	
Battery	Vpv2	Ppv2	
Grid	Vpv3	Ppv3	
UPS	Epv1_day	Epv1_all	
Other	Epv2_day	Epv2_all	
	Epv3_day	Epv3_all	

Solar	Vbat	Ibat	
Battery	Pchg	Pdischg	
Grid	Vbat_Inv	BatState	
UPS	SOC/SOH	CycleCnt	
Other	Vchgrf/Vcut	Bat capacity	
	I maxchg	I maxdischg	
	Vcellmax	Vcellmin	
	Tcellmax(°C)	Tcellmin(°C)	
	BMSEvent1	BMSEvent2	
	Echg_day	Edischg_day	
	Echg_all	Edischg_all	

Solar	Vgrid	Fgrid	
Battery	VgridL1N	VgridL2N	
Grid	Vgen	Fgen	
UPS	Pimport	Pexport	
Other	Pinv	Prec	
	Pload		
	Eimport_day	Eexport_day	
	Eimport_all	Eexport_all	
	Einv_day	Erec_day	
	Einv_all	Erec_all	
	Eload_day	Eload_all	

Solar	Vups	Fups	
Battery	VupsL1N	VupsL2N	
Grid	Pups	Sups	
UPS	PupsL1N	SupsL1N	
Other	PupsL2N	SupsL2N	
	Eups_day	Eups_all	
	EupsL1N_day	EupsL1N_all	
	EupsL2N_day	EupsL2N_all	

Solar	Status	StatusPre	
Battery	SubStatus	SubStatusPre	
Grid	FaultCode	AlarmCode	
UPS	Vbus1/Vbus2	VbusP/VbusN	
Other	T0/T1(°C)	T2/T3(°C)	
	OCP/Grid OnOff Cnt	ExitReason1/2	
	InnerFlag/Run Trace	NoDis/chgReason	
	Dis/chg LimitReason	Dis/chg CurrLimit	
	Inv/Rec LimitReason	Inv/Rec CurrLimit	
	Para status		

10.3.2 SETTING PARAMETERS

Click on the gear icon at the bottom of the screen to get into the parameter setting page for the inverter. If prompted during setting changes, enter “00000” as the password.

Basic Settings

Standby: This setting is for users to set the inverter to normal or standby status. In standby status, the inverter will stop any charging, discharging, or solar feed-in operations.

Restart Inverter: This selection restarts the system. *Please note the power may be interrupted when the unit is restarted.*

Basic	Standby:	Restart inverter	Reset
Charge			
Discharge			
Advanced			
Debug			
Device info.			



NOTE: Zero Export cannot prevent export of energy supplied by inverters that are AC Coupled to the 12kPV.

Charge Settings

Operating Mode: Users can decide to use state of charge (SOC) or battery voltage (Bat V) to control charge and discharge logic depending on battery type.

Bat. charge current limit (A): Users can set the maximum charge current.

AC Charge: Utility charge configuration. If users want to use grid power to charge their battery, then they can enable '**AC Charge**' and set up to three different time periods when AC charging can happen. Set '**AC charge power (kW)**' to limit utility charging power.

Set '**Stop AC Charge SOC (%)**' as the target SOC for utility charging or '**Stop AC charge Volt (V)**' as the target battery voltage for utility charging.

Charge first (PV): PV charge configuration. When using '**Charge first**,' PV will charge the battery as the priority. Users can set up to three different time periods when PV charge can happen.

Charge first power (kW): Limits PV charge power

Stop charge first SOC (%): The target SOC for PV charge first.

Stop charge first Volt(V): The target battery voltage for PV charge first.

Lead-Acid: When using a Lead-Acid battery, users need to set parameters in these programs. Follow the battery manufacturer's recommendation for these settings.

Generator

Bat. charge current limit(A): Maximum battery charge current from the generator. The generator will start charging according to the '**Charge start Volt/SOC**' and stop charging when the battery voltage or SOC reaches the '**Charge end Volt/SOC**' value.

Gen rated power(kW): The inverter has a peak-shaving function. Users can enable it and set up the Gen peak-shaving power with this setting.

Discharge Settings

Operating Mode: Users can choose **“Use SOC %”** or **“Use Bat V”** to control the battery discharge state.

Discharge current limit(A): The maximum discharge current from the battery.

Discharge start power(W): The minimum value can be set to 50.

When the inverter detects the import power is higher than this value, the battery starts discharging; otherwise, the battery will stay in standby.

On-grid Cut-off (%), Off-grid Cut off (%) / On-grid Cut-off(V), Off-grid Cut off(V): End of discharge SOC/Cutoff voltage when the system is in an on-grid or off-grid situation, respectively.

Forced discharge: This setting will force the battery to discharge within the programmed period. In the preset period, the inverter will discharge the battery at the power set by **“Discharge power(kW)”** until battery SOC or voltage reaches **“Stop discharge”** value.



IMPORTANT: The following settings may need to be adjusted by the installer after installation. Please consult with your installer/distributor before making any changes to avoid conflicting settings or damage to your system!

Advanced Settings

The screenshot shows the 'Advanced' settings tab. On the left is a sidebar with buttons: Basic, Charge, Discharge, Advanced (selected), Debug, and Device info. The main area contains the following settings:

- Grid type: [dropdown]
- Grid Freq: [dropdown] [Set]
- Grid regulation: [dropdown]
- Reconnect time(S): [input]
- HV1: [input] V [input] S HV2: [input] V [input] S HV3: [input] V [input] S
- LV1: [input] V [input] S LV2: [input] V [input] S LV3: [input] V [input] S
- HF1: [input] Hz [input] S HF2: [input] Hz [input] S HF3: [input] Hz [input] S
- LF1: [input] Hz [input] S LF2: [input] Hz [input] S LF3: [input] Hz [input] S
- Battery type: [dropdown] [Set]
- Lithium brand: [dropdown] Lead capacity(Ah): [input]

The screenshot shows the bottom section of the 'Advanced' settings tab. On the left is the same sidebar as the previous screenshot. The main area contains the following settings:

- PV input: [dropdown] Meter or CT: [dropdown] [Set]
- MODBUS addr: [input] Meter type: [dropdown]
- Vpv start (V): [input] CT ratio: [dropdown]
- Offgrid output: [input] CT direction reversed: [input] [Set]
- Seamless switch: [input] Charge last: [input] RSD disable: [input]
- AC couple: [input] No Battery: [input] Micro-grid: [input]
- Smart load: [input] Run without grid: [input] [Set]
- PV Arc: [input] PV Arc fault clear: [input] [Set]

Grid type: You can choose 240/120V or 220/208V

Grid Regulation: Select the correct grid safety regulation.

Grid Frequency: If the grid frequency is nominal at 50Hz, then the inverter's frequency will be adjusted to 50Hz automatically. If there is no grid power and it is read as 50Hz but the devices are 60Hz; then you can set to 60Hz manually. This is based on the rated frequency of the local grid regulation and devices.

Battery type: No battery, Lead-acid, or Lithium.

If **'Lead-acid'** battery is selected, please input the correct battery capacity.

If **'Lithium'** battery is selected, please choose the battery's brand in the Lithium brand drop-down list.

Meter or CT: The supported CT ratio is 1000:1, 2000:1, and 3000:1. The default CT ratio is 3000:1. If a third-party CT is used, please ensure the CT ratio is one of the three supported types and set it accordingly.

Meter type: Please choose setting according to the meter installed.

Off-grid output: Enabling this setting will cause the inverter to provide backup power if the grid is lost.

"Seamless switch" must be enabled if users want the load to be transferred seamlessly to the inverter backup power.

"No Battery" can be enabled to use solar power to supply load when the grid fails or load-shedding happens. If users do not have a battery installed yet but still wish to have inverter backup power with only solar panels connected, this setting can be enabled.

"Micro-grid" should be set **only** when the generator is connected to the inverter's Grid terminal. With this option enabled, the inverter will use AC power to charge the battery and will not export any power through the Grid terminal if AC power is present at the inverter's Grid terminal.

"Charge last" will use solar power in the following order: 1. Loads 2. Grid export 3. Battery charging.

"CT direction reversed" occurs when both CTs are installed in the wrong direction; the installer can remedy this by checking this box.

Export to Grid: This selection is for users to set a zero-export function. If exporting solar power is not allowed, users need to disable the “**Export to Grid**” option. If a user’s utility meter is tripped with minimal solar export, “**Zero Export**” can be enabled; thus, the export detection and adjustment will take place every 20ms, which will effectively avoid any solar power being exported. If export is allowed, users can enable “**Export to Grid**” and set a maximum allowable export limit in “**Max Export to Grid(kW)**”.

“**Role**” setting of the parallel system. It is set to “**1 phase master**” by default. **In a parallel system, only one inverter is allowed to be set as Master and the others are set as Slaves.**

“**Phase**” is the phase code setting of the load output. The system will automatically detect the phase sequence of the inverter (consistent with the phase sequence of the connected grid mains) and display it on the inverter after it is connected to the grid.

“**Share battery**”: If all inverters are connected to the same battery bank when configured as a parallel system, then this setting must be **enabled**. If the inverters are configured as a parallel system and are connected to independent battery banks, then this setting must be **disabled**.



REMINDER: All setting changes for parallel inverters must be done while in Standby Mode.

- If the system is connected to a Lithium battery, the host of the battery bank needs to communicate with the inverter that is set as Master in the parallel system.
- Keep all the settings the same for each inverter in the parallel system on the LCD or remote monitor!

11. OPERATING MODE DESCRIPTION

The EG4 12kPV can work in several different modes of operation:

- **Self-Consumption Mode:** The inverter will operate in a pre-set priority system. In this mode, the user will experience the inverter drawing power from the solar arrays to power the loads. When/if the solar power is insufficient, the inverter will then draw from the battery bank for loads. Only as a last resort will the inverter switch to bypass mode to power loads from AC input.
- **Battery Backup Mode:** The inverter will operate in a pre-set priority system. In this mode, the user will experience the inverter drawing power from the solar arrays to power the loads. When/if the solar power is insufficient, the inverter will then switch to bypass mode to power loads from AC input. The inverter will only power loads with battery when there are no other options.
- **Grid Sell Back with AC Couple:** The inverter will operate with full functionality while still allowing the inverter to sell back to the grid using the GEN port for an AC coupled system.

11.1 SELF-CONSUMPTION MODE

Ensure the inverter is in standby mode (load breaker off) before making any changes to the system settings.

Listed below are the combination of settings to achieve Self-Consumption Mode via the mobile app or monitoring website.



NOTE: Ensure settings match the below selections. If any settings are missing from the list below, contact the distributor for more information regarding commissioning.

- **Step 1**

PV Input Mode	7: PV1&2&3 in	Set
----------------------	---------------	-----

- **Step 2**

Grid Sell Back	Enable	Disable
-----------------------	--------	---------

- **Step 3**

Fast Zero Export	Enable	Disable
-------------------------	--------	---------

- **Step 4**

Run Without Grid	Enable	Disable
-------------------------	--------	---------

- **Step 5**

Seamless EPS switching	Enable	Disable
-------------------------------	--------	---------

- **Step 6**

On-Grid Cut-Off SOC(%) (?)	25	Set
-----------------------------------	----	-----

- **Step 7**

Charge Current Limit(Adc)	100	Set
----------------------------------	-----	-----

- **Step 8**

Discharge Current Limit(Adc) (?)	100	Set
---	-----	-----

11.2 BATTERY BACKUP MODE

Ensure the inverter is in standby mode before making any changes to the system settings.

Listed below are the combination of settings to achieve Battery Backup Mode via the mobile app or monitoring website.



NOTE: Ensure settings match the below selections. If any settings are missing from the list below, contact the distributor for more information regarding commissioning.

- **Step 1**

PV Input Mode	7: PV1&2&3 in	Set
----------------------	---------------	-----

- **Step 2**

Grid Sell Back	Enable	Disable
-----------------------	--------	---------

- **Step 3**

Fast Zero Export	Enable	Disable
-------------------------	--------	---------

- **Step 4**

Run Without Grid	Enable	Disable
-------------------------	--------	---------

- **Step 5**

Seamless EPS switching	Enable	Disable
-------------------------------	--------	---------

- **Step 6**

Charge Current Limit(Adc)	100	Set
----------------------------------	-----	-----

- **Step 7**

AC Charge Enable	Enable	Disable
-------------------------	--------	---------

- Step 8

Start AC Charge SOC(%)	90	Set
Stop AC Charge SOC(%)	100	Set

- Step 9

AC Charge Start Time 1	00	:	01	Set
AC Charge End Time 1	23	:	59	Set

- Step 10

Battery Priority (?)	Enable	Disable
----------------------	---------------------------------------	--

- Step 11

On-Grid Cut-Off SOC(%) (?)	90
----------------------------	---------------------------------

- Step 12

Discharge Current Limit(Adc) (?)	100	Set
----------------------------------	----------------------------------	------------------------------------

11.3 GRID SELL BACK WITH AC COUPLE

Ensure the inverter is in standby mode before making any changes to the system settings.
To achieve Grid Sell Back w/ AC Couple working mode, please refer to the following settings.



NOTE: Ensure settings match the below selections. If any settings are missing from the list below, contact the distributor for more information regarding commissioning.

- Step 1

PV Input Mode	7: PV1&2&3 in	Set
----------------------	---------------	-----

- Step 2

Run Without Grid	Enable	Disable
-------------------------	--------	---------

- Step 3

Seamless EPS switching	Enable	Disable
-------------------------------	--------	---------

- Step 4

Battery Priority (?)	Enable	Disable
-----------------------------	--------	---------

- Step 5

Charge Current Limit(Adc)	100	Set
----------------------------------	-----	-----

- Step 6

AC Couple	Enable	Disable
------------------	--------	---------

- Step 7

AC Couple Start SOC(%)	25	Set
AC Couple End SOC(%)	100	Set

- Step 8

On-Grid Cut-Off SOC(%) (?)	25	Set
-----------------------------------	----	-----

- **Step 9**

Discharge Current Limit(Adc) (?)	100	Set
---	----------------------------------	------------------------------------

12. DOUBLE CHECK ALL WIRING/VOLTAGES/AMPS

Once all settings are configured to achieve the desired mode, check all voltages at all available disconnects as an added safety step before outputting power from the inverter.

Ensure all circuit breakers are open (off). Using a multimeter, check voltages at all available disconnects. Once 0V on all lines are confirmed, proceed to full system start-up.

13. FULL SYSTEM START-UP

Follow the steps listed below for proper start-up sequence of the inverter:

1. If equipped, first close (turn on) the external DC breaker between the battery and inverter. Turn on the "BAT" breaker located in the cable box of the inverter and then power on the battery system.
2. Ensure the PV string voltages are within the operating parameters using a multimeter. Upon confirmation, turn on (close) the PV isolator switch between the inverter and the panel array.
3. Turn on (close) the PV isolator switch on the side of the unit.
4. Make sure Steps 1 and 2 are accomplished before turning on the grid power or generator breaker.
5. Power on the load breakers on the inverter.

14. FULL SYSTEM SHUTDOWN

Follow the steps listed below for proper shutdown sequence of the inverter:

1. Turn off (open) the grid breaker feeding the inverter.
2. Turn off the LOAD breaker.
3. Turn off the PV isolator switch.
4. Turn off the BAT breaker.


Once the LCD powers down, the inverter has been shut down.

15. INVERTER TROUBLESHOOTING

Please follow the troubleshooting steps in the tables below when encountering any faults and/or errors on the inverter.




15.1 VIEWING INFORMATION AND ALARM FAULT/RECORD

Home Screen



Fault/Alarm Information

By touching the bell icon at the bottom of the screen, users will see all the current and historical faults and warning information on this page.



15.2 REGULAR MAINTENANCE

Inverter Maintenance

- Inspect the inverter every 6 months to check for any damaged cables, accessories, or terminals, and inspect the inverter itself.
- Inspect the inverter every 3 months to verify if the operating parameters are normal and there is no abnormal heating or noise from all components in the system.
- Inspect the inverter every month to confirm nothing covers the inverter heat sink. If there is, shut down the inverter and clear the heat sink to restore proper cooling.

15.3 TROUBLESHOOTING BASED ON LCD SCREEN

Once there is any warning or fault occurring, users can troubleshoot according to the LED status description and the warning/fault information on the LCD screen.

15.3.1 FAULTS ON THE LCD AND FAULT LIST

If the dot on the left of the fault item is **red**, it means the fault is active.


When the dot is grey, it means the fault is inactive.

Fault status	Alarm status	Fault record	Alarm record
● M3 Rx failure	● Model fault	● Eps short circuit	
● Eps power reversed	● Bus short circuit	● Relay fault	
● M8 Tx failure	● M3 Tx failure	● Vbus over range	
● Eps connect fault	● PV volt high	● Hard over Curr	
● Neutral fault	● PV short circuit	● Temperature fault	
● Bus sample fault	● Inconsistent	● M8 Rx fault	
● Para Comm error	● Para master loss	● Para rating Diff	
● Para Spec Diff	● ParaPhase set error	● Para Gen unAccord	
● Para Sync loss	● Fault A	● Fault B	
● Fault C	● Fault D	● Fault E	

FAULT	MEANING	TROUBLESHOOTING
M3 Rx failure	M3 microprocessor fails to receive data from DSP	Restart the inverter. If the error persists, contact the supplier.
Model fault	Incorrect model value	
EPS short circuit	Inverter detected short-circuit on load output terminals	1. Check if the L1, L2, and N wires are connected correctly at the inverter load output terminal. 2. Disconnect the load breaker to see if fault remains. If the fault persists, contact the supplier.
EPS power reversed	Inverter detected power flowing into load terminal	Restart the inverter. If the fault persists, contact the supplier.
Bus short circuit	DC Bus is short circuited	
Relay fault	Relay abnormal	
M8 Tx failure	DSP fails to receive data from M8 microprocessor	
M3 Tx failure	DSP fails to receive data from M3 microprocessor	
Vbus over range	DC Bus voltage too high	Ensure the PV string voltage is within the inverter specification. Also, check inverter and battery voltage. If voltage readings are within range and this fault persists, contact the supplier.
EPS connect fault	Load terminal and grid terminal are connected wired incorrectly or reversed	Check if the wires on load terminal and grid terminal are wired correctly. If the fault persists, contact the supplier.
PV volt high	PV voltage is too high	Please check if the PV string voltage is within the inverter specification. If string voltage is within range and this fault persists, contact the supplier.
Hard over curr	Hardware level over current protection triggered	Restart the inverter. If the fault persists, contact the supplier.
Neutral fault	Voltage between N and G is greater than 30V	Ensure the neutral wire is connected correctly.
PV short circuit	Short circuit detected on PV input	Disconnect all PV strings from the inverter. If the error persists, contact the supplier.
Temperature fault	Heat sink temperature too high	Install the inverter in a place with good ventilation and no direct sunlight. If the installation site is okay, check if the NTC connector inside the inverter is loose.
Bus sample fault	Inverter detected DC bus voltage lower than PV input voltage	Restart the inverter, if the fault persists, contact the supplier.
Inconsistent	Sampled grid voltage values of DSP and M8 microprocessor are inconsistent	
M8 Rx fault	M8 microprocessor fails to receive data from DSP	
Para Comm error	Parallel communication abnormal	1. Check whether the connection of the parallel cable is loose. Connect the parallel cable correctly. 2. Ensure the PIN status of the CAN communication cable from the first to the end inverter is connected correctly.

Para master loss	No Master in the parallel system	1. If a Master has been configured in the system, the fault will automatically be removed after the Master works. 2. If a Master has not been configured and there are only Slaves in the system, set the Master first. Note: For a single-unit system, the role of the inverter should be set as “1 phase Master.”
Para rating Diff	Rated power of parallel inverters is inconsistent	Confirm that the rated power of all inverters is the same.
Para Phase set error	Incorrect setting of phase in parallel	First confirm the wiring for the parallel system is correct. Once verified, connect each inverter to the grid. The system will automatically detect the phase sequence and the fault automatically resolves after the phase sequence is detected. If the fault persists, contact the supplier.
Para Gen in Accord	Inconsistent generator connection in parallel	Some inverters are connected to generators, and some are not. Confirm <i>all</i> inverters in parallel are connected to common generator output, or <i>none</i> are connected to generators.
Para sync loss	Parallel inverter fault	Restart the inverter. If the fault persists, contact the supplier.

15.3.2 ALARM ON THE LCD AND ALARM LIST



Alarm List

ALARM	MEANING	TROUBLESHOOTING
Bat com failure	Inverter fails to communicate with battery	Check if the communication cable pinout is correct, and if the correct battery brand is selected on the inverter's LCD. If all is correct but the alarm persists, contact the supplier.
AFCI com failure	Inverter fails to communicate with AFCI module	Restart inverter. If the error continues, contact the supplier.
AFCI high	PV arc fault is detected	Check each PV string for correct open- circuit voltage and short-circuit current. If the PV strings are in good condition, please clear the alarm on the inverter LCD.
Meter com failure	Inverter fails to communicate with the meter	Check if the communication cable is connected correctly and in good working condition. Restart inverter. If the alarm persists, contact the supplier.
Bat Fault	Battery cannot charge or discharge	1. Check the battery communication cable for correct pinout on both inverter and battery end. 2. Check if an incorrect battery brand is selected. 3. Check if there is fault on battery's indicator. If there is a fault, please contact the battery supplier.
LCD com failure	LCD fails to communicate with M3 microprocessor	Restart the inverter. If the fault still occurs, contact the supplier.
Fwm mismatch	Firmware version mismatch between the microprocessors	Restart the inverter. If the fault still occurs, contact the supplier.
Fan stuck	Cooling fan(s) are stuck	Restart the inverter. If the fault still occurs, contact the supplier.
Trip by GFCI high	Inverter detected leakage current on AC side	1. Check if there is ground fault on grid and load side. 2. Restart inverter. If the alarm persists, contact the supplier.
Trip by dci high	Inverter detected high DC injection current on Grid terminal	Restart inverter. If the alarm persists, contact the supplier.

PV short circuit	Inverter detected a short circuit in PV input	1. Check whether each PV string is connected correctly. 2. Restart inverter. If the alarm persists, contact the supplier.
GFCI module fault	GFCI module is abnormal	Restart inverter. If the alarm persists, contact the supplier.
Bat volt high	Battery voltage too high	Check whether the battery voltage exceeds 59.9V; battery voltage should be within inverter specification.
Bat volt low	Battery voltage too low	Check whether the battery voltage is under 40V; battery voltage should be within inverter specification.
Bat open	Battery is disconnected from inverter	Check battery breaker or battery fuse. Reconnect as needed.
Off-grid overload	Overload on Load terminal	Check if load power on inverter LOAD terminal is within inverter specification.
Off-grid overvolt	Load voltage is too high	Restart inverter. If the alarm persists, contact the supplier.
Meter reversed	Meter connection is reversed	Check if the meter communication cable is connected correctly on the inverter and meter sides.
Off-grid dcv high	High DC voltage component on load output when running off-grid	Restart inverter. If the alarm persists, contact the supplier.
RSD Active	Rapid shutdown activated	Check if the RSD switch is pressed.
Para phase loss	Phase losing in parallel system	Confirm that the wiring of the inverter is correct. If the Master is set to 3-phase Master, the number of parallel inverters must be ≥ 3 . (The grid input for each inverter should be connected correctly to Grid L1, L2, L3.) If the Master is set to 2x 208 Master, the number of parallel inverters needs to be ≥ 2 . (And the grid input of each inverter should be connected correctly to Grid L1, L2, L3.)
Para no BM set	Master is not set in the parallel system	Set one of the inverters in the parallel system as the Master.
Para multi BM set	Multiple Primaries have been set in the parallel system	There are at least two inverters set as the Master in the parallel system. Keep one Master and set the other as Slave.

16. TROUBLESHOOTING WI-FI MODULE

16.1 CENTER LIGHT FLASHING

Why is the middle light for the Wi-Fi module flashing?

After setting the right Wi-Fi password, all three lights should be on solidly. If it is still flashing, try the following:

1. Check to see if the Wi-Fi is connected and that the correct password has been entered. The device can be used to connect to a Wi-Fi hotspot and visit the website 10.10.10.1 to check; the TCP client status should be "connected" as seen in the image. The login username and password are both "admin." Check your Wi-Fi name and password if it is.
2. Prior to setting the password, add the dongle to the system. After registering and entering the Wi-Fi SN and PIN, this dongle is automatically added to the system. While logged in, go to "Configuration" -> "Dongles" -> "Add dongle" to add this dongle to the current configuration if you have more than one dongle. Restart the Wi-Fi module by unplugging it and plugging it back in after installing the dongle.

10.10.10.1			1	
Run State			• 中文 English	
Wifi Mode Select			AP State	
AP Mode Setting			Function	Enable
Station Mode Setting			IP	10.10.10.1
Uart Setting			Netmask	255.255.255.0
Network Setting			STA State	
Moduel Manangement			Function	Enable
			Channel	6
			Signal Strength	-46%
			IP	192.168.0.146
			Netmask	255.255.255.0
			Gateway	192.168.0.1
			Command Mode State	
			Function	Disable
			Network 1 State	
			Function	Enable
			Protocol	TCP client
			TCP Client State	Connected

EG4ELECTRONICS

Monitor

Data

Configuration

Overview

Maintenance

☆

English

Stations

Dongles

Devices

Users

All Status

All Type

+ Add Dongle

Import Dongle

Search by dongle SN

	Serial number	Dongle type	Station name	EndUser	Firmware	Create date	Connect Status	Last Update Time	Action
1		Wi-Fi		EndUser		2023-08-11	Lost	2024-01-18 13:05	Management
2						2023-09-22	Lost		Management
3		Wi-Fi				2023-08-02	Lost	2023-08-15 14:34	Management
4						2024-03-03	Lost		Management
5		Wi-Fi				2023-10-13	Connected	2024-03-07 14:28	Management


16.2 DONGLE RECOVERY

This guide will detail the steps needed to recover Wi-Fi dongles with serial numbers starting with the letters "BA" after being reset to factory settings.

Please read the guide in its entirety before performing the steps listed below.


Step 1

Connect the dongle to the inverter's Wi-Fi dongle port as shown below.



Step 2

After ~30 seconds, the dongle's LED status will appear as shown below.



- INV LED “OFF”
- Network LED “Blinking”
- Module LED “ON”

Step 3

Connect the mobile device/PC to the dongle's network. The network name will match the serial number (SN) on the outer shell of the dongle. If unable to locate the network named after the SN, check for a network named, “MXCHIP-xxxxxxx”. Write this number down for step 6.

Step 4

Enter “10.10.10.1” (no quotes) into the browser. Both the username and the password are “admin” (no quotes). After logging in, select the language on the right side. See image below.



Step 5

Select the “Wifi Mode Select” option on the left-hand side of the screen. From here, select “AP and Station” and save. See image below.

MiCO IoTOS • 中文|English

Run State

Wifi Mode Select

AP Mode Setting

Station Mode Setting

Uart Setting

Network Setting

Moduel Management

Wifi Mode Select

☐ AP Mode

☐ Station Mode

☒ AP and Station

save

Step 6

Next, select the “AP Mode Setting” on the left-hand side of the screen. Enter the dongle’s SSID and select “save”. The SSID will match the dongle’s SN or “MXCHIP-xxxxxx” as determined by step 3 above. See image below for reference.

MiCO IoTOS • 中文|English

Run State

Wifi Mode Select

AP Mode Setting

Station Mode Setting

Uart Setting

Network Setting

Moduel Management

Ap Parameter Setting

SSID BA32401403

Encryption Mode Disable

save

IP Address Setting

IP 10.10.10.1

Netmask 255.255.255.0

Gateway 10.10.10.1

save

Step 7

Navigate to the “Network Setting” page. Under “Network Connection 1 Setting”, enter the following data and save.

- Protocol: TCP Client
- Remote Port: 4346
- Server Address (IP or domain) 3.101.7.137

Under “Network Connection 2 Setting”, enter the following data and save. (see image below)

- Protocol: TCP Server
- Local Port: 8000

MiCO IoTOS • 中文|English

Run State

Wifi Mode Select

AP Mode Setting

Station Mode Setting

Uart Setting

Network Setting

Moduel Management

Network Connection 1 Setting

Protocol: TCP Client

Remote Port: 4346

Server Address(ip or domain): 3.101.7.137

save

Network Connection 2 Setting

Protocol: TCP Server

Local Port: 8000

save

Step 8

Navigate to the “Station Mode Setting” page. Enter the home Wi-Fi SSID information. Ensure that “Encryption Mode” is set to “Enable”. Enter in the home Wi-Fi password and select “Save”. See figure below.

MiCO IoTOS • 中文|English

Run State

Wifi Mode Select

AP Mode Setting

Station Mode Setting

Uart Setting

Network Setting

Moduel Management

Station Parameter Setting

SSID:

scan

Encryption Mode: Enable

Password:

save

IP Setting

Auto: DHCP Client

IP:

Netmask: 255.255.255.0

Gateway:

save

17. BATTERY TROUBLESHOOTING



NOTE: *The software downloaded depends on the battery model. LL-S, LL V2 and WallMount batteries use BMS Tools. LifePower4 batteries use BMS Test.*

17.1 BMS TOOLS

The PC software “BMS Tools” provides real-time battery analysis and diagnostics for the LL-S, LL V2 and WallMount batteries. The battery cannot communicate with BMS Tools and a closed loop inverter at the same time.

17.2 BMS TEST

The PC software “BMS Test” provides real-time battery analysis and diagnostics for the LifePower4 model of EG4 batteries. The battery cannot communicate with BMS Test and a closed loop inverter at the same time.

17.3 WARNING/PROTECTION CODES TABLES (LL-S, V2 AND WALLMOUNT)

When the ALM light on the battery control panel is on, it means that the battery has given an alarm or has been protected from potential damage. Please check the cause of the failure through the app or BMS Tools and respond appropriately or go directly to the battery site to troubleshoot.

BMS Tools alarms are shown in the table below:

STATUS	NAME	DEFINITION	ACTION
Warning/ Protect	Pack OV	Pack over-voltage	Module needs to be discharged to lower its voltage.
	Cell OV	Cell over-voltage	Check individual cell voltage in BMS Tools.
	Pack UV	Pack under-voltage	Module needs to be charged.
	Cell UV	Cell under-voltage	Check individual cell voltage in BMS Tools.
	Charge OC	Charge over-current	Incoming current needs to be reduced.
	Discharge OC	Discharge over-current	Discharge current is too high. Lower loads.
	Temp Anomaly	Temperature anomaly	Check ambient and module temperature.
	MOS OT	MOSFET over-temperature	BMS temperature is too high. Power off module and cool down location.
	Charge OT	Charge over-temperature	Power off module and cool down location.
	Discharge OT	Discharge over-temperature	Power off module and cool down location.
	Charge UT	Charge under-temperature	Power off module and warm up location.
	Discharge UT	Discharge under temperature	Power off module and warm up location.
Warning	Low Capacity	Low battery capacity	Module needs to be charged.
Warning	Other Error	Error not listed	Contact the distributor.
Protect	Float Stopped	Float Stopped	Contact the distributor.
Protect	Discharge SC	Discharge short circuit	Discharge current is too high. Turn BMS and breaker off and back on to reset. Lower loads.

FAULT	ANALYSIS	ACTION
Inverter communication failure	Check communication port connection, and battery ID setting.	Input proper "host" battery DIP switch address, and power cycle the battery.
No DC output	Open breaker, or battery voltage is too low.	Check battery breaker or charge the battery.
Power supply unstable	Battery capacity is not at full power.	Check for proper battery cable connection.
Battery cannot be charged fully	DC output voltage is below the minimum charge voltage.	Check the charging settings on the inverter to ensure they match battery requirements.
ALM LED always on	Short circuit	Disconnect the power cable and check all cables.
The battery output voltage is unstable.	Battery management system does not operate normally.	Press the reset button to reset the battery, then reboot the system.
ALM LED flashes 20 times with SOC 1 LED on.	Unbalanced voltage within a cell	Deep discharge the battery bank (<20% SOC), then charge battery bank fully.
ALM LED flashes 20 times with SOC 2 LED on.	Unbalanced temperature	Contact the distributor.
ALM LED flashes 20 times with SOC 3/4 LED on.	BMS damaged	Contact the distributor.
Different SOC value of batteries in parallel operation.	No issue	Deep discharge the battery bank (<20% SOC), then charge battery bank fully.
Low voltage protection with no LED on	BMS is in low voltage protection, and is in sleep mode	Contact the distributor.
Deeply discharged with "RUN" LED on	The battery voltage is too low to start BMS.	Contact the distributor.



NOTE: *If any of the warnings or faults from both tables persist, please contact the distributor for additional troubleshooting steps.*

Notes

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Notes

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

