



HOW TO OPERATE YOUR ALARM



1. ACTIVATE BATTERIES

First, activate the batteries by pulling out the plastic tab protruding from the bottom of the alarm.



2. HOW TO ARM THE ALARM

On the remote, press the button with the CLOSED LOCK symbol. You should hear a ringtone, then shortly after one beep. Hearing the one beep means your alarm is in arm mode. If the alarm feels any movement it will issue two quick warning beeps. This is in case of an accidental movement. If the alarm is moved again (within a few seconds of the two warning beeps) it will fully sound off for 30 seconds. After 30 seconds the alarm automatically goes back into arm mode.



3. HOW TO DISARM ALARM

First, activate the batteries by pulling out the plastic tab protruding from the bottom of the alarm.

HOW TO SYNCH A NEW REMOTE WITH YOUR ALARM



OPEN THE ALARM CASE

Open the alarm case using the screwdriver and pry tool. Note: You may find it easier to use a pocket knife or flathead screwdriver instead of the pry tool. Remove one of three batteries, wait 5 seconds, put battery back in position.



PRESS AND HOLD THE BELL BUTTON

Open the alarm case using the screwdriver and pry tool. Note: You may find it easier to use a pocket knife or flathead screwdriver instead of the pry tool. Remove one of three batteries, wait 5 seconds, put battery back in position.



PRESS THE ARM BUTTON

Immediately press the ARM button once. You should hear a ringtone, which means your new remote control is now synched with your alarm.



FINAL STEPS

Turn off the alarm, put the alarm case back together, and put the screw back in place.

You may synch up to 8 alarms with one remote or up to 8 remotes with one alarm.



OPEN THE ALARM CASE

Open the alarm case using the screwdriver and pry tool. Note: You may find it easier to use a pocket knife or flathead screwdriver instead of the pry tool. Remove one of three batteries, wait 5 seconds, put battery back in position.



PRESS AND HOLD THE BELL BUTTON

Press and hold the BELL button for several seconds until you hear one subtle beep coming from the target Alarm.



PRESS THE ARM BUTTON

Immediately press the ARM button once. You should hear a ringtone, which means your new remote control is now synched with the target alarm. You will need to do the above process for each additional remote you'd like to add to the group.



FINAL STEPS

Immediately press the ARM button once. You should hear a ringtone, which means your new remote control is now synched with the target alarm. You will need to do the above process for each additional remote you'd like to add to the group.

HOW TO CHANGE THE SENSITIVITY LEVEL OF YOUR ALARM



PRESS AND HOLD THE THE OPEN LOCK BUTTON

Press and hold the remote's OPEN LOCK button until the LED light shuts off. Keep pressing until you see the LED light come back on.



PRESS THE LOCK BUTTON

Press the LOCK button on the remote control as many times as you need until you have reached the desired sensitivity level. You will hear 7 tones/levels: "Do Re Mi Fa So La Ti." "Do" is most sensitive all the way down to "Ti" being the least sensitive.



PRESS THE OPEN LOCK BUTTON

Press the open lock button one time to lock in the desired sensitivity level.

HOW TO SYNCH MULTIPLE ALARMS WITH ONE REMOTE OPEN THE ALARM

For additional alarm instructions including **VIDEOS**, visit: www.AlarmUserManual.com