



**FOGSTAR DRIFT**



LiFePO<sub>4</sub> Battery  
**USER MANUAL**

2024 V1.0  
[WWW.FOGSTAR-DRIFT.CO.UK](http://WWW.FOGSTAR-DRIFT.CO.UK)



## FOGSTAR DRIFT

Here at Fogstar, we've made it our mission to make Lithium Iron Phosphate batteries affordable and accessible to everyone. We've also made the manufacturing process a transparent one.

You can rest assured that your leisure battery contains quality products, including EVE Grade A LiFePO<sub>4</sub> Prismatic Cells and a JBD Battery Management System. We've also included heating, Bluetooth and an App as standard.

As a relatively small business based in Worcestershire, we've set our sights on providing customers with the very best product and customer service experience.

In this manual you'll find lots of useful information about your Fogstar Drift Leisure Battery. Of course, if you don't find the answers to your questions, you can always get in contact with our friendly team and we will always be happy to help.

*The Fogstar Team*

## CONTENTS

- 2 Welcome
- 3 Get to know your battery
- 4 Battery specifications
- 6 Alerts and warnings
- 7 The Fogstar Drift app
- 9 Warranty
- 10 Frequently asked questions
- 12 Our community





### Battery Management System

BMS Information	12V 105Ah	12V 230Ah	12V 280Ah	12V 300Ah	12V 460Ah	12V 560Ah	230Ah Seat Base	12V 608Ah	24V 230Ah	24V 280Ah
Maximum Discharge	100A	200A	200A	200A	200A	200A	200A	200A	200A	200A
Peak Discharge	200A	400A	400A	400A	400A	400A	400A	400A	400A	400A
Max Charging Current	100A	200A	200A	200A	200A	200A	200A	200A	200A	200A
Temperate Protection	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
OverCurrent Protection	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
OverDischarge Protection	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes



It can usually take between 4-5 cycles for the BMS to fully 'learn' the battery parameters. Make sure you charge your battery to the full 14.2V during the first few cycles.





Fogstar Drift 12V 608Ah	Fogstar Drift 24V 230Ah	Fogstar Drift 24V 280	Seat Base 12V 230Ah
Grade A EVE LF304	Grade A EVE LF230	Grade A EVE LF280K	Grade A EVE LF230
452P	851P	851P	451P
608Ah	230Ah	280Ah	230Ah
7782Wh	5888Wh	7168Wh	2944Wh
Lithium Iron Phosphate	Lithium Iron Phosphate	Lithium Iron Phosphate	Lithium Iron Phosphate
3.2V *8 (12.8V)	3.2V *8 (12.8V)	3.2V *8 (25.6V)	3.2V *4 (12.8V)
3500 Cycles @ 80% DOD	4000 Cycles @ 80% DOD	8000 Cycles @ 80% DOD	4000 Cycles @ 80% DOD
200A	200A	200A	200A
200A	200A	200A	200A
12.8V	12.8V	25.6V	12.8V
10V	10V	20V	10V
-20C to 60C	-20C to 60C	-20C to 60C	-20C to 60C
-20 to 60C (Heater Enabled)	-20 to 60C (Heater Enabled)	-20 to 60C (Heater Enabled)	-20 to 60C (Heater Enabled)
10C to 35C @ 50% SOC	10C to 35C @ 50% SOC	10C to 35C @ 50% SOC	10C to 35C @ 50% SOC
633mm x 245mm x 220mm	522mm x 218mm x 245mm	640mm x 245mm x 220mm	275mm x 187.5mm x 315mm
48KG	50KG	50KG	25kg
ABS Plastic	ABS Plastic	ABS Plastic	ABS Plastic

## Storing your Battery

We strongly suggest your batteries are stored at room temperature, charged to between 30% to 50% of their capacity. We recommend that batteries be charged once every three months to prevent over discharge.

## Battery Performance

Because Lithium Iron Phosphate batteries utilise a chemical reaction, battery performance will deteriorate over time even if stored for long periods without regular use.

If the various usage conditions such as charge, discharge, ambient temperature, etc. are not maintained within the specified ranges, the life expectancy of the battery may be shortened, or the device in which the battery is used may be damaged by electrolyte leakage.

## Battery Series and Parallel Mode

Batteries can be connected simultaneously with a maximum of four (4) in series OR (4) in parallel.

Our JBD BMS contain a wide range of protective features, ensuring optimal charging and battery health throughout the lifecycle of the cells. Some of these protective features include;



## Protective Alerts and Warnings

### Low Temperature Charging

The battery has detected that you are trying to charge whilst the temperature is around 0°C. This warning is normal, and it is used to trigger the heating pads in your battery. Incoming charge current will heat the pads first, and then the battery will allow charge through when it reaches 5°C.

### High Temperature Discharging (OTD)

The battery has detected that you are trying to discharge whilst the internal temperature is above 75°C. Discharging has been disabled until the temperature falls within an acceptable range.

### Low Temperature Discharging (UTD)

The battery has detected that you are trying to discharge whilst the temperature is below -20°C. Discharging has been disabled.

### Pack Over-Voltage (POV)

The total voltage of the pack has exceeded the maximum voltage. The BMS has turned off charging so that you do not overcharge the battery. Please discharge the battery.

### Pack Under-Voltage (PUV)

The total voltage of the pack has reached the minimum allowed voltage. Discharge has been disabled. Please charge the battery.

### Short Circuit (SCD)

A short circuit has been detected, and the BMS has protected you, and your battery. Please stop using the battery, and check your system thoroughly for anywhere a short circuit could have occurred. This could also be caused by an extremely large inverter charging its capacitors. If this is the case, disconnect the load and use a pre-charge resistor.

### Over Current Charging (OCC)

You have exceeded the 200A charging limit. The BMS has disabled charging.

### Over Current Discharging (OCD)

You have exceeded the 200A discharging limit. The BMS has disabled discharging.

### Cell Under-Voltage (CUV)

A cell has hit the minimum voltage and the BMS has disabled discharging to protect the cell. Please charge the battery.

### High Temperature Charging (OTC)

The battery has detected that you are trying to charge whilst the internal temperature is above 55°C. Charging has been disabled until the temperature falls within an acceptable range.

## Connecting to the App

The Fogstar Drift app works on all models of Android and iPhone and is available to download from the App Store and Google Play for free. We've made our app as simple as possible to use. It only contains the information you really need. The user-friendly interface is perfect for even the most hardened technophobes, and the simple navigation is deliberately designed to make for a simplistic user experience.




### Step 1 - Download the App

Scan the QR codes to find the Fogstar Drift App on both Android and iOS.

### Step 2 - Connect to your battery

1. Ensure your phone's Bluetooth and Location services are switched on
2. Open the Fogstar Drift App to search via Bluetooth
3. Locate your Fogstar Drift Battery on the Menu
4. Tap the dot to turn the Bluetooth on
5. You can also slide left on your battery to 'Auto Connect' (via the orange tab)
6. Wait a few moments for your phone and battery to establish a connection.
7. You may need to try these steps a few times to 'wake' the BMS.




### Step 3 - Charging and Discharging Buttons

On the main dashboard of the App, you'll find the 'Charging' and 'Discharging' buttons.

toggling these buttons to 'OFF' will turn the charge and discharge functions of the battery OFF.

Setting the Discharge button to 'OFF' will effectively put the battery into storage mode.



## The Main Battery Screen

When you open the Drift App, you'll land on the main screen allowing you to view the Battery Dashboard, this will show you;

- State of Charge (the % dial)
- Charging and discharging switch
- Battery voltage
- Battery current
- Power in and out
- Temperature detection
- Cycles.

At the bottom of the App, you'll find the Voltage and Dashboard tabs. You can use the information in these tabs to understand more in-depth data about your battery.



## Battery Settings

Under Dashboard > Advanced Settings there is a hidden area that contains your BMS settings. These battery parameters are locked by a password. We lock down the battery parameters to ensure your BMS settings remain protected and unable to be unchanged.

Changing the BMS parameters can permanently damage your unit. The set-up and configuration of these technical specifications are set by JBD BMS and Fogstar, adapting them could result in a significant cell imbalance or errors in the BMS.

Should you wish to reconfigure the BMS for a hybrid set-up, please contact a member of our team at [customerservice@fogstar.co.uk](mailto:customerservice@fogstar.co.uk) to obtain the password, discuss your set-up prior to altering any of the BMS vitals.

## Changing your battery name

It's really simple to alter the name of your battery.

1. Open your Battery Dashboard
2. Click the name at the top of the screen
3. Enter your new battery name
4. Once the 'success' notice flags, wait 15 seconds for the change to register.





We offer a 10 Year Warranty on our Fogstar Drift lithium leisure batteries.

There are stipulations to this warranty of course, for example warranties can only be registered to the original owner and not transferred.

It should also be noted that our warranty does not cover items that have been damaged due to gross negligence, normal wear and tear, damage due to accident or collision, abuse or incorrect installation.

We're confident you'll get many, many cycles of use out of your leisure battery - we're also confident we've created a superb product containing some of the best components around.

When you receive your Fogstar Drift, don't forget to register for your 10 Year Warranty. This ensures your battery is on our database should any issues arise over the coming years.

## Warranty Conditions

- Fogstar offers a 10 year warranty on all Fogstar Drift Leisure batteries.
- Warranties only apply to the original owner and are non-transferrable.
- Fogstar will verify your purchase prior to processing any warranty claims or returns.
- If it is determined that the product is faulty, we will ship a new product to you immediately, you will only be asked to cover the cost of the shipping.
- Our warranty does not cover items that have been damaged due to gross negligence, normal wear and tear, damage due to accident or collision, abuse or incorrect installation.

## Registering your Warranty

You can register your 10 year warranty as soon as you receive your battery.

Scan the QR code to get started, or visit our Fogstar Drift website.



## Reporting an Issue

Should you encounter a problem with your Drift it important you contact our Customer Services team first and foremost. This gives us an opportunity to help you resolve the issue before any problems arise. By coming directly to us, before posting on forums or groups, we can help you resolve any issues or concerns quickly and efficiently.

If possible, please send screenshots of your App pages, including the %SOC page, cells voltages, and protect history along with a description of your issue to [customerservice@fogstar.co.uk](mailto:customerservice@fogstar.co.uk). If your issue is urgent and you need to talk with a member of the tech team immediately, please call 01527 757980.

### Can I series or parallel connect my batteries?

Yes, you can connect up to 4 Fogstar Drift batteries in either series OR parallel - we've had our JBD BMS specially programmed to allow for this.

### What size terminals/posts are the Fogstar Drift Leisure batteries?

The Fogstar Drift terminals are M8 in size. All of our Drift Leisure batteries come with bolts and terminal posts as standard.

### What are the charging parameters of the Drift batteries?

12V = 14.2V Bulk/13.6V Float

24V = 28.4V Bulk/27.4V Float

48V = 57.6V Bulk/54.4V Float

### Could you tell me if your Fogstar Drift 12v leisure batteries are suitable for series connection at 24 or 48 volts please?

Yes - we modified the JBD BMS at the manufacturing stage to add series or parallel support up to 4S and 4P. Units cannot be connected in series-parallel.

### Why does my Drift only show temperatures on three of the cells?

It is perfectly normal for cell 4 not to be showing a temperature. Temp 1 is the BMS temperature, Temp 2 is 'battery bank 1' temperature, and Temp 3 is 'battery bank 2' temperature.

### What charger shall I use with my Drift PRO?

The recommended charging current for a lithium leisure battery is typically around 20-30% of the battery's capacity. For example, if the battery has a capacity of 200Ah, the recommended charging current would be around 40 amps. It's important to check the specifications of your particular battery to ensure you are using the correct charging current.

### Can I lay my Drift on it's side?

Yes, your Drift battery can be lay on it's side, in fact, you can lie a Drift battery in any configuration you wish. All we recommend is that you keep the terminals clear and clean.

### What is the maximum inverter size I can use with my Drift?

The Drift 105Ah contains a 100A JBD BMS - this enables you to use your battery with inverters up to 1000W. The Drift 230/280/300/460/560 and 24V versions contain a 200A JBD BMS - this enables you to use your battery with inverters up to 2500W.

### How does the heater work in the batteries?

The Drift heating pads are only activated when the battery is being charged, and are only powered by the incoming charge current, not the battery itself. If you put the battery on charge, it will heat the battery first, and then allow current through to the battery when the temperature is safe enough to do so.

### What settings do I use on my charger?

Most chargers have profiles for various different battery parameters (Lead Acid/AGM), you should choose one that fits as close as possible to 14.2V-14.4V bulk and 13.5V-13.6V float.

An acceptable charging range for the Drift batteries is 14.2V-14.6V bulk and 13.3-13.6V float. For Victron systems, please use a 14.2V bulk and 13.6V float.

### How can I store my battery when not in use?

**Charge the battery to 40-50% of its capacity:** This will ensure that the battery has enough power to maintain its internal protection circuits.

**Store the battery in a cool, dry place:** Avoid storing the battery in direct sunlight, extreme temperatures, or humid environments. An ideal storage temperature range is between 5°C and 15°C (41°F and 59°F).

**Disconnect the battery from any charging or load sources:** This will prevent accidental discharge or damage to the battery.

**Clean the battery terminals:** Wipe down the terminals with a clean, dry cloth to remove any dirt or corrosion. Use the bungs provided with the battery to prevent any damage to the terminals.

**Check the battery periodically:** Every 3-6 months, check the battery's voltage to ensure it remains within the recommended range. If the voltage drops below 12V, it's advisable to recharge the battery to prevent damage.

**For extended storage (over 6 months):** If you plan to store the battery for an extended period, it's recommended to charge it to 50% of its capacity every 3 months to maintain its health.

### What settings do I use for my Victron equipment?

First and foremost, it is important you consult your Victron Manual for specific set-up instructions. However we do have some settings to help you configure your equipment if using the 'User Defined' settings;

- **Absorption voltage:** 14.2V
- **Absorption time:** The recommended setting is half an hour per 100ah of LiFePO4 battery (for example if you have x2 105ah batteries select 1 hour).
- **Float Voltage:** 13.6V is acceptable for LiFePO4 batteries.
- **Equalisation voltage:** 14.2V (you do not need to equalise Lithium, so you can turn this off, but in case it ever runs a cycle the batteries will be ok at this voltage).
- **Temperature compensation:** should be disabled on Lithium batteries.
- **Low Temperature cut-off:** The Drift batteries have low temperature charging protection built into the battery. You can leave this off.
- **Discharge Floor:** 0%
- **Tail Current:** 4%
- **Peukert Exponent:** Not required - this is for Lead Acid batteries.



## Had a great experience with Fogstar Drift?

We would love to hear your feedback on our Drift product. If you have any photos, videos or clips of our product in action - we'd love to see them. Use the hashtag #fogstardrift to engage with us.

Follow us on Instagram (@FogstarDrift), drop us a Google review, or join our 'Fogstar Drift - Owners Group' on Facebook.



**@FogstarDrift**