

Troubleshoot XQD driver installation – Windows

1. *Remove XQD Device Driver (v2.01.0.07130) from your system.*


Control Panel → Programs and Features




- 2. Connect TX-1CXQ to computer.
- 3. Insert Lexar XQD card.
- 4. Go to *Device Manager* → *Other devices* and look for **XQD Memory Card with** yellow exclamation mark.



5. Right-click on **XQD Memory Card** and select **Update driver**.



6. Select **Search automatically for updated driver software**.




- 7. After the driver update is complete, eject Lexar XQD card, wait a few seconds (~5-7 seconds), and re-insert Lexar XQD card back into reader.
- 8. Windows system should now recognize the Lexar XQD card.
- 9. Remove Lexar XQD card from reader.
- 10. Insert Sony XQD card into reader.
- 11. Following instructions below to install the Sony XQD driver (v201).
- 12. Once driver installation is complete, eject Sony XQD card, wait a few seconds (~5-7 seconds), and re-insert Sony XQD card back into reader.

Download and Install XQD driver for Windows 10

1. Open a web browser, go to www.blackjetusa.com




2. From the Navigation menu on the upper right corner of webpage, click on **SUPPORT**.



3. Click on **Software** icon.




SUPPORT



4. Click on XQD Driver.




DRIVER



5. Download **Driver Instructions** and **XQD Driver**.




DRIVER




6. Navigate to the bottom of webpage and click on "...(Windows)" icon. Proceed to download and save the XQD Driver Installer on your Desktop or a folder of your choice. The default folder is your **Downloads** folder.




7. Navigate to the **Downloads** folder, right-click the zip file and select "Extract All"




8. Select a file location where you want to extract the files and then click on "Extract". The default location is your system's **Downloads** folder.




9. Double-click the **XQD_Drv_Installer_win_v201** subfolder in the **Downloads** folder.



10. Right-click the zip file and extract again.



11. Double-click on the **XQD_Drv_Installer_win_v201** to start XQD driver installation.



12. Follow the instructions on screen to install the XQD driver. **Restart** your computer after XQD driver installation is finished.

