

LEADING EDGE SAFETY


Complete Permanent Perimeter Fall Protection System



PRS
PREMIER RAIL SYSTEMS



WALL MOUNT GUARDRAIL Instruction Manual



WARNING

Serious injury or death may result if this product is used for purposes other than designed. The manufacturer provides the following instructions for the use and care of this equipment. It is the responsibility of the purchaser to understand and convey explicit instruction to each user. The Wall Mount Guardrail product complies with the requirements of the Federal Occupational Safety and Health Administration (OSHA) when set up and used according to the Manufacture's instructions.

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

E
N
G
L
I
S
H

Wall Mount Guardrail Instruction Manual

Published by Leading Edge Safety, LLC, North Kansas City, MO

1345 Taney Street
North Kansas City, Missouri 64116
888.990.2990
www.leadingedgesafety.net

Copyright © 2018 Leading Edge Safety, LLC

PRINTED IN THE UNITED STATES OF AMERICA



WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

DIAGRAM OF PARTS

The Wall Mount Guardrail is comprised of numerous components. Below are examples of the individual parts that comprise the system. These parts may or may not be a part of your particular system, and are shown for reference only.

GUARDRAIL COMPONENTS

Upright Assembly (FMB-000-17)




Outside Adjustable Corner PRS-302-12




Inside Adjustable Corner PRS-303-12




Rail Corner Support PRS-RCS-001-13




29"-43" Adjustable Length Rail RB-ARAIL-43




43"-70" Adjustable Length Rail RB-ARAIL-70



70"-120" Adjustable Length Rail RB-ARAIL-120




8' Fixed Length Rail RB-RAIL-08



WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

ENGLISH



PRIOR TO INSTALLATION

- A competent professional should ensure the substrate is adequate and structurally sound prior to any guardrail installation. Any improvements to the substrate shall be made prior to any guardrail installation.
- Establish the layout of the roof area to be protected. Any object that will interfere with the railing system should be evaluated and considered in the design layout. In most cases, a guardrail layout drawing is provided as a general layout guide. Actual field conditions may require layout modifications from the provided layout drawing.
- Recommended Fasteners:
 - Backup Plate (Inside Parapet Wall Mount Installation)**
 - Wood—1/4" x 1-1/2" GRK RSS Structural Screws or 5/16" x 2-1/2" GRK RSS Structural Screws
 - Concrete— 1/4" x 1-1/4" through 2-1/4" GRK Caliburn PH Screws
(1" minimum penetration is required)
 - Other Substrates and Code requirements – Consult Leading Edge Safety technical department.
 - Mounting Plate (Outside Wall Mount Installation)**
 - Wood—3/8" x 2" (min) Lag Screws
 - Concrete— 3/8" x 2" (min) Large Diameter Tapcon (LDT) Anchors
(1" minimum penetration is required)
- Begin installation at the corners and work toward the middle of the edge being guarded.
- Do not use impact drivers to secure flange head screws.
- Follow fastener manufacturer instructions for installation and proper installation tools.

WALL MOUNT GUARDRAIL INSTALLATION MANUAL


INSIDE WALL MOUNT INSTALLATION

(For Outside Wall Mount Installation, see page 10)


Determine the first corner from which work will begin. To ensure proper placement of the corner uprights, space each upright according to the appropriate figures below for your application.

Ensure uprights are plumb and the vertical face of the mounting bracket is flush with the substrate (ISW-1.3); attach to structure with appropriate fasteners.


INSIDE WALL MOUNT
ISW-1.1
(OUTSIDE CORNER)



INSIDE WALL MOUNT
ISW-1.2
(INSIDE CORNER)



ISW-1.3




*****Proper and secure fastening requires the fasteners are installed straight and fastener heads are flush and tight to the surface of the bracket.**

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

E
N
G
L
I
S
H


ISW-2

Attach backup plate to wall with appropriate fasteners.




ISW-3

Apply non-curing butyl around threaded studs per roof manufacturers recommendations.




ISW-4

Apply roof membrane target patch over backup plate per roofing manufacturers recommendations



ISW-5


Target patch installed.



WALL MOUNT GUARDRAIL INSTRUCTION MANUAL


ISW-6

Secure mounting bracket to backup plate threaded studs with 3/8" washers and 3/8" lock-nuts.




ISW-7

Tighten nuts and washers to threaded studs to create a compression seal.




ISW-8

Insert post into mounting bracket post receiver.



ISW-9

Secure post with 3/8-16 x 2-1/2" hex bolt, 3/8" washers and 3/8-16 lock-nuts.




WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

E
N
G
L
I
S
H

ISW-10


Complete installation of both corner posts.



ISW-11

Attach Corners by loosely fastening 3/8"-16 x 1" Flange Head Screw—DO NOT FULLY TIGHTEN YET.

3/8-16 X 3/4" Flange Head Screws on Adjustable Corners can be tightened to permanently set the adjustable length (see Figure ISW-11.1.)




ISW-11.1

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

ISW-12

Install uprights using the fixed length horizontal rails as a guide to set the next post. Unfasten one end of the adjustable corner from the previous step and reattach both the corner and the fixed length rail. Attach the opposite end of the fixed length rail to the next upright to be installed; plumb the upright and attach upright as shown in previous steps.


***Note—Always install railing with weep holes facing down.



ISW-13

Attach Rail Corner Supports, Adjustable Corners and rails to uprights with using 3/8-16 x 1-1/2" Flange Head Screws.

***NOTE—YOU ARE REPLACING THE 1" FASTENERS THAT CAME PRE-INSTALLED IN THE POSTS FOR THE CORNERS ONLY IN THIS STEP.




3/8-16 x 1-1/2" Flange Head Screw

3/8-16 x 1" Flange Head Screw

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

E
N
G
L
I
S
H



ISW-14

Complete guardrail section by securing the appropriate size adjustable rail, equidistant from each corner or as indicated on your project specific guardrail layout drawing, with 3/8-16 x 1" Flange Head Screws.

Set screws on adjustable rails may be left out set loose to act as an expansion joint.

***Note—Always install railing with weep holes facing down.

Set screw
3/8-16 x 3/4" Flange Head Screw




ISW-15

Secure all flange head screws for railing to the recommended torque of seventy (70) inch pounds for clean and dry bolts.

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

OUTSIDE WALL MOUNT INSTALLATION



Determine the first corner from which work will begin. To ensure proper placement of the corner uprights, space each upright according to the appropriate figures below for your application. Ensure uprights are plumb and the vertical face of the mounting bracket is flush with the substrate (**OSW-1.3**); attach to structure with appropriate fasteners.



*****Proper and secure fastening requires the fasteners are installed straight and fastener heads are flush and tight to the surface of the bracket.**



WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

ENGLISH





CONCRETE OR MASONRY ATTACHMENT


OSW-2
Secure mounting bracket to wall with appropriate fasteners.




CONCRETE OR MASONRY ATTACHMENT




WOOD ATTACHMENT




WALL MOUNT GUARDRAIL INSTRUCTION MANUAL



OSW-3
*Insert post into mounting bracket
post receiver.*



OSW-4
*Secure post with 3/8-16 x 2-1/2" hex
bolt, 3/8" washers and 3/8-16
lock -nuts.*



OSW-5
Complete installation of both corner posts.


WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

E
N
G
L
I
S
H

OSW-6


Attach Corners by loosely fastening 3/8"-16 x 1" Flange Head Screw—DO NOT FULLY TIGHTEN YET.

3/8-16 X 3/4" Flange Head Screws on Adjustable Corners can be tightened to permanently set the adjustable length (see Figure ISW-6.1.)



OSW-6.1


WALL MOUNT GUARDRAIL INSTRUCTION MANUAL



OSW-7

Install uprights using the fixed length horizontal rails as a guide to set the next post. Unfasten one end of the adjustable corner from the previous step and reattach both the corner and the fixed length rail. Attach the opposite end of the fixed length rail to the next upright to be installed; plumb the upright and attach upright as shown in previous steps.

*****Note—Always install railing with weep holes facing down.**



OSW-8

Attach Rail Corner Supports, Adjustable Corners and rails to uprights with using 3/8-16 x 1-1/2" Flange Head Screws.

*****NOTE—YOU ARE REPLACING THE 1" FASTENERS THAT CAME PRE-INSTALLED IN THE POSTS FOR THE CORNERS ONLY IN THIS STEP.)**

3/8-16 x 1-1/2" Flange Head Screw

3/8-16 x 1" Flange Head Screw

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL


ENGLISH

OSW-9

Complete guardrail section by securing the appropriate size adjustable rail, equidistant from each corner or as indicated on your project specific guardrail layout drawing, with 3/8-16 x 1" Flange Head Screws.

Set screws on adjustable rails may be left out set loose to act as an expansion joint.

***Note—Always install railing with weep holes facing down.




ISW-15

Secure all flange head screws for railing to the recommended torque of seventy (70) inch pounds for clean and dry bolts.

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL


OPTIONAL INTEGRATED LIGHTNING PROTECTION

STEP 1— Place Aluminum Upright Cap (A867) over Upright, matching A867 slot to Upright Insert Rivet Nut.




STEP 2— Attach Aluminum Rail Connector (A861) to aluminum railing tube. Tighten set screw to lock Rail Connector in place.

TIP— Cut tube as needed to match adjustable railing lengths.



STEP 3— Attach Aluminum Corner Assemblies and Aluminum Rail Assemblies thru slots in Upright Caps and to Uprights using 3/8"-16 x 1 1/2" Screws.



STEP 4— Ground Integrated Lightning Protection guardrail assembly from Aluminum Upright Cap (A867) terminals, as required per UL Standards, every 100 linear feet or less.

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

APPLICATIONS

The Wall Mount Guardrail is to be used as a guardrail system for roofs as described by OSHA Standard 1910.29 and 2012 International Building Code.

The Wall Mount Guardrail should be used as a part of a complete fall protection system plan.

USE AND LIMITATIONS

The Wall Mount Guardrail can be used with many different types of roofing, decking, edge, or parapet conditions provided a competent professional has determined that the roof, deck, edge and/or structure is capable of withstanding the load requirements of the specified system.

The Wall Mount Guardrail is intended for use as a guardrail system as defined by OSHA and meets and exceeds the requirements set for by OSHA Standard 1910.29 and 2012 International Building Codes when properly installed.

NO component of the Wall Mount Guardrail has been designed as an '*Anchorage*' point and should NEVER be used as such.

Hoisting and snap hook devices should never be attached to any component of the Wall Mount Guardrail.

Leading Edge Safety guardrail systems are designed to prevent employees from falling. While companies can provide safety training and safety systems, such as guardrail systems, every employee is responsible for their own safety and should act in a safe and responsible manner while on any roof.

In addition to fall protection such as guardrails, Leading Edge Safety recommends implementing a Fall Protection Plan for every roof and safety training in accordance with OSHA Standards.

Improper use of Leading Edge Safety guardrail systems can result in serious injury or death.

AFTER A FALL OR IMPACT

All components that have been subjected to fall or impact forces must be removed from service immediately for inspection and replacement if necessary by competent personnel.

BEFORE EACH USE

Guardrail systems should be inspected prior to each use for wear, damage or deterioration, and defective components shall be removed from service.

INSPECTION STEPS

STEP 1: Check for loose, bent or damaged parts.

STEP 2: Check fasteners/connectors for distortion, cracks, or other damage and proper torque.

STEP 3: All labels must be present and fully legible.

STEP 4: Check for corrosion on Parts.

MAINTENANCE AND CARE:

- A. Inspect all guardrail components before each use.
- B. Annually and before each use, inspect all fasteners for proper torque.
- C. Maintain paint finish to prevent corrosion.
- D. Replace damaged or deteriorated parts immediately.

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL

APPENDIX A - Assembly, Inspection and Maintenance Log

*** PLEASE COPY THIS EXAMPLE LOG AND REVIEW BEFORE EACH USE AND DURING REGULARLY SCHEDULED MAINTENANCE ***

DATE IN-SERVICE:	
ASSEMBLED BY: (PRINT NAME)	
SIGNATURE:	
COMPANY:	
INTENDED USE OR OTHER RELEVANT DETAILS:	

DATE:	
INSPECTED BY:	
NOTE CONDITION OF:	
UPRIGHTS:	
UPRIGHT RAIL CONNECTORS:	
RAILS:	
OTHER MISC PARTS:	
NOTES:	

DATE:	
INSPECTED BY:	
NOTE CONDITION OF:	
UPRIGHTS:	
UPRIGHT RAIL CONNECTORS:	
RAILS:	
OTHER MISC PARTS:	
NOTES:	

WALL MOUNT GUARDRAIL INSTRUCTION MANUAL



1345 Taney Street
North Kansas City, Missouri 64116
888.990.2990
www.leadingedgesafety.net



Copyright © 2019 by Leading Edge Safety, LLC

PRINTED IN THE UNITED STATES OF AMERICA

FMB-2019v1.0