

## GL-6000L CAL MODE 60 lb(500 lb) scale

1. Turn on the power while pressing the CALIBRATION BOLT(See the following photos) located next to the AC adapter with a sharp object to show "CAL" on the display.
2. Press "UNIT" key and show "C-Zero" on the display.
3. Press "TARE" x 2 times and show "20(120)" on the display.
4. Load 20 lb(120 lb) on the platter and press "TARE". It will show "40(200)" on the display.
5. Load 40 lb(200 lb) on the platter and press "TARE". It will show "60(500)" on the display.
6. Load 60 lb(500 lb) on the platter and press "TARE". It will show "PASS" on the display.
7. Unload all weights.

Email : [GoUSApops@gmail.com](mailto:GoUSApops@gmail.com) , C Phone : 201.679.7793 JOE KIM.

- The END -



Press down to enter CAL MODE.

CAL Switch, 1.5 inches deep