



RV-LD200B
User Guide for EcozyHome App

ENGLISH



Thank you for choosing our product.

If you have any questions, concerns, or need any help, please contact us at support@ecozy.com or call us via hotline

(443) 991-8777 (UTC 14:00-22:00, Monday to Friday)



Important Tip

Please directly contact us or visit www.ecozy.com for more detailed instructions.

App Downloading and Installation

Option 1:

Search for EcozyHome from App Store™/Google Play™, then download and install it on your mobile device.

Note:

Google Play™ is a trademark of Google Inc., and App Store™ is a trademark of Apple Inc.

Option 2:

Scan the QR codes below to download and install.



For iOS



For Android



App Registration and Login

Launch the App, register an account with your mobile phone number or a valid email address at your first use, then log in.

• Note:

For a successful connection, please allow the App to use your WLAN & Cellular Data when running it.

WiFi Connection

IMPORTANT:

For Your Robot Vacuum:

Make sure the robot vacuum has enough power and has been powered on.

For WiFi Network:

- ① Before connecting, please turn on location service/GPS on your phone and turn on all the permissions required by the App.
- 2 Make sure your mobile device is connected to a 2.4GHz WiFi. If your router is a dual-band router, please select the 2.4GHz network.
- ③ Make sure you've entered the correct WiFi name and password when connecting.
- 4 Avoid using an emoji or special characters or symbols in your WiFi name and password.
- (5) It's not recommended to use a VPN(Virtual Private Network) or Proxy Server.
- 6 Make sure the robot vacuum and your mobile device are close to the router when connecting.



7 WiFi Status Indicator



Flash Orange Slowly	Ready for Connection
Solid White	WiFi Connected







- 1 Tap Add Device.
- ② Select RV-LD200A(B).
- ③ Simultaneously press and hold ⑩ and ⑩ on the robot vacuum for 3s until you hear a voice prompt and the WiFi Status Indicator 🖁 is flashing orange slowly.









- 4 Select the same router's WiFi and enter the correct password.
- (5) Tap Go to Settings.
- 6 Tap WLAN.
- 7 Connect to the AP hotspot of the robot vacuum.
- 8 Go back to the EcozyHome App and tap Next.
- Connecting.
- 10 Connected.











Control the Robot Vacuum with Amazon Alexa

- Important:
- (1) Make sure the robot vacuum has enough power and has been powered on.
- 2 You have connected the robot vacuum to the **EcozyHome** App.
- (3) Make sure you've installed the **Alexa** App on your mobile device.
- (4) Make sure the WiFi connection is stable.

Step 1:

Log in to the Alexa App with your Amazon account, tap = and then select Skills & Games.

Step 2:

Search and select EcozyHome, then enable it by tapping ENABLE TO USE.

Step 3:

Enter the email address and password for logging in to the EcozyHome App, then tap Authorize to continue.

Step 4:

Tap CLOSE to close the page, then tap DISCOVER DEVICES to discover the robot vacuum which has been connected in the EcozyHome App.

Step 5:

After the robot vacuum is discovered, please tap CHOOSE DEVICE to set up your device.

Step 6:

Tap \bigcirc and allow the Alexa App to access the microphone of your mobile device.



Then you can say the following voice commands to your mobile device, the robot vacuum will respond accordingly.

"Alexa, turn on the robot(or the name of your robot vacuum if you have changed the device name)."

"Alexa, turn off the robot."

• Note:

If you have an Echo device at hand, please follow the steps below to make it available for voice commands.

Step 1:

Log in to your **Echo** device with the same Amazon account for logging into the **Alexa** App.

Step 2:

Tap **Devices** at the bottom, then tap **Echo** & **Alexa** to show your Echo device. Then you can speak the voice commands mentioned above to your **Echo** device, and the robot vacuum will respond accordingly as well.

Control the Robot Vacuum with Google Assistant

- Important:
- (1) Make sure the robot vacuum has enough power and has been powered on.
- ② You have connected the robot vacuum to the **EcozyHome** App.
- ③ Make sure you've installed the Google Home App on your mobile device.
- 4 Make sure the WiFi connection is stable.



Step 1:

Launch the Google Home App, then follow the in-app instructions to set up your Google account.

Step 2:

Tap Settings on the main page, then scroll down to the bottom to tap Works with Google.

Step 3:

Tap Q on the upper right corner, then search and select **EcozyHome**.

Step 4:

Enter the email address and password for logging in to the **EcozyHome** App.

Step 5:

Tap Authorize, it will show you EcozyHome is linked.

Step 6:

Follow the instructions to set up the device to finish the settings.

Step 7:

Tap **J** and allow **Google Home** to access the microphone on your mobile device.

Then you can say the following voice commands to your mobile device, and the robot vacuum will respond accordingly.

"OK Google, turn on the robot(or the name of your robot vacuum if you have changed the device name)."

"OK Google, turn off the robot."

"OK Google, where is the robot."



Note:

If you have a Google Home Speaker at hand, please follow the steps below to make it available for voice commands.

Step 1:

Plug your Google Home Speaker into the socket.

Step 2:

Tap + on the upper left corner of the main page, then select **Set up device**.

Step 3:

Tap New device, then tap Next to look for devices.

Step 4:

Follow the instructions of the Google Home App to connect your Google Home Speaker to WiFi.

Then you can speak the voice commands mentioned above to the speaker, and the robot vacuum will respond accordingly as well.

Troubleshooting Guide

- Q1. How many schedules can I set by the App?
 - * You can set 7 schedules via the **EcozyHome** App by tapping **Settings** > **Schedule**. The default cleaning time is 9:00, but you can tap it to change as needed.
- Q2. Why does the App show that the robot vacuum is offline?
 - * Make sure you have powered on the robot vacuum.
 - * Check the network connection of your mobile device.



Q3. Why cannot the robot vacuum connect to WiFi?

- * Make sure you've entered the right password.
- * Keep the robot vacuum, mobile device and your router being as close as possible.
- * Make sure you've selected a 2.4GHz WiFi.

O4. Why cannot I control the robot vacuum with Alexa?

- * Please check the network connection of your mobile device.
- * Make sure you've connected the the robot vacuum to the **EcozyHome** App.
- * Make sure your robot vacuum has been discovered in the Alexa App.
- * Make sure you start the voice command with "Alexa,"

Q5. Why cannot I control the robot vacuum with Google Assistant?

- * Please check the network connection of your mobile device.
- * Make sure you've connected the the robot vacuum to the **EcozyHome** App.
- * Make sure your robot vacuum has been discovered in the Google Home App.
- * Make sure you start the voice command with "OK Google, ..." or "Hey Google, ...".

Q6. How many robot vacuums can I connect to the same account?

* There is no limitation on the number of robot vacuums.

Q7. How many accounts can I share the robot vacuum with?

* There is no limitation on the number of accounts.