



Marine Grade 500 Watt 12/24 Volt Wind Generator

User Manual



⚠ WARNING: Read carefully and understand all ASSEMBLY AND OPERATION INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Item #70501

SAVE THESE INSTRUCTIONS

1. Introduction:

- ★ This manual contains installation and safety information for the Nature Power 500W Wind Generator. The information in this manual is believed to be accurate and reliable; however, The Distributor assumes no responsibility for inaccuracies or omissions. Nature Power reserves the right to make changes to this product specification, or its manual, without prior notice. Therefore, check the Nature Power Website for updates as necessary.
- ★ The Nature Power Wind Generator, like other sources of electrical power, must be installed following the guidelines established by state and local regulations. Consult a local electrician or local planning and zoning offices for detailed information about your area.
- ★ For your ease write the serial number of your wind generator on the front of this manual. Store your manual and receipt together. you will need this information in the event of a warranty claim

CONGRATULATIONS!



You will find your new wind generator easy to install. However, it is important that you read this manual thoroughly prior to installation to assure proper performance and safety. If you have any questions after reading the manual, please contact the Distributor.

TABLE OF CONTENTS

| | |
|---|-----------|
| 1. PRECAUTIONS | 3 |
| 1.1 MECHANICAL HAZARDS | 3 |
| 1.2 ELECTRICAL HAZARDS | 3 |
| 1.3 INSTALLATION PRECAUTIONS | 3 |
| 1.4 OPERATION PRECAUTIONS | 3 |
| 2. PACKAGE CONTENTS | 4 |
| 3.WIRING AND INSTALLATION PROCEDURES | 5 |
| 3.1 SYSTEM WIRING DIAGRAMS | 5 |
| 4.LOCATION SELECTION | 6 |
| 5. TOWER | 7 |
| 6.1 SINGLE WIND GENERATOR | 8 |
| 6.2 CONTROLLER WIRING | 9 |
| 6.3 INSTALLATION OPERATION | 10 |
| 6.4 ATTACHING TO POLE | 10 |
| 6.5 STEP-BY-STEP INSTRUCTION | 11 |
| 7. ELEVATION | 15 |
| 8. SPECIFICATIONS | 15 |
| 9. WARRANTY | 16 |

1. PRECAUTIONS

The Nature Power Wind Generator has been designed with your safety in mind. However, there are inherent dangers involved with any electrical and/or mechanical equipment. **Safety must be your primary concern as you plan the location, installation and operation of the turbine. At all times be aware of electrical, mechanical and rotor blade hazards.**

| |
|--|
|  WARNING This product can expose you to chemicals, including Di (2-ethylhexyl) phthalate (DEHP) which is known to the State of California to cause cancer, birth defects or other reproductive harm. For more information, go to www.p65warnings.ca.gov |
|  ADVERTENCIA Este producto puede exponerlo a productos químicos, incluidos Di (2-etilhexil) ftalato (DEHP) que el estado de California sabe que causa cáncer, defectos de nacimiento u otros daños reproductivos. Para obtener más información, vaya a www.p65warnings.ca.gov |

1.1 MECHANICAL HAZARD

Rotating blades present the most serious hazard. The rotor blades are made of very strong thermoplastic. At the tip, the blades may be moving at velocities over 275 miles per hour (440 km/hr). At this speed, the tip of a blade is nearly invisible and can cause serious injury. Under no circumstances should you install the generator where a person could come in contact with moving rotor blades. **DO NOT INSTALL THE GENERATOR WHERE ANYONE CAN APPROACH THE PATH OF THE BLADES.**

1.2 ELECTRICAL HAZARDS

*Observe all manufacturers' safety procedures when working around batteries and other electrical equipment.

The wind generator is equipped with sophisticated electronics designed to provide protection from high surge electrical dangers. The internal electronics of the wind generator prevents open circuit voltage from rising above 20 volts for 12-volt systems. please noted that the inherent personal dangers from electrical current still exist, therefore caution should always be used when connecting this and other electrical devices.

Heat in wiring systems is often a result of too much current flowing through an undersized wire or through a bad connection.

Batteries can deliver a dangerous amount of current. If a short occurs in the wiring from the batteries, a fire can result. In order to avoid this threat, a properly sized fuse or circuit breaker is required in the lines connecting to the battery.

1.3 INSTALLATION PRECAUTIONS:

Installation procedures should be performed at ground level.

Make sure that all batteries are disconnected throughout the installation process.

Never install the wind generator upside down. Choose a day when the wind is calm.

Connect the 2 wires coming from the wind generator to the control switch panel.

Then, connect control panel output wires to the battery bank.

There are two wires(black = Negative (-) Red = positive (+)), ensure that polarity maintained.

1.4 OPERATION PRECAUTIONS

Never approach the generator during operation

Check support structures, blades, and electrical systems regularly. The rotor blades are very strong; however, if they come in contact with a solid object, they can break. When performing periodic inspections, or if you must approach the path of the blades, disconnect the power leads from the battery and tie the wind generator output leads together to stop/slow the blades from roating.

Note: There is a short break-in period with new wind generator.

the bearing in both the generator yaw and the generator rotor will require approximately 60-100 hours of operation in normal wind speeds(approximately 18-20 mph, 8-9m/s) before they are running at peak efficiency. During this break in period, the generator operation might appear sluggish.

2. PACKAGE CONTENTS

USE CHART BELOW TO COMPARE PARTS.

ROTOR BLADES ARE SHARP. PLEASE HANDLE WITH CARE.

- | | |
|-------------------------------------|-------------------------------|
| 1. Nose Cone | 10. Rotor |
| 2. Screw Socket Head | 11. O-Ring |
| 3. Nut-Jam- SAE 5/8-18 | 12. Body Assembly |
| 4. Blade | 13. Snap Ring- 32 MM External |
| 5. HUB | 14. Yaw Shaft Assembly |
| 6. Nut-Nylock- SAE 6-32 | 15. Internal MPPT Controller |
| 7. Screw Socket head 10-24 x 1-1/2" | 16. Power Meter box |
| 8. Face Assembly | |
| 9. Stator | |




Figure 1

3. WIRING AND INSTALLATION PROCEDURES

Your wind generator is shipped partially assembled. Please completely read all procedures before beginning installation. NOTE: Do not install the blade/hub until the generator is mounted on the tower

Necessary Tools:

- 4mm hex key wrench (included)
- 5mm hex key wrench (included)
- 8mm hex key wrench (included)

Power cables (not included):

#12 AWG (American Wire Gage) copper stranded.

Batteries: 12 or 24V batteries (not included)

Steel Pipe: 1 1/2", Schedule 40 steel pipe (Actual OD 1.875 inches, 48mm) (not included)

Torque wrench with 4mm, 5mm, and 8mm hex drives (not included)

Soldering iron or propane torch (not included)

Rosin core solder (not included)

Electrical tape or 1/4" (6-7mm) heat shrink (not included)

Wire strippers (not included)

Wire crimpers (not included)


3.1 SYSTEM WIRING DIAGRAMS

Precheck

NOTE: Do not connect to the battery.
Spin rotor shaft slowly with your fingers while at the same time connecting and disconnecting the DC OUTPUT's positive and negative wires. With the wires connected, the rotor shaft should become more difficult to rotate. With the wires disconnected, it should spin freely.


Every time connect the DC OUTPUT's wires (RED= Positive, BLACK = Negative) directly to the set of posts of the power meter box, the box LED will light up to indicate that the power meter box is running properly.

CAUTION: DO NOT CONNECT WIND GENERATOR POSITIVE TO BATTERY NEGATIVE AND POWER METER BOX NEGATIVE TO BATTERY POSITIVE FOR EVEN A SECOND, OR ELSE WILL DAMAGE THE WIND GENERATOR'S CONTROLLER AND VOID YOUR WARRANTY.



4. LOCATION SELECTION

To ensure good performance from the wind generator, it is important that care is taken in the site of the machine. Buildings, trees and rocky outcrops etc. disrupt the smooth flow of wind creating a "Wind Shear" with the wind velocity nearer the ground being slower than that higher up. Turbulence is also created by these obstructions. Turbulence is detrimental as the swirling air causes the wind generator to yaw continually thus stressing the mechanical parts and greatly increasing wear and tear.



Turbulent airflow created by obstructions (Ad. P. Gipe, 93)

Therefore, as a general rule the wind generator should be mounted twice as high as any such obstructions. The power obtained from the wind is proportional the cube of the wind speed, and the wind speed increases with height from the ground. A 26% increase in wind speed from a higher tower will yield a 100% increase in power from the wind generator. A little more money spent on a higher tower will harvest the same power as 2 machines! Preference should be given to the prevailing wind direction, but it should be noted that tall features behind the wind generator can also slow down the wind flow through the wind generator.

The wind generator should be mounted on a tower a minimum of 25' (8 meters) above any surrounding objects within a 500' (150m) radius. If this is not possible, then place it as high as you can. If this is a roof top installation, it is important there are no objects around the structure that may block the wind.

5. TOWER

Great care should be taken in the selection and preparation of the wind generator's tower, as this is the most difficult and crucial aspect of the entire installation. If you select a tower from another source or build your own, you are responsible for assuring the tower is suitable. As with all towers, you must first evaluate your site to determine the appropriate tower height, available space and reasonable cost.

The following list considerations must be consulted:

- Number of Wind Generators
- Budget
- Type: guyed, freestanding or rooftop
- Site: hills, trees, buildings
- Ease of use

Note: Guyed And Freestanding Towers Are The Most Common Way To Install A Wind Generator. These Towers Are Available In All Shapes, Sizes And Costs.

Caution: Do Not Install The Wind Generator Where The Path Of The Blades Can Be Reached During Normal Operation! Never Approach The Wind Generator During Operation!

Usually, the higher tower is erected, the greater the output, but also the greater cost and effort of the installation. If purchasing a taller tower will provide significantly more power it might offset the additional cost and effort. It's very important to mount the wind generator in the best winds while being balanced by the cost and effort of the installation.

This wind generator is designed to use steel pipe 1.875 inch (48mm) outside diameter, equivalent to 1 ½ inch SCH 40 pipe, which can be used in some tower applications. If larger pipe is used for your tower, make sure that the 1.875 inch pipe is at least 22 inch long or will damage the blades. **Refer to SPHERE OF OPERATION (Minimum Safe Pole Length Above Obstructions).**


CAUTION: SAFETY, ENGINEERING AND LOCAL CODES MUST BE ADDRESSED BEFORE ATTEMPTING ANY INSTALLATION.

NOTE: The yaw wires can support loads up to a total of 155 lbs. (70kg). If the wire weight is higher, you must install a strain relief to minimize the stress put on the hanging wires.

NOTE: Towers must be capable of withstanding 155 lb. (70kg) of load in the horizontal direction at the Wind Generator.

6.1. Single wind generator


See Diagram below for further wiring information




The controller indicator lamp

| Mode | Lamp | Status | Cause | Operation |
|-------------|--|--------------------------------------|---|--|
| Normal Mode | Solid Green | Charging wind speed 3.13m/s to 9m/s | Rotor rotating at 0-1000rpm | Normally |
| Normal mode | Flashing green | Charging wind speed to 9m/s to 14m/s | Rotor rotating at 1000rpm to 1400rpm | Normally |
| Normal mode | Flashing red | Rotor rotating at low spin or stop | Battery fully charged (voltage exceeds 14.2V) or 24V system 28.4V | System returns to normal mode if the battery voltage drops below 13.1V, 24V system 26.2V |
| Stop mode | Solid red | Rotor rotating at low spin or stop | The output is reach peak power. | It will stop 30mins and restart again |
| Stop mode | Flashing red and green light alternatively | Rotor rotating at low spin or stop | The alternator temperature exceeded 90°C or temperature sensor damage | System returns to normal mode if the control temperature drops below 60°C |

6.2 CONTROLLER WIRING



Use bolt driver to remove the 4pcs screws on the backside of the meter box and open it, then install the cables from the wind turbine and battery to the power meter box board as the following photo:



⚠ Important

Wind"+" is Wind turbine"+" ; B"+" is battery"+"
Wind"-" is Wind turbine"-" ; B"-" is battery"-"

Assume to finish all the other connection first and the connection to the battery is the final step.

⚠ WARNING

Do not make a wrong positive and negative connections to the power meter box or the battery bank. The wrong positive and negative connection or positive and negative in short circuit condition will damage the power meter box or wind turbine controller, the warranty will not cover.

Note:

When the green light is on or flashing, it is normal charging.
Please connect with power meter box in any time, without power meter box positive and negative direct short circuit easily damaged internal controller in wind condition, the warranty will not covered. The power meter box main function is display and break the wind turbine, the MPPT controller in the wind turbine body.

For more information about some very economical tower kits for the wind generator, please refer or purchase them from your dealer or distributor.

6.3 INSTALLATION OPERATION

Choose a calm day and have someone available to help during the installation process.

NOTE: THE BLADE EDGES ARE SHARP. PLEASE HANDLE IT CAREFULLY.

NOTE: DO NOT install the blade assembly until the body is mounted on the tower.

CAUTION: ALL BATTERIES MUST DISCONNECTED THROUGHOUT THE INSTALLATION PROCESS!

CAUTION: DO NOT INSTALL THE WIND GENERATOR WHERE THE PATH OF THE BLADES CAN BE REACHED DURING NORMAL OPERATION! NEVER APPROACH THE WIND GENERATOR DURING OPERATION!

USE COMMON SENSE AND PLEASE BE CAREFUL!

6.4 Attaching to pole

While attaching the wind generator to the tower, be careful not to pinch the yaw wires. Slide the yaw all the way down over the end of pole. After the yaw is seated on the pole, move it back up a 1/8th inch (2mm) to prevent the bottom of the yaw from contacting the top of the pole. This way the only contact between the tower and yaw is through the rubber pad, which will reduce noise transmission. Tighten all mounting fasteners to 3-5 foot pounds. (4. 1-6.8 N.m.). Make sure that your tower allows for proper clearance of the blades. A minimum of 2 inches (20mm) clearance must be given between the blade tips and any obstructions.





Figure 3 Proper Blade-to-Tower Clearances

6.5 Step by step instructions


The following step by step installation procedures provides you with an outline of the wind generator installation process. This consolidated reference should only be used as an outline during installation. Refer to the appropriate sections for further details. Installation instructions assume a basic familiarity and comfort in working with DC voltage electrical wiring and batteries. If you are not knowledgeable on, or comfortable, working with DC voltage and electrical wiring please consult with a trained electrician or wind generator technician.

Warranty does not cover any damage due to improper installation, or faulty tower construction.

- 1).Ensure the voltage systems of the wind generator and the battery bank are the same. Prepare the appropriate wires.
- 2).Run the wire through the pipe and drag the wires near to the batteries (Do not connect to the battery), strip the insulation back from each set of wires.




- 3).Connect the wind generator to the wires and insulate the connections using either heat shrink tubing or a quality electrical tape.




4).Once the yaw shaft is on the tower, firmly tighten the yaw clamp screws with the 4mm hex key to 3-5 foot pounds(4.0-6.5Nm). Be sure that it is securely attached to the mounts.


Slide the yaw shaft all the way down over the end of pole being careful not to pinch the yaw wires. Be sure to leave enough slack in the wires so that if necessary, the wind generator can be removed.




5) Prepare a grounding cable from yaw shaft screw, secure the grounding cable against the pipe with insulation tape for grounding the wind generator by the pipe.



6).Place one of the blades on the hub socket and insert one of the M6-15 socket head cap screws. Place a plastic disk on the end of the screw, then place self-locking nut (M6) and tighten it with the 5mm hex key to 8-10 foot lbs. (10.5-13.5 N.m). Repeat this procedure on all three blades.




7). Remove the M16 nut from the rotor shaft. Slide the blades assembly onto the rotor shaft and place the nut on the shaft. DO NOT press the rotor shaft into the body.




Caution: over-torque will damage the blades and wind generator.

8). Insert the 8mm hex key into the rotor shaft and thread the nut on by spinning the blades assembly. Holding the blades assembly and tightening the M16 nut lightly with the 8mm hex key. Finally, spin the blades slowly to be sure they turn freely.



CAUTION: DO NOT SCREW M16 NUT TOO TIGHTLY, OTHERWISE THE FACE BEARING WILL BE STUCK AND THE BLADES ROTATE DIFFICULTLY!

9) Place the nose cone over the center line of the blades assembly and snap the nose cone into place. Carefully check it is secure by firmly pulling on and be sure all three edges are catch. Don't worry if the nose cone missing, it will not affect the performance of the wind generator.



- 10) Before attaching the wiring to the battery, make sure that:
- All wires connect to the power meter box and battery ok.
 - The stop switch is in the "Stop" position.

Note: Grounding

For long-term operation and protecting the electronics, properly grounding is very important. Grounding procedures must be followed along with any local electrical codes.

The negative wire of your system should be connected to a ground. This is usually done by connecting a wire from the negative battery terminal to a nearby ground rod. Wires with the same ratings as the positive and negative wires must connect all system grounds.

A ground electrode can be made for systems without an existing system ground from an 8 ft. (2.4 m) section of 3/4" (19 mm) galvanized pipe or conduit, or an 8 ft. (2.4 m) section of 5/8" (16 mm) iron or steel rod. This ground electrode must be buried completely beneath the soil, at no more than 45 degrees from vertical, or horizontally at least 2 1/2 ft. (75 cm) beneath the surface. It is recommended that the ground electrode be installed as close as possible to the batteries for maximum lightning protection. The base of the tower is also a good location for an appropriate surge arrestor.

Caution: Improper Grounding Will Damage Your Wind Generator And Void Your Warranty.

11) Carefully raise the tower and secure base and/or guy cables.

Caution: Ensure That The Tower Is Vertical So That The Wind Generator Can Yaw (turn Into The Wind) Properly.

CONGRATULATIONS! You have completed the installation process now.

7 ELEVATION

An important fact to keep in mind is elevation. The higher a wind generator is from sea level, the lower the air density. Air density is directly proportional to the output of your wind generator. Here are some general numbers to keep in mind when determine the maximum output that can be expected from a wind generator.

| FEET | METER | OUTPUT POWER |
|----------------|--------------|--------------|
| 1-500ft | 0-150m | 100% |
| 500-1,000ft | 150-300m | 97% |
| 1,000-2,000ft | 300-600m | 94% |
| 2,000-3,000ft | 600-900m | 91% |
| 3,000-4,000ft | 900-1,200m | 88% |
| 4,000-5,000ft | 1,200-1,500m | 85% |
| 5,000-6,000ft | 1,500-1,800m | 82% |
| 6,000-7,000ft | 1,800-2,100m | 79% |
| 7,000-8,000ft | 2,100-2,400m | 76% |
| 8,000-9,000ft | 2,400-2,700m | 73% |
| 9,000-10,000ft | 2,700-3,000m | 70% |

8. SPECIFICATIONS

| | |
|---------------------|---|
| MODEL | Nature Power 70501 Marine Grade 500 Watt Wind Generator |
| ROTOR DIAMETER | 47.2 inch |
| WEIGHT | 16 lbs |
| START UP WIND SPEED | 7.0 mph / 3.13m/s |
| VOLTAGE | DC12V and DC24V dual voltages |
| MAXIMUM WIND SPEED | 110 mph |
| RATED POWER | 500W at 31 mph / 14m/s wind speed |
| CONTROLLER | Smart internal MPPT controller |
| BLADES | Carbon fiber composite |
| BODY MATERIAL | Cast aluminum with marine powder coating |
| POLE DIMENSIONS | 1.5 inch in schedule 40 pipe |

9. Warranty policy proof of purchase is requires(Receipts)

Nature Power are warranted for a 2 year period, Against defective parts or manufactures workmanship.

What is NOT Covered

- Damage from lighting.
- Damage due to extreme winds (110MPH +).
- Damage from improper installation (Including poor tower design and inverted hanging).
- Damage from improper wiring.
- Damage to blades from debris.

Any and All modifications to the unit, not stated in this manual

No one has the authority to add to or vary this limited warranty, or to create any other obligations in connection to Nature Power and its products. Any implied warranty is limited to the duration that is stated on this manual. Nature Power will not be liable for damages that any person or property might suffer as a result to the breach and or implied warranty. This warranty applies to the original purchaser.

Customer's Responsibilities:

- Any modifications to the wind generator will void the warranty and compromise the safety of this machine.
- This wind generator must be installed and operated in accordance to the owner's manual and local codes.
- If necessary, all cost of shipping/handling to Nature Power will be the responsibility of the customer.



Please contact Nature Power Products to acquire more information:

1-800-588-0590

info@naturepowerproducts.com

www.naturepowerproducts.com

Made in China