

User manual of red rabbit wifi module





Copyright notice

This manual is for the use of the purchaser only and shall not be used in any manner, electronic, mechanical, or otherwise, including photocopying and recording, reproduction, or dissemination of any part of this manual for any purpose, without the written authorization of matrix technology.

Technical support

If you are interested in 3D printed motherboard products, development boards and related supporting modules, and would like to get more technical information and technical support, please contact us:

Website: <u>www.tronxy.com</u>

Email: support@tronxy.com

If you are interested in technical information at home and abroad, please pay attention to our website <u>www.tronxy.com</u>, we will serve you wholeheartedly.



1. Introduction

The main board of "red rabbit" is equipped with 32-bit high-speed ARM chip and adopts self-developed firmware, which has the advantages of open source hardware and has been optimized in many places. Firmware USES SD file configuration, easy to update.

The main board of "red rabbit" supports ESP8266 wifi module. At present, file transfer can be realized through mobile APP and PC control software, printer can be controlled remotely, and it can also be connected to the tablet.

1.1 dimensional parameters





1.2 wiring instructions





1.3 Update UI interface







2. Steps to use ChiTu V2.0 APP

1 Start the WIFI

Click WIFI button on the touch screen interface and tick it to start WIFI, as shown below.



2 Connection ChiTu V2.0

1. Turn on the WIFI of the mobile phone, scan to the hotspot at the beginning of the 3d printer and connect.Open ChiTu V2.0 and click "scan device" to see the machine hotspot, which defaults to "0.0.0.0".As shown in the figure below

178B/s 📚 🦼 69% 📻 11:39		
< WLAN		
开启WLAN		
3dprinter-313049 已连接		ç ()
HUAWEI 已保存		<u> (</u>)
1985sk8		<u>s</u> (j
Xiaomi_6D00		<u>ş</u> (j
DIRECT-81-HP M281	LaserJet	<u>s</u> ()
ChinaNet-RSZk		<u> </u>
ChinaNet-vZ6Z		7
360免费WiFi-7R		<u>s</u> ()
	(2) 高級	

www.TRONXY.com



2. Click the "connect" button, and the green light will be turned on at the bottom left corner after the connection is successful, as shown in the figure below.

0.00B/s 🤶 .,⊯ 69% 🔲 11:40					
🔊 3D Printer	APP	:			
HAND	FILE	SYSTEM			
Scan ShutOf	f 中/En				
Connect disconnect 192168.4.1/m					
Hatspat					
Password:					
Sot					
501	6 1				
Remote hotspot: Re	etresh				
Password:					
Set					

3. If you need to connect the phone to the router again, you can set the login hotspot (take CBD as an example), as shown in the figure below.

		244B/s 😤 🔬 68% 🛄					
_	746B/s 🕱 🦼 68% 🔲 11:51	A	3D Printe	r APP	:		
3D P	TRa						
	工程的 Xiaomi 6D00	ł	HAND	FILE	SYSTEM		
HAND	ChinaNet-vZ6Z		_	_			
	1985sk8		ShutC)ff 中/En			
Scan S	k ChinaNlot-7cYm						
HUA	HUAWEI	Con	inect di	sconnect	192.168.4.1/		
Connect DIR	DIRECT-81-HP M281 Lasorlot			500111001			
	Diffect of the mizor easement	Hotspo	ot:				
lotspot:	1985sk8		L				
Password: 3dp 198	3dprinter-313049	Passwo	ord:				
	1985sk8						
Set Sz	SZ/3SS 260合串W/iEi=7D	Set					
	300免费WIFF7A		-				
Remote hoten	ot: Befresh HUAWEI	Remote	a hotspot: F	Refresh	HUAWEI		
тепноте потар			-				
Password:		Passwo	ord:				
Set		Set					
			-				
		-					

www.TRONXY.com

EMail: support@tronxy.com



3.FAQ(Frequently asked questions)

1. If ChiTu V2.0 is needed for the red rabbit motherboard purchased before November 1, 2015, the firmware of the motherboard and WIFI firmware need to be upgraded, and the WIFI module needs to short two pins, as shown in the figure below. The red rabbit motherboard purchased after November 1, 2015 does not need any processing and can be used directly.



2. Can I add WIFI module to the motherboard I bought before? Answer: ChiTu V3.6 starts, all with WIFI expansion slots.Please confirm whether the previous version has WIFI extension interface by yourself, as shown in the figure below.

