


morphyrichards

2 slice sandwich press *Perfetto*



Please read and keep these instructions



getting the best from
your new sandwich press...



www.morphyrichards.co.uk
www.morphyrichardsindia.com

Important safety instruction:

The use of electrical appliance requires the following common sense safety rules.

Primarily there is danger of injury or death and secondly the danger of damage to the appliance. These are indicated in the text by the following two conventions:

WARNING: danger to the person!

IMPORTANT: Damage to the appliance ! In addition we offer the following safety advice.

Location:

- Remove all the packaging and retain for future reference.
- Ensure the sandwich grill is used on a firm, flat surface.
- Do not use the sandwich grill outdoors or in a bathroom.
- Do not place the sandwich grill on a highly polished wooden surface as damage may occur to the surface.
- Do not place the sandwich grill on or near hot surfaces such as a hole plate or radiant rings or near a naked flame.
- Do not let the mains lead hang over the edge of the table or worktop or touch hot surfaces.

Children:

Children do not understand the dangers associated with operating electrical appliances. Never allow children to use this appliance.

Personal safety:

During cooking steam and hot air will be emitted from the food. Take extreme care when opening and closing the appliance when hot.

Other safety considerations:

- In common with most cooking appliances your sandwich grill will get hot during use, particularly the plates, after placing your food on the hot plates touch only the handle during and immediately after cooking.
- Disconnect the sandwich grill from the mains supply when cleaning or not in use.
- Do not touch hot surfaces. Always use handles or knobs.
- Do not immerse the sandwich grill itself in water and always ensure the electrical connections are kept dry.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Ring the help line number for advice on examination and repair.
- The use of attachments or tools not recommended or sold by Morphy Richards may cause fire, electric shock or injury.
- Do not use the sandwich grill for anything other than its intended purpose.
- Do not leave unattended whilst switched on.

Worth noting:


If your sandwich press does not work, check the following points.

- Is the plug in its socket and the switch in "ON" position.
- Is the plug itself or the socket faulty check this plugging in another appliance.

Electrical requirements:

Check that the voltage on the rating plate of your appliance corresponds with you house electricity supply which must be A.C. (Alternating current).

Features:




- ❶ Locking clip
- ❷ Non slip feet
- ❸ Cord storage (on underside)
- ❹ Power on neon (Red)
- ❺ Ready to cook neon (Green)
- ❻ Control Dial
- ❼ Height adjustment knob
- ❽ Handle
- ❾ Oil Drip Tray

Using your sandwich press:

Open the sandwich grill by undoing the locking clip on the side of the sandwich grill and lift the upper half of the grill with the handle.

Check that the cooking plates are clean and dust free. If you need to wipe the grill plates over do so with a damp cloth.



Your sandwich grill should be in the closed position for pre-heating.


Note: The plug removed from the mains lead, if severed, must be destroyed as a plug with bared flexible cord is hazardous if engaged into a live socket outlet.

WARNING: THIS APPLIANCE MUST BE EARTHED.

Prepare your food in advance. Follow the cooling instructions in the recipes.

- Plug the sandwich grill into the mains socket and switch on. The red light 4 will glow indicating it is switched on.
- Keep the sandwich grill closed while preheating. When the green light 5 comes on this shows the sandwich grill is ready for use. Please note that this light will cycle between on / off during use.
- Now open the grill and place the food on the hot plates. (REMEMBER THE TOASTER PLATES ARE VERY HOT).
- When using for the first time you may notice a fine smoke haze being emitted from the unit, this is due to the "bake in" of some of the components and is not harmful.

- Pull down the handle until the upper half of the grill comes in contact with the lower plate.




Note : The storage clip must be used to clamp the sandwich grill together when the food is in the press.

- Time required to preheat varies according to dial setting. Cooking times will vary depending on type of food ingredients and personal preference. See next page for details.
- Once your food is cooked, push open the lid using the handle. When removing food from the press NEVER use a metal implement such as a knife or fork. Always use a heat proof plastic or wooden spatula.
- Take extreme care as the body of the appliance and the plates become very hot.
- Remember to re-heat the sandwich grill before cooking more.

Dial knob:

Different temperatures for various food types are to be adjusted with dial knob 6.

It is divided into 4 zones with approximate temperature




ranges as following:

Zone 0~1	0~100C
Zone 1~2	80~150C
Zone 2~3	130~180C
Zone 3~4	160~240C

Different food types has been shown on the dial as recommendation. Please however note that both temperature range & food type is only for reference & cannot be regarded as a precise data.

Oil drip tray:

When grilling meats oil & grease will melt & drip into the tray via the front opening of the lower grill plate. This helps in preparation of a low-fat & healthy recipe.




Toasting open sandwiches and melts:

Your sandwich grill has an adjustable height facility that enables you to make open sandwiches to melt topping of your choice.

- Pre-heat the sandwich grill with the lid closed until the green ready to cook neon lights.
- Place your sandwich on the grill plates.
- One you have selected the desired height

turn the adjustable height knob in a clockwise directions to fix the top sandwich plate in position.



- Melting will take approximately 3-4 minutes. Melting times may vary due to the desired taste and the set height of the top sandwich plate.

Hints and tips:

Breads

A wide variety of breads can be used, whole meal, wholegrain, kibbled wheat, raising loaf, fascia, Turkish bread, celibate baguettes as well as bread rolls. Sweet breads such as raising bread and brioche.

Fillings

Fillings such as tomatoes, jam and fruit may be hot and can burn your tongue immediately.

Cleaning and Storage:

Before cleaning, switch off and unplug the mains lead.


After use, allow the plates to cool down, wipe them with a damp cloth. Never use abrasives or cream cleaners. Clean any other parts of the toaster with a damp or kitchen paper roll.

Never immerse the sandwich press in water.

After the sandwich press has cooled down, close the sandwich press and click the locking clip into position to secure the handle.

Cord Storage:

The mains lead can be wound round the storage area and stored vertically to save space.



Technical Data:

Power Supply : AC 230V, 50 Hz
Wattage : 2000W

Morphy Richards products are intended for household use only

Morphy Richards has a policy of continuous improvement in product quality and design. The Company, therefore, reserves the right to change the specification of its models at any time.

Products & parts are indicative only, the actual product may differ.

morphy richards

Morphy Richards Ltd, Mexborough,
South Yorkshire, England, S64 8AJ