

## How to measure my **Multipoint lock** to find a replacement

**Step 1:** Find the manufacturer of your multipoint lock on the Faceplate or on the Gearbox

**Step 2:** Referring to the diagram below, measure distance **A** 'Backset' (distance between front of the faceplate to the centre of the euro hole cut out – marked green) & measure distance **B** 'Centres' (distance from the centre of the spindle to the centre of the euro hole cut out– marked red)

**Step 3:** Next you need to make a note of which type of Locking Points you have and the order that they are fixed to the strip. Below are the various types of Locking Points available:



### **Step 4**

The next step is to measure the distance from each of the various locking points on the strip to the centre of the spindle. These are shown as **C**, **D**, **E** and **F** on the diagram below.

### **Step 5**

Lastly you need to measure the width of the faceplate in mm and see if your faceplate is flat (Flat Plate) or U Shaped (U-Rail).

Now you have measured all the necessary parts you are ready to search through **our selection available below** (arranged by type) to find your new multipoint lock.

