

1.8 H. P. at 1800 R. P. M.

2.5 H. P. at 2400 R. P. M.

3.2 H. P. at 3000 R. P. M.

3.6 H. P. at 3600 R. P. M.

**OPERATING INSTRUCTIONS
PARTS MANUAL
AND
SALES AND SERVICE DIRECTORY**

KE 54-3

WARRANTY

We warrant and will replace free of charge for a period of three months from date of delivery of engine to original purchaser, all parts of Kohler Engines returned, prepaid to Kohler Co., Kohler, Wisconsin, which our examination shall disclose to our satisfaction to be defective in manufacture.

This warranty shall not apply to any engine which shall have been repaired, or altered by anyone other than an authorized representative of the manufacturer, or which has been improperly installed or repaired, neglected or operated contrary to our instructions. This warranty is in lieu of all other warranties, obligations and liabilities on our part expressed or implied, and we neither assume nor authorize anyone to assume for us any other liability in connection with the sale of Kohler Engines.

OPERATING INSTRUCTIONS

Introduction

To insure satisfactory operation of your K90 engine please follow instructions as your engine has been carefully inspected and adjusted before leaving our factory.

Before Starting

Remove the plug and gauge from the oil-fill hole. Add approximately 1½ pints of clean oil (SAE 30 in summer; SAE 10 in winter) and check oil level gauge. Crankcase oil should not be over the top mark on the gauge. Replace plug.

Remove the wing nut from the oil-bath air cleaner, take off the top, then add oil until the level reaches the arrow marked on the air cleaner (See C, Fig. 2). Replace top and wing nut.

Fill the gas tank with clean, fresh regular, gum-free gasoline of good grade. Do not mix oil with the gasoline. Check the gas tank cap vent hole which must be open.

If engine is equipped with a reduction gear unit, remove both plugs (See C & O, Fig. 1) and add oil (same grade as used in crankcase) to level of hole O. Replace both plugs. The vent in the oil-fill-hole plug of the reduction gear unit must be open.

To Start

Open valve on the sediment bowl (See D, Fig. 2) by turning the handle three full turns counter-clockwise. Move the choke lever so that it points straight up (See B, Fig. 2). Wind the rope around the starter pulley. A quick pull will usually start the engine. If a second pull should be necessary, push the choke lever back to its original position (away from the cylinder block).

More or less choking may be necessary due to engine condition, temperature, grade of fuel, etc. Little or no choking will be needed when the engine is warm. Experience will show you the degree of choking to use. Immediately after engine has started, slowly move the choke lever back to its original position.

To Stop

Press the "stop" button (See J, Fig. 1). When stopping the engine for long periods, we recommend that you shut off the fuel supply at the valve on the sediment bowl (instead of using the stop button) and allow the engine to run until the carburetor is empty. The engine will run approximately one minute (under full load) after the fuel supply has been shut off. Valve must be opened again before attempting to start the engine.

Inspection and Maintenance

EACH DAY: Check the oil level in the crankcase and air cleaner. Add oil only as needed; keep the level within marks on gauge.

EVERY 25 OPERATING HOURS: Change the oil in the crankcase and air cleaner; more often under




Figure 1

Power-take-off end with gear reduction unit installed.

A Power-take-off shaft	I Breaker points cover
B Crankcase	J "Stop" button
C Gear reduction unit oil fill plug & vent	K Governor arm
D Spark plug	L Governor shaft
E Gasoline tank cap	M Governor regulator disk
F Spark plug cable	N Gear reduction unit
G Carburetor	O Gear reduction unit oil-level hole
H Muffler	

extremely dusty conditions. Also remove the oil and dirt from the engine.

EVERY 50 OPERATING HOURS: In addition to the 25 hour inspection, check the oil level in the reduction gear unit to make sure it is up to the overflow hole. Be sure the vent hole in the filler-hole plug is open. Remove grass screen and clean, also clean air passages. Check and tighten any loose parts.

EVERY 100 OPERATING HOURS: In addition to the 25 and 50 hour inspections, clean the spark plug and reset the gap to .025 inch. Shut off the gas supply at the valve on the sediment bowl. Remove, clean, and replace the bowl. Re-open the valve.

Give engine general inspection.

If Engine Fails to Start

1. Check gasoline supply. Be sure gasoline line to carburetor is open.
2. Check spark plug; clean and adjust gap to .025".

3. Check engine for spark. Turn engine over with starter pulley and hold spark plug cable about $\frac{1}{8}$ " from spark plug. Spark should jump this gap as engine is cranked.
4. If spark does not jump this gap remove cover (See I, Fig. 1) and check breaker points. They must be clean, and gap should be .020".
5. Check valves by turning engine with starter pulley. If there is no noticeable back pressure, engine lacks compression, and valves must be resealed. Spark plug must be in engine when making this test.

With the exception of the cleaning and checking outlined on these pages, we suggest that you have only an authorized Kohler dealer remedy any trouble you may experience. His training and experience will assure you of quick, reliable service at a minimum cost.

If it is necessary for you to contact Kohler Co. concerning your engine, be SURE to give the model number, the "Spec" number, and the serial number of the engine. This information can be found on the nameplate.

Precautions

1. Stop the engine before filling the gasoline tank. Do not spill gasoline on hot engine. Use clean gasoline and oil.
2. Warm up engine before applying load.




Figure 2

Starter-pulley end

- | | |
|------------------------------|----------------------|
| A Gasoline line | F Thumb nut |
| B Choke lever | G Starter pulley |
| C Air cleaner oil-level mark | H Cooling air screen |
| D Fuel shut-off valve | I Nameplate |
| E Sediment bowl | |

3. Engine should not be operated at speeds greater than 3600 R.P.M.
4. On belt applications mount pulley as close to engine as possible
5. Best performance depends on proper cooling. Keep engine and cooling air screen clean.

Instructions for Storing

Any engine that is stored for a considerable time should be cared for according to the following suggestions to prevent trouble when engine is again placed in service.

1. Close valve on sediment bowl.
2. Remove bowl.
3. Open valve, drain fuel from tank.
4. Start the engine and let it run until no fuel remains in the line and carburetor.
5. Replace sediment bowl, leaving valve open.
6. Pour one tablespoon SAE 20 lubricating oil into spark Plug hole and crank engine slowly.
7. Replace spark plug.

Attaching Remote Throttle Control

The following procedure for installing a remote throttle control on your engine is recommended.




Figure 3

Loosen bushing (c) and point bracket (F) in the direction your throttle cable will be brought to the engine. *Position of the disc and spring should not be changed.*




Figure 4

If bracket (F) is pointing between 6 and 10 o'clock, the tab (E) on disc (D) must be straightened as shown in figure 4. Do not remove drive screw.




Figure 5

If bracket (F) is pointing between 12 and 5 o'clock, pry out drive screw (A) with a screw driver as shown in figure 5. Do not straighten the tab.




Figure 8




Figure 6

Bend the end of your throttle cable as shown in figure 6, to obtain the best results in rotating the disc.




Figure 7

Move throttle control lever (J) to an open position as shown in figure 7. Cable clamp (K) remains loose until the end of cable is inserted in disc (D).

Hold disc (D) with spring (B) in a twelve o'clock position, regardless of the location of the bracket. Bring throttle cable parallel to the bracket on the side indicated by an arrow, and insert the cable in the hole as illustrated. Tighten cable clamp bolt.

Operate control handle from open to closed positions to check that disc (D) rotates spring (B) between twelve and three o'clock position.

RETRACTABLE STARTER




Figure 9 — A-220254 Retractable Starter

Installation of Retractable Starter

The retractable starter can be installed by observing the following instructions:

1. Remove the screen and starter pulley nut.
2. Install nut 220169 on the crankshaft to secure the flywheel.
3. Place the starter assembly on the shroud in an approximate centralized position.

4. Hold the starting cable so drive member teeth line up with teeth in the flywheel nut.
5. While starter is held in this position, spot four holes in the shroud for supporting starter. Check clearance between flywheel nut and drive member. Adjust clearance to .020/.032 using shims No. 220301 under flywheel nut.
6. Remove starter assembly.
7. Remove shroud from engine.
8. Drill 13/64 diameter holes in shroud for starter assembly, and 9/32 diameter holes for shroud reinforcement as shown in Figure 36.
9. Bolt starter assembly to shroud and replace complete assembly on engine.
10. Pull cable to check whether drive and driven members are in line. If not properly aligned loosen starter and shift so members line up perfectly.
11. Add a drop or two of lubricating oil in shaft end periodically.
12. When operating starter, allow cable to return slowly, do not let it snap back into housing.




Figure 10 — Installation Diagram—Retractable Starter

K90 ENGINE PARTS LIST

Part No.	Description	Price	Part No.	Description	Price
X-5-1	Screw, hex. cap 1/4—20 x 5/8.....		D-997	Washer, copper.....	
X-5-4	Screw, hex. cap 1/4—20 x 1 1/4.....		AC-1782	Nut, wing.....	
X-5-7	Screw, hex. cap 1/4—20 x 1.....		200110	Bearing, ball.....	
X-5-8	Screw, hex. cap 1/4—20 x 3/4.....		200361	Valve, throttle.....	
X-5-13	Screw, hex. cap 1/4—20 x 1/2.....		200365	Valve, choke.....	
X-5-26	Screw, hex. cap 1/4—20 x 1 1/2.....		200366	Needle, adjusting.....	
X-6-2	Screw, hex. cap 1/4—20 x 1 1/2.....		200367	Nozzle.....	
X-6-14	Screw, hex. cap 5/16—18 x 7/8.....		200368-A	Lever, choke—assembly.....	
X-6-23	Screw, hex. cap 5/16—24 x 3/4.....		200369	Nut, bowl (with gasket).....	
X-6-38	Screw, H.C. 5/16—24 x 1/2.....		200371	Gasket, needle seat.....	
X-14-6	Screw, F.H.M. 8—32 x 1/4.....		200372	Gasket, bowl nut.....	
X-14-9	Screw, throttle adj.....		200373	Float.....	
X-15-6	Screw, F.H.M. 10—24 x 3/8.....		200374	Bowl.....	
X-15-10	Screw, F.H.M. 10—24 x 5/16.....		200375	Gasket, bowl.....	
X-18-2	Washer, lock No. 8.....		200376	Pin, float lever.....	
X-19-1	Washer, lock No. 10.....		200377	Valve, needle.....	
X-20-1	Washer, lock 1/4.....		200378	Screw, idle adjusting.....	
X-21-1	Washer, lock 5/16.....		200379	Screw, valve attaching.....	
X-22-15	Washer, lock 7/16 I.E.T.....		200381	Spring, idle adjusting.....	
X-22-21	Washer, shakeproof E.T. 5/16.....		200382	Spring, choke shaft.....	
X-23-1	Washer, lock 7/16.....		200383	Spring, adjusting needle.....	
X-25-6	Washer, plain No. 8.....		200385	Ball, choke shaft.....	
X-25-7	Washer, plain No. 10.....		200391	Shaft, throttle.....	
X-25-35	Washer, plain 1/4.....		205013	Plug, pipe 1/4.....	
X-25-44	Washer, plain 5/16.....		210101-A	Bowl, sediment—assembly.....	
X-43-3	Key, woodruff No. 5.....		210112	Gasket, body.....	
X-50-13	Screw, R.H.M. 10—32 x 1/4.....		210113	Body, lower.....	
X-50-22	Screw, R.H.M. 10—24 x 1 3/4.....		210114	Element, w/cover.....	
X-50-27	Screw, R.H.M. 10—24 x 1 5/8.....		210116-A	Cleaner, air—assembly.....	
X-51-8	Screw, R.H.M. 8—32 x 1/4.....		210149	Clip, cable spring.....	
X-51-14	Screw, R.H.M. 8—32 x 5/16.....		210223	Gasket, carburetor.....	
X-51-35	Screw, F.H.M. 8—32 x 1 5/8.....		210293	Clamp, coil fastening.....	
X-61-36	Rivet, R.H. 1/16 x 3/32.....		210440	Elbow, air cleaner.....	
X-61-41	Rivet, R.H. 1/8 x 3/8.....		210449	Cleaner, dry mesh.....	
X-67-5	Screw, drive 2 x 3/16.....		210467	Bowl, glass.....	
X-67-8	Screw, sheet metal No. 6 x 1/4.....		210468	Gasket, bowl.....	
X-67-9	Screw, drive No. 4 x 1/4.....		210469	Gasket, air cleaner.....	
X-72-4	Nut, hex. 8—32.....		210333	Muffler.....	
X-75-2	Plug, pipe 1/4.....		214045	Muffler.....	
X-75-7	Plug, pipe.....		220003	Pin, Piston.....	
X-81-1	Nut, hex. 1/4—20.....		220004	Retainer, pin.....	
X-81-3	Nut, hex. 1/4—20 brass.....		220008	Valve, intake (For Service use 220192).....	
X-82-1	Nut, hex. 5/16—18.....				
X-88-2	Nut, hex. 7/16—20.....		220009	Valve, exhaust (For Service use 220191).....	
X-113-1	Screw, Phillip hd. 1/4—20 x 5/8.....				
X-206-9	Nipple, pipe.....		220010	Spring, valve.....	
X-212-1	Ball, steel 7/16 dia.....		220011	Retainer, valve spring.....	
X-230-11	Plug, extension.....		220013	Tappet, valve.....	
X-269-13	Ring, snap.....		220018	Cap, connecting rod.....	
D-271	Plug, welch.....		220022	Dipper, connecting rod.....	
X-271-11	Seal, gear cover.....		220036	Housing, blower.....	
X-271-15	Seal, oil.....		220040	Plug, spark, J8.....	
X-271-16	Seal, rear oil.....		220043	Stud, valve cover.....	
B-893	Nipple, pipe.....		220044	Button, stop.....	

K90 ENGINE PARTS LIST

Part No.	Description	Price	Part No.	Description	Price
220045	Spring, stop button.....		220126	Arm, governor.....	
220046	Seal, breather.....		220127	Disc, governor regulation.....	
220047	Reed.....		220128	Bushing, governor thrust.....	
220048	Gasket, valve cover.....		220130	Block, cylinder.....	
220049	Baffle, head.....		220131	Shaft, governor.....	
220051	Plate, breather.....		220132	Bushing, governor shaft.....	
220052	Pin, spring lock.....		220133	Stud, muffler.....	
220053	Pin, camshaft.....		220134	Head, cylinder.....	
220054	Baffle, cylinder.....		A-220136	Cover, breaker—assembly.....	
220055	Cover, valve.....		A-220137	Point, breaker—assembly.....	
A-220066	Breather—assembly.....		220138	Adapter, carburetor.....	
220068	Cap, gas tank.....		A-220140	Camshaft—assembly.....	
220069	Stud, air cleaner.....		220141	Gasket, adapter.....	
A-220070	Rod, connecting—assembly.....		A-220145	Muffler—assembly.....	
220071	Gasket, bearing plate.....		220146	Ell, compression.....	
220072	Rod, breaker push.....		220147	Nameplate.....	
220073	Bracket.....		220148	Washer, wave—8.37m.....	
220074	Diaphragm, breaker seal.....		220150	Pulley, starter.....	
A-220076	Contact breaker—assembly.....		220151	Gaskets, set of engine.....	
220078	Linkage, carburetor.....		220152	Screw, H. C. ¼—20 x 1½.....	
220079	Rotor magneto.....		220153	Tank, gasoline.....	
220080	Coil, magneto.....		220154	Strap, tank.....	
220081	Plate, stator.....		220156	Bracket, hand speed control.....	
220082	Condenser.....		220157	Gasket, oil pan.....	
A-220083	Lead, breaker—assembly.....		220158	Bracket, tank—L.H.....	
A-220084	Lead, hi-tension—assembly.....		220159	Bracket, tank—R.H.....	
220086	Grommet.....		220160	Plate, bearing.....	
220087	Bracket, air cleaner support.....		220162	Elbow, exhaust.....	
220088	Flywheel.....		220164	Tank, gasoline.....	
A-220089	Magneto—assembly.....		220165	Screw, hex. cap ¼—20 x ¾.....	
A-220090	Rope, starter—assembly.....		220166	Webbing, tank.....	
220091	Lock, conn. rod screw.....		220167	Base, oil pan (double drain).....	
A-220092	Plug, oil filler—assembly.....		220169	Member, nut driven.....	
220095	Insert, exhaust valve.....		220174	Gasket, breaker cover.....	
220097	Line, fuel.....		220175	Cover, breaker.....	
220098	Screen, grass.....		220176	Ring, compression—std.....	
220099	Spacer, grass screen.....		220177	Ring, compression—.010.....	
A-220100	Carburetor—assembly.....		220178	Ring, compression—.020.....	
220103-A	Piston—assembly (Incl. 220003 & 220004).....		220179	Ring, compression—.030.....	
A-220105	Piston—assembly—.010 (Incl. 220003 & 220004).....		220181	Ring, compression—std.....	
A-220107	Piston—assem. .020 (Incl. 220003 & 220004).....		220182	Ring, compression—.010.....	
A-220109	Piston—assem. .030 (Incl. 220003 & 220004).....		220183	Ring, compression center .020.....	
220116	Camshaft—finished.....		220184	Ring, compression center .030.....	
220117	Rod, connecting.....		220186	Ring, oil control—std.....	
220119	Spring, governor.....		220187	Ring, oil control—.010.....	
220120	Crankshaft, ¾" Ex.....		220188	Ring, oil .020.....	
220121	Base, oil pan (single drain).....		220189	Ring, oil .030.....	
220122	Gasket, exhaust manifold.....		220190	Block, cylinder.....	
220124	Gasket, cylinder head.....		220191	Valve, exhaust—service only.....	
220125	Retainer, flyball.....		220192	Valve, intake—service only.....	
			A-220193	Handle, carrying.....	
			220211	Housing, gear reduction.....	
			220212	Cover, gear reduction.....	
			220213	Gear, drive.....	

K90 ENGINE PARTS LIST

Part No.	Description	Price	Part No.	Description	Price
220214	Shaft, reduction gear.....		220232	Housing, sheave—assembly.....	
220215	Crankshaft.....		220233	Cable, w/handle—assembly.....	
220216	Bushing, drive shaft.....		220234	Spring, recoil.....	
220218	Gasket, gear cover.....		220235	Nut, plate.....	
220219	Crankshaft.....		220236	Housing, starter.....	
220220	Housing, blower.....		220242	Ring, camshaft retaining.....	
220228	Axle, w/pin and clutch—assembly		220247	Crankshaft, 5/8" Ex.....	
220339	Plate, mounting and brush —assembly.....		220249	Bracket, exhaust adapter.....	
220230	Sheave—assembly.....		230160	Strap, tank.....	
220231	Washer.....		240316	Sparkplug, J12.....	
			220341	Gasket, spark plug.....	

ILLUSTRATED PARTS LIST




Figure 11
Model K90 with 6:1 Gear Reduction




Figure 12
Cylinder and Breather Assembly




Figure 13
Cylinder Head




Figure 14
Cylinder Block and Breaker Assembly




Figure 15
Cylinder, Crankshaft and Magneto




Figure 16
Camshaft and Valve Assembly




Figure 17
Cylinder and Oil Base




Figure 18
Piston and Connecting Rod Assembly




Figure 19
Flywheel Starter Pulley and Screen




Figure 20 Reduction gear shaft and parts




Figure 21

Accessories




Figure 22
Breaker Assembly




Figure 23
Magneto Assembly




Figure 24 Hand Throttle Control Lever and Cable Kit 225000-A