



JOEL GRIMES  
BEAUTY DISH  
SWITCH

**Quick Start Guide**


# Included Components



**Beauty Dish Switch**



**Outer Diffusion Panel**



**Deflector Plate**



**Carry Case**

*Light Mount Inserts sold separately. Please visit [fjwestcott.com/switch](http://fjwestcott.com/switch) for available options.*

## Assembly




### Attaching a Switch Insert

On the edge of the Beauty Dish Switch ring, locate the 3 metal tabs and the thumb lock. Slide the Switch Insert (sold separately) under the 3 tabs while shifting the thumb lock outwards. Once in place, release the thumb slide to secure.<sup>1</sup>



### Opening a Beauty Dish Switch

Hold the Beauty Dish Switch in one hand by grasping the Insert and open the Beauty Dish Switch. Slide the included deflector plate through the ribs and snap into place on the Beauty Dish's center shaft.



With the opposite hand, press down on the runner towards the center shaft and slide into place. Rotate runner until you feel the Beauty Dish lock into place and fabric appears taut.<sup>2</sup>

## Mounting a Strobe or Constant Light



Place your light source onto a light stand.



After affixing your light source's compatible Switch Insert (sold separately) to the Beauty Dish, align the ring with the face of your light.



Secure the Beauty Dish Switch to your light source. Refer to your light source manual for proper mounting methods.<sup>3</sup>

# Mounting a Speedlite

1



After attaching the Switch Speedlite Insert #2541 (sold separately) to the Beauty Dish Switch, locate the two pins on the Speedlite Insert. While pressing the longer pin, rotate the adapter mount counter-clockwise until it locks into place.

2



Locate the shoe mount tilter bracket included with the Switch Speedlite Insert. Align the bracket's screw to the channel located on the Speedlite Insert. Tighten screw to secure bracket at the height required for your speedlite.

3



Loosen tension knob on the base of the tilter bracket and place on a light stand. Tighten tension knob to secure.

4



Loosen the tension screw on the side of the cold shoe bracket and slide your speedlight into place. Tighten screw to secure.<sup>3</sup>

5



Utilize the cold shoe's lower tension knob to adjust the speedlite's distance from the Beauty Dish Switch.

# Attaching Diffusion Fabric



To attach the outer diffusion fabric, simply press the fabric's loop edge onto the Beauty Dish Switch's hoop edge until fabric is taut.

# Changing Switch Inserts



Remove your light source.



To remove your Switch Insert, locate the thumb lock on the rear of the Beauty Dish Switch, slide outward, and gently pull.

# Caution

- <sup>1</sup> Failure to properly lock the Insert in place may cause damage to the Beauty Dish Switch and light.
- <sup>2</sup> Failure to confirm that the Beauty Dish Switch is securely assembled could place unnecessary stress on the ribs and can cause permanent damage to your Beauty Dish Switch.
- <sup>3</sup> Failure to secure your light to the Beauty Dish Switch could result in damage to your equipment.
- <sup>4</sup> Failure to secure your speedlite could result in damage to your light.


The Beauty Dish Switch is heat-rated for up to a maximum of 650-watts.

## Care Instructions

Gently spot clean diffusion panels by hand with a damp cloth.


Do not apply cleaner to the reflective surface, as this may damage the product.

## Accessories



### Switch Light Mount Inserts

Use these durable aluminium light mount inserts to attach any Rapid Box Switch or Beauty Dish Switch light modifier to a light source.



### Egg Crate Grids

The optional 40° Egg Crate Grid is designed to direct light forward and eliminate light spill. The grid attaches via hook-and-loop tape and can be used in tandem with the diffusion panel and/or the deflector plate.

Visit [FJWESTCOTT.COM/SWITCH](https://www.fjwestcott.com/switch) for options and availability.



### Westcott Cares About the Environment

Recycling electronics and light bulbs is a great way to reduce your environmental impact and ensure that you're playing your part in preserving an environment that can be enjoyed by future generations. Many retail stores have bins designed for recycling these items. You can also contact a local recycling center to inquire about recycling your electronics and bulbs there.

# Warranty

Westcott's warranty obligations for the Beauty Dish Switch ("product") are limited to the following terms.

The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of **ONE (1) YEAR** from the date of retail purchase from Westcott or an authorized retailer by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the Westcott trademark, trade name, or logo affixed to them.

This warranty does not apply to: (a) damage caused by accident, abuse, misuse, flood, fire, wind, mold, or other external causes; (b) damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) a product or part that has been modified to alter functionality or capability without the written permission of Westcott; or (d) cosmetic damage, including but not limited to scratches and dents.

**Disclaimer:** By purchasing, borrowing and/or using this product for any event, both public or private, you, the customer, accepts all responsibility and releases Westcott, and its associates, of any and all liability in the event of manufacturer's defect, malfunction or misuse of the product which may lead to further injuries or complications unforeseen by the user. Westcott is not responsible for any potential or incurred damage caused by failure to properly mount, hang, or store the product, which includes, but is not limited to damage to cameras, electronics, electrical equipment, buildings, building materials, personal injury, death, or disability, fire damage, or any and all other damage not mentioned previously.

Please contact Westcott's Repair Department for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the limited warranty will be returned at the expense of the sender.

**Repair Department:** 800-886-1689 / 419-243-7311 (International)

**Email:** [service@fjwestcott.com](mailto:service@fjwestcott.com)

**Shipping:** F.J. Westcott Co, 1425-B Holland Rd. Maumee, OH 43537

Register your new gear online at [FJWESTCOTT.COM/REGISTER](https://fjwestcott.com/register)

Visit [FJWESTCOTT.COM](https://fjwestcott.com) for videos, pro tips, inspiration, and more!

Westcott products are made to the company's traditionally high standards of quality and comply with all applicable government safety regulations and requirements. In an effort to provide the best quality products possible, we periodically make product modifications. Actual products may not be identical to items pictured. Designed in Ohio, USA. Assembled in Korea. © F.J. Westcott Co. All rights reserved. AU0418