

ACWVO[®]

DWOTS 727

User Manual



Appearance:

1. Left Earbud
2. Right Earbud
3. Charging Case
4. Left Earpiece Charging Socket
5. Right Earpiece Charging Socket
6. Multi-Function Touch Area
7. Type-C Charging Interface



What You Will Find In The ACwO Box?

- Charging Case
- Pair Of Earbuds
- Type-C Charging Cable
- Warranty Card
- Scan Me Card
- ACwO X Sunil Chhetri Catalogue
- Comfortable Ear Tips

Kindly Note:

Please take off the sticker peels attached below the earbuds before you charge them.

Charge the charging case and the DwOTS 727 Wireless Earbuds at least 70% before the first usage.

Charging:

Charging Case:

Connect the type-c charger to the charging case to charge your DwOTS 727.

Earbuds:

Place the earbuds in the charged Charging Case to charge the DwOTS 727.

Bluetooth Pairing Process:

- 1 Take out the DwOTS 727 Earbuds from the Charging Case and place them in your ears.
- 2 Go to the Bluetooth settings of your device and switch it on.
- 3 Scan available devices.
- 4 Search For "ACwO DwOTS 727" from the list of available devices.
- 5 Pair "ACwO DwOTS 727" from the list and your Earbuds will be connected.

Once you've completed the initial pairing process, the ACwO DwOTS 727 will seamlessly connect to your device every time you open the charging case thereafter.

Kindly Note:

If the earbuds are not in use and are left outside the charging case, they will automatically turn off after approximately 5 minutes.

Bluetooth Reset Process:

- 1) In case your earbuds encounter pairing issues or if only one earbud is functioning, you can easily perform a reset.
- 2) Clear all Bluetooth data named "ACwO DwOTS 727" from your device and disable Bluetooth.
- 3) Place the earbuds back into their charging case and then remove them to initiate the Bluetooth pairing process once more.

Product Features:

HYPER BOOST™ (10Mins Charge - 120Mins Playtime)

SONIC SHIELD™ Environmental Noise Cancellation

BasS BooM X™ Real Drivers

nFS™ Gaming Ready 40ms Low Latency

Voice Assistant ("Ok Google" & "Hey Siri")

IPX5 Water & Sweat Resistant

42 Hours Of Music Playtime (With ANC Off)

Active Noise Cancellation Up To 25DB

Type-C Charging Interface

Bluetooth Version 5.3
Instant Auto Connect

How To Use Your ACwO DwOTS 727?

Touch Controls:

The Multi-Functional Touch Area, often referred to as the "Touch Area," is situated on the upper section of the earbud's handle.

Safety Guidelines:

- Please refrain from dismantling the product or attempting to remove its battery. Such actions can pose a fire hazard or cause electrical malfunctions. Seek the services of a qualified technician or the manufacturer for any necessary maintenance or repairs.
- When cleaning the earbuds, exercise caution by using a damp, soft cloth. Avoid using any oily or volatile liquids for cleaning purposes. Additionally, ensure that the earphones are kept away from extreme temperature conditions, both hot and cold.
- Please be aware that any damage to the earbuds that is not attributed to a manufacturing defect will render the product's warranty null and void.
- Do not wear them in situations where it is unsafe, such as when operating a vehicle, crossing streets, or engaging in activities requiring full situational awareness.

- To safeguard your hearing, ensure that the volume on your music player is set at an appropriate level when using the earphones. Prolonged exposure to high noise levels can gradually lead to hearing impairment.
- Do not wear the earbuds for a long period of time as it can lead to possible hearing loss or major hearable issues.

Smart Touch Function:

Play & Pause

Single tap on the Multi-Function Touch Area of either earbud.

Switch Between Normal/Gaming Mode

Triple tap on the Multi-Function Touch Area of the right earbud

To On/Off ANC Mode

Triple tap on the Multi-Function Touch Area of the left earbud

Next Track

Hold for 2 seconds on the Multi-Function Touch Area of the right earbud.

Repeat Track

Hold for 2 seconds on the Multi-Function Touch Area of the left earbud.

To Answer Calls

Single Tap on the Multi-Function Touch Area of either earbud.

To Hang Up Calls:

Single Tap on the Multi-Function Touch Area of either earbud.

To Decline Calls:

Hold for 2 seconds on the Multi-Function Touch Area of either earbud.

Call Voice Assistant

Double Tap on the Multi-Function Touch Area of either earbud.

One need not activate Environmental Noise Cancellation as the built-in mic is already equipped with the same and activated by default to make your conversations smoother and clear without any disturbances no matter how noisy your environment is.