

PHOENIX PHASE CONVERTERS

USER MANUAL




TABLE OF CONTENTS

NL and NH Wiring Diagram 230 or 460 Volt Models	PAGE 3
PL and PH Wiring Diagram 230 or 460 Volt Models	PAGE 4
Wire and Breaker Size Guide 230 Volt Models	PAGE 5
Wire and Breaker Size Guide 460 Volt Models	PAGE 6
Pairing two Phase Converter Together Fig 1	PAGE 7
Pairing two Phase Converter Together Fig 2	PAGE 8
Connecting a Transformer with a Phase Converter PL Models	PAGE 9
Connecting a Transformer with a Phase Converter NL Models	PAGE 10
Separate AutoStart Panel and Phase Converter Panel Connection	PAGE 11
Separate AutoStart Panel, Phase Converter Panel, and Transformer Connection	PAGE 12
AutoStart Phase Converter with Transformer Connection	PAGE 13
AutoStart Phase Converter Diagram	PAGE 14
Connection Diagram of the AutoLink, connecting two phase converters together	PAGE 15
Connection Diagram of the AutoLink, connecting a phase converter with a transformer	PAGE 16
Phase Converter Panel Dimensions	PAGE 17
3 HP and 5 HP Idler Motor Dimensions	PAGE 18
7.5 HP Idler Motor Dimensions	PAGE 19
10 HP Idler Motor Dimensions	PAGE 20
15 HP and 20 HP Idler Motor Dimensions	PAGE 21
25 HP and 30 HP Idler Motor Dimensions	PAGE 22
40 HP and 50 HP Idler Motor Dimensions	PAGE 23
60 HP and 75 HP Idler Motor Dimensions	PAGE 24
Three phase motor chart, wire size, conduit, Transformer size if required to change voltage.	PAGE 25
Useful common charts, transformer amps, converter resistive load amps, HVAC LRA to size to converter HP required.	PAGE 26
KVA, KW to Volts amps chart.	PAGE 27
Troubleshooting and help videos	PAGE 28

NL and NH - MODEL ONLY


Phase Converters WITHOUT a start and stop button on the front lid.



Diagrams are located on the name plate.

PL and PH - MODEL ONLY

Phase Converters WITH a start and stop button on the front lid.



**230 Volt Connection for NL AND PL Models
(low voltage)**

**460 Volt Connection for NL AND PL Models
(high voltage)**

Diagrams are located on the name plate.

**MUST BE
INSTALLED BY AN
INDUSTRIAL
LICENSED
ELECTRICIAN**

Wire And Breaker Size Guide

230 VOLT MODELS ONLY

Idler Horsepower	3	5	7.5	10	15	20	25	30	40	50	60	75	100
Minimum Breaker Size	10	15	20	20	30	40	40	50	60	80	100	125	150
Maximum Breaker Size	25	30	40	40	80	100	125	150	200	250	300	350	400
Single Phase Wire Size	10	8	8	6	4	4	2	2	1/0	2/0	3/0	4/0	300
Idler Motor Wire Size	10	10	10	8	8	6	4	3	3	2	1	1/0	2/0

Important Guide Lines Of Installation

Increase Wire Size For Every 50 Feet And Round Up - For Breakers Use 2 Times the Full Load of the Equipment

1. Make sure you have enough power to start the phase converter, check with your local electric company to see what size transformer you have on the pole. The Transformer KVA Number should be higher than the phase converter HP number
2. You must use an Industrial Licensed Electrician
3. All loads including transformers must be disconnected or in the off position before starting the phase converter each time.
4. Magnetic controls, single phase loads, or resistive loads must be energized by L1 and L2.




Wire And Breaker Size Guide

>> 460 VOLT MODELS ONLY <<

Idler Horsepower	3	5	7.5	10	15	20	25	30	40	50	60	75	100
Minimum Breaker Size		10	10	15	15	20	20	25	30	40	50	80	75
Maximum Breaker Size		15	20	25	40	50	60	75	100	125	150	175	200
Single Phase Wire Size		8	8	8	6	8	4	4	1	2	2	2/0	2/0
Idler Motor Wire Size		10	10	8	8	8	6	6	4	4	4	2	2


Important Guide Lines Of Installation

Increase Wire Size For Every 50 Feet And Round Up - For Breakers Use 2 Times the Full Load of the Equipment




1. Make sure you have enough power to start the phase converter, check with your local electric company to see what size transformer you have on the pole. The Transformer KVA Number should be higher than the phase converter HP number
2. You must use an Industrial Licensed Electrician
3. All loads including transformers must be disconnected or in the off position before starting the phase converter each time.
4. Magnetic controls, single phase loads, or resistive loads must be energized by L1 and L2.

Pairing two phase converters together with a Disconnect or AutoLink Box second phase converter self starting.




We recommend to use one of our AutoLink Boxes to pair two phase converters together, it will pair the phase converters together automatically, or you can turn the second phase converter off with a push of a button in the diagram above the second phase converter will automatically start one the first one is started manually. It is important that you use the proper wire sizes for both converters.

Pairing two phase converters together with a Disconnect or AutoLink Box.




This is the best recommend install to pair two or more phase converters together, smaller breakers are used in the drawing, also bringing the appropriate wire size to each phase converters is easier.

PL Model using a AutoLink or disconnect to a transformer.




NL Model using a AutoLink or disconnect to a transformer.




Separate AutoStart Panel and Phase Converter Panel

Connection




MUST BE
INSTALLED BY AN
INDUSTRIAL
LICENSED
ELECTRICIAN


Separate AutoStart Panel, Phase Converter Panel, and Transformer Connection




AutoStart Phase Converter with Transformer Connection




AutoStart Phase Converter Diagram




Connection Diagram of the AutoLink, connecting two phase converters together



Connection Diagram of the AutoLink, connecting a phase converter with a transformer






Phase Converter Panel Dimensions



HP	HEIGHT	WIDTH	DEPTH	WEIGHT
2-3-5	12	12	4	8
7.5-10-15-20	19.5	12	6	15
25-30-40	23	18	8	35
50-60	26	26	8.5	62
75-100	32	32	8	110

NOTE: Due to COVID-19, box dimensions and colors could vary as we are using more than a couple resources to fill the demand of our orders.




3 HP and 5 HP Idler Motor Dimensions and Weight



Weight: 3 HP = 94.815 lbs



Weight: 5 HP = 110.25 lbs

7.5 HP Idler Motor Dimensions and Weight




Weight: 158.76 lbs




10 HP Idler Motor Dimensions and Weight



Weight: 181.9 lbs






15 HP and 20 HP Idler Motor Dimensions and Weight



Weight: 15 HP = 278.9 lbs

Weight: 20 HP = 330.75 lbs




25 HP and 30 HP Idler Motor Dimensions and Weight



Weight: 25 HP = 330.75

Weight: 30 HP = 396.9 lbs



40 HP and 50 HP Idler Motor Dimensions and Weight



Weight: 40 HP = 539.1 lbs


Weight: 50 HP = 600.8 lbs

60 HP and 75 HP Idler Motor Dimensions and Weight



Weight: 60 HP = 782.75 lbs

Weight 75 HP = 873.18 lbs



Three phase motor chart, wire size, conduit, Transformer size if required to change voltage.

HORSEPOWER	220-240 VOLTS				440-480 VOLTS			
	WIRE SIZE	CONDUIT SIZE IN INCHES	FULL LOAD AMPS	KVA TRANSFORMER REQUIRED	WIRE SIZE	CONDUIT SIZE IN INCHES	FULL LOAD AMPS	KVA TRANSFORMER REQUIRED
1	12	3/4	3.6	3	12	3/4	1.0	3
2	12	3/4	6.8	6	12	3/4	3.4	6
3	10	3/4	9.6	6	12	3/4	4.8	6
5	10	3/4	15.2	9	12	3/4	7.6	9
7.5	8	3/4	21	15	12	3/4	11.5	15
10	8	3/4	27	15	12	3/4	14	15
15	6	1	42	30	10	3/4	21	30
20	4	1	52	30	10	3/4	28	30
25	4	1.5	68	45	8	1	34	45
30	3	1.5	80	45	8	1	40	45
40	1	1.5	104	75	6	1	52	75
50	1/0	2	130	75	4	1.5	65	75
60	3/0	2	154	75	3	1.5	77	75
75	250kcmil	2.5	192	112.5	1	1.5	96	112.5
100	350kcmil	3	248	112.5	2/0	2	124	112.5

Useful common charts, transformer amps, converter resistive load amps, HVAC LRA to size to converter HP required.

3 PHASE TRANSFORMER AMPERES			
KVA	208 AMPS	240 AMPS	480 AMPS
3	8.4	7.2	3.1
6	16.7	14.4	7.22
9	27.8	24.1	12
15	41.6	36.1	18
30	83.3	72.2	36.1
45	125	108.4	54.2
75	208.2	180.4	90.2
112.5	312.5	271.6	135.3
150	416.3	360.8	180.4
225	625	541.9	270.7





PHASE CONVERTER SIZE TO A RESISTIVE LOAD, HEATING ELEMENTS, WELDERS, ECT.	
CONVERTER HP	230 VOLTS AMPS
2	4
3	5
5	7
7.5	10
10	14
15	22
20	28
25	35
30	42
40	56
50	70
60	84
75	105
100	135

LRA (LOCKED ROTOR AMPS) MOSTLY USED TO SIZE A CONVERTER TO HVAC UNITS		
HP	LRA (460)	CONVERTER HP REQUIRED
1	30 (15)	3
2	50 (25)	5
3	64 (32)	7.5
5	92 (46)	15
7.5	127 (63)	20
10	162 (81)	25
15	232 (116)	40
20	290 (146)	50
25	365 (182)	60
30	436 (217)	80
40	580 (290)	100









KVA, KW to Volts amps chart.

KVA	KW	208V	220V	240V	440V	480V
8	6.3	17.5	16.5	15.2	8.3	8.1
9.4	7.5	26.1	24.7	22.6	12.3	11.3
12.5	10	34.7	33	30.1	16.6	15.1
18.7	15	52	49.5	45	24.9	22.5
25	20	69.5	66	60.2	33.2	24
31.3	25	87	82.5	75.5	41.5	37.8
37.5	30	104	99	90.3	49.8	45.2
50	40	139	132	120	66.5	60
62.5	50	173	165	152	83	81
75	60	208	198	181	99.6	91
93.8	75	261	247	226	123	113
100	80	278	264	240	133	120
125	100	347	330	301	166	150
156	125	433	4134	375	208	188
187	150	520	495	450	249	225
219	175	608	527	527	289	264
250	200	694	660	601	332	301









Troubleshooting and help videos

PROBLEM	SOLUTION	LINK TO VIDEO	QR CODE TO VIDEO		
Phase converter doesn't want to start, moves slow, growls.	The single line is mostly likely the cause of this. If it is dropping in voltage the phase converter won't start. It could be because of a bad connection, too long of wire, too small of wire, or your service is weak. You can also add start capacitors to make up for your voltage drop in some cases.	https://phoenixphaseconverters.com/tv.php Also Check Check the 2 pole contactor pulling in. https://www.youtube.com/watch?v=rsfiozxlB3o Add an additional start capacitor https://www.youtube.com/watch?v=6g-yPkAHWHw	Trouble shooting video 	Checking the contractor 	Adding a capacitor 
Capacitor failed.	Run Capacitors (Silver in color) usually don't ever fail, the start capacitors can, usually if you start and stop too frequently, or your voltage is dropping either when you start the phase converter or the equipment you are running with the phase converter. We need to check the voltages, also check the 2 pole contactor and see if they are fused together	Checking the 2 pole contactor link. https://www.youtube.com/watch?v=zRrBsoo_At0 Checking the voltage. (VIDEO COMING SOON)			
Checking the voltage I get 120 on L1 and 120 on L2 and 220 on L3. Why?	All phase converter will output a delta voltage, this is normal. Click on the link to see the video on how to check the voltage. From phase to phase you should get 230 all the way across depending on your input voltage.	https://www.youtube.com/watch?v=0GpoUAKQBFc			
The phase converter panel makes a buzzing noise.	Normally when that happens there is dust or debri inside the contactor. There is two metal plates that pull together by a magnetic coil, if there is anything inbetween, the plates will vibrate. Please watch the video on how to fix this issue.	https://www.youtube.com/watch?v=EeEkcVZ2qc4			

PROBLEM	SOLUTION	LINK TO VIDEO	QR CODE TO VIDEO		
My amps are not balanced after the phase converter going to my equipment.	This is perfectly normal, you have a phase converter load on the single phase line (L1 and L2) and on your three phase equipment is on (L1, L2 and L3), your equipment is getting even amps, the phase converter is drawing L1 and L2 to have higher amps because of its load	There isn't a video on this section	N/A		
I push the start button and nothing happens.	Try pushing the stop button first, if so then the button is upside down on the back part of it. Next make sure the small controls wires have a good connection, then measure the voltage on you input power and see if you have voltage there.	There isn't a video on this section	N/A		
Equipment runs backward.	Simply reverse any two power wires going to your equipment, make sure any magnetic contractors or single phase loads are powered by your single phase line (L1 and L2)	There isn't a video on this section	N/A		
Machine doesn't start or run	Check the voltage at the machine, if there is the correct voltage there then contact the manufacture of the equipment you are trying to run. If there isn't any voltage but the phase converter is running at full speed then there is a connection issue with the wire.	There isn't a video on this section	N/A		

	Description	QR code to link	Weblink
	<p>50 MFD - 370 Volts Run - Titan Pro</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/start-capacitor-1.html</p>
	<p>270-324 MFD - 220 Volts Start Capacitor</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/start-capacitor.html</p>
	<p>Start and Stop panel mounted push button</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/start-and-stop-button-with-indicating-led.html</p>
	<p>Voltage Meter Display - Panel Mounted 0 to 500 AC</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/voltage-meter-0-to-500-volts-ac.html</p>

	<p>Two Pole Contactor 230 Volts - 30 Amps</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/two-pole-contactor-230-volts-30-amps.html</p>
	<p>Potential Relay 90-66</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/potential-relay-90-66.html</p>
	<p>9 X 50 Mfd Run Capacitor Holder</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/9-x-50-mfd-run-capacitor-holder.html</p>
	<p>75 Amp - 3 Pole - 230 Volt Coil - Contactor</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/75-amp-3-pole-230-volt-coil-contactor.html</p>
	<p>90 Amp - 3 Pole - 230 Volt Coil - Contactor</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/75-amp-3-pole-230-volt-coil-contactor-1.html</p>

	<p><u>Push Button and Mag Starter Kits-5 HP</u></p>		<p>https://www.phoenixphaseconverters.com/Shop/default/push-button-and-mag-starter-kits-5-hp.html</p>
	<p>Push Button And Mag Starter Kits-10 Hp</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/push-button-and-mag-starter-kits-10-hp.html</p>
	<p>Wireless Pushbutton kit for 25 to 40 HP Phase Converter 230 volts</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/wireless-remote-contactor-start-stop-230-volts-60-hp-rotary-phase-converter-1.html</p>
	<p>Wireless Pushbutton kit for 50 to 60 HP Phase Converter 230 volts</p>		<p>https://www.phoenixphaseconverters.com/Shop/default/wireless-remote-contactor-start-stop-230-volts-60-hp-rotary-phase-converter-2.html</p>