

Pro-Stitcher® PREMIUM

Quick Reference Guide

This guide will help you through the learning curve of the user interface, finding commonly used features, and becoming familiar with new features you'll love using.

THE PRO-STITCHER WORKSPACE

Tabs: Select any tab to display its buttons and functions.

Help buttons: Select the Help tab for on-screen indexed and hyperlinked help content. Select the Help button and then click a button or tab on the screen for context-sensitive help.


Quick-Access Toolbar: Buttons shown here are always visible. You can add your favorite commands to this toolbar.

Workspace Toolbar: Buttons shown here are always visible. Only one button can be selected at a time.

Ribbon: The buttons on the Ribbon change according to which tab is selected.

Sidebar: The sidebar includes buttons for the functions tied to the various Ribbon buttons. The Sidebar Tabs relate to other aspects of the workspace.

Zoom the workspace: Touch the plus (+) or minus (-) buttons to zoom in or out, or use the slider bar: slide right to zoom in or left to zoom out.



Rulers

Jump (purple dotted line): not stitched


Pan Scroll Bars

Design rubber band (green)

Design start point (green)

Design end point (red)

Design bounding box (blue)



LEARNING PRO-STITCHER PREMIUM

WHERE'S THE USER MANUAL?



Your Pro-Stitcher came with a Getting Started Guide that includes installation instructions, safety information, troubleshooting tips, the warranty and warranty registration card, and the training checklist for your Babylock retailer to use when providing you an overview to Pro-Stitcher. Be sure to complete the warranty registration card and return to Babylock as directed on the card.

The software operation and reference information is available as an on-screen, context-sensitive help system and has an indexed and hyperlinked reference guide. Both are accessible from within Pro-Stitcher. This enables you to look up instructions related to a specific function while you are using the software.

ACCESSING ON-SCREEN HELP IN PRO-STITCHER

Context-sensitive onscreen help: The context sensitive help enables you to point to a button or function within Pro-Stitcher and display a pop-up help window describing just that feature. The information is usually more concise than using the Reference Guide. If after reading the context-sensitive help you want more information, refer to the Reference Guide.

Reference Guide: The reference guide is structured much like other help systems in Microsoft Windows-based software. It has a table of contents, an index, search capability, and hyperlinks between help topics.

To Do This	Select This	Then Do This
Display context-sensitive onscreen help		Select a Pro-Stitcher tab, button, or area on the workspace to display a text box with information about that function.
Access the reference guide		Select the reference guide help tab, then select the Help button in the Ribbon.

FIND COMMONLY USED FEATURES

General instructions: To access the various Pro-Stitcher Premium functions, you will typically select one of the tabs which displays a ribbon of buttons below the tabs. When you select a ribbon button, customization options for that function display in a sidebar along the right side of the screen. (If the Sidebar is closed, choose the Open Sidebar arrow button at the upper-right corner by the Pro-Stitcher workspace.)

To Do This	Select This	Then Do This
Open, close, or save one or more design(s).	File tab	Choose Design > Open, Close > Selected , or Save > Selected from the Ribbon.
Shut down Pro-Stitcher	File tab	Choose the File tab, and then choose Shutdown from the Ribbon. From the menu choose Shut down to shut down the Pro-Stitcher tablet and the software; choose Reboot to restart the tablet and the software; or Exit to Windows to shut down the software but return to the Windows desktop.
Show or hide the design, the bounding box, the area box, the rubber band, the jump points, start and stop points, the grid lines, the scroll bars, or the rulers	View tab	Choose the items from the Ribbon that you want to display or not.
Duplicate or clear a design	Edit tab	Choose Duplicate or Clear All from the Ribbon.
Create an area	Area tab	Choose 2-Corner or Multi-Point from the Ribbon; then fine tune on the Sidebar.
Baseline the design modifications	Modify tab	Choose Baseline from the Ribbon; you can also assign the Baseline button to the Quick Access Toolbar.
Rotate, flip, or mirror a single or grouped design	Modify tab	Choose Rotate ; choose either Group or Single on the sidebar; then choose from the rotate options.

To Do This	Select This	Then Do This
Crop the design relative to an area	Modify tab	Create the area. Choose Crop from the Ribbon, choose Outside or Inside on the Sidebar. Then indicate whether to perform a tieoff at the jump points (disable the Edges button) or to stitch between jump points (select the Edges button).
Crop the design based on the design's start and end points	Modify tab	Move the design's start and/or end points (Pro-Stitcher > New Start/End). Then choose Crop from the Ribbon and Start-End on the sidebar. Then indicate whether to perform a tieoff at the jump points (disable the Edges button) or to stitch between jump points (select the Edges button).
Change the dimensions of the design	Modify tab	Choose Resize from the Ribbon. Choose Lock to lock the aspect ratio if desired. Choose either Width , Height , Original Width , or Original Height on the sidebar; then use the Plus (+) and Minus (—) to adjust the dimension.
Skew the design	Modify tab	Create an area and open a design. Select Modify > Skew to open the Skew sidebar. Generally you will use Skew 1 when skewing to a convex area and Skew 2 when skewing to a concave area.
Swap the quilting start and end points	Modify tab	Select the Swap button.
Repeat designs in the workspace	Repeat tab	Add or remove design repeats using the Plus (+) and Minus (—) buttons, or select the Fit button to have Pro-Stitcher automatically calculate the optimal number of repeats both horizontally and vertically. Add more horizontal or vertical repeats if desired, and then stretch them vertically and horizontally to fit them to the area.
Wrap repeated designs in the workspace	Repeat tab	Offset rows of repeated designs, or shift the entire design window.
Stitch perfectly straight lines across the quilt	Pro-Stitcher tab	Use Channel Lock to stitch horizontally or vertically, or use Move with the Stitch button selected to stitch up, down, left, right, or diagonally.
Quilt a design	Pro-Stitcher tab	Select Quilt from the Ribbon. (Make sure the Stitch button is selected in the Sidebar.) Then select Run .
Recover from a thread break or running out of bobbin thread	Pro-Stitcher tab	Use New Start & End to change the start point of the design to the position where Pro-Stitcher needs to resume stitching.

SIDEBAR RIBBON BUTTON REFERENCE

FILE TAB RIBBON BUTTONS



Design: Opens a design file. Navigate through your computer's file system to locate the design file you want to use. The drop-down menu also shows the design files you most recently used for quick access.



Workspace: Opens a workspace file. Navigate through your computer's file system to locate the workspace file you want to use. The drop-down menu also shows the workspace files you most recently used for quick access.



Area: Open an area file. Navigate through your computer's file system to locate the area file you want to use. The drop-down menu also shows the area files you most recently used for quick access. You can have only one area open at a time.



Save: Select to save the selected design(s), the workspace, or the area.



Close: Select to close the selected design(s), the workspace, or the area. You will be prompted to save any objects that have had changes.



Clear All: Select to close everything in the workspace. Be sure to save anything you want to keep before clearing.



Update: After downloading the update to a USB drive, insert the drive into the Pro-Stitcher computer and select this button to update the Pro-Stitcher software.



Shut Down: Select to exit Pro-Stitcher. From the menu, select **Shut Down** to quit the software and shut down the tablet computer; select **Reboot** to restart both the tablet computer and software; or select **Exit to Windows** to exit the software but leave the tablet computer on.

EDIT TAB RIBBON BUTTONS



History: Use to show a list of your most recent actions with Pro-Stitcher. Select an item on the History list to return the design to the state it was when that function was performed. Or select **Clear History** to clear the entire design history.



Undo: Use the **Undo** button to undo the last function performed. Continue selecting **Undo** as needed to get the design back to where you want it.



Redo: If you change your mind about the last Undo action, select the **Redo** button.



Cut: Cuts the selected design(s).



Copy: Copies the selected design(s).



Paste: Pastes the copied design(s), positioning the design start point at the needle position (indicated by the cross hairs).



Duplicate: Select the design(s) you want to duplicate and then choose the **Duplicate** button. If one design is selected, only that design is duplicated. If multiple designs are selected, all selected designs are duplicated.



Clear All: Select to close everything in the workspace. Be sure to save anything you want to keep before clearing.

AREA TAB RIBBON BUTTONS



File: Use to open an area file you have saved. Navigate through your computer's file system to locate the area file you want to use. The drop-down menu also shows the area files you most recently used for quick access.



Select: Selects the area in the workspace. The area turns from a purple line to a green line to indicate it is selected. You can then use your finger to drag and drop it, or select the **XForm** (Transform) button and use the transform handles to resize, rotate, or reposition the area.



Clear: Select to clear the current area.



2 Corner: Use to create a 2-corner (rectangular) area. Position the needle where you want the area to begin and select **2 Corner**, usually the upper-left corner of the area. Then move the cross hairs to the opposite corner of the area and press **2 Corner** again. Fine tune the dimensions of the area in the Area sidebar.



Multi-Point: Use to create a multi-point (concave or convex) area. Position the needle where you want the area to begin and select **Multi-Point**. Move the needle to the next point along the perimeter of the area and select **Multi-Point** again. Continue in this manner until you have created an area.

MODIFY TAB RIBBON BUTTONS



Baseline: Use the Baseline button to "freeze" the modifications you have made to the design. Once you baseline, all modifications treat the design as a new unaltered design. However, baseline does not save the design to your computer.



Rotate: Select the **Rotate** button to open the Rotate Sidebar. You can rotate a single design or multiple designs.



Reposition: Use the Reposition options to position a design relative to the needle position (represented by the cross hairs on the screen).



Resize: Select the **Resize** button to open the Resize Sidebar. You can adjust the height and width, as well as the original height and original width (if the design has been rotated). You may also lock the aspect ratio so the height and width increase or decrease proportionately.



Crop: Use the Crop function in conjunction with a defined area. After a design has been loaded and modified as needed, mark an area that represents the region to be cropped. Select the **Crop** button to open the Crop Sidebar. If the Crop options are not available, an area has not yet been defined.



Align: After you create an area, use the align options to position the design within the area. To open the Alignment Sidebar, select the **Align** button. Then select from the alignment button(s) to position the design within the area.



Skew: After you create an area, use the skew options to fit the design within the area. Any further formatting you do to the design will also stretch to the limits of the area. The Skew options aren't available until you define an area and open a design.



Swap: Use this button for those times when you want to switch the quilting start and end points, such as when you rotate or flip a design and the start point is now at the right side of the design.

REPEAT TAB RIBBON BUTTONS




Basic: Provides several options for repeating designs both vertically and horizontally. If you have created an area, you can also have Pro-Stitcher determine how many repeats will fit within the area.



Wrap: Provides several options for wrapping, or offsetting, designs either vertically or horizontally. Most of these options can be done with or without a defined area.

PRO-STITCHER TAB SIDEBAR BUTTONS



Half Stitch: Select to cycle the needle either to the up or the down position based on the current position of the needle.



Full Stitch: Select to cycle the needle a full stitch to the up position. If the needle is in the down position, it will move only a half cycle so it stops in the up position. Subsequent presses of the button, however, will cycle a full stitch, always ending with the needle in the up position.



Follow: Select **Follow** when you want to ensure that the cross hairs remain in view when you have zoomed into a design. This saves you from having to use Pan to find the cross hairs. It is also helpful to enable Follow when you stitch a wide design because you can both zoom in on the design and always see what is being stitched on the screen.



Measure: Select to measure distances in a design or directly on the quilt.



Quilt: Select when you are ready to begin quilting; then select **Run**. If Verify Before Quilt is enabled (Settings Tab > Advanced > General), Pro-Stitcher displays all of the settings for you to review. Press **Proceed** to continue.



Channel Lock: Select this button have Pro-Stitcher stitch horizontal or vertical lines that are perfectly square with the frame. On the Channel Lock Sidebar, choose either the Horizontal or Vertical button and begin stitching.



Move: The **Move** option enables you to move the quilting machine in any of the 8 directions indicated by the direction arrows by pressing that arrow button. Select the **Continuous** button for the machine to move continuously, select the **Stitch** button to stitch as you press the arrow button, or select both the **Continuous and Stitch** buttons to stitch continuously. Press the **Stop** button that appears to turn off the **Continuous** operation.



New Start & End: Use this button to start quilting a design from some point other than the design's start point. You may need to do this because the thread breaks, the bobbin runs out, or you simply want to stitch a specific portion of a design. Similarly, you may change the ending point to a point other than the design's original end point.



Record: Pro-Stitcher can record the movement of the quilting machine. For example, record your own background designs across the width of the quilt. Or record your signature so you can quilt your signature into your quilts.



Gears: Typically you will engage the Pro-Stitcher motors when using computerized quilting and disengage them for free-motion quilting. Choose the **Gears** button to automatically engage or disengage the motors if you have an EZ Carriage. If you have a carriage with levers, manually raise the levers to disengage or lower them to engage the motors. If you are going to have Pro-Stitcher record your stitching (Pro-Stitcher Tab > Record), disengage the motors for a smoother free-motion quilting experience.




Clear Trace: As Pro-Stitcher stitches, the portion of the design that has been stitched turns to orange on the screen. At any time you can clear that "tracing" by choosing the **Clear Trace** button. If you are in the process of stitching out the design, first select the **Pause** button and then **Clear Trace**. Then press **Resume** to continue stitching.



VIEW TAB RIBBON BUTTONS



Rulers: Select to hide or show the workspace top and side rulers. This button may be added to the Quick-Access toolbar to quickly turn the rulers on or off.



Grid: Select to hide or show the workspace grid. This button may be added to the Quick-Access toolbar to quickly turn the workspace grid on or off.



Scroll: Select to hide or show the bottom and right-side scroll bars in the workspace. Use the scroll bars to pan up and down or left and right. This button may be added to the Quick-Access toolbar to quickly turn the scroll bars on or off.



Transparency: Select to hide or show the workspace lightly below Pro-Stitcher screen areas beyond the main workspace, such as below the ribbon buttons, the sidebar, the status bar, and the toolbars.



Area: Select to hide or show the area box. This button may be added to the Quick-Access toolbar to quickly switch between showing the area box or removing it from view.



Design: Select to hide or show the design from the workspace. This button may be added to the Quick-Access toolbar.



Bounds: Select to hide or show the bounding box around the selected design(s). This button may be added to the Quick-Access toolbar.



Rubber Band: Select to hide or show the rubber band around the selected design(s). The rubber band shows the smallest area required by the entire design.




Jumps: Select to hide or show the stitching path between jump points, or places where you need to stop stitching, tie off your thread, and then continue stitching at the next start point. This button may be added to the Quick-Access toolbar.



Start End: Select to hide or show the quilting start and end points in a design. This button may be added to the Quick-Access toolbar.

TOOLS TAB RIBBON BUTTONS



Art & Stitch: Select to pass the selected design(s) to *Art & Stitch*, select the Tools tab and then select the *Art & Stitch* button. If *Art & Stitch* is open and has been licensed, the design will open in *Art & Stitch*. If *Art & Stitch* has not yet been licensed, a licensing screen will appear for entering license information.

SETTINGS TAB RIBBON BUTTONS



Display: Select to turn on or off Touch Mode, customize the Quick-Access Toolbar, and configure Pro-Stitcher so it works best with your tablet computer.



Defaults: Select to set the Nudge increment and Auto Jump threshold defaults.



Speed: Select to control how fast the Pro-Stitcher carriage will move through the quilting design. Because the quilting machine regulates its own speed to maintain a specific stitches-per-inch setting, the speed does not directly set the needle speed. Instead it sets how fast the machine moves across the frame system.



Auto Jump: Select to temporarily override the Auto Jump default. Touch the Plus Sign (+) to increase or Minus Sign (-) to decrease the stitches per inch. Alternately, touch the number box and type a value directly and press Enter.



Stitches per Inch: Select to set the stitches per inch. Touch the Plus Sign (+) to increase or Minus Sign (-) to decrease the length of Auto Jump. Alternately, touch the number box and type a value directly and press Enter.



Tieoffs: Select to specify your preferred method for how and when Pro-Stitcher performs tieoffs.



Pullup: Select to specify your preferred method for how Pro-Stitcher performs pullups.



Pause Delay: Select to specify your preferences for how Pro-Stitcher pauses for you to trim threads after starting to stitch the design. Specify either the number of seconds it will pause for you to cut your threads or how many inches it will stitch before pausing for you to cut the threads.



Cut Thread: Select to have your machine use its built-in bobbin thread cutter. (Available for the HQ Infinity only.)



Advanced: Settings that are not likely to be used often can be found by selecting the Advanced button. Some of these settings include communications between the quilting machine and the Pro-Stitcher, Simulation mode, and other options.

HELP TAB RIBBON BUTTONS



Help: Select to open the on-screen Pro-Stitcher reference guide. It has a table of contents, an index, search capability, and hyperlinks between help topics.



About: Select to open the About box. This is where you will find the Pro-Stitcher version number, as well as the key code you'll need if you decide to purchase any digital designs that are encrypted.



FOR THE LOVE OF SEWING

www.BabyLock.com

BLPS4 • Jan2017