

Specifications

Frequency:	433.39 MHz
Security:	128-bit AES encryption
Range:	up to 30 metres
Battery life:	up to 3 years
Battery type:	AA 1.5V 3000 m/a Lithium Battery x2 (included)
Replacement battery type:	Eveready AA 1.5V lithium battery x2



e-LOOP Mini Fitting Instructions

Step 1 – Coding e-LOOP Mini

1. Hold the e-Loop next to the antenna of the transceiver
2. Now press and release the CODE button on the transceiver or gate controller. The e-Loop will flash the Yellow LED and the transceiver will flash the Blue LED 3 times. If coding to the gate controller with LCD screen, the screen will display 'LOOP PAIRED'. The system is now coded.

Step 2 – Fitting the e-LOOP Mini base plate to the driveway

1. Face the arrow on the base plate towards the gate. Using a 5mm concrete masonry drill, drill the two mounting holes 55mm deep, then use the 5mm concrete screws supplied to fix to the driveway.

Step 3 – Fitting the e-LOOP Mini to base plate

(Refer to diagram on the right)

1. Now fit the e-loop Mini to the base plate using the 4 hex screws supplied, making sure the arrow also points towards the gate (this will ensure keyway is aligned). The e-Loop will become active after 3 minutes.

NOTE: Ensure hex screws are tight as this forms part of the water sealing process.

! IMPORTANT: Never fit near high voltage cables, this can effect the e-Loop's vehicle detection and radio range capabilities.

