



English

# Operating Manual for HEKA Incubators



**HEKA-Favorit-Olymp 1500**  
**HEKA-Favorit-Olymp 2200**

**HEKA-Favorit-Olymp 1500/S**  
**HEKA-Favorit-Olymp 2100/S**  
**HEKA-Favorit-Olymp 2200/S**



HEKA-Brutgeräte

Langer Schemm 290  
Tel.: +49 52 44 / 17 18

D-33397 Rietberg  
Fax: +49 52 44 / 1 01 59

E-Mail: [info@heka-brutgeraete.de](mailto:info@heka-brutgeraete.de)

## Preface

The purpose of this manual is to familiarise the reader with the incubator and provide instructions on use.

The operating manual contains important information for the safe, economic, and correct operation of the incubator. Compliance with this manual helps to avoid dangers, minimise repair costs and downtime, and increase the reliability and service life of the machine.

The operating manual is suitable for adding environmental protection regulations to the instructions on the basis of existing national accident prevention regulations.

The operating manual must always be kept at the place of deployment of the incubator. All individuals who are authorised to work with the incubator must read and observe the operating manual. This includes instructions in the following areas:

- Operation
- Troubleshooting
- Care and maintenance
- Transport

The operator must ensure that only authorised persons work with the incubator. The operator must check the incubator for externally visible damage and defects on a daily basis. Moreover, the operator must promptly report any changes that impair the safety. This also includes changes in the operating behaviour. The incubator may only be operated if its condition is flawless.

As a matter of principle, safety equipment must not be removed or disabled.

Should it be necessary to remove safety equipment during preparation, repair, or maintenance, the safety equipment must be reinstalled immediately upon completion of the maintenance or repair work.





The manufacturer does not assume any liability for damages resulting from unauthorised modification of the incubator.

All safety information and warnings on the incubator must be observed.

In addition to the information in the operating manual, the generally applicable safety and accident prevention regulations must also be complied with.

# Structure of the safety instructions

All safety instructions have a uniform structure:

Pictogram	Signal word		
		Meaning	Consequences of non-observance
 General danger	<b>Danger!</b>	Imminent danger to persons	Very severe to fatal injury
	<b>Warning!</b>	Potentially very dangerous situation for persons	Very severe to fatal injury
	<b>Caution!</b>	Potentially dangerous situation for persons	Minor injury
 Dangerous electric voltage			
	<b>Attention!</b>	Potential damage to property	Damage to the device
		Useful information or tip	

## Other notes in the operating manual

### Caution! Risk of injury due to hot surface!



Warning pointing to a risk of injury to the operator from hot surfaces.



Please read and observe the operating manual.



Disconnect the power plug before opening the device.

# General safety instructions!

---

**Caution!** Non-observance of the following safety precautions can result in bodily injury or damage to the incubator.



Apart from the notes listed below, please also observe the general safety and accident prevention regulations.

---



## **Read the operating manual!**

Do not start using the incubator until you have read the associated operating manual.

---

- Do not operate the incubator on the ground. Keep a minimum distance of 50 cm from the ground!
- Do not use the incubator outdoors.
- Do not place the incubator in direct sunlight (counts also for storage and transport).
- Before connecting the incubator, compare the voltage of the power supply with the voltage on the type plate.
- In accordance with the intended use, the incubator may only be used to incubate eggs.
- Never operate the incubator if any part(s) are damaged, if it does not function properly, or if you suspect damage.
- Defective power cables may only be replaced by the manufacturer, its customer service, or a similarly qualified person.
- Maintenance work may only be performed by appropriately trained personnel.
- Repair work and special maintenance work may only be performed by authorised personnel (manufacturer's personnel) or appropriately trained personnel.
- Work on the electrical equipment may only be performed by qualified electricians and persons instructed in electrical engineering (see DIN VDE 0105).
- Working on live parts and equipment is not permitted.
- Conversion or modification of the incubator is not permitted.

# Table of contents

Preface .....	2
Structure of the safety instructions .....	3
General safety instructions.....	4
Table of contents .....	5
1 Description .....	7
2 Setup and connection.....	8
2.1 Loading the incubator.....	10
3 Operating the incubator .....	11
3.1 Control elements / control panel .....	11
3.2 Switching on/off .....	11
3.3 Switching the light on .....	11
4 Programming and settings.....	12
4.1 Temperature.....	12
4.2 Humidity .....	13
4.3 Cooling-Temperature .....	13
4.4 Alarm-Temperature .....	13
4.5 Cool-Down-Cycle .....	14
4.6 Cool-Down-Length .....	14
4.1 Turning (not available in hatchers HEKA Favorit-Olymp 1500/S, 2100/S und 2200/S) .....	15
5 Tips for successful incubation.....	16
5.1 Incubation temperature .....	16
5.2 Humidity .....	16
5.3 Turning the eggs .....	18
5.4 Cooling the eggs .....	19
5.5 Inserting the hatching eggs .....	20
5.6 Putting the eggs into the hatching-trays.....	20
7. Shutting-down after incubation .....	21
6 Maintenance and care .....	21
6.1 Incubation or hatching chamber .....	21
6.2 Technical compartment.....	22
6.3 Float-Valve .....	22
6.4 Replacing the power-cable.....	23
7 FAQs – frequent questions .....	24

8	Disposal .....	25
9	CE- Declaration of conformity .....	26
10	Appendix: Analysis of mistakes at incubation / bad hatching	27
11	Appendix: Incubation periods .....	28


# 1 Description

HEKA-FAVORIT-OLYMP incubators are made of plastic and consist of a two-compartment housing:

The upper part contains the technic (distribution, control, fan, heater, and water supply), and the lower part the incubation or hatching chamber with trays.

The HEKA-FAVORIT-OLYMP models are equipped with a microprocessor control. The temperature, humidity, cooling-temperature, alarm-temperature, cool-down-cycle and cool-down-length are displayed in large red illuminated digits.

Serially the motorised incubators feature the following equipment: automatic turning mechanism (not in hatchers), automatic humidity control, double thermostat with alarm trigger, thermopane glazing.



## 1.1 Specifications

Model HEKA-FAVORIT- OLYMP	1500	2200	1500/S	2100/S	2200/S
Height in cm	148	178	113	137	195
Breadth in cm	137	137	148	148	137
Depth in cm	58	58	87	87	58
Weight ca. in kg	110	135	100	125	145
Power supply	230 V / 50 Hz				
Power demand ca. in Watt (W)	1000	1300	1000	1000	1300

## 2 Setup and connection

The incubator is ready to be connected.

The incubator must be set up as follows:

- Horizontal position
- Must not shake
- Door(s) must open easily
- Must not be set up outdoors and must be at least 50 cm above the ground
- Must be protected from direct sunlight
- There must be at least 5 cm of free space above the device in order to allow air circulation.
- The environment of the incubator should be well ventilated.
- The ventilation slots must not be covered.

A power supply (230 V / 50 Hz) must be available at the installation site. The incubator must not be connected to an offgrid-inverter, which are used in autonomous power-supply like solar-electricity-power-supply.

For the water-intake of the water-cooling (right water-tap) and humidification (middle water-tap) there must be connected those water-taps with water-tubes to your water-mains (1-5bar). The water must be clean and not calcareous, because otherwise the magnetic valve for water-intake can become dirty, which could lead to malfunctions in switching on/off the water-intake. In case of doubt, install a filter and/or decalcification between the water-mains and the water-intake of the



incubator. The water-outtake is effected by the left water-tap – lead this water with a water-tube into a tailrace-pool.

Serially, the incubator is equipped with water-canister and the matching brass-float-valve for low-pressure. The water canister must be filled with distilled water and placed in a position above the incubator (directly onto the top of the incubator or – better – hanging above the incubator).



To enable the water to flow freely, make sure there are no air bubbles in the connection hose.

---

The ideal ambient temperate is 10°C - 20°C. However, smooth function is also guaranteed at an ambient temperature of 5°C - 30°C. Even at ambient temperatures of 40°C these incubators are successfully in use, even if a lower temperature is absolutely recommended.

The humidity must be suitable for the intended purpose. Attention must be paid to the indoor humidity in particular if it is necessary to achieve a low humidity value in the device; the device can humidify but not reduce the humidity. If you choose the correct installation site, humidity values between 35-45% and 85-95% can be reached.

After setting up the device, check the incubation chamber and remove any items such as the thermometer and other accessories that were ordered and stored in the incubation chamber during transport.

After removing all foreign items from the incubation chamber, you can connect the device to the mains.

## 2.1 Loading the incubator

---

Pres the on/off-button

**Ein/Aus**

The incubator is switched off.

---

Check:

If "Off", the dot is illuminated in the display module.



---

### HEKA-Favorit-Olymp 1500, 2200

In these models, the turning frame is electrically positioned horizontally. To activate this process, press the top button on the right-hand side of the control. After charging the device with the hatching eggs the turning frame will remain in the horizontal position. The turning process will automatically be resumed.



Open the door, take out the turning-tray, charge the turning tray – and then put it back into the aluminium-frame carefully.

Close the door and switch-on the incubator.

---

Pres the on/off-button

**Ein/Aus**

The incubator is switched on.

---


Check:

When the incubator is "On", the actual temperature appears in the display module, and the fan(s) start(s) running.

---

### 3 Operating the incubator

#### 3.1 Control elements / control panel



- 1 Only dot: „ready“ otherwise: decimal-point
- 2 Display for values (°C und %) and time (minutes or hours)
- 3 LED-indicators
- 4 Light on/off and in adjust-mode: save
- 5 Select program and set values
- 6 Display of the current value
- 0 Power on/off

#### 3.2 Switching on/off

Press the on/off-button

**Ein/Aus**

Power on/off

Check:

When "On", the actual temperature is displayed in the display module. The control status is displayed by the LED indicators.

In the active state, the corresponding LED flashes.



LED lit: the heater is not heating  
LED flashing: the heater is heating

#### 3.3 Switching the light on

Press **S**

The interior light is switched on.

The lamp automatically goes off after 1 minute.





The light phase is limited to 1 minute in order to prevent excessive emission of heat to eggs close to the lamp.

For a shorter lighting period:

Press **S**

The lamp goes off immediately.

## 4 Programming and settings


As a general rule, you need to press the  - or  - button to select the desired value for programming.



The current actual values appear in the right-hand digital display field under temperature and humidity. The humidity display is marked by the decimal point.

For the cooling-temperature, alarm-temperature, cool-down-cycle and cool-down-length the stored values are displayed.

In the basic mode, the display always shows the actual temperature.

---

Button  The stored value is displayed.

Button  or  Set the desired value.

Button  drücken The new value is saved.


Check: On the display, "SSS" appears for about 0.5 seconds.

The new value is saved permanently and will be retained even in the event of a power failure.

---

### 4.1 Temperature


---


Press button  The target temperature is displayed.

The target value is 36°C to 39°C


---

Press button  or  Set new target value:

 = higher temperature

 = lower temperature

---


Press button  The new value is stored permanently.

Check: On the display, "SSS" appears for about 0.5 seconds.

---

Press button  The stored value is checked.











---

Press button  The control returns to the normal starting position.

---

## 4.2 Humidity

---

Press button  or 	Until the "Humidity" LED is lit
Press button 	The stored target value is displayed.
Press button  or 	Sets new target value:  = higher humidity  = lower humidity
Press button 	The new value is stored permanently.
Check:	On the display, "SSS" appears for about 0.5 seconds.
Press button 	The stored value is checked.
Press button 	The control returns to the normal starting position.

---

## 4.3 Cooling-Temperature

The adjustment takes place as described under "Temperature". The cooling-temperature must be set at least 0,1°C higher than the incubation-temperature. If the cooling-temperature is reached, the water-cooling is activated. If the incubation-temperature then falls again below the cooling-temperature, the cooling is deactivated – the cooling-effect leads to temperature falling by 0,3°C until the microprocessor-control then again precisely regulates the temperature.

## 4.4 Alarm-Temperature

The adjustment takes place as described under "Temperature". The alarm-temperature should be set at lesat 0,5°C above the incubation-temperature.

---


### Caution!



If the incubator goes up to the set alarm-temperature, the emergency cutdown is activated and all heating-elements are deactivated until the alarm is reset.

---

### Reset the alarm

Press the on/off-button  2x : the alarm disappears.



An alarm can be caused, if the door is opened for too long; because heat and humidity escapes and the temperature and humidity sensors detect incorrect values.

The microprocessor now attempts to compensate for the low values and this causes the heating systems to heat up considerably. After closing the door, the extremely hot heating elements take effect and this causes an excess temperature for a few minutes so that an alarm is triggered.

---



### Caution!

Switch off the incubator before opening the incubator doors in order to prevent the alarm from being triggered as described above.

---

Press the on/off-button **Ein/Aus**: the device is off

## 4.5 Cool-Down-Cycle

The setting is as described previously for "Humidity".

The display is in hours.

Example: Cooling time = 12

The eggs are cooled 2x a day (every 12 hours).

Cooling time = 24

The eggs are cooled 1x a day (every 24 hours).

---

### Caution!



The cooling period must be set.

Cooling does **not** occur if you do not set a cool-down-length (value: 0; see below)

---

## 4.6 Cool-Down-Length

The adjustment takes place as described under "Humidity". The values are displayed in minutes (adjustment range: 10 – 120 minutes).

The cooling period is the time during which the heaters are turned off.

The cooling period of the incubator depends heavily on the ambient temperature.

---



Normally, cooling is not performed at the hatching stage. Therefore, the cooling period should be set to 0 minutes during this time.

---

**Caution!** Do only use the automatic cool-down, if the water-cooling is not

---



necessary. Because the cool-down only switches off the heating-elements, the cool-down has no effect and there is even risk, that the temperature rises at cool-down. Then, cool-down manually by opening the door (switch-off the incubator!) and/or taking out the trays.

#### 4.1 Turning (not available in hatchers HEKA Favorit-Olymp 1500/S, 2100/S und 2200/S)

##### Turning-Timer



- 1 Setting = clock-symbol (don't change position!)
- 2 Minute hand
- 3 Hour hand

The turning-timer is preset to 12 turnings per day, so that you don't have to change these settings. If you want to change settings, consider the following hints:

Set with the minute hand (2) the right time; the hour hand slides automatically with every turning of the minute hand.

With every change of impressed and expressed riders one turning is executed; i.e. for the preset/advised turning every 2 hours, there must be impressed and expressed in change each 8 riders. If you want to set (for example) only hourly turning (= 24 turnings per day), there must be impressed and expressed always each 4 riders.

Please not, that serially the turning can't be deactivated, because the incubators are not designed for hatching. To take out the trays for candling, weighing or putting the eggs into hatching-trays, read chapter 2.1.

If desired, we can install a switch for deactivating the turning. Then you can activate/deactivat the turning after having brought the turning-frame into horizontal position like described in chapter 2.1.

## 5 Tips for successful incubation


### 5.1 Incubation temperature

Generally, we recommend a temperature of 37,8°C. For incubating bantam, quails or pheasants (partly also ducks and geese) we recommend 37,5-37,6°C - for raptors, parrots and parakeet a temperature of 37,0-37,2°C. If different (poultry-)eggs are incubated together, you should set a temperature of 37,7-37,8°C. Ostriches, rheas and nandus are an exception with much less temperature.

### 5.2 Humidity

Apart from the temperature, the incubation humidity plays a significant role for the incubation results. During incubation, every egg must lose weight. The weight loss must amount to at least 15% of the fresh egg. A weight loss of 17% is ideal. You can check this with a special accuracy weighing machine – breeders of very valuable (and thus mostly sensitive, difficult to incubate) animals weigh every single egg every day and adjust the humidity according to the weight-loss to come to 100% hatching success (the higher humidity, the less weight-loss; and vice versa).

With the weight-loss comes along a steadily growing air cell. This can be checked with a candling-lamp to adjust the humidity (if necessary; the less humidity, the bigger the air cell). The air cell must be steadily growing over the complete time of incubating – until shortly before hatching it takes about one-third of the egg.



*Fig.: Optimum size of the air cell in a chicken-egg (incubation-length: 21 days)*

Due to the different characteristics of the eggshell, a different humidity is necessary for various kinds of fowl to come to the right weight-loss and size of the air cell. For example, a chicken egg (at the same humidity) loses weight much more slowly than a waterfowl egg.

The weight-loss even varies for chicken of different types, which means that the eggs normally should be incubated at different humidity levels. The weight loss is also determined by the size of the egg. In practice incubating with different values of humidity mostly is not possible. Thus, we recommend well-proven mean values, which experiential lead to very good hatching-results:



Chicken and bantam eggs	53 %
Goose eggs	57 – 58 %
Duck eggs	60 – 63 %
Pheasant eggs	48 – 53 %
Quail eggs	53 %
Ostrich eggs	19 – 23 %
Emu eggs	40-45 %
Rhea eggs	53-58 %

But please note, that there are also considerably outliers because of the characteristics of the eggshell (e.g. Marans: 40-45%) and/or the climate of their natural habitat (e.g. Crested-partridge 65-70%; Muscovy ducks 50-55%).

For parakeet and parrot eggs general recommendations are not possible, because the required humidity varies extremely. The required humidity depends on the location of their natural breeding areas (humid tropics or dry savanna). For incubating species from very arid/dry habitats normally you need a humidity as low as possible (viz.: no water in the incubator/water basin; air-vent(s) fully open). Only in the hatching stage the humidity is raised as normal.



When you take eggs out of the incubator for weighing or candling and thus you switched on the light – don't forget to switch it off again.

Light should not be switched on (when door closed) longer than 5 minutes.

---



In case of failing water-supply to the incubator (because of missing water in the tank or stuck valve) you must set the humidity to „0“, because otherwise the alarm will be activated.

---

### 5.3 Turning the eggs

Expert opinions vary considerably concerning the turning interval.

The purpose of turning the eggs is to prevent the embryo from sticking to the egg and dying. This objective already is reached by turning the eggs three times within 24 hours. On the other hand, practical experience has shown that continuous turning at intervals of 2 hours (setting: turning-cycle 120, turning 3) has an extremely positive effect on the incubation results.

Chicken eggs must be turned from the third day after insertion, and duck and goose eggs from the fourth day.

In the last 3-4 (depending on the incubation period) of hatching, the turning must be deactivated (setting: turning-cycle 120, turning-length 0).



Though this is not necessary, the hatching eggs can be turned from the first day without being damaged.

---

## 5.4 Cooling the eggs

In this field, too, experts express different opinions.

However, it is undisputed that the eggs of wildfowl and waterfowl must be cooled. The cooling strengthens the embryo in the egg. The cooling period depends heavily on the ambient temperature.

As a general rule, wildfowl and waterfowl must be cooled once a day, at least to an extent that the egg no longer feels warm and the temperature display drops below 30°C.

Especially when incubating goose eggs, cooling is an important factor that has a decisive effect on the hatching result.

We recommend cooling goose eggs once a day from the 11th to the 27th incubation day (when incubation period is 30 days). The cooling-length should be at least 30 minutes, though longer cooling phases are not detrimental.



If the device stands in a temperate room, a cooling period of about 60-90 minutes is necessary.

---

For a hen's eggs, cooling in HEKA-EURO-LUX incubators is not absolutely necessary, but recommended.

The strengthening of the embryo results in a shorter hatching phase, both for wildfowl and for waterfowl.



The cooling times are shorter for chicken eggs. We recommend 20-30 minutes.

---

Generally, we consider one cooling cycle per day to be sufficient.

Airing by opening the door is not necessary in HEKA incubators. The incubated eggs are supplied with an adequate amount of oxygen by the fan(s) and the air-vent(s).

For good hatching results, it actually makes sense to keep the device closed whenever possible and only to open it if you need to take some action such as candling, weighing, reloading, etc.

## 5.5 Inserting the hatching eggs

After setting the correct humidity and temperature values, place the eggs (horizontal or slightly vertical with air cell on top) on the incubation trays in the incubator.

---

### Attention!



Handle the hatching eggs with care. Especially hatching eggs whose incubation process has started are very sensitive.

---

Please make sure that the eggs are not too old. (max. 10 - 14 days). If you store the eggs more than 4-5 days: daily turn the eggs, don't store too dry, optimum temperature: 12-15°C.

## 5.6 Putting the eggs into the hatching-trays

3 days before the date of hatching the eggs should be put into the hatching trays or into the hatcher; the eggs must not be turned anymore. Switch off the turning. In the hatching stage all eggs need a higher humidity than in the incubation stage. Humidity should be 20-25% higher than before in the incubation stage (e.g. from 53% to 73-78%). Raising of the humidity should be made in steps. First day 10% more, next day again 10% more – and when the chicks begin to come out of the eggs again some percentage more.



Don't raise the humidity to more than 90% - otherwise there's risk of chicks not drying and having water (condensed) on the bottom of the incubator. When the pane of a double-glass door begins to steam up, reduce the humidity a bit. Only for waterfowl and other eggs, which already needed very high humidity in the stage of incubating, it can be necessary or helpful to have such a high humidity (of 80-90%), that the double-glass pane begins to steam up.

If you use simple hatching trays (without cover), place them central, so that to the door and to the back you just have little space left. Nevertheless, with very agile chicks it can happen, that some hop over the edge of the hatching tray. To avoid risk of drowning in the water basin, cover the water basin with mesh-wire or net – or alternatively use our pedigree-hatching-trays with cover and partitions.

---

## 7. Shutting-down after incubation

When you have had hatching in the incubator and plan to put in eggs shortly, make at least a light maintenance and care according to chapter 9. Empty the water-reservoir (or disconnect it from the water-mains) and also empty the stainless-steel water-basins (water-heating and floater) inside the incubator – and set the humidity to “0”, so that the incubator won’t activate the water-heating. Run the incubator without water until the humidity has fallen to that value, which you need for the next incubation.

If you don’t plan to put in eggs shortly, make maintenance and care like described in chapter 9. Switch-on again the incubator after maintenance and care (without water in the water-basins and humidity set to “0”) and run it until the humidity doesn’t fall anymore. Depending on the room, weather conditions and season this will be 30-50%. Thus you avoid, that high humidity (from last hatching or from cleaning) remain in the incubator without possibility to really get it out while storage / until next incubation.

Afterwards switch off and unplug the incubator.

## 6 Maintenance and care

### 6.1 Incubation or hatching chamber



We recommend cleaning the hatching device or incubator thoroughly and disinfecting it after every major hatch.

---

#### Attention!



After disinfection, the incubator must be ventilated according to the manufacturer's instructions. We recommend waiting a few days before using the hatching device/incubator again.

---

The incubation chamber and the incubation trays must be cleaned and disinfected regularly. To do this:

- Open the hatching device/incubator
- Remove the hatching/incubating trays
- Clean and disinfect the hatching/incubating chamber and the hatching/incubating trays (with “Amo-Des” or “Euphagol”)
- Reinstall the hatching/incubating trays

## 6.2 Technical compartment



**Disconnect the power plug before opening the cover.**

---

### **Caution! Dangerous voltage!**



Before cleaning, disconnect the power plug to make sure no voltage is present.

---

### **Caution! Danger of injury from hot surface!**



Before opening the lid, wait for approximately 10 minutes until the heating elements have cooled off.

---

Regularly clean and disinfect the "technology compartment" under the lid:

- Unscrew the screws at each corner of the incubator cover (total of four).
- Lift the lid, exerting slight pressure.
- Empty the stainless-steel water-basins
- Remove incubation dust, incubation dirt, and residue
- Disinfect the hatching device/incubator (with "Amo-Des" or "Euphagol")
- Close the lid.
- Re-tighten the screws.

## 6.3 Float-Valve

Due to knocks during transport, undesigned adjustment at cleaning or impurity it can happen, that the water supply does not work correctly. Open the lid of the incubator according to the description and the safety warnings in chapter 9.2 (maintenance and care: technical compartment) and Follow these steps:

1. Check, if both stainless-steel water-basins are filled up to ~0,5-1cm below the edge of the water-basins. If only the basin with the water-heating is not filled sufficiently, the tube between the two basins is blocked and must be cleaned. If both basins are not filled sufficiently, go on with the next point:
2. Check, if the brass-float-valve is exactly vertical and does not stuck in its table-track (at the basin). If the floater "jumped" out of its position or got stuck, just correct its position. If the water-reservoir is on/over the incubator, water directly will (slowly) run into the basin(s). Wait, until the final filling-level is reached. If water seems to rise above the edge of the basins, adjust the brass-float-valve to a slightly lower position (with the wing-nut at the arm of the floater).

If this should not help, go on with the next point:

3. Close the lid of the incubator and set the humidity to “0”. Run the incubator as long as possible (at least 60min.).
4. Take away the lid of the incubator again.
5. Unscrew the wing-nut of the brass-float-valve.
6. Pull the front-bar of the floater to the highest position (= max. filling-level).
7. Tighten the wing-nut.
8. With the screw-thread at the back-part of the floater you also adjust the filling-level of the water-basins. This screw must not be tightened completely! The more you unscrew it, the higher the filling-level (and vice versa).
9. Let water run in until the water-basins are filled sufficiently (~0,5-1cm below the edge) and adjust the wing-nut and/or the screw-thread so that this water-level is hold.
10. Don't let the incubator be unobserved, because overflowing water can lead to damages of the incubator.
11. Empty the water-basin of the water-heating and check, if the right filling-level is reached again without making any adjustments. Failing this: repeat steps 7-10.
12. Close the lid and screw it. Set humidity to the desired value.

If this proceeding does not help, the seal of the brass-float-valve is dirty or torn or the pipe-fitting for the water-tank in the back-wall of the incubator is dirty. Unplug the water-tank at the back of the incubator and also unscrew the brass-float valve inside the incubator (point 9). Clean the hole in the pipe-fitting (which now still is mounted in the back-wall of the incubator) – if this hole is blocked by debris, no water can run into the incubator. Also clean the black seal in that part of the brass-float-valve, which you have demounted. If this seal should be swollen or torn (durability: ~10 years), it must be changed, because a swollen seal can't open the valve wide enough.

## 6.4 Replacing the power-cable

---

### Attention!



Defective power cables may only be replaced by the manufacturer, its customer service, or a similarly qualified person.

---

## 7 FAQs – frequent questions

- Why do I need to set the device up 50cm above the floor?"  
→ To protect it against flooding.
- "The device is not turning."  
→ 1. The device does not turn continually, but for 3 minutes every 2 hours. Check in 2 hours, if the position of the frame/trays has changed.  
→ 2. You have entered the wrong values in the turning program. Refer to Chapter 4.3 and 4.4 on p.14f for details.
- "The actual humidity is above the set humidity level."  
→ The device only has a humidifier; it does not have a dehumidification-system. Operating the heater and ventilator can bring the humidity down to ~10% below the ambient humidity. If necessary, install the device in a drier room. If you need an extremely low humidity level for exotic birds, remove the water from the water-tank and the stainless steel basins in the technical compartment. And set the humidity to "0", so that the incubator won't try to make humidity.
- "The actual humidity is below the set humidity level."  
→ Check, that the tube does not runs below the brass-float-valve and that there are no air bubbles in the tube (chapter 2)  
→ Check, that the water-tank is filled enough with water  
→ Check the brass-float-valve (chapter 7.3)  
→ If both stainless steel tanks are filled with water and you are still unable to achieve sufficient humidity, this is due to the ambient temperature being too high. To avoid excess temperature in the device, the water heater for generating humidity is only actuated if the device needs to generate more heat. You can check that the humidifier is working correctly by opening the door and thus allowing cold air to enter the device. The device now needs to generate more heat, which also generates humidity (LED for "Humidity" flashes, water heater becomes warm). Place the device in a colder room to achieve the preset humidity value. Additionally, opening the air-vent(s) can help as this allows warm air to escape from the device so that it needs to generate more heat.



## 8 Disposal



**WEEE reg. no.:**  
**DE 96968236**

The sticker with the crossed out wheeled bin on this product indicates that this product must not be disposed of as domestic waste. To avoid a potential impairment of the environment or human health, this product must not be treated as domestic waste but must be recycled in an eco-friendly manner.

For information concerning disposal, please contact the manufacturer of the product. We will have your product collected by a forwarding agent.

HEKA-Brutgeräte      Tel: +49 5244 1718  
Langer Schemm 290      Fax: +49 5244 10159  
D-33397 Rietberg

## 9 CE- Declaration of conformity

**The manufacturer** HEKA-Brutgeräte

Address: Langer Schemm 290  
33397 Rietberg

### hereby declares that

Products HEKA-Favorit-Olymp plastic-incubator

Models Incubators: Favorit-Olymp 1500, 2200,  
Hatchers: Favorit-Olymp 1500/S, 2100/S,  
2200/S

### is in conformity with the following directives:

- 98/37/EG Machinery Directive
- 2006/95/EG Low Voltage Directive
- 2004/18/EG EMC Directive

The following standards were used to assess the conformity:

- DIN EN ISO 12 000-1
- DIN EN ISO 12 000-2
- DIN EN 60 204-1
- DIN EN 60 335-1
- DIN EN 60 335-2-71



The conformity of the products with the above-mentioned standards and directives is confirmed with the CE mark.

A handwritten signature in black ink, appearing to read 'Christa Hemel', written in a cursive style.

Rietberg, 17.11.2012

Christa Hemel

## 10 **Appendix: Analysis of mistakes at incubation / bad hatching**

Normally, 5-10% of the eggs are unfertilized. If less than 70-80% of the remaining chicks hatch, you should analyse the reason(s) to have better success at next hatching. Analysing the symptoms first of all allow the following conclusions (further reading in specialized books), whereof “too high humidity in incubating stage” is the absolutely most frequent mistake.

### **Mostly died in first week:**

Wrong storage of eggs, parental predisposition, virus infection, incubation-temperature much too high/low, no turning, (too long) cooling of eggs

### **Mostly died in second week (without huge loss in first week):**

Huge parental vitamin deficiency, infection in incubator, overheating or undercooling at candling, too high (seldom: too low) humidity at incubation, oxygen deficiency

### **Mostly died in third week before beginning of respiration by lung (without huge loss before):**

All a.m. factors, especially too high or too low humidity in incubation stage

### **Died at hatching, eggshell circular scored:**

Too low humidity at hatching stage

### **Died at hatching, eggshell pierced (central or astride; liquid leaves at pierced point):**

Too high humidity at hatching stage

### **Hatched chicks stick at eggshell:**

Too low humidity (especially at hatching stage)

### **Hatched chicks are clammy:**

Too high humidity at incubation stage

### **Hatched chicks uncleanly cut the cord:**

Too high temperature or oscillations in temperature

### **Hatched chicks with stressed respiration:**

Too high humidity in incubation stage, too less humidity at hatching stage, temperature too high at hatching stage

### **Hatched chicks malformed:**

Temperature too high/low or oscillating, heredity

# 11 Appendix: Incubation periods

## Domesticated Birds:

Bantam:	19-21 Days
Chicken:	21 Days
Ducks:	28 Days
Geese:	28-35 Days
Guineafowl:	27 Days

Muscovy Ducks:	35 Days
Peacocks (all species):	28 Days
Pigeons:	16-18 Days
Turkeys:	28 Days

## Wild Birds

Mallards:	25-26 Days
Partridges:	23 Days
Pheasants:	24 Days

Quails:	23 Days
Vulturine Guineafowl:	23-24 Days

## Flightless Birds

Emu:	57-62 Days
Rhea:	35-40 Days

Ostrich:	35-42 Days
----------	------------

## Pheasants

Alectoris:	23-26 Days
Amherst's Pheasant:	23 Days
Arborophila:	20-24 Days
Barbary Partridge:	25 Days
Black Francolin:	18-19 Days
Blood Pheasant:	28 Days
Blue Eared Pheasant:	26-28 Days
Brown Eared Pheasant:	26-27 Days
Bulwer's Pheasant:	25 Days
Copper Pheasant:	24-25 Days
Crested Argus:	25 Days
Crested Fireback:	24-25 Days
Crestless Fireback:	24-25 Days
Cheer Pheasant:	26 Days
Edward's Pheasant:	21-23 Days
Elliot's Pheasant:	25 Days
Gallopheasants:	23-25 Days
Golden Pheasant:	23 Days

Great Argus:	25 Days
Himalayan Snowcock:	27-28 Days
Hume's Pheasant:	27 Days
Junglefowl:	19-21 Days
Koklass Pheasant:	21-23 Days
Lewis's Silver Pheasant:	23 Days
Mikado Pheasant:	26-28 Days
Monals:	27 Days
Peacock-Pheasants:	21-22 Days
Red-legged Partridge:	23-24 Days
Reeves's Pheasant:	24-25 Days
Salvadori's Pheasant:	22-25 Days
Sand Partridge:	27 Days
Silver Pheasant:	25 Days
Sri Lankan Junglefowl:	18 Days
Swinhoe's Pheasant:	25 Days
Tragopans:	28 Days
White Eared Pheasant:	24 Days

**Quails**

Banded Quail:	21-23 Days
Beared Tree Quail:	28 Days
Brown Quail:	20-22 Days
California Quail:	22-23 Days
Crested Bobwhite:	22-23 Days
Crested Partridge:	18-20 Days
Harlequin Quail:	14-16 Days
Japanese Quail:	18 Days
King Quail:	18 Days
Long Tailed Quail:	28 Days

Montezuma Quail:	25-26 Days
Mountain Quail:	24-25 Days
New Zealand Quail:	21 Days
Northern Bobwhite:	21 Days
Painted Bush Quail:	16-18 Days
Rain Quail:	18-19 Days
Scaled Quail:	23 Days
Spot-Winged Wood-Q.:	18-19 Days
Yucatan Bobwhite:	23-24 Days

**Grouse**

Black Grouse:	26 Days
Dusky Grouse:	25 Days
Greater Prairie Chicken:	24-25 Days
Hazel Grouse:	25 Days
Red Grouse:	22 Days
Rock Ptarmigan:	20-21 Days

Ruffed Grouse:	24 Days
Sharp-tailed Grouse:	24-25 Days
Spruce Grouse:	21-22 Days
Western Capercaillie:	26-28 Days
Willow Ptarmigan:	23 Days

**Swans**

Bewick's Swan:	30 Days
Black-necked Swan:	36 Days
Black Swan:	36 Days
Coscoroba Swan:	35 Days

Mute Swan:	37 Days
Trumpeter Swan:	33 Days
Tundra Swan:	36 Days
Whooper Swan:	36 Days

**Geese**

Bar-headed Goose:	28 Days
Barnacle Goose:	28 Days
Brant:	22 Days
Canada Goose:	28 Days
Emperor Goose:	24 Days
Fighting Geese:	28-31 Days
Greater White-fronted Goose:	26 Days
Greylag Goose:	28 Days

Hawaiian Goose:	29 Days
Lesser White-fronted G.:	25 Days
Pink-footed Goose:	28 Days
Red-breasted Goose:	25 Days
Ross's Goose:	23 Days
Snow Goose:	25 Days
Taiga Bean Goose:	25-29 Days
Toulouse Goose:	30 Days

**Anserinae**

Andean Goose:	30 Days
Ashy-headed Goose:	30 Days
Blue-Winged Goose:	31 Days

Kelp Goose:	32 Days
Orinoco Goose:	30 Days
Ruddy-headed Goose:	30 Days

Egyptian Goose:	30 Days	Upland Goose:	30 Days
Freckled Duck:	26-28 Days		
<b>Whistling Ducks</b>			
Black-bellied Whistl. Duck:	28 Days	Spotted Whistling Duck:	31 Days
Fulvous Whistling Duck:	28 Days	Wandering Whistl. Duck:	30 Days
Lesser Whistling Duck:	28 Days	West Indian Whistl. Duck:	30 Days
Plumed Whistling Duck:	30 Days	White-faced Whistl. Duck:	28 Days
<b>Anatidae</b>			
Cape Barren Goose:	30 Days	Ruddy Shelduck:	30 Days
Radjah Shelduck:	30 Days	Shelduck:	30 Days
<b>Perching Ducks</b>			
Australian Wood Duck:	30 Days	Mandarin Duck:	32 Days
Knob-billed Duck:	30 Days	Wood Duck:	32 Days
<b>Eider Ducks</b>			
Common Eider:	24 Days	Spectacled Eider:	24 Days
King Eider:	22 Days	Steller's Eider:	24 Days
<b>Teals</b>			
Baikal Teal:	24-28 Days	Grey Teal:	25 Days
Blue-winged Teal:	24 Days	Hottentot Teal:	24 Days
Brazilian Teal:	25 Days	Marbled Duck:	25 Days
Bronze-winged Duck:	30-31 Days	Puna Teal:	26 Days
Brown Teal:	28 Days	Red-billed Teal:	25-28 Days
Cape Teal:	25 Days	Ringed Teal:	24-28 Days
Chestnut Teal:	26 Days	Sharp-winged Teal:	24 Days
Cinnamon Teal:	24 Days	Silver Teal:	25 Days
Garganey:	24 Days	Yellow-billed Teal:	24 Days
Green-winged Teal:	24 Days		
<b>Shovelers</b>			
Australian Shoveler:	24 Days	Nordic Shoveler:	25 Days
Cape Shoveler:	26 Days	Red Shoveler:	25 Days
New Zealand Shoveler:	26 Days	Shoveler:	26 Days

**Wigeons**

American Wigeon: 24 Days  
 Chiloé Wigeon: 26 Days  
 Eurasian Wigeon: 25 Days

Falcated Duck: 25 Days  
 Gadwall: 26 Days

**Oxyurinae**

Masked Duck: 24 Days  
 Ruddy Duck: 24 Days

White-backed Duck: 26 Days

**Mergansers**

Goosander: 30 Days  
 Hooded Merganser: 28 Days

Red-breasted Merganser: 30 Days  
 Smew: 28 Days

**Goldeneyes**

American Goldeneye: 28 Days  
 Bufflehead: 22 Days

Eurasian Goldeneye: 28 Days  
 Barrow's Goldeneye: 30 Days

**Pintails**

Chilean Pintail: 25 Days  
 Northern Pintail: 22-23 Days

White-cheeked Pintail: 25 Days  
 Yellow-billed Pintail: 25-26 Days

**Mallards**

African Black Duck: 28-30 Days  
 American Black Duck: 26 Days  
 Hawaiian Duck: 26 Days  
 Indian Spot-billed Duck: 26 Days  
 Laysan Duck: 26 Days  
 Mallard: 26 Days

Mottled Duck: 26 Days  
 Pacific Black Duck: 26 Days  
 Philippine Duck: 26 Days  
 White Pekin: 28 Days  
 Yellow-billed Duck: 27 Days

**Pochards**

Baer's Pochard: 27 Days  
 Canvasback: 26 Days  
 Common Pochard: 27 Days  
 Ferruginous Duck: 26 Days  
 Greater Scaup: 24-28 Days  
 New-Zealand Scaup: 26 Days

Red-crested Pochard: 27 Days  
 Redhead: 28 Days  
 Ring-necked Duck: 23-26 Days  
 Rosy-billed Pochard: 28 Days  
 Southern Pochard: 26 Days  
 Tufted Duck: 25 Days

**Scoters**

Common Scoter: 28 Days  
 Harlequin Duck: 30 Days

Long-tailed Duck: 23 Days  
 Velvet Scoter: 28 Days

**Doves**

Collared Dove:	14 Days
Common Ground Dove:	12-14 Days
Common Wood Pigeon:	15 Days
Crested Pigeons:	17-19 Days
Diamond Dove:	13 Days
Domestic Pigeon:	17 Days
Eurasian Collared Dove:	16 Days
European Turtle Dove:	14 Days

Galápagos Dove:	16 Days
Gallicolumba:	15 Days
Laughing Dove:	13 Days
Mourning Dove:	15 Days
Namaqua Dove:	14-15 Days
Rock Dove:	17 Days
Western Crowned Pigeon:	28 Days

**Parrots / Parakeets / Oscine Birds**

Amazonas Parrots:	24-29 Days
Black-Capped Lory:	23-26 Days
Blue-and-yellow Macaw:	28 Days
Blue Eyed Cockatoo:	28 Days
Blue-winged Macaw:	24-26 Days
Budgerigar:	18 Days
Citron-crested Cockatoo:	24 Days
Domestic Canary:	13 Days
Galah:	23 Days
Gang-gang Cockatoo:	25-27 Days
Grey Parrot:	26-30 Days
Hyacinth Macaw:	24-29 Days
Large Parrots:	23-25 Days
Little Corella:	29 Days
Long-billed Corella:	29 Days
Macaws:	26-28 Days

Major Mitchell's Cockatoo:	27 Days
Medium Parrots:	18-20 Days
Red-tailed Black Cockat.:	28 Days
Red-vented Cockatoo:	28 Days
Salmon-crested Cockatoo:	30 Days
Scarlet-chested Parrot:	18 Days
Solomon Island Parrot:	28-30 Days
Sulphur-crested Cockatoo:	30 Days
Sun parakeet:	26 Days
Tanimbar Corella:	28 Days
Western Corella:	23-24 Days
White Cockatoo:	28-30 Days
Yellow-crested Cockatoo:	24 Days
Yellow-naped Amazon:	25-27 Days
Yellow-tailed Black Cock.:	29 Days

**Birds of Prey / Owls**

Amur Falcon:	28-30 Days
Barn Owl:	32 Days
Black Kite:	32 Days
Common Kestrel:	30 Days
Eurasian Eagle-owl:	33 Days
Eurasian Pygmy Owl:	28-30 Days

Gyrfalcon:	30-32 Days
Northern Goshawk:	35-37 Days
Peregrine Falcon:	34 Days
Red Kite:	35 Days
Tawny Owl:	32 Days

**No responsibility is taken for the correctness of this information!**

**You are welcome to tell us corrections and additions!**









