

# TRIUMPH CAMSHAFT BUSHING LINE REAMER KIT INSTRUCTIONS



Congratulations on your new tool kit! - should you have any questions please contact us

### TRIUMPH 350 / 500 (UNIT) INSTRUCTIONS

- 1. Install both camshaft bushings (2) into the drive-side crankcase half
- 2. Bolt both crankcase halves together
- 3. Insert the reamer into the pilot (use heavy duty grease on shaft)
- 4. Take the pilot / reamer and insert it into the timing side camshaft housing
- 5. Begin to ream your drive side bushing (always apply lube or oil when cutting; cut in a clockwise direction)
- 6. Check your work and clean thoroughly



Please see the backside of this page for more details



## TRIUMPH 650 / 750 (UNIT) & 500 (PRE-UNIT) INSTRUCTIONS

- 1. Install all camshaft bushings into both cases; drive side and timing side
- 2. Lube the 7/8 ball bearing and push the chrome ball bearing through both timing side camshaft bushings; you may need to do this a few times to allow the pilot to fit
- Once the timing side bushings are broached, you will need to unbolt your crankcase halves
- 4. Insert the reamer sleeve (pilot) from the outside of the the timing bushing
- Insert your 13/16 reamer through the inside of the timing bushing and bolt your crankcase halves back together
- Proceed to ream your drive side bushing until both are sized (always apply lube or oil when cutting; cut in a clockwise direction)
- 7. Check your work and clean thoroughly

### **QUICK TIPS**

You may find that the steel pilot may be a tight fit on the 13/16" reamer as it gets closer to the cutting flutes; this is caused by the 13/16" reamers shaft being sightly tapered and larger towards the cutting flutes. We try to keep no more .0013" clearance on all pilots once sized to allow a smooth and rigid set-up. The slight interference near the taper is nothing to worry about..

To drive the 13/16" reamer I like to use a large drill chuck; the shaft diameter is approx 5/8". There are many other ways to drive the reamer. I recommend performing the cutting by hand and monitoring your work at all times

When removing the 13/16" reamer from the sized bushing, make sure to rotate the reamer in as clockwise direction as you begin to remove the reamer. NEVER turn the reamer counterclockwise

#### <u>QUESTIONS?</u>

sales@classicbritishspares.com or (661) 951-2120 10-16-2020 www.classicbritishspares.com