


TC580 Display Manual

1. Outlook&Size:












2. Display Area:
















3.Extended Function Display Summary:







Item / Function	TC428	TC430	TC470	TC480	TC488	TC580
Battery Indicator	⊙	⊙	⊙	⊙	⊙	⊙
Auto Dormancy	⊙	⊙	⊙	⊙	⊙	⊙
3 Speed PAS	⊙	⊙	⊙			
Manual Cruise		⊙				⊙
Pedal/Throttle Propel	⊙	⊙	⊙			⊙
5 Speed PAS				⊙	⊙	⊙
Instantaneous Power				⊙	⊙	⊙
Speed				⊙	⊙	⊙
Trip/ODO				⊙	⊙	⊙
Average Speed					⊙	
Intelligent Error Codes				⊙	⊙	⊙
KM/Mile Switch				⊙	⊙	

4. TC-580 Screen Display:

Display Contents	Function	Description
	Speed	Unit: KM/H or MP/H
	ODO/TRIP	ODO (Odometer/ Trip switch by the function key
	Battery Indicator	SOC(State of Charge) Display
	Brake instruction	Display when brake. If display when not brake, can judge for brake fault
	Light instruction	Display, lighting
	Motor Fault	Display,motor hall fault
	Controller Fault	Display,controller failure
	Power	Power Display
	PAS Instruction	1-5 file display speed PAS

5. Operating instructions

Key	Operation	Display	Function	Description
	1x briefly		ON	Click can turn on TC580. After this, Illumination is switched on/off with a key press
	Again 1x briefly		on/off	on /off the light
	2x briefly		Trip mileage reset	Continuous press 2 times TRIP mileage reset
	1x long		OFF	Pressing this button for longer switches the display off
	1x briefly		PAS increase	Every click, PAS increase a gear, total of five gear
	2x briefly		ODO mileage	Continuous press 2 times, ODO mileage is displayed
	1x long		ODO mileage reset	Long press 2 seconds ODO mileage reset
	1x briefly		PAS reduce	Every click, PAS reduce a gear, total reduce of five gear
	2x briefly		Trip mileage	Continuous press 2 times, TRIP, mileage is displayed
	1x long		6KM/H	Long time press to enter the 6km/h implement mode

Set the function 1 (Wheel diameter setting)				
	1×long		Wheel diameter	See the following description
	<p>Wheel diameter setting: Red circle marked two keys two keys at the same time long press 5 seconds to enter the wheel diameter settings, the default speed display area flashing for the instrument default factory rotation of the characters, 16-28 inch of any one value), (The upper right corner of the instrument will appear icon ) , that has entered the set wheel interface, while releasing the two keys, and then through the "plus" or "minus" key to adjust to the required value of the wheel diameter, adjustable The range is (16-28 inch) to adjust to the required wheel diameter value, and then press the red circle marked two keys for 5 seconds until the speed display area character zero does not flash and the instrument appears in the upper right  corner of the icon After the disappearance of the confirmation is completed.</p>			
Set the function 2 (Speed Limitation)				
	1×long		Speed Limitation	See the following description
	<p>Speed Limitation setting: Red circle marked two keys two keys while long press 5 seconds to enter the speed limit setting, the default speed display area flashing for the instrument default factory speed limit characters, while releasing the two keys, and then through the "plus" or "Down" key to adjust to the required speed limit, the adjustable range is 12-40, adjust the required speed limit value, and then press the red circle marked two keys for 5 seconds until the speed display area character zero Do not flash after confirmation. (40 on behalf of the speed limit, 12-40 for the corresponding speed limit)</p>			

6. Configuration instructions

- Work voltage: 24V;36V; 48V
- This displayer adapter the Controller product by DONG MEI HE CHUANG, Carry high precision speed sensor.
- Closed system power
- Drive LED headlight
- Adapter motor: the motor have speed output, Using this motor can accurately displaying speed.

Ordinary motor. Speed display for approximation, not accurate.