



## air-wave modulation source

Module Width (10hp)

Module Depth ( 22mm ) / ( 25mm incl. Power Cable)

Current Consumption +12v (87mA) -12v (35mA)

The **Awms** is a voltage controlled FM radio designed to introduce broadcasted randomness in your modular system anything from randomized and distorted radio stations to random voltage derived from broadcasting.

**FM Source Section** is a simple, quick, and dirty, voltage-controlled FM radio Receiver. It's CV input, and the Tune knob lets you scroll through your favorite static noises and radio stations. Not only is it a great noise source to have for your modular setup, due to the output being normalized to the sample and hold input, random voltages based on the current broadcasting stations / static are also available.

Bandwidth of 87 ~ 108 Mhz or 64 ~ 108Mhz is selectable via a jumper pin on the back side of the module.

Squeeze switch lets you amplify and asymmetrically clip the signal to bring the static in between stations to useful amplitudes or clip the broadcasted audio. (Great for use in underground situations with bad reception. It may replace your white noise generators! Also in our case can still be useful as a random voltage generator as well)

Clean signal maximum ranges 10 volts Peak to Peak (Depending on the broadcasting dynamic range) and the Squeezed signal 13 volts Peak to Peak (-2 ~ 11v due to asymmetrical LED clipping, biasing the sample and hold output to mostly be positive)

Cv input range 0~5v when fully CCW.

The tuning is continuous, meaning it isn't a trigger or button based automatic tuner like most tuners today, and because of that it may not tune in the highest fidelity every single time. (When feeding the cv input consider a more stepped voltage rather than a smooth one, or with a smooth voltage consider using a slow attenuated control voltage to fit your intended range) This device is not designed to be a precision instrument!

**The LFO section** is a triangle and square wave voltage-controlled low-frequency oscillator. A three-way toggle switch can switch between three different frequency ranges. Each range is according to the list below.

**Fast** - 3 sec ~ 19Hz

**Very Fast** - 319Hz ~ 15.69KHz

**Slow** - 17 sec ~ 3Hz

### Output voltage range

Triangle wave  $\pm 6v$

Square Wave  $\pm 10v$

The Squarewave Output is normalized to the Sample and Hold circuits trigger input.

**Sample and Hold** By default, with nothing plugged into the input, it samples the audio coming out of the FM radio to generate random voltages. It can sample external inputs as well as external clock sources.

### PATCH TIP!

with the LFO's frequency range set to "VERY FAST" the output of the sample and hold yields bit crushed audio from the **AIR-WAVES** (~ use groovy font) or your sound source of choice with the external sample input.

Included in the Box is a small 3.5mm adaptable antenna, however if you lose it or forget to bring it with you, you can always use a long patch cable.

# Block Diagram of internal routing

