

Silent Partner Ball Machine Battery Health

The machine is supplied with the Fast Smart Charger. The Smart Charger will not allow the battery to over charge. The machine comes with a battery that has a factory charge (75%). We suggest that you charge the machine prior to using it. It may only take a couple of hours to fully charge. The LED light on the charger will change from Red to Green when it is fully charged.

To keep the battery healthy, it should be at room temperature. When not using the machine for a long period of time, it is best to keep the battery charged. Do not leave the machine on the charger for that long a period of time. The maximum should be about 1 week on the charger.

The best option for keeping the battery healthy during the offseason is to charge the battery after the last use and unplug it once it is fully charged. Every two to three weeks, you should turn the machine on without balls for about 30-45 minutes. You can then recharge it and unplug it when finished. Repeat the cycle about every two to three weeks to keep the battery as healthy as possible.