



## Cook Jug

### CARE AND USAGE GUIDE

Please read and follow these usage and safety guidelines to maximise the life of your Decor product



### CARE

- Before use, remove labels and wash the storer.
- Do not use abrasive materials when washing; applying a paste of baking soda and water then rinsing thoroughly can reduce discolouration and food stains. We recommend hand washing product to ensure a longer life on the printed graduations.
- Freezer, microwave reheat and dishwasher safe (top rack only).
- Premium heat-resistant borosilicate glass.



**microwave  
reheat**



**dishwasher  
safe**



**bpa free**



**food safe**

### WARNINGS:

- Suitable only for microwave reheat, not suitable for ovens or microwave ovens
- Avoid sudden or severe temperature changes.
- Do not heat an empty or nearly empty jug in the microwave.
- Not suitable for cooking popcorn or for use with special browning papers.
- Use minimum cooking time and monitor regularly.
- After microwaving, contents and glass jug may be very hot.
- Use oven mitts to prevent risk of burn injury.
- Do not handle glass jug with anything wet.
- Do not place a hot glass jug on a cold or wet surface, we recommend using a heat mat.
- Do not add cool or room temperature liquid to a hot glass jug.
- Do not use on hotplates, stovetops, in a toaster oven, under a grill or over flames.
- Do not place the lid on base while base or contents are hot. Do not use the lid as the heat mat for the base.
- Glass jugs are breakable and must be handled with care to avoid personal injury or property damage. Cease use if glass is chipped, cracked or has significant scratches.
- Not suitable for children under 48 months old.
- If product is damaged, discontinue use.