



Elite 1500 Plug 'n' Play Adaptor Harness HT-140823

Supported Models

MITSUBISHI EVOLUTION 4, 5, 6
MITSUBISHI EVOLUTION 6.5 TOMMI MAKINEN
MITSUBISHI EVOLUTION 7
MITSUBISHI EVOLUTION 8
MITSUBISHI ECLIPSE 2G TURBO

Package Contents

THIS MITSUBISHI EVOLUTION/ECLIPSE PACKAGE CONTAINS THE FOLLOWING:

- MITSUBISHI EVOLUTION 4 - 8, ECLIPSE 2G TURBO ELITE 1500 PLUG 'N' PLAY ADAPTOR (HT-140823)
- ELITE SERIES PLUG 'N' PLAY ADAPTOR HARNESS (HT-130201)
- INTAKE AIR TEMPERATURE SENSOR (HT-010200)



Application Notes

THIS MITSUBISHI EVOLUTION 4 - 8 & ECLIPSE 2G TURBO ELITE 1500 PLUG 'N' PLAY ADAPTOR HARNESS IS SUITABLE FOR USE WITH A HALTECH **ELITE 1500 & ELITE 2500** ECU. PLEASE NOTE THAT USE WITH AN **ELITE 1500** ECU WILL REDUCE SOME OF THE CARS FUNCTIONALITY. THESE FUNCTIONS ARE LABELED (Available to Elite 2500 Only) IN THE NOTES COLUMN OF THE CONNECTOR TABLES.

ENSURE THAT THE CORRECT BASEMAP IS LOADED BEFORE STARTING THE VEHICLE.

THE BASEMAP IS ONLY FOR USE AS A STARTING POINT AND THE ECU WILL REQUIRE APPROPRIATE TUNING.

HALTECH WILL NOT BE HELD RESPONSIBLE FOR ENGINE DAMAGE DUE TO THE IMPROPER USE OF BASEMAPS.

THE 16 PIN AUXILIARY CONNECTOR PROVIDES A NUMBER OF ADDITIONAL INPUT/OUTPUT LINKS TO THE HALTECH ELITE ECU.

THIS KIT IS SUPPLIED WITH SPARE PINS FOR USE WITH THE 16 PIN AUXILIARY CONNECTOR.

AN APPROPRIATE CRIMPING TOOL IS RECOMMENDED TO USE THE 16 PIN AUXILIARY CONNECTOR.

A CRIMPING TOOL KIT (PART # HT-070300) CAN BE PURCHASED AT WWW.HALTECH.COM

AFTER THE INSTALLATION OF THIS PLUG 'N' PLAY KIT, FACTORY PANELS MAY BE RE-INSTALLED.

Jumper ID Settings

THIS MITSUBISHI EVOLUTION 4 - 8 & ECLIPSE 2G TURBO PLUG 'N' PLAY ADAPTOR HARNESS IS CAPABLE OF BEING CONFIGURED FOR USE WITH OTHER VEHICLES.

INSIDE THE ADAPTOR BOX THERE ARE 2 HEADERS WITH YELLOW LABELS NEXT TO THEM.

THESE LABELS ARE **A, B, C, D, E, F, G & H**

THESE MUST BE CHANGED TO USE THIS PRODUCT WITH OTHER COMPATIBLE VEHICLES.


THE JUMPER SETTINGS ARE SHOWN BELOW WITH VARIOUS CONFIGURATIONS.

THIS PLUG 'N' PLAY ADAPTOR IS FACTORY CONFIGURED TO SUIT THE MITSUBISHI EVOLUTION 7 & 8 ELITE 1500 APPLICATION

DEFAULT CONFIGURATION

MITSUBISHI EVOLUTION 7 & 8

 ID JUMPER




JUMPERS REQUIRED
A
C
E
F
H

ALTERNATE CONFIGURATION

MITSUBISHI EVOLUTION 4,5,6, 6.5 (TOMMI MAKINEN)

 ID JUMPER




JUMPERS REQUIRED
B
C
D
F
G

ALTERNATE CONFIGURATION

MITSUBISHI ECLIPSE 2G TURBO

 ID JUMPER



JUMPERS REQUIRED
B
E
F
G

Elite 1500/2500 Basemaps

MAKE	MODEL	CODE	ENGINE	BASEMAP
MITSUBISHI	EVOLUTION	4-5-6	4G63T	HT-140823 - Mitsubishi Evolution 4-5-6 4G63T.e1500
MITSUBISHI	EVOLUTION	6.5	4G63T	HT-140823 - Mitsubishi Evolution 6.5 4G63T.e1500
MITSUBISHI	EVOLUTION	7	4G63T	HT-140823 - Mitsubishi Evolution 7 4G63T.e1500
MITSUBISHI	EVOLUTION	8	4G63T	HT-140823 - Mitsubishi Evolution 8 4G63T.e1500
MITSUBISHI	ECLIPSE	2G	4G63T	HT-140823 - Mitsubishi Eclipse 2G Turbo 4G63T.e1500
MITSUBISHI	EVOLUTION	4-5-6	4G63T	HT-140823 - Mitsubishi Evolution 4-5-6 4G63T.e2500
MITSUBISHI	EVOLUTION	6.5	4G63T	HT-140823 - Mitsubishi Evolution 6.5 4G63T.e2500
MITSUBISHI	EVOLUTION	7	4G63T	HT-140823 - Mitsubishi Evolution 7 4G63T.e2500
MITSUBISHI	EVOLUTION	8	4G63T	HT-140823 - Mitsubishi Evolution 8 4G63T.e2500
MITSUBISHI	ECLIPSE	2G	4G63T	HT-140823 - Mitsubishi Eclipse 2G Turbo 4G63T.e2500

Basemap Notes

THE BASEMAPS SUPPLIED WITH THIS PRODUCT HAVE BEEN SETUP USING THE ELITE ECU INTERNAL 3 BAR MAP SENSOR.

PLEASE CONNECT THE ELITE ECU INTERNAL MAP SENSOR TO THE INTAKE MANIFOLD PRIOR TO STARTING THE VEHICLE.




Figure 1 - Elite ECU internal MAP sensor

ECU Location

MITSUBISHI EVOLUTION 4, 5, 6, 6.5 (TOMMI MAKINEN)

THE FACTORY MITSUBISHI EVOLUTION 4,5,6 ECU IS LOCATED BEHIND THE PASSENGER SIDE KICK PANEL. REMOVING THE KICK PANEL WILL ALLOW SPACE TO INSTALL THE ADAPTOR HARNESS. THE ELITE ECU CAN BE INSTALLED ON THE LEFT HAND SIDE OF THE GLOVEBOX IN THE FREE SPACE. ALL FACTORY PANELS MAY BE RE-USED AFTER INSTALLATION.



Figure 2 - Haltech Installation in EVO 4 - 6.5

MITSUBISHI EVOLUTION 7, 8

THE FACTORY MITSUBISHI EVOLUTION 7, 8 ECU IS LOCATED BEHIND THE PASSENGER SIDE GLOVE BOX. IT CAN BE ACCESSED BY REMOVING THE GLOVEBOX AND REMOVING THE TWO 10MM BOLTS HOLDING IT IN PLACE. THE GLOVEBOX CAN STILL BE USED AFTER THE INSTALLATION OF THE HALTECH PRODUCTS.



Figure 3 - Haltech Installation in EVO 7 - 8

MITSUBISHI ECLIPSE 2G TURBO

THE FACTORY MITSUBISHI ECLIPSE 2G TURBO ECU IS LOCATED UNDERNEATH AND BEHIND THE RADIO IN THE CENTRE CONSOLE OF THE VEHICLE. REMOVING THE TWO SIDE PANELS OF THE CENTRE CONSOLE UNDER THE RADIO WILL EXPOSE THE FACTORY ECU. THE HALTECH PRODUCTS MAY BE INSTALLED AND THE SIDE PANELS REPLACED AFTERWARDS.

Air Temperature Sensor

An air temperature sensor is a required sensor used in Volumetric Efficiency (VE) tuning to compensate for changes in air density due to air temperature. Cold air has a higher density than warm air and therefore requires a greater volume of fuel to maintain the same air/fuel ratio.

The Haltech ECU can automatically compensate the fuel delivery for changes in air density based on temperature using the signal received from the air temperature sensor.

On many vehicles the OEM air temperature sensor is located either within the mass airflow sensor or molded into the intake air manifold, however in performance applications the airflow sensor and air intake piping are often modified, removed or replaced. For this reason an air temperature sensor (HT-010200) is provided for use as a substitute to the factory air temperature sensor.

This sensor should be mounted to provide the best representation of the actual temperature of the air entering the combustion chamber, i.e. after any turbocharger, supercharger and intercooler.

The sensor needs to be in the moving air stream to give fast response times and reduce heat soak effects. Be aware in some situations, mounting the sensor into the inlet manifold (especially at the rear) may cause heat soak problems (where the sensor reads the temperature of the manifold itself rather than the air that is moving through the manifold into the engine).

Once a suitable position has been located for the air temperature sensor to be installed, a hole should be drilled and tapped to accept the sensor. The intake manifold or inlet piping should be removed from the engine before this is done to prevent any metal shavings or swarf entering the engine.

This package includes an air temperature sensor (HT-010200). This air temperature sensor should be installed by utilising an auxiliary Analogue Voltage Input (AVI) and signal ground located on the 16 pin auxiliary connector.

Please refer to the auxiliary connector pinout table and sensor wiring diagram below.





Figure 4 - Air Temperature Sensor wiring

MAF/Air Temp Sensor




REAR VIEW (WIRE SIDE)
WIRING BASED ON
MITSUBISHI ELECTRIC E5T07072 SENSOR

PIN	COLOUR	FUNCTION
1	GREY	+5V Sensor Power
2	YELLOW/BLUE	Barometer Signal
3	WHITE/RED	Mass Air Flow Signal
4	YELLOW/RED	+12V Switched Power
5	BLACK	Sensor Ground
6	RED/BLUE	Intake Air Temperature Signal
7	BLUE	Reset

IF THE FACTORY **MAF** SENSOR IS REMOVED, AN **INTAKE AIR TEMPERATURE (IAT)** SENSOR CAN BE INSTALLED BY UTILISING PINS 5 (**SENSOR GROUND**) AND 6 (**AVI 7**) OF THE FACTORY MAF SENSOR CONNECTOR. PIN 5 (**SENSOR GROUND**), PIN 6 (**AVI 7**) AND PIN 3 (**SPI 2**) OF THE FACTORY **MAF** CONNECTOR MAY ALSO BE USED AS **SPARE AVI/SPI** IF REQUIRED.

Auxiliary Connector




**AUXILIARY CONNECTOR (16 PIN)
REAR VIEW (WIRE SIDE)**

An auxiliary connector allows easy connection of additional ECU inputs and outputs.
Please see pinout information below for spare inputs and outputs available to this application.

Position (16 Pin Plug)	Connection	Function	Notes
1	From Haltech ECU (A9)	+5V	+5V DC Sensor Supply (50mA Max)
2	From Haltech ECU (A15)	AVI 9	Spare AVI when OEM Manifold Absolute Pressure Sensor is not available *
3	From Haltech ECU (A16)	AVI 2	Spare Analogue Voltage Input
4	From Haltech ECU (B14, B15, B16)	SIGNAL GROUND	Signal Ground For Input Sensors
5	From Haltech ECU (B17)	IGN 7	Secondary Air Solenoid/EGR Solenoid EVO 7/8, Eclipse 2G (Available to Elite 2500 Only)
6	From Haltech ECU (B18)	IGN 8	Alternator Control (Available to Elite 2500 Only)
7	From Haltech ECU (B8)	SPI 1	Spare SPI (Optional Flex Fuel Input)
8	From Haltech ECU (A26)	+12V (INU)	+12V DC Supply for Relays and Solenoids (500mA Max)
9	From Haltech ECU (A9)	+5V	+5V DC Sensor Supply (50mA Max)
10	From Haltech ECU (A17)	AVI 3	Spare Analogue Voltage Input (EVO 4-6.5 & Eclipse 2G Only)
11	From Haltech ECU (B13)	AVI 1	Spare Analogue Voltage Input
12	From Haltech ECU (B14, B15, B16)	SIGNAL GROUND	Signal Ground For Input Sensors
13	From Haltech ECU (A29)	INI 7	Check Engine Light (Available to Elite 2500 Only)
14	From Haltech ECU (A30)	INI 8	Spare Output (Available to Elite 2500 Only)
15	-	-	-
16	From Haltech ECU (A26)	+12V (INU)	+12V DC Supply for Relays and Solenoids (500mA Max)

*OEM Manifold Absolute Pressure Sensor fitted to some USDM variants and Eclipse 2G


Main Connectors



CONNECTOR (32 PIN)
REAR VIEW (WIRE SIDE)

Position (32 Pin Plug)	ECU Connector (34 Pin Plug)	Function	Description
1	A1	DPO 2	Cooling Fan Speed Control (EVO 7 & 8) / Cooling Fan Relay (EVO 4-6.5 & Eclipse 2G)
2	A2	AVI 4	Power Steering Switch
3	A3	IGN 1	Ignition Coils 1 & 4
4	A4	IGN 2	Ignition Coils 2 & 3
5	A5	IGN 3	Wastegate Solenoid
6	A6	IGN 4	Cooling Fan / Condenser Fan (Hi) Relay
7	A7	IGN 5	EVAP Solenoid (Available to Elite 2500 Only)
8	A8	IGN 6	Secondary Air Solenoid (EVO 7 Only) (Available to Elite 2500 Only)
9	A9	+5V	+5V DC Sensor Supply
10	A10	BATTERY GROUND	Battery Negative
11	A11	BATTERY GROUND	Battery Negative
12	A12	+8V	+8V DC Sensor Supply
13	A13	IGNITION INPUT	Ignition Switch
14	A14	AVI 10	Throttle Position Sensor
15	A15	AVI 9	OEM Manifold Absolute Pressure Sensor / Spare AVI *
16	A16	AVI 2	Clutch Switch (some EVO variants only)
17	A17	AVI 3	Manual Intercooler Spray (EVO 7/8 Only) / Spare Input (EVO 4-6.5 Only)
18	A18	DPO 1	A/C Control Relay
19	A19	INJ 1	Injector #1
20	A20	INJ 2	Injector #2
21	A21	INJ 3	Injector #3
22	A22	INJ 4	Injector #4
23	A23	DPO 3	Tachometer
24	A24	DPO 5	Fuel Pump Relay / A/C Control (EVO 6.5/8 Only)
25	A25	DPO 6	Engine Control Relay Output
26	A26	+12V (INJ)	Fused Power
27	A27	INJ 5	Spare Output (Available to Elite 2500 Only)
28	A28	INJ 6	Spare Output (Fuel Pressure Solenoid) (Available to Elite 2500 Only)
29	A31	STEP1 P1	Idle Control Valve (B1)
30	A32	STEP1 P2	Idle Control Valve (B2)
31	A33	STEP1 P3	Idle Control Valve (A1)
32	A34	STEP1 P4	Idle Control Valve (A2)

*OEM Manifold Absolute Pressure Sensor fitted to some USDM variants and Eclipse 2G. Otherwise this input can be used as a Spare Analogue Voltage Input.



CONNECTOR (24 PIN)
REAR VIEW (WIRE SIDE)

Position (24 Pin Plug)	ECU Connector (26 Pin Plug)	Function	Description
1	B1	TRIGGER	Crankshaft Sensor (+)
2	B2	HOME	Cam Position Sensor
3	B3	AVI 7	Air Temperature Sensor
4	B4	AVI 8	Coolant Temperature Sensor
5	B5	TRIGGER -	Not Used
6	B6	HOME -	Not Used
7	B7	SPI 4	A/C Request
8	B8	SPI 1	Spare SPI (Optional Flex Fuel Input)
9	B9	SPI 2	Mass Air Flow Sensor
10	B10	SPI 3	Vehicle Speed Sensor
11	B11	+12V (ECU)	Fused Power
12	B12	AVI 6	O2 Sensor
13	B13	AVI 1	Spare Analogue Voltage Input
14	B14	SIGNAL GROUND	Signal Ground for Input Sensors
15	B15	SIGNAL GROUND	Signal Ground for Input Sensors
16	B16	SIGNAL GROUND	Signal Ground for Input Sensors
17	B23	CAN HIGH	Not Used
18	B24	CAN LOW	Not Used
19	B19	DPO 4	Fuel Pump Speed
20	B20	AVI 5	Spare Analogue Voltage Input / ACD-AYC
21	B21	KNOCK 1	Knock Sensor Signal
22	B22	KNOCK 2	Not Used
23	B25	DBW 1	Water Spray Relay
24	B26	DBW 2	A/C Control / Fuel Pump Relay (EVO 6.5/8 Only)



WARNING - HALTECH OFF-ROAD USAGE POLICY

It is unlawful to tamper with your vehicle's emissions equipment.

Haltech products are designed and sold for sanctioned off-road/competition non-emissions controlled vehicles only. Using Haltech products for street/road use on public roads is prohibited by law. It is the responsibility of the installer and/or user of this product to ensure compliance with all applicable local and federal laws and regulations. Please check with your local vehicle authority before using any Haltech product

INSTALLATION OF HALTECH PRODUCTS

No responsibility whatsoever is accepted by Haltech for the fitment of Haltech Products. The onus is clearly on the installer to ensure that both their knowledge and the parts selected are correct for that particular application. Any damage to parts or consequential damage or costs resulting from the incorrect installation of Haltech products are totally the responsibility of the installer.

Always disconnect the battery when doing electrical work on your vehicle. Avoid sparks, open flames or use of electrical devices near flammable substances. Do not run the engine with a battery charger connected as this could damage the ECU and other electrical equipment. Do not overcharge the battery or reverse the polarity of the battery or any charging unit. Disconnect the Haltech ECU from the electrical system whenever doing any welding on the vehicle by unplugging the wiring harness connector from the ECU. After completing the ECU installation, make sure there is no wiring left uninsulated. Uninsulated wiring can cause sparks, short circuits and in some cases fire. Before attempting to run the engine ensure there are no leaks in the fuel system. All fuel system components and wiring should be mounted away from heat sources, shielded if necessary and well ventilated. Always ensure that you follow workshop safety procedures. If you're working underneath a jacked-up car, always use safety stands!

HALTECH LIMITED WARRANTY

Unless specified otherwise, Haltech warrants its products to be free from defects in material or workmanship for a period of 12 months from the date of purchase, valid in the original country of purchase only. Proof of purchase, in the form of a bill of sale or receipted invoice, which indicates that the product is within the warranty period, must be presented to obtain warranty service. Haltech suggests that the purchaser retain the dealer's dated bill of sale/receipt as evidence of the date of retail purchase. If the Haltech product is found to be defective as mentioned above, it will be replaced or repaired if returned prepaid along with proof of purchase. This shall constitute the sole liability of Haltech. To the extent permitted by law, the foregoing is exclusive and in lieu of all other warranties or representations, either expressed or implied, including any implied warranty of merchantability or fitness. In no event shall Haltech be liable for special or consequential damages.

PRODUCT RETURNS

Please include a copy of the original purchase invoice along with the unused, undamaged product and its original packaging. Any product returned with missing accessory items or packaging will incur extra charges to return the item to a re-saleable condition. All product returns must be sent via a freight method with adequate tracking, insurance and proof of delivery services. Haltech will not be held responsible for product returns lost during transit. The sale of any sensor or accessory that is supplied in sealed packaging is strictly non-refundable if the sealed packaging has been opened or tampered with. This will be clearly noted on the product packaging. If you do not accept these terms please return the sensor in its original unopened packaging within 30 days for a full refund.

Returning a sensor or accessory product within 30 days of purchase: Product may be returned for credit or full refund. (Any sealed packaging must not have been opened or tampered with)

Returning a sensor or accessory product after 30 days of purchase: Product may be returned for credit only (no refunds given) and is subject to a 10% Restocking fee. (Any sealed packaging must not have been opened or tampered with)

Need more help?



Intl: +61 2 9729 0999
USA: +1 888 298 8116



Intl: support@haltech.com
USA: usasupport@haltech.com



www.haltech.com



[/Haltechecu](https://www.youtube.com/Haltechecu)



[/HaltechEngineManagement](https://www.facebook.com/HaltechEngineManagement)