



**YAMAHA**

**BW200N**

**Service Manual**

*Lit11616BW20*

**BW200N**

**SERVICE MANUAL**

**©1984 by Yamaha Motor Corporation, U.S.A.**

**1st Edition, June 1984**

**All rights reserved. Any reprinting or  
unauthorized use without the written  
permission of Yamaha Motor Corporation,  
U.S.A. is expressly prohibited.**

**Printed in U.S.A.**

**P/N LIT-11616-04-63**

---

## NOTICE

This manual was written by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to put an entire mechanic's education into one manual, so it is assumed that persons using this book to perform maintenance and repairs on Yamaha motorcycles have a basic understanding of the mechanical concepts and procedures inherent in motorcycle repair technology. Without such knowledge, attempted repairs or service to this model may render it unfit to use and/or unsafe.

Yamaha Motor Company, Ltd. is continually striving to improve all models manufactured by Yamaha. Modifications are significant changes in specifications or procedures will be forwarded to all Authorized Yamaha dealers and will, where applicable, appear in future editions of this manual.

OVERSEAS SERVICE  
OVERSEAS OPERATIONS  
YAMAHA MOTOR CO., LTD.

## HOW TO USE THIS MANUAL

### PARTICULARLY IMPORTANT INFORMATION

This material is distinguished by the following notation.

**NOTE:** A NOTE provides key information to make procedures easier or clearer.

**CAUTION:** A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle.

**WARNING:** A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

### MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.






















In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings;

Pitting/Damage → Replace.

### EXPLODED DIAGRAM

Each chapter provides exploded diagrams before each disassembly section for ease in identifying correct disassembly and assembly procedures.

|  |  |   |
|--|--|---|
| ①<br><b>GEN<br/>INFO</b>  | ②<br><b>INSP<br/>ADJ</b>  |   |
| ③<br><b>ENG</b>           | ④<br><b>COOL</b>          |   |
| ⑤<br><b>CARB</b>          | ⑥<br><b>CHAS</b>          |   |
| ⑦<br><b>ELEC</b>          | ⑧<br><b>APPX</b>          |   |
| ⑨                         | ⑩                         |   |
| ⑪                       | ⑫                       |   |
| ⑬                       | ⑭                       |   |
| ⑮                       | ⑯                       | ⑰  |
| ⑱                       | ⑲                       | ⑳  |
| ㉑                       |  |   |

## SYMBOLS

(Refer to the illustration)

Symbols ① to ⑧ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Periodic inspection and adjustment
- ③ Engine
- ④ Cooling system
- ⑤ Carburetion
- ⑥ Chassis
- ⑦ Electrical
- ⑧ Appendices








Symbols ⑨ to ⑭ indicate specific data as the following items:

- ⑨ Filling fluid
- ⑩ Lubricant
- ⑪ Tightening
- ⑫ Wear limit, clearance
- ⑬ Engine speed
- ⑭  $\Omega$ , V, A

Symbols ⑮ to ㉑ in the exploded diagram indicate grade of lubricant and location of lubrication point.

- ⑮ Apply engine oil
- ⑯ Apply gear oil
- ⑰ Apply molybdenum disulfide oil
- ⑱ Apply wheel bearing grease
- ⑲ Apply lightweight lithium soap base grease
- ⑳ Apply molybdenum disulfide grease
- ㉑ Apply locking agent (LOCTITE®)

# INDEX



|   |  |
|---|--|
| <b>GENERAL INFORMATION</b>                      | <br><b>GEN<br/>INFO 1</b> |
| <b>PERIODIC INSPECTIONS<br/>AND ADJUSTMENTS</b> | <br><b>INSP<br/>ADJ 2</b> |
| <b>ENGINE OVERHAUL</b>                          | <br><b>ENG 3</b>          |
| <b>CARBURETION</b>                              | <br><b>CARB 4</b>        |
| <b>CHASSIS</b>                                  | <br><b>CHAS 5</b>       |
| <b>ELECTRICAL</b>                               | <br><b>ELEC 6</b>       |
| <b>APPENDICES</b>                               | <br><b>APPX 7</b>       |



---

## **CHAPTER 1. GENERAL INFORMATION**

|   |     |
|---|-----|
| <b>MOTORCYCLE IDENTIFICATION</b> .....  | 1-1 |
| VEHICLE IDENTIFICATION NUMBER .....     | 1-1 |
| ENGINE SERIAL NUMBER .....              | 1-1 |
| <br><b>IMPORTANT INFORMATION</b> .....  | 1-2 |
| ALL REPLACEMENT PARTS .....             | 1-2 |
| GASKETS, OIL SEALS, AND O-RINGS.....    | 1-2 |
| LOCK WASHER/PLATES AND COTTER PINS..... | 1-2 |
| BEARINGS AND OIL SEALS .....            | 1-3 |
| CIRCLIPS .....                          | 1-3 |
| <br><b>SPECIAL TOOLS</b> .....          | 1-4 |
| FOR TUNE-UP .....                       | 1-4 |
| FOR ENGINE SERVICE .....                | 1-4 |
| FOR CHASSIS SERVICE .....               | 1-6 |
| FOR ELECTRICAL COMPONENTS .....         | 1-7 |



**GENERAL  
INFORMATION**

**MOTORCYCLE IDENTIFICATION**

**VEHICLE IDENTIFICATION NUMBER**

The vehicle identification number ① is on the left side of the steering head pipe.

**Starting Serial Number:**  
**BW200N .....JYA54G00\*FA000101**


**ENGINE SERIAL NUMBER**

The engine serial number ① is stamped into the elevated part of the right rear section of the engine.

**Starting Serial Number:**  
**BW200N .....54G-000101**

**NOTE:** \_\_\_\_\_  
The first three digits of these numbers are for model identifications; the remaining digits are the unit production number.

**NOTE:** \_\_\_\_\_  
Designs and specifications are subject to change without notice.




**IMPORTANT INFORMATION**

**ALL REPLACEMENT PARTS**

1. Use only genuine Yamaha parts for all replacements. Use oil and/or grease recommended by Yamaha for assembly and adjustment. Other brands may be similar in function and appearance, but inferior in quality.

**GASKETS, OIL SEALS, AND O-RINGS**


1. All gaskets, seals, and O-rings should be replaced when an engine is overhauled. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.



**LOCK WASHERS/PLATES AND COTTER PINS**

1. All lock washers/Plates ① and cotter pins must be replaced when they are removed. Lock tab(s) should be bent along the bolt or nut flat(s) after the bolt or nut has been properly tightened.






**BEARINGS AND OIL SEALS**

1. Install the bearing(s) and oil seal(s) with their manufacturer's marks or numbers facing outward. (In other words, the stamped letters must be on the side exposed to view.) When installing oil seal(s), apply a light coating of light-weight lithium base grease to the seal lip(s). Oil the bearings liberally when installing.


① Oil seal



**CAUTION**

**Do not use compressed air to spin the bearings dry. This causes damage to the bearing surfaces.**

① Bearing




**CIRCLIPS**

1. All circlips should be inspected carefully before reassembly. Always replace piston pin clips after one use. Replace distorted circlips. When installing a circlip ①, make sure that the sharp edged corner ② is positioned opposite to the thrust ③ it receives. See the sectional view.


④ Shaft

**SPECIAL TOOLS**


The proper special tools are necessary for complete and accurate tune-up and assembly. Using the correct special tool will help prevent damage caused by the use of improper tools or improvised techniques.

**FOR TUNE-UP**


1. Timing Light  
P/N. YU-08037





2. Inductive Tachometer  
P/N. YU-08036




3. Compression Gauge and Adapter  
P/N. YU-33223  
YU-33223-3

**FOR ENGINE SERVICE**


1. Clutch Hub Holder  
P/N. YM-91042




2. Valve Guide Remover  
P/N. YM-4064-A




3. Valve Guide Installer  
P/N. YM-4065



4. Valve Guide Reamer  
P/N. YM-4066



5. Valve Seat Cutter  
P/N. YM-91043




6. Valve Spring Compressor  
P/N. YM-04019


## SPECIAL TOOLS




**GEN  
INFO**




7. Valve Adjusting Tool  
P/N. YM-08035




8. Slide Hammer  
P/N. YU-01083-A




9. Rotor Puller  
P/N. YM-01080-A




**FOR CHASSIS SERVICE**  
1. T-Handle  
P/N. YM-01326




2. Fork Damper Rod Holder  
P/N. YM-33256



- 3. Fork Oil Seal Driver Weight and Attachment  
P/N. YM-33963  
YM-1369




- 4. Steering Nut Wrench  
P/N. YU-33975



**FOR ELECTRICAL COMPONENTS**

- 1. Pocket Tester  
P/N. YU-03112



- 2. Electro Tester  
P/N. YU-03021

---

## **CHAPTER 2.**

# **PERIODIC INSPECTIONS AND ADJUSTMENT**

|   |      |
|---|------|
| <b>INTRODUCTION</b> .....                     | 2-1  |
| <b>PERIODIC MAINTENANCE/LUBRICATION</b> ..... | 2-1  |
| <b>ENGINE</b> .....                           | 2-2  |
| VALVE CLEARANCE .....                         | 2-2  |
| THROTTLE CABLE.....                           | 2-3  |
| IDLE SPEED .....                              | 2-3  |
| DECOMPRESSION CABLE .....                     | 2-3  |
| ENGINE OIL .....                              | 2-4  |
| AIR FILTER CLEANING .....                     | 2-5  |
| CAM CHAIN.....                                | 2-6  |
| CLUTCH .....                                  | 2-7  |
| IGNITION TIMING .....                         | 2-8  |
| COMPRESSION PRESSURE .....                    | 2-9  |
| SPARK PLUG.....                               | 2-10 |
| <b>CHASSIS</b> .....                          | 2-11 |
| FRONT AND REAR BRAKES .....                   | 2-11 |
| TIRES .....                                   | 2-12 |
| STEERING HEAD ADJUSTMENT.....                 | 2-13 |
| DRIVE CHAIN.....                              | 2-14 |
| MIDDLE SPROCKETS SHAFT.....                   | 2-16 |
| CABLE INSPECTION AND LUBRICATION.....         | 2-16 |
| BRAKE PEDAL/BRAKE AND CLUTCH LEVERS.....      | 2-17 |
| SIDESTAND .....                               | 2-17 |
| FRONT FORK OIL CHANGE.....                    | 2-17 |
| <b>ELECTRICAL</b> .....                       | 2-18 |
| HEADLIGHT .....                               | 2-18 |

**PERIODIC INSPECTIONS AND ADJUSTMENTS**

**INTRODUCTION**

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.


**PERIODIC MAINTENANCE/LUBRICATION**

Unite: km (mi)

| Item                   | Remarks   | Initial |          |          | Every    |        |
|------------------------|---|---------|----------|----------|----------|--------|
|                        |   | 1 month | 3 months | 6 months | 6 months | 1 year |
| Valve(s)               | Check valve clearance. Adjust if necessary.                               | ○       |          | ○        | ○        | ○      |
| Cam chain              | Check chain tension. Adjust if necessary.                                 | ○       |          | ○        | ○        | ○      |
| Spark plug             | Check condition. Clean or replace if necessary.                           | ○       | ○        | ○        | ○        | ○      |
| Air filter             | Clean. Replace if necessary.  |         | ○        | ○        | ○        | ○      |
| Carburetor             | Check idle speed/ starter operation. Adjust if necessary.                 |         | ○        | ○        | ○        | ○      |
| Fuel line              | Check fuel hose for cracks or damage. Replace if necessary.               |         |          | ○        | ○        | ○      |
| Engine oil             | Replace (Warm engine before draining).                                    | ○       |          | ○        | ○        | ○      |
| Engine oil filter      | Replace.  | ○       |          | ○        |          | ○      |
| Engie oil strainer     | Clean. Replace if necessary.  | ○       |          | ○        |          | ○      |
| Brake                  | Check operation. Adjust if necessary.                                     | ○       | ○        | ○        | ○        | ○      |
| Clutch                 | Check operation. Adjust if necessary.                                     | ○       |          | ○        | ○        | ○      |
| Drive chain            | Check operation/ Adjust as required/ Replace as required.                 | ○       | ○        | ○        | 1 Month  |        |
| Decompression system   | Check operation. Adjust if necessary.                                     |         |          | ○        | ○        | ○      |
| Wheels                 | Check balance/ damage/ runout. Repair if necessary.                       | ○       |          | ○        | ○        | ○      |
| Wheel bearings         | Check bearings assembly for looseness/ damage. Replace if damaged.        | ○       |          | ○        | ○        | ○      |
| Rear arm pivot         | Apply grease lightly every 12 months. **                                  |         |          |          |          | ○      |
| Middle sprockets shaft | Lubricate every 6 months. **  |         |          | ○        | ○        | ○      |
| Steering bearing       | Check bearing assembly for looseness. Moderately repack every 12 months.* | Check   |          | Check    | Check    | ○      |
| Fittings/ Fasteners    | Check all chassis fittings and fasteners. Correct if necessary.           | ○       | ○        | ○        | ○        | ○      |


\* Medium weight wheel bearing grease.


\*\* Lithium soap base grease.




## ENGINE VALVE CLEARANCE Measurement

1. Remove:
  - Seat
  - Fuel tank
  - Valve covers ①
  - Spark plug ②
  
2. Remove:
  - Timing window plug
  - Crankshaft end cover
  
3. Align:
  - "T" mark ①  
(on the flywheel with the stationary pointer ② on the crankcase cover)
  
4. Measure:
  - Valve clearance
 Out of specification → Adjust




|   |  |
|---|--|
|  | <b>Valve Clearance: (Cold)</b>                         |
|   | <b>Intake: 0.09 ~ 0.13 mm</b><br>(0.0035 ~ 0.0043 in)  |
|   | <b>Exhaust: 0.15 ~ 0.19 mm</b><br>(0.0059 ~ 0.0075 in) |




## Adjustment





1. Loosen:
  - Locknut ①
2. Adjust:
  - Valve clearance
3. Tighten
  - Locknut ①

② Valve adjusting tool

|   |                                   |
|---|-----------------------------------|
|  | <b>Locknut:</b>                   |
|   | <b>7 Nm (0.7 m•kg, 5.1 ft•lb)</b> |

|   |                                   |
|---|-----------------------------------|
|  | <b>Spark Plug:</b>                |
|   | <b>20 Nm (2.0 m•kg, 14 ft•lb)</b> |
|   | <b>Valve Cover:</b>               |
|   | <b>7 Nm (0.7 m•kg, 5.1 ft•lb)</b> |





**THROTTLE CABLE**

1. Check:
  - Throttle grip free play (a)
  - Out of specification → Adjust



**Free Play: 5 mm (0.2 in)**

- ① Adjuster
- ② Locknut

2. Adjust:
  - Throttle grip free play (a)
  - (by turning the adjuster ① in or out)

**NOTE:**

After adjusting, turn the handlebar to right and left and make sure that the engine idling does not run faster.

- ② Locknut

**IDLE SPEED**

1. Start the engine and warm it up for a few minutes.
2. Adjust:
  - Idle speed
  - (by turning the throttle stop screw ① in or out)



**1,350 ± 50 r/min**

**DECOMPRESSION CABLE**

1. Align:
  - "T" Mark ①
  - (on the flywheel with the stationary pointer ② on the crankcase cover)

**NOTE:**

Be sure piston is at Top Dead Center (TDC) on compression stroke.

2. Adjust:
  - Decompression cable free play ①
  - (by turning the adjuster ② in or out)




**Free Play:  
2~3 mm (0.08~0.12 in)**

- ③ Locknut

**ENGINE OIL**  
Checking

1. Start the engine and warm it up for a few minutes.
2. Hold the motorcycle in an upright position.



3. Check:
  - Oil level (through the level window ①)


**NOTE:**

Wait a few minutes until the oil level settles before checking.

- ② Maximum level
- ③ Minimum level

**Oil and Oil Filter Replacement**

1. Start the engine and warm it up for a few minutes. Place an oil pan under the engine.
2. Remove:
  - Oil filler cap
  - Drain plug ①



**CAUTION:**


When removing the drain plug, the O-ring, spring, and oil strainer, will fall off. Take care not to lose these parts.




3. Remove:
  - Drain bolt ①
  - Filter cover screws ②

**NOTE:**

If the oil filter is not replaced, remove only drain bolt and drain the oil in the filter case.





4. Install:
  - Removed parts

|   |                                   |
|---|-----------------------------------|
|  | <b>Drain Plug ①:</b>              |
|   | 43 Nm (4.3 m•kg, 31 ft•lb)        |
|   | <b>Filter Cover Screw:</b>        |
|   | 7 Nm (0.7 m•kg, 5.1 ft•lb)        |
|   | <b>Drain bolt (Filter Cover):</b> |
|   | 10 Nm (1.0 m•kg, 7.2 ft•lb)       |



**ENGINE OIL/AIR FILTER CLEANING**



5. Fill
  - Engine oil

**Recommended Oil:**  
**SAE 20W40 type SE motor oil**  
**Periodic Oil Change:**  
**1.0 L (0.88 Imp qt, 1.06 US qt)**  
**With Oil Filter Change:**  
**1.1 L (0.97 Imp qt, 1.16 US qt)**

6. Install:
  - Filler cap
7. Start the engine and check oil level.

**CAUTION:**

After replacing the engine oil, be sure to check the oil flow as described below.

- Slightly loosen the oil gallery bolt ① from the cylinder head.
- Start the engine and keep it idling until oil flows out of the check hole. If no oil comes out after a lapse of one minute, turn off the engine immediately so it will not seize.
- Turn the engine off, and tighten the bolt to specification.



**Oil Gallery Bolt:**  
**7 Nm (0.7 m•kg, 5.1 ft•lb)**

Locate and resolve the problem then recheck the oil pressure.




**AIR FILTER CLEANING**

1. Remove:
  - Seat
  - Side covers
  - Air filter case assembly



2. Remove:
  - Air filter case cover
3. Loosen:
  - Air filter element holding screw ①
4. Remove:
  - Air filter element ②  
(from air filter case)
5. Remove:
  - Element guide ①  
(from air filter element ②)



## Air Cleaner Element

1. Clean:
  - Air cleaner element

Wash the element in solvent.  
Squeeze excess solvent out of the element and dry.
2. Apply:
  - A small quantity of 2-stroke engine oil

Squeeze excess oil.




## CAM CHAIN

1. Remove
  - Timing window
  - Crankshaft end cover
2. Align
  - "T" mark ①  
(on the flywheel with the stationary pointer ② on the crankcase cover)

**NOTE:** \_\_\_\_\_

Be sure piston is at Top Dead Center (TDC) on compression stroke.



3. Remove:
  - Adjuster cap
4. Loosen
  - Adjuster locknut ①
5. Turn the adjuster ② in until the push rod ③ (inside the adjuster) is flush with the end of the adjuster.

**NOTE:**

Start the engine. While keeping it idling, check the movement of the push rod. If it moves slightly, the adjustment is correct. If it does not move at all, the adjuster is too tight. Loosen the adjuster so the push rod moves slightly.

6. Tighten:
  - Adjuster locknut
7. Install:
  - Adjuster cap
  - Timing window plug
  - Crankshaft end cover




**Adjuster Locknut:**

**30 Nm (3.0 m·kg, 22 ft·lb)**

**Adjuster Cap:**

**5 Nm (0.5 m·kg, 3.6 ft·lb)**



**CLUTCH**

**Free play adjustment**


1. Loosen:
  - Locknuts ①
2. Adjust:
  - Free play ②

(by turning the adjuster ② )








**Clutch Lever Free Play:**

**2 ~ 3 mm (0.08 ~ 0.12 in)**



# CLUTCH/IGNITION TIMING



## Mechanism Adjustment

1. Loosen:
  - Cable adjusters (handlebar and engine side)
2. Drain:
  - Engine oil
3. Remove:
  - Kick starter lever
  - Right side crankcase cover
4. Loosen:
  - Mechanism adjuster locknut ①
5. Push the push lever ② toward the front of the engine with your finger until it stops. With the push lever in this position, turn the adjuster ③ either in or out until the push lever mark and crankcase match mark ④ are aligned. Tighten the locknut.

## IGNITION TIMING

1. Remove:
  - Timing window plug
2. Check:
  - Ignition timingUse Timing Light (YU-08037) and Inductive Tachometer (YU-08036)

|  |                           |
|--|---------------------------|
|  | Engine Speed: 1,350 r/min |
|--|---------------------------|

**NOTE:** \_\_\_\_\_

The stationary pointer (in the timing window) should be within the firing range shown on the flywheel. If the pointer is not within the range or if it is not steady, check the flywheel and/or pickup assembly for tightness and damage. (See "Chapter 6: Electrical" for further information.)



## COMPRESSION PRESSURE

## NOTE:

Insufficient compression pressure will result in performance loss.

1. Measure:
  - Valve clearance  
Out of specification → Adjust.  
(See page 2-2)
2. Check:
  - Decomp lever free play.  
No free play → Adjust.  
(See page 2-3)
3. Warm up the engine.
4. Remove:
  - Spark plug

**Compression Pressure Measurement Steps:**

- Install the Compression Gauge (YM-33223) ① using an adapter.
- Crank over the engine with the kick starter with the throttle wide open until the compression reading on the gauge stabilizes.
- Check readings with specified levels (See chart).

**Compression Pressure (at sea level):****Standard:**

882 kPa (9 kg/cm<sup>2</sup>, 128 psi)

**Minimum:**

785 kPa (8 kg/cm<sup>2</sup>, 114 psi)

**Maximum:**

1,030 kPa (10.5 kg/cm<sup>2</sup>, 149 psi)

**WARNING:**


When cranking the engine, ground spark plug wire to prevent sparking.


- If pressure falls below the minimum level:
  1. Squirt a few drops of oil into the cylinder.
  2. Measure the compression again.

| Compression Pressure<br>(with oil introduced into cylinder) |   |
|---|---|
| Reading   | Diagnosis   |
| Higher than without oil                                     | Worn or damaged piston  |
| Same as without oil   | Defective ring, valves, cylinder head gasket or piston is possible.         |
| Above maximum level   | Inspect cylinder head, valve surfaces, or piston crown for carbon deposits. |

**SPARK PLUG**

1. Remove:
  - Side cover (right)
  - Spark plug cap
  - Spark plug
2. Inspect:
  - Electrode ①  
Wear/ Damage → Replace.
  - Insulator color ②
3. Measure:
  - Plug gap ③  
Out of specification → Regap.  
Use a Wire Gauge or Feeler Gauge.






**Spark Plug Gap:**  
0.6 ~ 0.7 mm (0.024 ~ 0.028 in)

Clean the plug with a spark plug cleaner if necessary.

**Standard spark Plug:**  
D8EA (NGK)  
X24ES-U (NIPPONDENSO)

Before installing a spark plug, clean the gasket surface and plug surface.

4. Tighten:
  - Spark plug




**20 Nm (2.0 m·kg, 14 ft·lb)**

**NOTE:** \_\_\_\_\_

Finger-tighten the spark plug(s) before torquing to specification.





**CHASSIS**


**FRONT AND REAR BRAKES**

**Rear Brake Pedal Height Adjustment**

1. Loosen:
  - Adjuster locknut ①
2. Adjust:
  - Brake pedal height ②
  - by turning the adjuster ③ in or out.



**Brake Pedal Height:**  
10 mm (0.4 in)  
Above the top of the footrest





**Free Play Adjustment**

1. Check:
  - Brake lever/pedal free play
  - Out of specification → Adjust




**Brake Lever Free Play:**  
Front ①:  
3 ~ 7 mm (0.1 ~ 0.3 in)  
Rear ②:  
20 ~ 30 mm (0.8 ~ 1.2 in)



2. Adjust:
  - Brake lever/pedal free play
  - (by turning the adjuster in or out)

- ① Front brake adjuster
- ② Rear brake adjuster



### Brake Lining Inspection

1. See the wear indicator ① position while applying the brake.  
Indicator reaches to the wear limit line ②  
→ Replace.

### NOTE:

For the rear brake lining inspection, it is necessary to remove the rear wheel. See Chapter 5.

### TIRES

1. Measure:
  - Air pressure  
Use an air gauge


**Reference tire pressure: (Front and Rear)**  
 29.4 kPa (0.3 kg/cm<sup>2</sup>, 4.3 psi)  
**Minimum tire pressure:**  
 11.8 kPa (0.12 kg/cm<sup>2</sup>, 1.8 psi)

### WARNING:

This model is equipped with low pressure tires. Pay attention to the following points:

**Recommended tire pressure:**  
 29.4 kPa (0.3 kg/cm<sup>2</sup>, 4.3 psi)  
**Vehicle load limit: 100 kg (220 lb)**  
**Tire size: Front 25.0×8-12**  
**Rear 23.0×12-9**

1. Excessive tire pressure (over 137 kPa 1.4 kg/cm<sup>2</sup>, 20 psi) may cause tire to burst. Inflate tires very slowly. Fast inflation could cause tire to burst.
2. Too low a pressure (below 11.8 kPa (0.12 kg/cm<sup>2</sup>, 1.8 psi)) will cause the rim to dislodge from the tire.
3. Set tire pressures cold.



### WARNING:

If a tire is cracked, damaged or abnormally worn, replace it. If a tire is imbedded with pebbles or metal pieces, remove them.





**Tire Wear Limit:**  
 3 mm (0.12 in)

## STEERING HEAD ADJUSTMENT

### Steering Head Inspection

1. Place the motorcycle on a proper stand, then elevate the front wheel.
2. Check:
  - Steering assembly bearings  
Grasp the bottom of the forks and gently rock the fork assembly back and forth.  
Looseness → Adjust steering head.



### Steering Head Adjustment

1. Remove:
  - Handlebar assembly
2. Loosen:
  - Steering shaft nut ①
  - Inner tube pinch bolts ②
3. Tighten:
  - Ring nut  
Use Ring Nut Wrench (YU-33975) ①

#### Tightening Steps:

Using the steering nut wrench as shown, tighten the nut with specified torque shown below, and back it out 1/3 or 1/4 turn.



**Ring Nut Tightening Torque:**  
38 Nm (3.8 m·kg, 27 ft·lb)

#### NOTE:

- The nut should be installed with the beveled side facing downward.
- The nut should be tightened so that the front forks can be turned smoothly, but not too loosely.

4. Tighten:
  - Steering shaft nut
  - Inner tube pinch bolts
  - Handlebar assembly



**Steering Shaft Nut:**  
85 Nm (8.5 m·kg, 61 ft·lb)

**Handlebar:**  
20 Nm (2.0 m·kg, 14 ft·lb)


**Inner Tube Pinch Bolt:**  
20 Nm (2.0 m·kg, 14 ft·lb)

**DRIVE CHAIN**

**Slack Check**

**NOTE:**

Before checking and/or adjusting, rotate the rear wheel through several revolutions and check tension at several points to find the tightest point. Check and/or adjust the chain slack with the rear wheel in this "tightest" position.




(Primary)

1. Hold the motorcycle in an upright position.
2. Check:
  - Slack  
Push the chain ② downward by the fingers. If the chain top is in line with the indicator ①, adjust or replace the chain as required.

③ Limit



**NOTE:**

The primary drive chain slack can be adjusted only once. If the chain is slack again after the adjusted, replace the chain and sprockets.



(Secondary)


1. Check:
  - Slack ①




**Slack Adjustment**

(Primary)

1. Loosen:
  - Pivot shaft nut ①
2. Remove:
  - Stopper screws ②






3. Use the special tool (included in the owner's tool kit) and turn both adjusting nuts (thrust covers) halfway in either direction so the adjusting nut cut can be in line with the screw hole.
4. Install:
  - Stopper screws
5. Tighten:
  - Pivot shaft nut



**Pivot Shaft:**  
80 Nm (8.0 m•kg, 58 ft•lb)



(Secondary)

1. Loosen:
  - Axle nut ①
2. Turn the chain puller ② both left and right until axle is situated in same puller slot position on each side.
3. Tighten:
  - Axle nut



**Axle Nut:**  
85 Nm (8.5 m•kg, 61 ft•lb)


4. Adjust:
  - Brake pedal free play

### Cleaning and lubrication

**CAUTION:** \_\_\_\_\_

< Primary drive chain only >

This machine has a drive chain with small rubber O-rings between the chain plates. Steam cleaning, high-pressure washes, and certain solvent can damage these O-rings. Use only kerosene to clean the drive





chain. Wipe it dry, and thoroughly lubricate it with SAE 30~50W motor oil. Do not use any other lubricants on the drive chain. They may contain solvents that could damage the O-rings.



**Recommended Lubricant:**

**Primary: SAE 30~50W motor oil**

**Secondary: Yamaha chain and cable lube or SAE 10W30 motor oil**



## MIDDLE SPROCKETS SHAFT

Using a grease pump, grease the middle sprockets shaft till a little grease leak out from oil seal lip.



**Lithium-soap Base Grease**

## CABLE INSPECTION AND LUBRICATION

**Cable Inspection and Lubrication Steps:**

- Remove the two screws that secure throttle housing to handlebar.
- Hold cable end high and apply several drops of lubricant to cable.
- Coat metal surface of disassembled throttle twist grip with suitable all-purpose grease to minimize friction.
- Check for damage to cable insulation. Replace any corroded or obstructed cables.
- Lubricate any cables that do not operate smoothly.



**SAE 10W30 Type SE Motor Oil**

**BRAKE PEDAL/BRAKE AND CLUTCH  
LEVERS**

Lubricate pivoting parts of each lever and pedal.




**SAE 10W30 Type SE Motor Oil**

**SIDESTAND**

Lubricate sidestand at their pivot point.



**SAE 10W30 Type SE Motor Oil**




**FRONT FORK OIL CHANGE**


1. Elevate the front wheel by placing a suitable stand under the engine.
2. Loosen:
  - Front fork pinch bolt ①
3. Remove:
  - Cap bolt ②
  - Spacer ③
4. Place an open container under the drain hole.
5. Remove:
  - Drain screw ①
6. Slowly raise and lower the inner tube to pump out the oil.
7. Install:
  - Drain screw




**Drain Screw:  
2 Nm (0.2 m•kg, 1.4 ft•lb)**


8. Fill:
  - Front fork

|   |  |
|---|--|
|  | <b>Recommended Fork Oil:</b><br>Yamaha Fork Oil 10wt<br><b>Capacity:</b><br>272 cm <sup>3</sup> (9.59 Imp oz, 9.20 US oz)<br><b>Oil Level:</b><br>140 mm (5.51 in) |
|---|--|



9. Install:
  - Spacer ①
  - Cap bolt ②
10. Tighten:
  - Pinch bolt ③

|   |  |
|---|--|
|  | <b>Cap Bolt:</b><br>23 Nm (2.3 m•kg, 17 ft•lb)<br><b>Pinch Bolt:</b><br>20 Nm (2.0 m•kg, 14 ft•lb) |
|---|--|




## ELECTRICAL

### HEADLIGHT


#### Headlight Bulb Replacement

1. Remove:
  - Headlight assembly
  
3. Remove:
  - Bulb  
Turn the bulb holder ① counterclockwise to release bulb.
4. Install:
  - Bulb (New)  
Secure the new bulb with the bulb holder.
  - Headlight cover assembly



#### Headlight Beam Adjustment

1. Adjust:
  - Headlight  
(Vertically)



| Vertical Adjustment |   |
|---------------------|---|
| Higher              | Turn the adjusting screw ① clockwise        |
| Lower               | Turn the adjusting screw ① counterclockwise |





## CHAPTER 3. ENGINE OVERHAUL

|  |             |
|--|-------------|
| <b>ENGINE REMOVAL .....</b>                                  | <b>3-1</b>  |
| <b>PREPARATION FOR REMOVAL .....</b>                         | <b>3-1</b>  |
| <b>REMOVAL .....</b>   | <b>3-2</b>  |
| <br>   |             |
| <b>ENGINE DISASSEMBLY .....</b>                              | <b>3-3</b>  |
| <b>CYLINDER HEAD, CYLINDER AND PISTON .....</b>              | <b>3-3</b>  |
| <b>FLYWHEEL MAGNETO .....</b>                                | <b>3-4</b>  |
| <b>CLUTCH .....</b>  | <b>3-5</b>  |
| <b>KICK STARTER .....</b>                                    | <b>3-5</b>  |
| <b>PRIMARY DRIVE GEAR AND BALANCER DRIVEN GEAR .....</b>     | <b>3-6</b>  |
| <b>OIL PUMP .....</b>  | <b>3-6</b>  |
| <b>SHIFT SHAFT .....</b>                                     | <b>3-6</b>  |
| <b>CRANKCASE .....</b>                                       | <b>3-6</b>  |
| <b>TRANSMISSION, CRANKSHAFT AND BALANCER .....</b>           | <b>3-7</b>  |
| <br>   |             |
| <b>INSPECTION AND REPAIR .....</b>                           | <b>3-8</b>  |
| <b>CYLINDER HEAD .....</b>                                   | <b>3-8</b>  |
| <b>VALVE, VALVE GUIDE, VALVE SEAT AND VALVE SPRING .....</b> | <b>3-9</b>  |
| <b>ROCKER ARM AND ROCKER ARM SHAFT .....</b>                 | <b>3-16</b> |
| <b>CAMSHAFT, CAMSHAFT BUSHING AND CAM SPROCKET .....</b>     | <b>3-18</b> |
| <b>CYLINDER .....</b>  | <b>3-19</b> |
| <b>PISTON .....</b>  | <b>3-20</b> |
| <b>CRANKSHAFT .....</b>                                      | <b>3-22</b> |
| <b>OIL PUMP .....</b>  | <b>3-24</b> |
| <b>CLUTCH .....</b>  | <b>3-24</b> |
| <b>TRANSMISSION .....</b>                                    | <b>3-26</b> |
| <b>STARTER .....</b>   | <b>3-27</b> |
| <br>   |             |
| <b>ENGINE ASSEMBLY AND ADJUSTMENT .....</b>                  | <b>3-29</b> |
| <b>CRANKSHAFT, TRANSMISSION AND CRANKCASE .....</b>          | <b>3-29</b> |
| <b>SHIFTER .....</b>   | <b>3-31</b> |
| <b>BALANCER DRIVE GEAR AND DRIVEN GEAR .....</b>             | <b>3-32</b> |
| <b>OIL PUMP .....</b>  | <b>3-32</b> |
| <b>KICK STARTER .....</b>                                    | <b>3-34</b> |
| <b>CLUTCH .....</b>  | <b>3-35</b> |
| <b>CAM CHAIN .....</b>                                       | <b>3-36</b> |
| <b>PISTON AND CYLINDER .....</b>                             | <b>3-37</b> |
| <b>CYLINDER HEAD .....</b>                                   | <b>3-40</b> |
| <b>FLYWHEEL MAGNETO AND CAM CHAIN TENSIONER .....</b>        | <b>3-42</b> |
| <br>   |             |
| <b>REMOUNTING ENGINE .....</b>                               | <b>3-43</b> |



## ENGINE OVERHAUL

### ENGINE REMOVAL



#### NOTE:

It is not necessary to remove the engine in order to remove the following components:

- Clutch/Primary drive gear
- Kick starter
- Shift shaft
- Flywheel magneto

#### PREPARATION FOR REMOVAL

1. Remove all dirt, mud, dust, and foreign material before removal and disassembly.




2. Use proper tools and cleaning equipment. Refer to chapter 1 "SPECIAL TOOL"



#### NOTE:

When disassembling the engine, keep mated parts together. This includes gears, cylinders, pistons, and other parts that have been "mated" through normal wear. Mated parts must be reused as an assembly or replaced.




3. During engine disassembly, clean all parts and place them in trays in the order of disassembly. This will speed up assembly time and help assure that all parts are correctly reinstalled in the engine.




4. Drain:
  - Engine oil

## REMOVAL

1. Remove:
  - Side covers
  - Seat
2. Disconnect:
  - Fuel pipe
3. Remove:
  - Fuel tank




4. Remove:
  - Exhaust pipe (without muffler body)
  - Spark plug cap
  - Engine guard



5. Remove:
  - Carburetor
6. Disconnect
  - Clutch cable
  - Crankcase ventilation hose
  - Electrical lead wires




7. Remove:
  - Shift pedal
  - Sprocket cover
  - Drive sprocket



8. Remove:
  - Engine mounting bolts
  - Left footrest
  - Engine  
(from the right side of frame)

**NOTE:**


The engine and rear arm are installed using the same pivot shaft. Therefore, take care so that the pivot shaft is pulled, not entirely out, but for enough to set the engine free.

**DISASSEMBLY****CYLINDER HEAD, CYLINDER AND PISTON**


1. Disconnect:
  - Decomp wire
2. Remove:
  - Cam chain tensioner assembly ①
3. Remove:
  - Cam sprocket cover
  - Left crankcase cover
  - Cam sprocket holding bolt

**NOTE:**

Hold the flywheel securing bolt to remove cam sprocket bolt.



- Cam sprocket



4. Remove:
  - Cylinder head bolts

**NOTE:**

Loosen the bolts in the order indicated in the photo.

- Cylinder head
- Cylinder
- Cam chain guide #1

5. Remove:

- Piston pin clip

**NOTE:**

Cover the crankcase with a clean rag so you will not accidentally drop the clip into the crankcase.


- Piston pin
- Piston

**FLYWHEEL MAGNETO**

1. Remove:


- Flywheel securing bolt
- Flywheel






Use Rotor Puller (YU-01080) ①



2. Remove:

- Woodruff key
- Cam chain guide #2 ①
- Cam chain ②



**CLUTCH**

1. Remove:
  - Kick crank
  - Decomp lever ①
  - Right crankcase cover

**NOTE:**


For this removal, slits ② in the crankcase can be used as shown.

2. Remove:
  - Clutch spring holding screws
  - Pressure plate
  - Clutch plates/Friction plates
  - Ball ①
  - Push rod ②
3. Remove:
  - Locknut
  - Lock washer
  - Use Clutch Boss Holder (YM-91042) ① to hold clutch boss.
  - Clutch boss ②
  - Clutch housing ③

4. Remove:
  - Set screw ①
  - Push lever ②

**KICK STARTER**


1. Remove:
  - Kick axle assembly
  - Decomp lever shaft
  - Kick idle gear



### PRIMARY DRIVE GEAR AND BALANCER DRIVEN GEAR


1. Loosen
  - Primary drive gear securing nut ①
  - Balancer gear securing nut ②  
(Place a folded rag between the teeth of the balancer drive gear and driven gear to lock them.)

2. Remove:
  - Oil pump drive gear ③
  - Primary drive gear ④
  - Balancer drive gear ⑤
  - Balancer driven gear ⑥




### OIL PUMP

1. Remove:
  - Oil pump assembly



### SHIFT SHAFT

1. Remove:
  - Shift shaft assembly ①
  - Stopper lever ②
  - Segment ③




### CRANKCASE

1. Remove:
  - Crankcase securing screws

**NOTE:** \_\_\_\_\_  
Working in a crisscross pattern, loosen all screws 1/4 turn each. Remove them after all are loosened.






2. Remove:
  - Right crankcase

**NOTE:** \_\_\_\_\_

For this removal, slits ① in the crankcase can be used as shown.

---




### TRANSMISSION, CRANKSHAFT AND BALANCER

1. Remove:
  - Transmission
  - Shift forks
  - Shift cam

**NOTE:** \_\_\_\_\_

Tap lightly on drive shaft with a soft hammer.

---




2. Remove:
  - Crankshaft ①
  - Balancer ②

**NOTE:** \_\_\_\_\_


Remove assembly carefully. Note the position of each part. Pay particular attention to the location and direction of shift forks.

---




**INSPECTION AND REPAIR  
CYLINDER HEAD**


1. Remove:
  - Tappet covers
  - Bearing stopper plate
2. Remove:
  - Rocker arm shaft ①  
Use 6 mm (0.24 in) screw ② or Slide Hammer (YU-01083-A)
  - Rocker arm
  - Camshaft  
Use 10mm (0.39 in) bolt
3. Attach:
  - Valve Spring Compressor (YM-04019) ①



4. Remove:
  - Valve retainers ①
  - Valve spring seat ②
  - Valve springs ③
  - Oil seal ④
  - Valve spring seat ⑤
  - Valve ⑥




**NOTE:** \_\_\_\_\_  
 Deburr any deformed valve stem end. Use an oil stone to smooth the stem end.  
 \_\_\_\_\_



- ① Deburr
- ② Valve stem

5. Eliminate:
  - Carbon deposit  
Use rounded scraper


**NOTE:** \_\_\_\_\_  
 Do not use a sharp instrument and avoid damaging or scratching:  
 • Spark plug threads  
 • Valve seat  
 • Cylinder head  
 \_\_\_\_\_



6. Measure:
- Cylinder head warpage  
Under specification → Resurface.  
Over specification → Replace.




Less than 0.05 mm (0.002 in)



**VALVE, VALVE GUIDE, VALVE SEAT AND VALVE SPRING**

**Intake and Exhaust Valve**

1. Inspect:
- Valve face
  - Stem end
- Wear/Pitting/Out of specification → Replace.



**Margin Thickness ①:**  
1.0 ± 0.2 mm (0.039 ± 0.008 in)  
**Beveled ②:** 0.5 mm (0.020 in)  
**Minimum Length (Service limit) ③:**  
4.0 mm (0.157 in)


2. Measure:
- Valve stem clearance (cold)  
Out of specification → Replace either valve and/or guide.

|         | Valve stem clearance                     | Maximum                |
|---------|--|------------------------|
| Intake  | 0.010 ~ 0.037 mm<br>(0.0004 ~ 0.0015 in) | 0.08 mm<br>(0.0031 in) |
| Exhaust | 0.025 ~ 0.052 mm<br>(0.0010 ~ 0.0020 in) | 0.10 mm<br>(0.0039 in) |


Valve clearance = [B] - [A]

- ① Valve
- ② Bore gauge
- ③ Valve guide


- [A] Valve stem outside diameter
- [B] Valve guide inside diameter



3. Inspect:
  - Valve stem end  
Mushroom shape/Larger diameter than rest of stem → Replace valve, valve guide, and oil seal.



4. Measure:
  - Valve stem runout  
Out of specification → Replace.




**Maximum Runout:**  
0.03 mm (0.0012 in)

### Valve Guide

**NOTE:** \_\_\_\_\_

- Always replace valve guide if valve is replaced.
- Always replace oil seal if valve is removed.

1. Inspect:
  - Valve guide  
Wear/Oil leakage into cylinder → Replace.




### Valve Guide Removal

**NOTE:** \_\_\_\_\_






- Heat the head in an oven to 100°C (212°F) to ease guide removal and installation and to maintain correct interference fit.

1. Remove:
  - Valve guide  
Use Valve Guide Remover (YM-04064)  
①



### Valve Guide Installation

1. Install:
  - Valve guide (Oversize)  
Use Valve Guide Remover (YM-04064)  
① with Valve Guide Installer (YM-04065)  
②

**NOTE:**

After installing valve guide:

- Use 6 mm (0.24 in) Valve Guide Reamer (YM-04066) (1) to obtain proper valve guide/valve stem clearance.
- Recut the the valve seat.

(2) Valve guide

**Valve Seat**

1. Remove:
  - Carbon  
(from valve seat and valveface)
2. Apply:
  - Mechanics bluing dye (Dykem) (1)  
(to valve face)
3. Insert:
  - Valves  
(to cylinder head)  
Lap the valve to the seat by rotating the lapping stick (1) in both directions.
4. Remove:
  - Valves
5. Measure:
  - Valve face/Valve seat contact surface.  
Wherever valve seat and valve face made contact, bluing will have been removed.  
Out of specification/Pitting/Variation of valve seat width → Cut valve seat further.

**Seat Width:**

Std:  $1.0 \pm 0.1$  mm  
( $0.039 \pm 0.0039$  in)


Limit: 1.6 mm (0.063 in)

## 6. Resurface:


- Valve Seats  
Use a 30°, 45° and 60° Valve Seat Cutter/YM-91043) (1)

**CAUTION:**

When twisting cutter, keep an even down ward pressure (4~5 kg) to prevent chatter marks.



| Cut sections as follows |        |
|-------------------------|--------|
| Section                 | Cutter |
| A                       | 30°    |
| B                       | 45°    |
| C                       | 60°    |



**Valve Seat Recutting Steps:**


- Valve seat is uniform around perimeter of valve face but too wide or not centered on valve face.

| Valve Seat Cutter Set |            | Desired Result                            |
|-----------------------|------------|---|
| Use either            | 30° cutter | To center the seat or to reduce its width |
|                       | 45° cutter |   |
|                       | 60° cutter |   |

- Valve face indicates that valve seat is centered on valve face but is too wide (see "A" diagram).

| Valve Seat Cutter Set |            | Desired Result                                  |
|-----------------------|------------|---|
| Use lightly           | 30° cutter | To reduce valve seat width to 1.0 mm (0.039 in) |
|                       | 60° cutter |   |

- Valve seat is in the middle of the valve face but too narrow (see "B" diagram).




| Valve Seat Cutter Set |            | Desired Result   |
|-----------------------|------------|--|
| Use                   | 45° cutter | To achieve a uniform valve seat width of 1.0 mm (0.039 in) |

- Valve seat is too narrow and right up near valve margin (see "C" diagram).

| Valve Seat Cutter Set |                   | Desired Result   |
|-----------------------|-------------------|--|
| Use                   | 30° cutter, first | To center the seat and to achieve its width of 1.0 mm (0.039 in) |
|                       | 45° cutter        |  |

- Valve seat is too narrow and is located down near the bottom edge of the valve face (see diagram "D").

| Valve Seat Cutter Set |                   | Desired result                            |
|-----------------------|-------------------|---|
| Use                   | 60° cutter, first | To center the seat and increase its width |
|                       | 45° cutter        |   |




### Valve/Valve Seat Assembly Lapping

1. Apply:
  - Coarse lapping compound (small amount) (to valve face ①)
  - Molybdenum disulfide oil (to valve stem)

#### CAUTION:

Be sure no compound enters into the gap between the valve stem and guide.

2. Position:
  - Valve (in cylinder head)



3. Rotate:
  - Valve  
Turn until valve and valve seat are evenly polished, then clean off all compound.

#### NOTE:

To obtain the best lapping results, lightly tap the valve seat while rotating the valve back and forth between your hands.

4. Apply:
  - Fine lapping compound (small amount) (to valve face)
5. Repeat steps 2 and 3.


#### NOTE:

Be sure to clean off all compound from valve face after every lapping operation.

6. Inspect:
  - Valve face  
Not yet uniformly smooth → Repeat procedure from step 1.
7. Apply:
  - Mechanics bluing dye (Dykem) (to valve face and seat)

8. Rotate:
  - Valve
9. Inspect:
  - Valve face

Valve must make full seat contact indicated by grey surface all around. The valve face where bluing was removed.  
Faulty contact → Repla (See procedure below)



10. Clean:
  - Intake/Exhaust port and valve assembly (spray solvent with compressed air)

**NOTE:** \_\_\_\_\_

After the lapping has been completed and the valve assemblies have been reinstalled the valve seal should be tested.

Pour solvent ① into intake and exhaust ports. There should be no leakage past the seat ②.


11. Check:
  - Valve seal

Leakage past valve seat → Relap.  
(See procedure below)

**Relapping steps:**

- Disassemble head parts.
- Repeat lapping steps using fine lapping compound.
- Clean all parts thoroughly.
- Reassemble and check for leakage again using solvent.
- Repeat steps as often as necessary to achieve satisfactory seal.






**Valve Spring**

This engine uses two springs of different sizes to prevent valve float or surging. Valve spring specifications show the basic value characteristics.


- ① Outer spring
- ② Inner spring



1. Measure:
  - Spring free length
  - Out of specification → Replace.




**Minimum Free Length:**  
 Outer: 37.2 mm (1.46 in)  
 Inner: 35.5 mm (1.40 in)



2. Measure:
  - Spring tilt ①
  - Out of specification → Replace.




**Tilt Limit:**  
 25° or 1.2 mm (0.047 in)



3. Measure:
  - Spring force (Installed length) ①
  - Out of specification → Replace.




**Compressed Force ②/Installed Length ①:**  
 Outer: 18.5 ± 1.9 kg  
 (40.8 ± 4.2 lb)/32.0 mm (1.26 in)  
 Inner: 9.3 ± 0.9 kg  
 (20.5 ± 2.0 lb)/30.5 mm (1.20 in)



**Valve Installation**

1. Lubricate
  - Valve stem ①
  - Oil seal ②




**High-Quality Molybdenum Disulfide Motor Oil or Molybdenum Disulfide Grease**

2. Install:
  - Valve ①
  - Oil seal ②
  - Valve spring seat ③
  - Valve springs ④
  - Valve spring seat ⑤
  - Valve retainers ⑥


**NOTE:** \_\_\_\_\_

Install both springs with wider-gapped coils ① facing upwards as shown.




- ① Larger pitch
- ② Smaller pitch


**ROCKER ARM AND ROCKER ARM SHAFTS**



1. Inspect:
  - Rocker arm shaft  
Groove can be felt (bearing surface). Blue discoloration (rocker arm shaft) → Replace then inspect lubrication system.



2. Inspect:
  - Rocker arm shaft hole ①
  - Cam lobe contact surface ②
  - Adjuster surface ③  
Wear/Pitting/Scratches/Blue discoloration → Replace.




## 3. Measure:

- Rocker arm inside diameter  
Use a Bore Gauge ①  
Out of specification → Replace.



**Rocker arm Inside Diameter:**  
 $12 \begin{smallmatrix} +0.018 \\ -0 \end{smallmatrix} \text{ mm } (0.4724 \begin{smallmatrix} +0.0007 \\ -0 \end{smallmatrix} \text{ in})$




## 4. Measure:

- Rocker arm shaft outside diameter  
Use a Micrometer ①  
Out of specification → Replace.




**Rocker arm shaft Outside Diameter:**  
 $12 \begin{smallmatrix} -0.009 \\ -0.019 \end{smallmatrix} \text{ mm } (0.4724 \begin{smallmatrix} +0.0004 \\ -0.0006 \end{smallmatrix} \text{ in})$



## 5. Measure:

- Rocker arm/Rocker shaft clearance  
Calculate clearance by subtracting outside diameter [A] or rocker arm shaft from inside diameter [B] of rocker.






**Arm-to Shaft Clearance:**  
 $0.009 \sim 0.037 \text{ mm } (0.0004 \sim 0.0015 \text{ in})$   
 Limit:  $0.1 \text{ mm } (0.004 \text{ in})$


## CAMSHAFT, CAMSHAFT BUSHING AND CAM SPROCKET

### Camshaft

1. Inspect:
  - Cam lobes  
Pitting/Scrashes/Blue discoloration → Replace.
  
2. Measure:
  - Cam lobes  
Use Micrometer  
Out of specification → Replace




|  | A   | B   |
|---|---|---|
| Intake  | $36.59 \pm 0.05 \text{ mm}$<br>( $1.440 \pm 0.002 \text{ in}$ ) | $30.20 \pm 0.05 \text{ mm}$<br>( $11.89 \pm 0.002 \text{ in}$ ) |
| Exhaust   | $36.59 \pm 0.05 \text{ mm}$<br>( $1.440 \pm 0.002 \text{ in}$ ) | $30.20 \pm 0.05 \text{ mm}$<br>( $11.89 \pm 0.002 \text{ in}$ ) |




### Camshaft Bushing

1. Clean and dry bushings
2. Inspect:
  - Bushings (Inner surfaces)  
Rust spots/Pitting/Scoring → Replace.




### Cam Chain

1. Inspect:
  - Cam chain  
Chain stretch/Cracks → Replace.




**Cam Sprockets**

1. Inspect:
  - Cam sprockets
  - Wear/Damage → Replace.



**Cam Chain Guide**


1. Inspect:
  - Front Guide
  - Rear Guide
  - Wear/Damage → Replace



**Cam Chain Tensioner**


2. Inspect:
  - All parts
  - Damage/Wear → Replace.


- ① End Cap
- ② O-rings
- ③ Locknut
- ④ Adjuster
- ⑤ Spring
- ⑥ Tensioner rod



**CYLINDER**

1. Inspect:
  - Cylinder wall
  - Wear/Scratches → Rebore or replace.
2. Measure:
  - Cylinder bore "C"
  - Use Cylinder Bore Gauge
  - Measure the cylinder bore "C" horizontally and laterally at 24.0 mm (0.945 in) from the cylinder top.
  - Then find the coverage of the measurements.
  - Out of specification → Rebore.

|  | Standard   | Wear limit            |
|--|--|-----------------------|
|  Cylinder bore C: | 67 $^{+0.02}_{-0.03}$ mm<br>(2.6378 $^{+0.0004}_{-0.0006}$ in) | 67.1 mm<br>(2.647 in) |




**PISTON**

1. Inspect:
  - Wear/Scratches/Damage → Replace.
  - Carbonized/ → Remove

**NOTE:** \_\_\_\_\_

Do not use a sharp instrument and avoid damaging or scratching.




2. Measure:
  - Piston outside diameter P
  - Use micrometer
  - Out of specification → Replace.

**NOTE:** \_\_\_\_\_


Measurement should be made at a point 7.5 mm (0.30 in) ① above the bottom edge of the piston.

|            | Size A              |
|------------|---------------------|
| Standard   | 67.0 mm (2.638 in)  |
| Oversize 2 | 67.50 mm (2.657 in) |
| Oversize 4 | 68.00 mm (2.677 in) |

3. Measure:
  - Piston clearance
  - Out of specification → Rebore cylinder or replace piston.





**Piston Clearance = C-P:**  
**0.025 ~ 0.045 mm**  
**(0.0010 ~ 0.0018 in)**  
**Limit: 0.1 mm (0.004 in)**




C: Cylinder bore

**Piston Ring**


1. Measure:
  - Side clearance use a feeler gauge ③
  - Out of specification → Replace piston and/or rings.




|  | Standard                               | Limit                  |
|---|--|------------------------|
| Top ring  | 0.03 ~ 0.07 mm<br>(0.0012 ~ 0.0028 in) | 0.12 mm<br>(0.0047 in) |
| 2nd ring  | 0.02 ~ 0.06 mm<br>(0.0008 ~ 0.0024 in) | 0.12 mm<br>(0.0047 in) |

- ① Piston ring (Keystone)
- ② Piston ring (barrel)
- ④ Piston

2. Position
  - Piston ring  
(into cylinder)  
Push the ring with the piston crown.
3. Measure:
  - End gap  
Use feeler gauge ①  
Out of specification → Replace rings as a set.


|  | Standard                             | Limit                |
|---|--------------------------------------|----------------------|
| Top ring  | 0.15 ~ 0.30 mm<br>(0.006 ~ 0.012 in) | 0.6 mm<br>(0.024 in) |
| 2nd ring  | 0.15 ~ 0.30 mm<br>(0.006 ~ 0.012 in) | 0.6 mm<br>(0.024 in) |
| Oil control<br>(Rails)  | 0.30 ~ 0.90 mm<br>(0.012 ~ 0.035 in) | —                    |



**Oversize Piston Rings**


- The oversize top and middle ring sizes are stamped on top of the ring

|            |                     |
|------------|---------------------|
| Oversize 2 | 0.50 mm (0.0197 in) |
| Oversize 4 | 1.00 mm (0.0394 in) |




### Piston Pin

1. Lubricate:
  - Piston pin ① (lightly)
2. Install:
  - Piston pin  
(into small ② end of connecting rod)
3. Check:
  - Free play  
Free play → Inspect connecting rod for wear.  
Wear → Inspect connecting rod and piston pin.



4. Position
  - Piston pin ①  
(into piston)
5. Check:
  - Free play  
When pin is in place in piston  
ree play → Replace piston pin and/or piston.



### CRANKSHAFT

1. Measure:
  - Runout ①, ②  
Use V-Blocks and Dial Gauge (YU-03097)  
Out of specification → Replace.




**Runout Limit:**  
0.03 mm (0.0012 in)

- Side clearance ③  
Out of specification → Replace the connecting rod.



**Big End Side Clearance:**  
0.35 ~ 0.65 mm (0.014 ~ 0.026 in)





- Small end free play ④  
Out of specification 4 → Replace connecting rod.




**Small End Free Play:**  
**STD: 0.8 ~ 1.0 mm (0.031 ~ 0.039 in)**  
**Limit: 2.0 mm (0.079 in)**

- Assembly width ⑤  
Out of specification → Replace crankshaft



**Crank Width:**  
**55.95 ~ 56.00 mm (2.203 ~ 2.205 in)**

5. Check:
  - Crankshaft bearing  
Play → Replace.



6. To disassemble and reassemble the crank, follow the illustration.

**NOTE:** \_\_\_\_\_

Make sure the oil passages of the crank and crank pin are lined up during assembly.


- ① Crank assembly
- ② Oil passage
- ③ Oil passage


**NOTE:** \_\_\_\_\_

Oil from the oil pump flows to the crankshaft passage by the pin.

Check the movement of the pin and the stretch force.

- ① Crankcase cover
- ② Pin
- ③ Spring
- ④ Crankshaft






**OIL PUMP**


1. Measure:


- Housing ①/outer rotor ② clearance **A**  
Use Feeler Gauge.  
Out of specification → Replace oil pump assembly.

 **Side Clearance "A":**  
0.03 ~ 0.09 mm  
(0.0012 ~ 0.0035 in)

2. Measure:

- Outer rotor ②/inner rotor ③ clearanc **B**  
Use Feeler Gauge  
Out of specification → Replace oil pump assembly.

 **Tip Clearance "B":**  
0.09 ~ 0.15 mm (0.0035 ~ 0.0059 in)



**CLUTCH**

**Clutch Housing**

1. Inspect:

- Dogs on the housing  
Cracks/Wear/Damage → Deburr or replace.
- Clutch housing bearing  
Chafing/Wear/Damage → Replace.


**Clutch Boss**

1. Inspect:

- Clutch boss splines  
Scoring/Wear/Damage → Replace clutch boss assembly.

**NOTE:** \_\_\_\_\_

Scoring on the clutch plate splines will cause erratic operation.




### Friction Plates

1. Inspect:
  - Friction plate  
Damage/Wear → Replace friction plate as a set.
2. Measure:
  - Friction plate thickness  
Measure all at four point.  
Out of specification → Replace friction plate as a set.



**Wear Limit:**  
2.8 mm (0.11 in)




### Clutch Plates

1. Measure:
  - Clutch plate warpage  
Use surface plate and feeler gauge  
Out of specification → Replace.



**Warp Limit:**  
0.2 mm (0.0079 in)




### Push Rod

1. Measure:
  - Push rod runout (long rod)  
Use V-Blocks and Dial Gauge  
Out of specification → Replace.



**Bending Limit:**  
0.2 mm (0.008 in)




### Clutch Springs

1. Measure:
  - Clutch spring free length  
Out of specification → Replace springs as a set.




**Clutch Spring Minimum Length:**  
22.4 mm (0.88 in)



### Clutch Push Lever


1. Inspect:
  - Push lever  
Wear → Repair using 300 – 400 grit sand paper.



### TRANSMISSION


#### Shift Fork

1. Inspect:
  - Shift forks  
(on the gear and shift cam contact surfaces)  
Wear/Chafing/Beds/Damage → Replace.
  
2. Check:
  - Shift fork movement  
(on its guide bar)  
Unsmooth operation → Replace fork and/or guide bar.



#### Shift Cam




1. Inspect:
  - Shift cam grooves  
Wear/Damage/Scratches → Replace.
  - Shift cam segment  
Damage/Wear → Replace.



#### Main and Drive Axles

1. Measure:
  - Axle runout  
Use centering device and Dial Gauge ①.  
Out of specification → Replace.

**Runout Limit: 0.08 mm (0.0031 in)**



2. When replacing the main axle or pinions, take the following steps:

- a. Apply molybdenum oil to the 4th and 5th pinion bosses.
- b. Using a hydraulic press, force-fit the 2nd pinion ⑤ to the position specified below.

- ① Main axle
- ② 4th pinion
- ③ 3rd pinion
- ④ 5th pinion
- ⑤ 2nd pinion

- c. After installing the pinions onto the main axle, make sure the 4th and 5th pinions turn freely around the main axle.


**A**: 9.1 mm (3.59 in)

#### Gears


1. Inspect:
  - Gears  
Damage/Wear → Replace.
2. check:
  - Gear movement  
Unsmooth operation → Replace.
3. Inspect:
  - Mating dogs  
Cracks/Wear/Damage → Replace.

#### STARTER

1. Inspect:
  - Kick gear
  - Idle gear  
Pitting/Damage → Replace.



2. Measure:
- Kick gear spring clip tension out of specification → Replace.



**Kick Clip Tension:**  
**0.65 ~ 1.05kg (1.43 ~ 2.3116)**



**ENGINE ASSEMBLY AND ADJUSTMENT**


**CRANKSHAFT, TRANSMISSION, AND CRANKCASE**

- ① Main axle
- ② 5th pinion
- ③ 3rd pinion
- ④ 4th pinion
- ⑤ 2nd pinion
- ⑥ Washer

- ⑦ Circlip
- ⑧ 1st wheel
- ⑨ 5th wheel
- ⑩ 3rd wheel
- ⑪ 4th wheel
- ⑫ Drive axle


- ⑬ 2nd wheel
- ⑭ Oil seal
- ⑮ Drive sprocket
- ⑯ Sprocket holder
- ⑰ Guide bar
- ⑱ Shift fork 1
- ⑲ Shift fork 2
- ⑳ Segment
- ㉑ Dowel pin

- ㉒ Shift cam
- ㉓ Stopper lever
- ㉔ Stopper spring
- ㉕ Shift fork 3









## 1. Install:

- Crankshaft ①  
(onto the right case half by tapping the crank pin area with a soft head hammer while turning the crankshaft.)
- Balancer ②


## 2. Install:

- Main axle ③/Drive axle ④
- Shift cam
- Shift fork 1, 2/Guide bar ⑤
- Shift fork 3/Guide bar ⑥

**NOTE:** \_\_\_\_\_


Oil each gear and bearing thoroughly.

---



## 3. Apply:

- Quick Gasket® (ACC-11001-05-0 1) ①  
(to the mating surfaces of the both case halves)



## 4. Install:

- Left-half crankcase  
Tap the case on lightly using a soft hammer.

## 5. Tighten:

- Crankcase securing screws  
(in numerical order)



**7 Nm (0.7 m•kg, 5.1 ft•lb)**


**SHIFTER**


## 1. Install:

- Segment ①  
(Apply LOCTITE® to the securing bolt)



**12 Nm (1.2 m•kg, 8.7 ft•lb)**






2. Install
  - Stopper lever ①

**NOTE:** \_\_\_\_\_  
 Take care for stopper lever spring position.

- Shift shaft assembly ②




## BALANCER DRIVE GEAR AND DRIVEN GEAR


1. Assemble:
  - Balancer drive gear ③
2. Install
  - Straight key ①
  - Washer ②
  - Balancer drive gear assembly ③
  - Washer ④



3. Install:
  - Balancer driven gear ⑤  
(with the punch marks in alignment)
  - Straight key ⑥
  - Lock washer ⑦
4. Tighten:
  - Balancer driven gear securing nut ⑧


50 Nm (5.0 m·kg, 36 ft·lb)

Bend lock washer tab against nut flat.



5. Install:
  - Primary drive gear
  - Oil pump drive gear
  - Lock washer
6. Tighten
  - Primary drive gear securing nut



**50 Nm (5.0 m•kg, 36 ft•lb)**


Bend lock washer tab against nut flat.

### OIL PUMP

1. Install:
  - Oil pump rotor assembly ①

### NOTE:

Apply liberal coating of 4-stroke engine oil to the oil pump rotor.




**7 Nm (0.7 m•kg, 5.1 ft•lb)**

- Pump cover/driven gear ②


## KICK STARTER

- |            |                  |
|------------|------------------|
| ① Ball     | ⑦ Return spring  |
| ② Spring   | ⑧ Spring cover   |
| ③ Oil seal | ⑨ Kick gear      |
| ④ Washer   | ⑩ Kick clip      |
| ⑤ Circlip  | ⑪ Kick axle      |
| ⑥ Spacer   | ⑫ Kick idle gear |



1. Install:
  - Decomp lever shaft
  - Kick axle

**NOTE:** Make sure the decomp lever and kick axle are properly engaged. And the kick clip fits into its home position.




2. Hook
  - Return spring ①
3. Install:
  - Kick idle gear ②
4. Check:
  - Kick gear operation
  - Faulty or unsmooth operation → Reassemble.


- ③ Washer



**CLUTCH**

- |                  |                  |
|------------------|------------------|
| ① Locknut        | ⑪ Thrust washer  |
| ② Clutch spring  | ⑫ Clutch housing |
| ③ Pressure plate | ⑬ Ball           |
| ④ O-ring         | ⑭ Push rod       |
| ⑤ Push plate     | ⑮ Push lever     |
| ⑥ Adjuster       | ⑯ Cir clip       |
| ⑦ Lock washer    | ⑰ Oil seal       |
| ⑧ Clutch plate   | ⑱ Bush           |
| ⑨ Friction plate |                  |
| ⑩ Clutch boss    |                  |






1. Install:
  - Clutch housing ①
  - Thrust washer
  - Clutch boss ②

2. Install:
  - Lock washer
3. Tighten:
  - Clutch securing nut
  - Use Clutch Boss Holder (YM-91042) ③

**50 Nm (5.0 m•kg, 36 ft•lb)**


Bend lock washer tab against nut flat.



4. Install:
  - Ball
  - Friction plates/Clutch plates
  - Pressure plate
  - Clutch springs
  - Clutch spring holding screws

**6 Nm (0.6 m•kg, 4.3 ft•lb)**

5. Adjust:
  - Clutch push rod free play  
(See "CLUTCH" on page 2-7)



## CAM CHAIN

1. Install:
  - Cam chain guide 1
  - Cam chain guide 2 ①


**8 Nm (0.8 m•kg, 5.8 ft•lb)**


- Cam chain ②




PISTON AND CYLINDER

- ① Top ring
- ② 2nd ring
- ③ Oil ring (Upper)
- ④ Oil ring (Lower)
- ⑤ Piston
- ⑥ Piston pin
- ⑦ Piston pin clip
- ⑧ Cam chain guide 2
- ⑨ Chain tensioner cap
- ⑩ O-ring
- ⑪ Locknut
- ⑫ Adjuster
- ⑬ Spring
- ⑭ Damper
- ⑮ Push rod
- ⑯ Dowel pin
- ⑰ Cam chain guide 1






1. Install:
  - Piston rings  
(onto the piston)
  - Piston  
(onto the connecting rod)
  - Piston pin  
Apply engine oil
  - Piston pin clip



2. Install:
  - O-ring (new) ①
  - Gasket (new) ②
  - Dowel pin ③



3. Align:
    - Piston ring ends
- ① Top  
 ② Oil ring (Lower rail)  
 ③ Oil ring (Upper rail)

**NOTE:** \_\_\_\_\_  
 Manufacturer's marks or numbers stamped on rings should be on top of rings.  
 \_\_\_\_\_





## 4. Lubricate:

- Piston
- Piston rings
- Cylinder  
(with engine oil)





## 5. Install:

- Cylinder  
Route cam chain and cam chain guide through cam chain journal in each cylinder. Compress piston rings with fingers and hand install cylinders.
- Cylinder holding bolts


## CYLINDER HEAD

- |                          |                          |             |
|--------------------------|--------------------------|-------------|
| ① Valve cotter           | ⑪ Camshaft               | ⑳ Gasket    |
| ② Valve spring retainer  | ⑫ Dowel pin              | ㉑ Cam chain |
| ③ Valve stem seal        | ⑬ Camshaft bushing       |             |
| ④ Valve spring           | ⑭ Cam sprocket           |             |
| ⑤ Valve spring seat      | ⑮ O-ring                 |             |
| ⑥ Intake valve           | ⑯ Circlip                |             |
| ⑦ Locknut                | ⑰ Valve guide            |             |
| ⑧ Adjuster               | ⑱ Oil checking bolt      |             |
| ⑨ Rocker arm             | ⑲ Camshaft bearing plate |             |
| ⑩ Rocker shaft (Exhaust) | ⑳ Lock washer            |             |


|          |  |
|----------|--|
| <b>A</b> | <b>VALVE CLEARANCE (COLD)</b>                          |
| <b>B</b> | <b>INTAKE:</b><br>0.09 ~ 0.13 mm (0.0035 ~ 0.0051 in)  |
| <b>C</b> | <b>EXHAUST:</b><br>0.15 ~ 0.19 mm (0.0059 ~ 0.0075 in) |



|          |   |
|----------|---|
| <b>E</b> | <b>WARP LIMIT</b><br>0.05 mm (0.002 in) |
|----------|---|




|                                 |  |
|---------------------------------|--|
| D8EA (N.G.K.)<br>X24ES-U (N.D.) |  |
| <b>G</b>                        | <b>GAP:</b><br>0.6 ~ 0.7 mm (0.024 ~ 0.028 in) |



1. Install:
  - Cylinder head gasket
  - Dowel pins
  - Cylinder head
2. Tighten
  - Cylinder head bolts  
(in the order indicated in the photo)




**8 mm Frange Bolt (4pcs): ①~④**  
 22 Nm (2.2 m•kg, 16 ft•lb)  
**8 mm Bolt (2pcs) ⑤, ⑥**  
 20 Nm (2.0 m•kg, 14 ft•lb)  
**6 mm Bolt (2pcs) ⑦, ⑧**  
 10 Nm (1.0 m•kg, 7.2 ft•lb)



3. Install:
  - Rocker arms
  - Rocker arm shafts ①

**NOTE:**

Rocker arm shaft end, with inside thread, ② must face out of cylinder head otherwise rocker shaft cannot be removed.




4. Install:
  - Cam shaft
  - Bearing stopper plate
  - Lock washer ①




**8 Nm (0.8 m•kg, 5.8 ft•lb)**

Bend lock washer tab against bolt flat.




5. Install:
  - Cam sprocket  
Align sprocket timing mark ① with cylinder head timing mark ② and at the same time, align crankshaft timing mark ③ with crankcase timing mark ④.
  - Washer
  - Bolt




## FLYWHEEL MAGNETO AND CAM CHAIN TENSIONER

1. Install:
  - Woodruff key
  - Flywheel magneto

 **50 Nm (5.0 m•kg, 36 ft•lb)**



2. Tighten:
  - Cam sprocket bolt


 **60 Nm (6.0 m•kg, 43 ft•lb)**



3. Install:
  - Cam chain tensioner

Adjust the tensioner (Refer to Chaptre 2, "CAM CHAIN" on page 2-\*\*.)

4. Install:
  - Cam sprocket cover
  - Crankcase cover (L and R)
  - Kick crank
  - Drain plug

 **Cam Sprocket Cover:**  
 10 Nm (1.0 m•kg, 7.2 ft•lb)  
**Crankcase Cover (L and R):**  
 7 Nm (0.7 m•kg, 5.1 ft•lb)  
**Kick Crank:**  
 15 Nm (1.5 m•kg, 11 ft•lb)  
**Drain Plug:**  
 43 Nm (4.3 m•kg, 31 ft•lb)

**ENGINE MOUNTING**


1. Install:
  - Engine  
(from right side)
  - Engine stay
2. Tighten:
  - Engine mounting bolts



**8 mm Bolt:**  
32 Nm (3.2 m•kg, 23 ft•lb)

**Pivot Bolt:**  
80 Nm (8.0 m•kg, 58 ft•lb)

3. Install:
  - Carburetor
4. Connect:
  - Stator lead wires
  - Plug cap
  - Crankcase ventilation hose
  - Clutch cable
  - Throttle cable
5. Install:
  - Drive sprocket:
  - Sprocket cover:
  - Shift pedal



① Apply Yamaha bond #4




**Sprocket:**  
10 Nm (1.0 m•kg, 7.2 ft•lb)

**Cover ②:**  
8 Nm (0.8 m•kg, 5.8 ft•lb)


**Shift Pedal:**  
10 Nm (1.0 m•kg, 7.2 ft•lb)


6. Install:
- Exhaust pipe
  - Engine guard

|   |   |
|---|---|
|  | <p><b>Exhaust Pipe:</b><br/>10 Nm (1.0 m•kg, 7.2 ft•lb)</p> <p><b>Engin Guard:</b><br/>20 Nm (2.0 m•kg, 15 ft•lb)</p> |
|---|---|

- Fuel tank
- Seat
- Side covers


7. Fill:
- Engine oil

|   |   |
|---|---|
|  | <p><b>Total Amount:</b><br/>1.3 L (1.14 Imp qt, 1.37 US qt)</p> |
|---|---|



8. Adjust:
- Decomp wire free play ①  
(See "DECOMPRESSION CABLE" on page 2-3)

- ② Adjuster
- ③ Locknut

|   |  |
|---|--|
|  | <p><b>Free play:</b><br/>2~3 mm (0.08~0.12 in)</p> |
|---|--|



---

## CHAPTER 4. CARBURETION

|                                  |     |
|----------------------------------|-----|
| <b>CARBURETOR</b> .....          | 4-1 |
| SECTION VIEW .....               | 4-2 |
| <b>CARBURETOR OVERHAUL</b> ..... | 4-2 |
| REMOVAL AND DISASSEMBLY .....    | 4-2 |
| INSPECTION .....                 | 4-3 |
| ASSEMBLY AND INSTALLATION .....  | 4-4 |
| FUEL LEVEL ADJUSTMENT .....      | 4-4 |





**CHAPTER 4  
CARBURETION**

**CARBURETOR**

- ① Jet needle
- ② Throttle valve
- ③ Starter plunger
- ④ Needle valve assembly
- ⑤ Pilot jet
- ⑥ Main jet
- ⑦ Needle jet
- ⑧ Float
- ⑨ Drain screw
- ⑩ Pilot screw
- ⑪ Throttle stop screw


| SPECIFICATIONS    |                                   |
|-------------------|-----------------------------------|
| Main jet          | #108                              |
| Jet needle        | 4C81-5                            |
| Needle jet        | 2.600                             |
| Pilot jet         | #38                               |
| Pilot screw       | 1 1/2 ± 1/8                       |
| Starter jet       | #58                               |
| Valve seat        | ø2.0                              |
| Float height      | 25.0 ± 1.0 mm<br>(0.98 ± 0.04 in) |
| Fuel level        | 3.5 ± 1.0 mm<br>(0.14 ± 0.04 in)  |
| Engine idle speed | 1,350 ± 50 r/min                  |






## SECTION VIEW

- |                  |           |
|------------------|-----------|
| ① Throttle valve | Ⓐ Air     |
| ② Pilot screw    | Ⓑ Mixture |
| ③ Pilot jet      | Ⓒ Fuel    |
| ④ Main jet       |           |
| ⑤ Needle jet     |           |
| ⑥ Jet needle     |           |





## CARBURETOR OVERHAUL REMOVAL AND DISASSEMBLY

1. Remove:
  - Side cover (Left)
2. Disconnect:
  - Fuel hose
3. Loosen:
  - Hose clamps ①
4. Remove:
  - Carburetor assembly
5. Remove:
  - Carburetor top
  - Throttle valve assembly ①




6. Remove:
  - Float pin ①
  - Float ②
  - Float valve assembly ③






7. Remove:
- Starter plunger assembly ①
  - Pilot jet ②
  - Main jet ③
  - Needle jet ④
  - Pilot screw ⑤




**INSPECTION**


1. Inspect:
- Carburetor body
  - Fuel and Air passages  
Contamination → Wash in petroleum-based solvent.
2. Blow out all passages and jets with compressed air.



3. Inspect:
- Float  
Damaged → Replace.
  - Needle valve
  - Valve seat  
Wear → Replace as a set.



4. Inspect:
- Starter plunger ①
  - Throttle valve ②  
Damage/Wear → Replace.
  - Jet needle ③  
Bend/Wear → Replace.



5. Measure:
- Float height ①

### Float height measurement steps:

- Hold the carburetor in an upside down position.
- Incline the carburetor at 60° ~ 70° (so that the end of the float valve ② does not hang down of float weight).

Measure the distance from the mating surface ③ of the float chamber (gasket removed) to the top of the float using a gauge.


### NOTE:

The float should be just resting on, but not depressing, the spring loaded inlet valve.



### Float Height:

$25.0 \pm 1.0 \text{ mm}$  ( $0.98 \pm 0.04 \text{ in}$ )



### Float height adjustment step:

- Remove the float.
- Adjust float height by bending the float tang ① slightly.

## ASSEMBLY AND INSTALLATION

1. Reverse disassembly and removal steps.


## FUEL LEVEL ADJUSTMENT

1. Measure:
  - Fuel level ①
 Out of specification → Adjust.




### Fuel Level:

$3.5 \pm 1.0 \text{ mm}$  ( $0.14 \pm 0.04 \text{ in}$ )



### Measurement Steps:

- Place the motorcycle on a level surface.
- Use a garage jack under the engine to ensure that the carburetor is positioned vertically.
- Connect the Fuel Level Gauge ① (90890-01312) to the drain pipe ②.
- Loosen the drain screw ③ and start the engine.
- Check the fuel level (a).



2. Adjust:
  - Fuel level  
If necessary.

**Adjustment Steps:**

- Remove the float chamber.
- Adjust float level by bending the float tang ① slightly.

---

## CHAPTER 5. CHASSIS


|   |      |
|---|------|
| <b>FRONT WHEEL</b> .....  | 5-1  |
| REMOVAL.....  | 5-2  |
| INSPECTION.....   | 5-2  |
| INSTALLATION.....   | 5-4  |
| <br>  |      |
| <b>REAR WHEEL</b> .....   | 5-5  |
| REMOVAL.....  | 5-6  |
| INSPECTION.....   | 5-6  |
| INSTALLATION.....   | 5-7  |
| <br>  |      |
| <b>FRONT FORK</b> .....   | 5-8  |
| REMOVAL AND DISASSEMBLY.....  | 5-9  |
| INSPECTION.....   | 5-10 |
| REASSEMBLY.....   | 5-11 |
| INSTALLATION.....   | 5-13 |
| <br>  |      |
| <b>STEERING HEAD</b> .....  | 5-14 |
| REMOVAL.....  | 5-15 |
| INSPECTION.....   | 5-15 |
| INSTALLATION.....   | 5-16 |
| <br>  |      |
| <b>SWINGARM, MIDDLE SPROCKETS SHAFT AND<br/>REAR SHOCK ABSORBER</b> ..... | 5-17 |
| SWINGARM FREE PLAY INSPECTION.....  | 5-18 |
| REMOVAL.....  | 5-18 |
| INSPECTION.....   | 5-19 |
| INSTALLATION.....   | 5-20 |




CHAPTER 5.  
CHASSIS

FRONT WHEEL


- ① Collar
- ② Dust cover
- ③ Oil seal
- ④ Bearing
- ⑤ Spacer
- ⑥ Hub
- ⑦ Drum
- ⑧ Ring
- ⑨ Brake shoe
- ⑩ Camshaft
- ⑪ O-ring
- ⑫ Camshaft lever





**REMOVAL**

1. Place the motorcycle on a proper stand.
2. Remove:
  - Brake adjuster ①
  - Axle shaft ②
  - Front wheel




**INSPECTION**

**Wheel and Axle**

1. Inspect:
  - Axle shaft
 Roll the axle on a Flat Surface.  
 Bends → Replace.

**WARNING:**

**Do not attempt to straighten a dent axle.**




2. Inspect:
  - Wheel:
    - Cracks/ Bends/ Warpage → Replace.
3. Measure:
  - Wheel runout
 Out of specification → Replace.



**Rim Runout Limits:**

- Radial — 1.0 mm (0.04 in)
- Lateral — 1.0 mm (0.04 in)



4. Inspect:
  - Wheel bearings
 Bearings allow play in the wheel hub or wheel turns roughly → Replace.

**Wheel Bearing Replacement Steps:**

- Clean the outside of the wheel hub.
- Drive out the bearing.
  1. Lateral free play ①
  2. Radial free play ②

**WARNING:**

**Eye protection is recommended when using striking tools.**







- Install the new bearing by reversing the previous steps.

**CAUTION:**

Do not strike the center race or balls of the bearing. Contact should be made only with the outer race.

**Brake Shoe**

1. Inspect:
  - Brake shoes
  - Glazing → File with coarse sandpaper.
2. Measure:
  - Lining thickness ①
  - Out of specification → Replace.

**Brake Shoe Thickness**

STD: 4.0 mm (0.16 in)

Limit: 2.0 mm (0.08 in)

**Brake Drum**

1. Inspect:
  - Brake drum
  - Scratch/Rust → Remove with a emery cloth.
2. Measure:
  - Brake drum inside diameter
  - Out of specification → Replace.

**Brake Drum Inside Diameter**

STD: 110 mm (4.33 in)

Limit: 111 mm (4.37 in)


**INSTALLATION**

When installing the front wheel, reverse the removal procedure. Note the following points.

1. Apply:
  - Brake camshaft/Pivot shaft
  - Oil seal lips
  - Axle shaft



**Lightweight Lithium-soap  
Base Grease**



2. Check for proper engagement of the boss on the outer fork tube with the locating slot on the brake shoe plate.




**Front Wheel Axle Nut:  
50 Nm (5.0 m•kg, 36 ft•lb)**





**REAR WHEEL**

- ① Chain puller      ⑪ Hub
- ② Collar            ⑫ Oil seal
- ③ Camshaft lever   ⑬ Dust cover
- ④ Camshaft
- ⑤ Brake shoe
- ⑥ Ring
- ⑦ Drum
- ⑧ Bearing
- ⑨ Wheel collar
- ⑩ Spacer



|          |  |
|----------|--|
| <b>A</b> | <b>TIRE SIZE:</b><br>23.0 × 12 - 9         |
| <b>B</b> | <b>WEAR LIMIT:</b><br>3 mm (0.12 in)       |
| <b>C</b> | <b>RIM RUNOUT LIMIT:</b>                   |
| <b>D</b> | <b>Radial/Lateral:</b><br>1.0 mm (0.04 in) |




**REMOVAL**

1. Place the motorcycle on a proper stand.
2. Remove:
  - Brake adjuster
3. Unhook:
  - Drive chain
4. Remove:
  - Axle shaft
  - Rear wheel

**INSPECTION**


Inspection for rear wheel, axle shaft, brake shoe and brake drum, refer to "FRONT WHEEL" section.



**Drive Chain and Sprockets**

1. Check:
  - Sprocket wear  
Wear → Replace chain and sprockets as a set.

① 1/4 tooth    ② Correct    ③ Roller    ④ Sprocket




2. Check:
  - Drive chain  
Stiff → Lubricate or replace.

**NOTE:** \_\_\_\_\_

For the primary drive chain checking, this method is not available.

- 
- Side plates/ Rollers  
Damage/ Play → Replace.



## 3. Measure:

- Drive chain
- Out of specification → Replace.



**Drive Chain Wear Limit:**  
**150.1 mm (5.91 in)/**  
**10-Pitch distance**

- Ⓐ 10-pitch distance

**INSTALLATION**


When installing the rear wheel, reverse the removal procedure. Pay attention to the following points:

## 1. Grease:


- Brake camshaft/Pivot shaft
- Oil seal lips
- Axle shaft



**Lightweight Lithium-soap**  
**Base Grease**



2. When installing the chain, make certain the closed end of the master link clip ① is facing direction of rotation ②.
3. Check for proper engagement of the boss on the swingarm with the locating slot on the brake shoe plate.
4. Adjust the drive chain slack.
5. Adjust the rear brake.





**Rear Wheel Axle Shaft:**  
**85 Nm (8.5 m·kg, 61 ft·lb)**

**FRONT FORK**

- ① Inner tube
- ② Snap ring
- ③ Dust seal
- ④ Oil seal
- ⑤ Oil seal washer
- ⑥ Slide metal
- ⑦ Outer tube
- ⑧ Drain screw
- ⑨ Damper rod bolt
- ⑩ Cap bolt
- ⑪ O-ring
- ⑫ Spacer
- ⑬ Spring seat
- ⑭ Spring
- ⑮ Damper rod
- ⑯ Taper spindle

|          |   |
|----------|---|
| <b>A</b> | <b>FORK OIL (EACH):</b>   |
| <b>B</b> | <b>Capacity:</b><br>272 cm <sup>3</sup> (9.59 Imp oz, 9.20 US oz) |
| <b>C</b> | <b>Grade:</b><br>Yamaha fork oil 10 wt                            |
| <b>D</b> | <b>FORK SPRING:</b>   |
| <b>E</b> | <b>Free length limit:</b><br>372.5 mm (14.67 in)                  |







### REMOVAL AND DISASSEMBLY

1. Remove:
  - Front wheel
  - Brake cable
2. Loosen:
  - Front fork pinch bolt (Upper) ①
  - Front fork cap bolt ②
  - Front fork pinch bolts (Lower) ③


3. Remove:
  - Front fork
  - Fork boot ④




4. Remove:
  - Cap bolt ①
  - Spacer ②
  - Spring seat ③
  - Spring ④



5. Drain
  - Fork oil




6. Remove:
  - Spring clip ①



### 7. Remove:


- Damper rod securing bolt ⑤.  
Use T-Handle (YM-01326) ① and Fork Damper Rod Holder (YM-33256) ②

- ③ Damper rod
- ④ Inner tube



### Outer Tube Bushings Removal Steps:

- Hold fork leg horizontally.
- Clamp the axle mounting boss of the outer tube securely in a vise with soft jaws.
- Remove the bushings from the outer tube by forcefully, but carefully, with drawing the inner tube.




### INSPECTION

1. Inspect:
  - Inner fork tube  
Scratches/ Bends → Replace.

### WARNING:


Do not attempt to straighten a bent inner fork tube as this may dangerously weaken the tube.



2. Inspect:
  - Outer fork tube  
Scratches/ Bends/ Damage → Replace.
  - Fork spring  
Over specified limit → Replace.



**Fork Spring Free Length:**  
376.5 mm (14.82 in)  
**Limit:**  
372.5 mm (14.67 in)




3. Inspect:
  - Damper rod ①
  - Piston ring ②  
Wear/ Damage → Replace.


### NOTE:

Blow out all oil passages with compressed air.





4. Inspect:
  - Slide metals ①
  - Wear/ Damage → Replace.




**REASSEMBLY**

Before reassembling, clean and inspect all parts and replace when necessary.


1. Install:
  - Damper rod rebound spring ①
  - Damper rod ②
  - (into inner fork tube ③)

Allow the rod to slide slowly down the tube until the it protrudes from the bottom.




2. Install:
  - Taper spindle ①
  - (onto damper rod ②)
  - Inner fork tube ③
  - (into outer tube ④)
3. Tighten:
  - Damper securing bolt
  - Use Damper Rod Holder (YM-33256) and T-Handle (YM-01326).

**23 Nm (2.3 m·kg, 17 ft·lb)**  
**LOCTITE®**



4. Install:
  - Slide metal ①
  - (into outer tube)
  - Use Fork Seal Driver (Weight (YM-33963) ③ and Adaper (YM-1369) ②)

- ④ Inner tube
- ⑤ Outer tube



5. Install:
  - Washer ①  
(on top of the slide metal ③)
  - Oil seal ②  
Use Seal Driver Weight (YM-33963) ④  
and Adapter (YM-1369) ⑤. Grease the  
lips and install with numbered side up.

- ⑥ Inner tube
- ⑦ Outer tube


6. Install:
  - Dust seal  
Use special tools ④  
(YM-33963, YM-1369)
  - Snap ring

7. Fill:
  - Front fork

**Oil Quantity:**  
272 cm<sup>3</sup> (9.59 Imp oz, 9.20 US oz)  
(each):

**Oil Level:**  
140 mm (5.51 in)  
(From top of inner tube fully  
compressed without spring.)

**Oil Grade:**  
Yamaha fork oil 10wt  
(After filling, slowly pump the  
fork up and down to distribute  
oil.)



8. Install:
  - Spring ①
  - Spring seat ②
  - Spacer ③
  - Cap bolt ④
  - Fork boot

**INSTALLATION**

1. Install:
  - Fork
2. Tighten:
  - Inner tube pinch bolts
  - Cap bolt


**Inner Tube Pinch Bolt:****20 Nm (2.0 m•kg, 14 ft•lb)****Cap Bolt:****23 Nm (2.3 m•kg, 17 ft•lb)**


3. Continue Installation; Reverse the removal procedures.




**STEERING HEAD**

- ① Steering shaft nut
- ② Handle crown
- ③ Ring nut
- ④ Bearing cover
- ⑤ Bearing (Upper)
- ⑥ Bearing (Lower)
- ⑦ Steering seal
- ⑧ Lower bracket


 **RING NUT WRENCH:**  
P/N YU-33975



**REMOVAL**

1. Remove:
  - Front wheel
  - Front forks
  - Front fender
  - Headlight assembly

2. Disconnect:
  - Electrical lead wires
  - Brake cable



3. Remove:
  - Handlebar  
(and put aside)
  - Steering fitting nut ①
  - Handle crown ②




4. Remove:
  - Ring nuts ①  
Use Steering Nut Wrench (YU-01268)

**NOTE:**

Support the lower bracket not to drop the balls.

- Lower bracket ②

**INSPECTION**

1. Clean the balls and the races.
2. Inspect:
  - Balls
  - Races
 Pitting/ Dent/ Rust → Replace as a set.

3. When removing the race, drive out by striking it in steps. And fit the race squarely in the head pipe.

**CAUTION:**

**If the ball race is fitted not squarely, the head pipe could be damaged.**



**INSTALLATION**

1. Grease the races and put the balls in it.


**NOTE:**

Make sure the balls are of the same size and the quantity is correct.

|             |                |
|-------------|----------------|
| Upper ..... | 22 psc 3/16 in |
| Lower ..... | 19 psc 1/4 in  |




2. Install:
  - Lower bracket ①
  - Bearing cover ②
  - Ring nut ③



3. Tighten:
  - Ring nut
  - Use Ring Nut Wrench (YU-33975) ①
  - See Chapter 2 "Steering Head Adjustment".


4. Continue Assembly; Reverse the disassembly procedures.

|   |                               |
|---|-------------------------------|
|  | <b>Steering Shaft Nut:</b>    |
|   | 85 Nm (8.5 m•kg, 61 ft•lb)    |
|   | <b>Handlebar:</b>             |
|   | 20 Nm (2.0 m•kg, 14 ft•lb)    |
|   | <b>Inner Tube Pinch Bolt:</b> |
|   | 20 Nm (2.0 m•kg, 14 ft•lb)    |







**SWINGARM, MIDDLE SPROCKETS SHAFT AND REAR SHOCK ABSORBER**

- ① Drive chain
- ② Middle sprocker (IN)
- ③ Collar
- ④ Oil seal
- ⑤ Swingarm
- ⑥ Bearing
- ⑦ Rubber
- ⑧ Circlip
- ⑨ Middle sprockets shaft
- ⑩ Middle sprocket (OUT)
- ⑪ Stopper screw
- ⑫ Adjusting nut (Thrust cover)
- ⑬ Shim
- ⑭ Bush
- ⑮ Distance collar
- ⑯ Indicator



## SWINGARM FREE PLAY INSPECTION

1. Remove:
  - Rear wheel
  - Rear shock absorber lower bolts
2. Check:
  - Swingarm side play ①  
Grasp and move from side to side.  
Side play → Check and adjust bearing.
  - Swingarm vertical movement ②  
Tightness/ Binding/ Rough spots →  
Check and adjust bearing.  
Damage → Replace bearing.



## REMOVAL


1. Remove:
  - Rear wheel
  - Chain covers
2. Loosen:
  - Middle sprockets shaft nuts (inside and outside)

### NOTE:

Apply rear brake to lock the shaft. If stiff, put the transmission in first gear and turn the crankshaft as shown.


3. Remove:
  - Secondary drive chain ①
  - Sprockets ②
  - Middle gears shaft ③
4. Disconnect:
  - Primary drive chain ④  
Use Drive Chain Cutter (YM-33858)






5. Remove:
  - Shock absorber pivoting bolts (lower)
  - Stopper screws ①
  - Pivot shaft ②
  - Swingarm

**NOTE:** \_\_\_\_\_  
 Note the adjusting nut (thrust cover) direction.




6. Remove:
  - Rear shock absorber

**INSPECTION**



1. Inspect:
  - Collars ①
  - Bushes ②
  - Wear/ Damage/ Rust → Replace.
  - Thrust cover ③
  - Wear/ Damage → Replace.





2. Inspect:
  - Oil seals ①
  - Wear/ Damage → Replace.
  - Bearings ②
  - Tightness/ Binding/ Rough spots → Replace.



3. Inspect:
  - Shock absorber
  - Oil leakage/ Bending push rod → Replace.

# SWINGARM, MIDDLE SPROCKETS SHAFT AND REAR SHOCK ABSORBER



## INSTALLATION

When installing the swingarm, reverse the removal procedure. Note the following points.

1. Apply grease to the collors, bushes, oil seal lips, pivot shaft bearings and shock absorber bushes.



**Lithium-soap Base Grease**

2. Fit the oil seals in the direction as shown.

- ① Oil seal (Inside)
- ② Oil seal (Outside)
- ③ Frontward

3. Fit the adjusting nuts (Thrust covers) in the same direction as before disassembly.
4. Then make sure that the adjusting nuts are properly fitted with stopper screws in the nuts notches.





**Stopper Screw:**

**8 Nm (0.8 m•kg, 5.8 ft•lb)**

**Pivot Shaft:**

**80 Nm (8 m•kg, 58 ft•lb)**



4. Tighten the middle sprockets and bend the lock washers tabs against nut flats.



**Middle Sprocket:**

**85 Nm (8.5 m•kg, 61 ft•lb)**

5. Adjust:
  - Secondary drive chain slack
  - Rear brake



---


## **CHAPTER 6. ELECTRICAL**

|                                     |     |
|-------------------------------------|-----|
| <b>CIRCUIT DIAGRAM</b> .....        | 6-1 |
| <b>IGNITION SYSTEM</b> .....        | 6-2 |
| TROUBLESHOOTING .....               | 6-3 |
| <b>LIGHTING SYSTEM</b> .....        | 6-5 |
| TROUBLESHOOTING .....               | 6-6 |
| SWITCHING HEADLIGHT TERMINALS ..... | 6-7 |




CHAPTER 6.  
ELECTRICAL


CIRCUIT DIAGRAM






## IGNITION SYSTEM



- ① Headlight
- ② Lighting switch
- ③ Regulator
- ④ Taillight
- ⑤ Body earth
- ⑥ C.D.I. magneto
- ⑦ C.D.I. unit
- ⑧ Ignition coil
- ⑨ Engine stop switch



**TROUBLESHOOTING**

If the ignition spark is of poor quality or if there is no spark at all, use the following procedure, to locate and repair the problem.

## 1. Check:

- Spark plug

Ground the spark plug to the cylinder head, and kick the starter.

↓ No spark

## 2. Check:

- Spark gap

Hold the high tension lead 6 mm (0.24 in) from the cylinder head, and kick the starter.

Good Spark → Check plug cap.  
Replace spark plug.

↓ No spark

## 3. Check:

- Engine stop switch

Disconnect the Black/White lead of engine stop switch at C.D.I. unit.

If start → Replace.


↓ Does not start

## 4. Check:


- All connectors and couplers

Loose/ Dirt/ Rust → Correct connection.

↓ OK




5. Measure:
- Ignition coil windings
- Out of specification → Replace.




**Primary Coil Resistance ① :**  
 $1.6\Omega \pm 10\%$

**Secondary Coil Resistance ② :**  
 $6.6k\Omega \pm 20\%$

↓ OK



6. Measure:
- Pickup coil resistance
  - Source coil resistance
- Out of specification → Replace pickup coil or stator assembly.




**Pickup Coil Resistance:**  
 $265\Omega \pm 10\%$  (White – Green)

**Source Coil Resistance:**  
 $415\Omega \pm 10\%$  (Red – Brown)






LIGHTING SYSTEM



- ① Headlight
- ② Lighting switch
- ③ Regulator
- ④ Taillight
- ⑤ Body earth
- ⑥ C.D.I. magneto
- ⑦ C.D.I. unit
- ⑧ Ignition coil
- ⑨ Engine stop switch



## TROUBLESHOOTING

If the headlight or taillight will not come on, make checkups in the following sequence to determine the cause of trouble, and repair or replace the light (bulb).

1. Check:
  - Bulb

**Burn out** → Replace.

↓ **OK**




2. Check:
  - Headlight switch

Disconnect the leads from the lighting switch, and connect the Yellow/Red lead directly to the Blue lead.

**Comes on** → Repair or replace.


① Headlight switch

↓ **Does not come on**



3. Measure:
  - Lighting coil resistance

**Out of specification** → Replace.

|   |  |
|---|--|
|  | <b>Lighting Coil Resistance:</b><br><b>0.494Ω ± 10% (Yellow/Red – Black)</b> |
|---|--|


↓ **OK**

4. Measure:
  - Lighting voltage

To check, use the pocket tester in the AC20V range.

**Out of specification** → Check all connectors and couplers or replace the bulb.

↓ **OK**



---

## CHAPTER 7. APPENDICES

|  |      |
|--|------|
| <b>SPECIFICATIONS</b> .....                | 7-1  |
| GENERAL SPECIFICATIONS .....               | 7-1  |
| MAINTENANCE SPECIFICATIONS .....           | 7-4  |
| ENGINE .....                               | 7-4  |
| CHASSIS .....                              | 7-10 |
| ELECTRICAL .....                           | 7-12 |
| <b>GENERAL TORQUE SPECIFICATIONS</b> ..... | 7-14 |
| <b>DEFINITION OF UNITS</b> .....           | 7-14 |
| <b>LUBRICATION DIAGRAMS</b> .....          | 7-15 |
| <b>CABLE ROUTING</b> .....                 | 7-17 |
| <b>WIRING DIAGRAM</b> .....                | 7-20 |




## CHAPTER 7 APPENDICES

### SPECIFICATIONS

#### GENERAL SPECIFICATIONS

| Model                         | BW200N   |
|-------------------------------|--|
| Model Code Number             | 54G  |
| Vehicle Identification Number | JYA54G00 * FA000101                                  |
| Engine Starting Number        | 54G-000101   |
| Dimensions:                   |  |
| Overall Length                | 1,985 mm (78.1 in)                                   |
| Overall Width                 | 830 mm (32.7 in)                                     |
| Overall Height                | 1,090 mm (42.9 in)                                   |
| Seat Height                   | 795 mm (31.3 in)                                     |
| Wheelbase                     | 1,380 mm (54.3 in)                                   |
| Minimum Ground Clearance      | 240 mm (9.45 in)                                     |
| Basic Weight:                 |  |
| With Oil and Full Fuel Tank   | 116 kg (256 lb)                                      |
| Minimum Turning Radius        | 2,100 mm (82.7 in)                                   |
| Engine:                       |  |
| Engine Type                   | Air cooled, 4-stroke, gasoline, SOHC                 |
| Cylinder Arrangement          | Single cylinder, Forward inclined                    |
| Displacement                  | 196 cm <sup>3</sup>                                  |
| Bore × Stroke                 | 67.0 × 55.7 mm (2.64 × 2.19 in)                      |
| Compression Ratio             | 9.5 : 1  |
| Starting System               | Kick starter   |
| Lubrication System            | Wet sump   |
| Oil Type or Grade:            |  |
| Engine Oil                    | Yamalube 4-cycle oil or SAE 20W 40 type SE motor oil |
| Oil Capacity:                 |  |
| Engine oil                    |  |
| Periodic Oil Change           | 1.0 L (0.88 Imp qt, 1.06 US qt)                      |
| With Oil Filter Replacement   | 1.1 L (0.97 Imp qt, 1.16 US qt)                      |
| Total Amount                  | 1.3 L (1.14 Imp qt, 1.37 US qt)                      |
| Air Filter                    | Wet type element                                     |
| Fuel:                         |  |
| Type                          | Regular gasoline                                     |
| Tank Capacity                 | 6.5 L (1.43 Imp gal, 1.72 US gal)                    |
| Reserve Amount                | 0.5 L (0.11 Imp gal, 0.13 US gal)                    |
| Carburetor:                   |  |
| Type/Manufacturer             | Y24P-3P/TEIKEI                                       |
| Spark Plug:                   |  |
| Type/Manufacturer             | D8EA (NGK) or X24ES-U (NIPPON DENSO)                 |
| Gap                           | 0.6 ~ 0.7 mm (0.024 ~ 0.028 in)                      |

# GENERAL SPECIFICATIONS





| Model  | BW200N  |
|--|---|
| Clutch Type  | Wet, multiple-disc  |
| <b>Transmission:</b><br>Primary Reduction System<br>Primary Reduction Ratio<br>Secondary Reduction System<br>Secondary Reduction Ratio<br>Transmission Type<br>Operation<br>Gear Ratio<br><div style="margin-left: 100px;">1st</div> <div style="margin-left: 100px;">2nd</div> <div style="margin-left: 100px;">3rd</div> <div style="margin-left: 100px;">4th</div> <div style="margin-left: 100px;">5th</div> | Gear<br>74/20 (3,700)<br>Chain drive<br>16/12 × 37/14 (3,524)<br>Constant mesh, 5-speed<br>Left foot operation<br><br>34/12 (2.833)<br>34/19 (1.789)<br>29/22 (1.318)<br>26/25 (1.040)<br>23/28 (0.821) |
| <b>Chassis:</b><br>Frame Type<br>Caster Angle<br>Trail   | Steel tube Diamond<br>27.25°<br>88 mm (3.46 in)   |
| <b>Tire:</b><br>Type<br>Size (F)<br>Size (R)   | Tubeless<br>25.0 × 8-12<br>23.0 × 12-9  |
| <b>Tire Pressure (Cold tire):</b><br>Reference tire pressure<br>Minimum<br>Maximum   | 29.4 kPa (0.3 kg/cm <sup>2</sup> , 4.3 psi)<br>11.8 kPa (0.12 kg/cm <sup>2</sup> , 1.8 psi)<br>137 kPa (1.4 kg/cm <sup>2</sup> , 20 psi)  |
| <b>Brake:</b><br>Front Brake Type<br>Operation<br>Rear Brake Type<br>Operation   | Drum brake<br>Right hand operation<br>Drum brake<br>Right foot operation  |
| <b>Suspension:</b><br>Front Suspension<br>Rear Suspension  | Telescopic fork<br>Swing arm  |
| <b>Shock Absorber:</b><br>Front Shock Absorber<br>Rear Shock Absorber  | Coil spring, Oil damper<br>Gas, Coil spring, Oil damper   |

**GENERAL SPECIFICATIONS**

| Model  | BW200N                               |
|--|--------------------------------------|
| Wheel Travel:<br>Front Wheel Travel<br>Rear Wheel Travel | 160 mm (6.30 in)<br>160 mm (6.30 in) |
| Electrical:<br>Ignition System<br>Generator System       | C.D.I. Magneto<br>Flywheel magneto   |
| Headlight Type   | Bulb type                            |
| Bulb Wattage/ Quantity:<br>Headlight<br>Tail Light       | 45W/ 45W × 1<br>5W × 1               |

MAINTENANCE SPECIFICATIONS








A. ENGINE

| Model   | BW200N  |
|---|---|
| Cylinder Head:<br>Warp Limit<br>   | 0.05 mm (0.002 in)<br>*Lines indicate straightedge measurement:   |
| Cylinder:<br>Bore Size<br>< Limit >   | 67 $\begin{smallmatrix} +0.02 \\ -0.03 \end{smallmatrix}$ mm (2.6378 $\begin{smallmatrix} +0.0004 \\ -0.0006 \end{smallmatrix}$ in)<br>67.1 mm (2.642 in)   |
| Camshaft:<br>Drive Method<br>Cam Cap Inside Diameter<br>Camshaft Outside Diameter<br>Shaft-to Cap Clearance<br>Cam Dimensions:<br>Intake<br> Exhaust<br>Camshaft Runout Limit:<br>Cam Chain Type/ Number of Links<br>Cam Chain Adjustment Method | Chain (Left)<br>R/H = 25 $\begin{smallmatrix} +0.021 \\ 0 \end{smallmatrix}$ mm (0.9843 $\begin{smallmatrix} +0.0008 \\ 0 \end{smallmatrix}$ in)<br>L/H = 20 $\begin{smallmatrix} +0.021 \\ 0 \end{smallmatrix}$ mm (0.7874 $\begin{smallmatrix} +0.0008 \\ 0 \end{smallmatrix}$ in)<br>R/H = 25 $\begin{smallmatrix} -0.021 \\ 0 \end{smallmatrix}$ mm (0.9843 $\begin{smallmatrix} -0.0008 \\ 0 \end{smallmatrix}$ in)<br>L/H = 20 $\begin{smallmatrix} -0.021 \\ 0 \end{smallmatrix}$ mm (0.7874 $\begin{smallmatrix} -0.0008 \\ 0 \end{smallmatrix}$ in)<br>0.021 ~ 0.061 mm (0.00083 ~ 0.00240 in)<br>"A"<br>36.59 ± 0.05 mm (1.440 ± 0.002 in)<br>"B"<br>30.20 ± 0.05 mm (1.189 ± 0.002 in)<br>"C"<br>6.59 mm (0.259 in)<br>"A"<br>36.63 ± 0.05 mm (1.442 ± 0.002 in)<br>"B"<br>30.32 ± 0.05 mm (1.194 ± 0.002 in)<br>"C"<br>6.63 mm (0.261 in)<br>0.03 mm (0.0012 in)<br>D.I.D. 25SH/104 Links<br>Manual |
| Rocker Arm/ Rocker Arm Shaft:<br>Rocker Arm Inside Diameter<br>Shaft Outside Diameter<br>Arm-to Shaft Clearance   | 12 $\begin{smallmatrix} +0.018 \\ 0 \end{smallmatrix}$ mm (0.4724 $\begin{smallmatrix} +0.0007 \\ 0 \end{smallmatrix}$ in)<br>12 $\begin{smallmatrix} -0.009 \\ -0.019 \end{smallmatrix}$ mm (0.4724 $\begin{smallmatrix} -0.0004 \\ -0.0008 \end{smallmatrix}$ in)<br>0.009 ~ 0.037 mm (0.0004 ~ 0.0015 in)  |
| Valve Clearance (Cold)<br>IN.<br>EX.  | 0.09 ~ 0.13 mm (0.0035 ~ 0.0043 in)<br>0.15 ~ 0.19 mm (0.0059 ~ 0.0075 in)  |





| Model                                | BW200N |  |
|--------------------------------------|--------|--|
| Valve Dimensions:                    |        |  |
|                                      |        |  |
| "A" Head Dia.                        | IN.    | 34 ± 0.1 mm (1.339 ± 0.004 in)   |
|                                      | EX.    | 28.5 ± 0.11 mm (1.122 ± 0.004 in)  |
| "B" Face Width                       | IN.    | 2.26 ± 0.2 mm (0.089 ± 0.008 in)   |
|                                      | EX.    | 2.26 ± 0.2 mm (0.089 ± 0.008 in)   |
| "C" Seat Limit Width                 | IN.    | 1.0 ± 0.1 mm (0.039 ± 0.004 in)  |
|                                      | EX.    | 1.0 ± 0.1 mm (0.039 ± 0.004 in)  |
| "D" Margin Thickness Limit           | IN.    | 1.0 ± 0.2 mm (0.039 ± 0.008 in)  |
|                                      | EX.    | 1.0 ± 0.2 mm (0.039 ± 0.008 in)  |
| Stem Outside Diameter                | IN.    | 6 <sup>-0.010</sup> <sub>-0.025</sub> mm (0.2362 <sup>-0.0004</sup> <sub>-0.0010</sub> in) |
|                                      | EX.    | 6 <sup>-0.025</sup> <sub>-0.040</sub> mm (0.2362 <sup>-0.0010</sup> <sub>-0.0016</sub> in) |
| Guide Inside Diameter                | IN.    | 6 <sup>+0.012</sup> <sub>0</sub> mm (0.2362 <sup>+0.0005</sup> <sub>0</sub> in)            |
|                                      | EX.    | 6 <sup>+0.012</sup> <sub>0</sub> mm (0.2362 <sup>+0.0005</sup> <sub>0</sub> in)            |
| Stem-to Guide Clearance              | IN.    | 0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in)  |
|                                      | EX.    | 0.025 ~ 0.052 mm (0.0010 ~ 0.0020 in)  |
| Stem Runout Limit                    |        | 0.03 mm (0.0012 in)  |
|                                      |        |  |
| Valve Seat Width Standard/ < Limit > |        | 1.0 ± 0.1 mm (0.0394 ± 0.0039 in)/1.6 mm (0.063 in)  |
| Valve Spring:                        |        |  |
| Free Length                          |        |  |
| Inner Spring                         | IN.    | 35.5 mm (1.40 in)  |
|                                      | EX.    | 35.5 mm (1.40 in)  |
| Outer Spring                         | IN.    | 37.2 mm (1.46 in)  |
|                                      | EX.    | 37.2 mm (1.46 in)  |
| Compressed Length (Valve Closed)     |        |  |
| Inner Spring                         | IN.    | 30.5 mm (1.20 in)  |
|                                      | EX.    | 30.5 mm (1.20 in)  |
| Outer Spring                         | IN.    | 32.0 mm (1.26 in)  |
|                                      | EX.    | 32.0 mm (1.26 in)  |



| Model   |  | BW200N  |  |
|---|--|---|--|
| Tilt Limit*<br>Inner Spring                      IN. & EX.<br>Outer Spring                        IN. & EX. |  | 2.5° or 1.5 mm (0.059 in)<br>2.5° or 1.5 mm (0.059 in)  |  |
|                            |  |   |  |
| Direction of Winding (Top view)   |  | Inner Spring  | Outer Spring   |
|   |  |                                      |   |
| Piston:<br>Piston Size/<br>Measuring Point*   |  |                                     |  |
|   |  | $67^{+0.015}_{-0.065}$ mm ( $2.6378^{+0.0006}_{-0.0026}$ in) / 7.5 mm (0.30 in)<br>(From bottom line of piston skirt) |  |
| Piston Clearance/ < Limit ><br>Oversize                              2nd<br>4th                             |  | 0.025 ~ 0.045 mm (0.0010 ~ 0.0018 in) < 0.1 mm (0.004 in) ><br>67.50 mm (2.657 in)<br>68.00 mm (2.677 in)             |  |
| Piston Ring:<br>Sectional Sketch  |  |   |  |
|                          |  | Top Ring  | Barrel<br>$B = 1.2^{+0.01}_{-0.03}$ mm ( $0.0472^{+0.0004}_{-0.0012}$ in)<br>$T = 2.7 \pm 0.1$ mm ( $0.106 \pm 0.0039$ in) |
|                          |  | 2nd Ring  | Taper<br>$B = 1.2^{+0.01}_{-0.03}$ mm ( $0.0472^{+0.0004}_{-0.0012}$ in)<br>$T = 2.7 \pm 0.1$ mm ( $0.106 \pm 0.0039$ in)  |
|                          |  | Oil Ring  | $B = 2.5^{+0.03}_{+0.01}$ mm ( $0.098^{+0.012}_{+0.004}$ in)<br>$T = 2.8 \pm 0.15$ mm ( $0.110 \pm 0.006$ in)              |
| End gap (Installed)   |  | Top Ring  | 0.15 ~ 0.35 mm (0.0059 ~ 0.0138 in)  |
|   |  | 2nd Ring  | 0.15 ~ 0.35 mm (0.0059 ~ 0.0138 in)  |
|   |  | Oil Ring  | 0.3 ~ 0.9 mm (0.0118 ~ 0.0354 in)  |
| < Limit >   |  | Top Ring  | 0.6 mm (0.0236 in)   |
|   |  | 2nd Ring  | 0.6 mm (0.0236 in)   |
| Side Clearance  |  | Top Ring  | 0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in)  |
|   |  | 2nd Ring  | 0.02 ~ 0.06 mm (0.008 ~ 0.0024 in)   |
| < Limit >   |  | Top Ring  | 0.12 mm (0.0047 in)  |
|   |  | 2nd Ring  | 0.12 mm (0.0047 in)  |



| Model   | BW200N   |
|---|--|
| <p><b>Crankshaft:</b></p>  <p>Crank Width "A"<br/>                     Runout Limit "B"<br/>                     Small End Free Play "C"<br/>                     &lt;Limit&gt;<br/>                     Big End Side Clearance "D"</p>  | <p><math>56_{-0.05}^0</math> mm (<math>2.205_{-0.0020}^0</math> in)<br/>                     0.03 mm (0.0012 in)<br/>                     0.8 ~ 1.0 mm (0.0315 ~ 0.0394 in)<br/>                     2.0 mm (0.079 in)<br/>                     0.35 ~ 0.65 mm (0.014 ~ 0.026 in)</p>  |
| <p><b>Balancer Drive Method</b></p>   | <p>Gear</p>  |
| <p><b>Clutch:</b><br/>                     Friction Plate Thickness/ Quantity<br/>                     Wear Limit<br/>                     Clutch Plate Thickness/ Quantity<br/>                     Warp Limit<br/>                     Clutch Spring Free Length/ Quantity<br/>                     Clutch Spring Minimum Length<br/>                     Primary Reduction Gear<br/>                     Backlash Tolerance<br/>                     Clutch Release Method<br/>                     Push Rod Bending Limit</p> | <p><math>3 \pm 0.1</math> mm (<math>0.118 \pm 0.004</math> in)/5<br/>                     2.8 mm (0.11 in)<br/>                     1.6 mm (0.063 in)/4<br/>                     0.2 mm (0.008 in)<br/>                     37.3 mm (1.469 in)/4<br/>                     22.4 mm (0.882 in)<br/>                     0.009 ~ 0.073 mm (0.0004 ~ 0.0029 in)<br/>                     Inner push (Cam Push)<br/>                     0.2 mm (0.0079 in)</p> |
| <p><b>Transmission:</b><br/>                     Main Axle Deflection Limit<br/>                     Drive Axle Deflection Limit</p>  | <p>0.08 mm (0.0031 in)<br/>                     0.08 mm (0.0031 in)</p>  |
| <p><b>Shifter Type</b></p>  | <p>Guide bar</p>   |
| <p><b>Kick Starter:</b><br/>                     Kick Starter Type<br/>                     Kick Clip Friction Weight<br/>                     &lt;Min. ~ Max.&gt;</p>   | <p>Kick &amp; Mesh,<br/>                     P = 0.85 kg (1.87 lb)<br/>                     0.65 ~ 1.05 kg (1.43 ~ 2.31 lb)</p>  |
| <p><b>Air Filter Oil Grade (Oiled Filter)</b></p>   | <p>SAE 10W 30 SE motor oil</p>   |

# MAINTENANCE SPECIFICATIONS



| Model                           | BW200N  |
|---------------------------------|---|
| <b>Carburetor:</b>              |   |
| Type/ Manufacturer/ Quantity    | Y24P-3P/TEIKEI/ 1   |
| I.D. Mark                       | 54G00   |
| Main Jet (M.J.)                 | # 108   |
| Main Air Jet (M.A.J.)           | ø1.4  |
| Jet Needle-clip Position (J.N.) | 4C81-5  |
| Needle Jet (N.J.)               | 2,600   |
| Pilot Jet (P.J.)                | #38   |
| Pilot Air Jet (P.A.J.)          | ø2.1  |
| Air Screw (turns out) (P.A.S.)  | 1 1/2 ± 1/8   |
| Valve Seat (V.S.)               | ø2.0  |
| Starter Jet (G.S.)              | GS <sub>1</sub> # 58, GS <sub>2</sub> # 70                        |
| Fuel Level (F.L.)               | 3.5 ± 1.0 mm (0.14 ± 0.04 in)                                     |
| Float Height (F.H.)             | 25 ± 1.0 mm (0.98 ± 0.04 in)                                      |
| Engine Idling Speed             | 1,350 ± 50 r/min  |
| <b>Lubrication System:</b>      |   |
| Oil Filter Type                 | Wire mesh   |
| Oil Pump Type                   | Trochoid pump   |
| Tip Clearance                   | 0.09 ~ 0.15 mm (0.0035 ~ 0.0059 in)                               |
| Side Clearance                  | 0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in)                               |
| Bypass Valve Setting Pressure   | 78.5 ~ 117.7 kPa (0.8 ~ 1.2 kg/cm <sup>2</sup> , 11.4 ~ 17.1 psi) |



## Tightening Torque

| Part to be tightened          | Part name      | Thread size | Q'ty | Tightening torque |        |         | Remarks          |
|-------------------------------|----------------|-------------|------|-------------------|--------|---------|------------------|
|                               |                |             |      | Nm                | m · kg | ft · lb |                  |
| Cylinder head                 | Flange bolt    | M8          | 4    | 22                | 2.2    | 16.0    | Apply oil.       |
|                               |                | M8          | 2    | 20                | 2.0    | 14.0    |                  |
| Cylinder body                 | Hex bolt       | M6          | 2    | 10                | 1.0    | 7.2     |                  |
| Cylinder head cover           | Hex bolt       | M6          | 5    | 10                | 1.0    | 7.2     |                  |
|                               | Pan head screw | M6          | 2    | 7                 | 0.7    | 5.1     |                  |
| Camshaft bearing plate        | Hex bolt       | M6          | 2    | 8                 | 0.8    | 5.8     | Use lock washer. |
| Oil checking bolt             | Hex bolt       | M6          | 1    | 7                 | 0.7    | 5.1     |                  |
| Spark plug                    | —              | M14         | 1    | 17.5              | 1.75   | 13.0    |                  |
| Balancer weight               | Hex nut        | M14 × 1.0   | 1    | 50                | 5.0    | 36.0    | Use lock washer. |
| Flywheel magneto              | Hex nut        | M10 × 1.25  | 1    | 50                | 5.0    | 36.0    |                  |
| Valve clearance<br>(Lock nut) | Hex nut        | M6          | 2    | 14                | 1.4    | 10.0    |                  |
| Cam sprocket                  | Bolt           | M10         | 1    | 60                | 6.0    | 43.0    |                  |
| Chain guide                   | Bolt           | M6          | 2    | 8                 | 0.8    | 5.8     |                  |
| Oil pump                      | Panhead screw  | M6          | 3    | 7                 | 0.7    | 5.1     |                  |
| Drain plug                    | —              | M35         | 1    | 43                | 4.3    | 31.0    |                  |
| Filter cover                  | Hex bolt       | M6          | 1    | 10                | 1.0    | 7.2     |                  |
|                               | Panhead screw  | M6          | 2    | 7                 | 0.7    | 5.1     |                  |
| Carburetor joint              | Hex bolt       | M6          | 2    | 12                | 1.2    | 8.7     |                  |
| Carburetor clamp hose         | Panhead screw  | M5          | 1    | 2                 | 0.2    | 1.4     |                  |
| Muffler mount                 | Hex bolt       | M6          | 1    | 10                | 1.0    | 7.2     |                  |
|                               | Flange bolt    | M8          | 1    | 27                | 2.7    | 19.0    |                  |
| Exhaust pipe                  | Hex bolt       | M6          | 2    | 10                | 1.0    | 7.2     | Use<br>Loctite®  |
| Exhaust pipe protector        | Panhead screw  | M6          | 2    | 10                | 1.0    | 7.2     |                  |
| Crankcase, case cover         | Panhead screw  | M6          | 11   | 7                 | 0.7    | 5.1     |                  |
| Clutch spring                 | Hex bolt       | M6          | 4    | 6                 | 0.6    | 4.3     |                  |
| Clutch boss                   | Hex nut        | M14         | 1    | 50                | 5.0    | 36.0    |                  |
| Primary drive gear            | Hex nut        | M14         | 1    | 50                | 5.0    | 36.0    |                  |
| Push lever stopper            | Hex bolt       | M8          | 1    | 12                | 1.2    | 8.7     |                  |
| Push rod adjustment           | Hex nut        | M6          | 1    | 8                 | 0.8    | 5.8     |                  |
| Drive sprocket                | Hex bolt       | M6          | 2    | 10                | 1.0    | 7.2     |                  |
| Shift pedal                   | Hex bolt       | M6          | 1    | 10                | 1.0    | 7.2     |                  |
| Magneto base                  | Panhead screw  | M6          | 4    | 7                 | 0.7    | 5.1     |                  |



**B. CHASSIS**

| Model   | BW200N  |  |  |  |   |  |  |  |
|---|---|--|--|--|---|--|--|--|
| <b>Steering System:</b><br>Steering Bearing Type<br>No. Size of Steel Balls <table style="margin-left: 20px;"> <tr> <td>Upper</td> <td></td> </tr> <tr> <td>Lower</td> <td></td> </tr> </table>   | Upper   |  | Lower  |  | Ball Bearing<br>22 pcs/ 3/ 16 in<br>19 pcs/ 1/ 4 in   |  |  |  |
| Upper   |   |  |  |  |   |  |  |  |
| Lower   |   |  |  |  |   |  |  |  |
| <b>Front Suspension:</b><br>Front Fork Travel<br>Fork Spring Free Length<br>Spring Rate/ Stroke<br><br>Optional Spring<br>Oil Capacity or<br>Oil Level<br><br>Oil Grade   | 160 mm (6.30 in)<br>376.5 mm (14.82 in)<br>$K_1 = 4.90 \text{ N/mm (0.5 kg/mm, 28.0 lb/in) /}$<br>0 ~ 160 mm (0 ~ 6.30 in)<br><br>No.<br>$272 \pm 4 \text{ cm}^3 (9.59 \pm 0.14 \text{ Imp oz, } 9.20 \pm 0.13 \text{ US oz})$<br>140 mm (5.51 in)<br>(From top of inner tube fully compressed<br>without spring.)<br>Yamaha fork oil 10 wt |  |  |  |   |  |  |  |
| <b>Rear Suspension:</b><br>Shock Absorber Travel<br>Spring Free Length<br>Spring Rate/ Stroke<br><br>Optional Spring<br>Enclosed Gas Pressure   | 62 mm (3.23 in)<br>187.5 mm (8.86 in)<br>$K_1 = 55.41 \text{ N/mm (5.65 kg/mm, 316.3 lb/in) /}$<br>0 ~ 62 mm (0 ~ 2.17 in)<br><br>No.<br>1176.84 kPa (12 kg/cm <sup>2</sup> , 170.64 psi)   |  |  |  |   |  |  |  |
| <b>Rear Arm:</b><br>Side Clearance Free Play Limit <table style="margin-left: 20px;"> <tr> <td>End</td> <td></td> </tr> </table>  | End   |  | 1.0 mm (0.039 in)<br>0.4 ~ 0.7 mm (0.016 ~ 0.028 in) |  |   |  |  |  |
| End   |   |  |  |  |   |  |  |  |
| <b>Wheel:</b><br>Front Wheel Type<br>Rear Wheel Type<br>Front Rim Size/ Material<br>Rear Rim Size/ Material<br>Rim Runout Limit <table style="margin-left: 20px;"> <tr> <td>Vertical</td> <td></td> </tr> <tr> <td>Lateral</td> <td></td> </tr> </table>              | Vertical  |  | Lateral  |  | Panel Wheel<br>Panel Wheel<br>12 × 6.5/ Aluminum<br>9 × 9/ Aluminum<br>1.0 mm (0.04 in)<br>1.0 mm (0.04 in) |  |  |  |
| Vertical  |   |  |  |  |   |  |  |  |
| Lateral   |   |  |  |  |   |  |  |  |
| <b>Drive Chain:</b><br>Type/ Manufacturer<br>Number of Links<br>Chain Free Play <table style="margin-left: 20px;"> <tr> <td>Primary/ 2ndary</td> <td></td> </tr> <tr> <td>Primary/ 2ndary</td> <td></td> </tr> <tr> <td>Primary/ 2ndary</td> <td></td> </tr> </table> | Primary/ 2ndary   |  | Primary/ 2ndary                                      |  | Primary/ 2ndary   |  | 50HDL/520D/ D.I.D.<br>42 Links/ 74 Links<br>—/ 25 ~ 40 mm (0.98 ~ 1.57 in) |  |
| Primary/ 2ndary   |   |  |  |  |   |  |  |  |
| Primary/ 2ndary   |   |  |  |  |   |  |  |  |
| Primary/ 2ndary   |   |  |  |  |   |  |  |  |





| Model                                 |         | BW200N  |
|---------------------------------------|---------|---|
| <b>Drum Brake:</b>                    |         |   |
| Type                                  | Front   | Leading and Trailing  |
|                                       | Rear    | Leading and Trailing  |
| Drum Inside Dia                       | Front   | 110 mm (4.33 in)  |
|                                       | <Limit> | 111 mm (4.37 in)  |
|                                       | Rear    | 110 mm (4.33 in)  |
|                                       | <Limit> | 111 mm (4.37 in)  |
| Lining Thickness                      |         | 4 mm (0.16 in)  |
|                                       | <Limit> | 2 mm (0.08 in)  |
| Shoe Spring Free Length               | Front   | 54.0 ± 0.5 mm (2.13 ± 0.02 in)  |
|                                       | Rear    | 54.0 ± 0.5 mm (2.13 ± 0.02 in)  |
| <b>Brake Lever &amp; Brake Pedal:</b> |         |   |
| Brake Lever Free Play/ Position       |         | 3 ~ 7 mm (0.12 ~ 0.28 in) at lever pivot                              |
| Brake Pedal Position                  |         | 10 mm (0.4 in)<br>Vertical height below footrest top                  |
| Brake Pedal Free Play                 |         | 20 ~ 30 mm (0.79 ~ 1.18 in)/<br>Vertical height below brake pedal top |
| Clutch Lever Free Play/ Position      |         | 2 ~ 3 mm (0.08 ~ 0.12 in)/ at lever pivot                             |

**Tightening torque**

| Part to be tightened                     | Thread size | Q'ty                  | Tightening torque |        |         |      |      |
|--|-------------|-----------------------|-------------------|--------|---------|------|------|
|  |             |                       | Nm                | m · kg | ft · lb |      |      |
| Front axle nut                           | M14 × 1.5   | 1                     | 50                | 5.0    | 36      |      |      |
| Handle crown — Inner tube                | M 8 × 1.25  | 2                     | 20                | 2.0    | 14.0    |      |      |
|  |             | — Steering shaft      | M14 × 1.25        | 1      | 85      | 8.5  | 61.0 |
|  |             | — Handle upper holder | M 8 × 1.25        | 4      | 20      | 2.0  | 14.0 |
| Under bracket — Inner tube               | M 8 × 1.25  | 4                     | 20                | 2.0    | 14.0    |      |      |
| Front fork (Cylinder)                    | M10 × 1.0   | 2                     | 23                | 2.3    | 17.0    |      |      |
|  |             | (Cap bolt)            | 2                 | 23     | 2.3     | 17.0 |      |
|  |             | (Drain screw)         | M 4 × 0.7         | 2      | 2       | 0.2  | 1.4  |
| Steering ring nut                        | M25 × 1.0   | 1                     | 38                | 3.8    | 27.0    |      |      |
| Wheel panel — Hub (Front and Rear)       | M 8 × 1.25  | 8                     | 28                | 2.8    | 20.0    |      |      |
| Brake cam lever — Shaft (Front and Rear) | M 6 × 1.0   | 2                     | 9                 | 0.9    | 6.5     |      |      |
| Engine Mount (All)                       | M 8 × 1.25  | 4                     | 33                | 3.3    | 24.0    |      |      |
| Pivot shaft                              | M12 × 1.25  | 1                     | 80                | 8.0    | 58.0    |      |      |
| Middle sprockets                         | M16 × 1.0   | 2                     | 85                | 8.5    | 61.0    |      |      |
| Rear axle nut                            | M16 × 1.5   | 1                     | 85                | 8.5    | 61.0    |      |      |
| Rear sprocket                            | M 8 × 1.25  | 6                     | 28                | 2.8    | 20      |      |      |
| Rear shock absorber                      | M10 × 1.25  | 4                     | 32                | 3.2    | 23.0    |      |      |
| Footrest (Left)                          | M12 × 1.25  | 2                     | 60                | 6.0    | 43.0    |      |      |
| Footrest (Right)                         | M10 × 1.25  | 2                     | 45                | 4.5    | 32.0    |      |      |



C. ELECTRICAL

| Model  | BW200N  |
|--|---|
| Voltage  | 12V   |
| Ignition System:<br>Ignition Timing (B.T.D.C.)<br>Advanced Timing (B.T.D.C.)<br>Advancer Type  | $9^\circ \pm 1^\circ$ at 1,300 r/min<br>$29^\circ \pm 1.3^\circ$ at 6,000 r/min<br>Electrical<br>  |
| C.D.I.:<br>Magneto — Model/ Manufacture<br>Pickup Coil Resistance (Color)<br>Charging Coil Resistance (Color)<br>C.D.I. Unit-Model/ Manufacturer | F36X/YAMAHA<br>$265\Omega \pm 10\%$ at 20°C (68°F) (White — Green)<br>$415\Omega \pm 10\%$ at 20°C (68°F) (Red — Brown)<br>12V-MO/YAMAHA  |
| Ignition Coil:<br>Model/ Manufacturer<br>Minimum Spark Gap<br>Primary Winding Resistance<br>Secondary Winding Resistance                         | C2T4/YAMAHA<br>15 kV or more at 5,000 r/min<br>12 kV or less at 8,000 r/min or 6 mm (0.24 in)<br>$1.6\Omega \pm 10\%$ at 20°C (68°F)<br>$6.6\text{ k}\Omega \pm 20\%$ at 20°C (68°F)  |
| Charging System/ Type  | Flywheel magneto  |
| F.W. Magneto:<br>Lighting Voltage<br>Lighting Coil Resistance (Color)  | $13.5\text{V}$ or more at 3,000 r/min<br>$17.5\text{ V}$ or less at 8,000 r/min<br>$0.494\Omega \pm 10\%$ at 20°C (68°F) (Yellow — Black)<br> |




| Model  | BW200N   |
|--|--|
| Voltage Regulator:<br>Type<br>Model/ Manufacture<br>No Load Regulated Voltage            | Semi Conductor<br>SU229Y/ STANLEY<br>13.5 ± 0.5V |
| Circuit Breaker:<br>Type<br>Amperage for Individual Circuit/ Quantity<br>Main<br>Reserve | Fuse<br>10A × 1<br>10A × 1                       |



**GENERAL TORQUE SPECIFICATIONS**

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.



| A<br>(Nut) | B<br>(Bolt) | General torque specifications |        |         |
|------------|-------------|-------------------------------|--------|---------|
|            |             | Nm                            | m · kg | ft · lb |
| 10 mm      | 6 mm        | 6                             | 0.6    | 4.3     |
| 12 mm      | 8 mm        | 15                            | 1.5    | 11      |
| 14 mm      | 10 mm       | 30                            | 3.0    | 22      |
| 17 mm      | 12 mm       | 55                            | 5.5    | 40      |
| 19 mm      | 14 mm       | 85                            | 8.5    | 51      |
| 22 mm      | 16 mm       | 130                           | 13.0   | 94      |


**DEFINITION OF UNITS**

| Unit          | Read                  | Definition                                  | Measure            |
|---------------|-----------------------|---|--------------------|
| mm            | millimeter            | $10^{-3}$ meter                             | Length             |
| cm            | centimeter            | $10^{-2}$ meter                             | Length             |
| kg            | kilogram              | $10^3$ gram                                 | Weight             |
| N             | Newton                | $1 \text{ kg} \times \text{m}/\text{sec}^2$ | Force              |
| Nm            | Newton meter          | $\text{N} \times \text{m}$                  | Torque             |
| m · kg        | Meter kilogram        | $\text{m} \times \text{kg}$                 | Torque             |
| Pa            | Paskal                | $\text{N}/\text{m}^2$                       | Pressure           |
| N/mm          | Newton per millimeter | $\text{N}/\text{mm}$                        | Spring rate        |
| L             | Liter                 | —   | Volume or Capacity |
| $\text{cm}^3$ | Cubic centimeter      | —   | Volume or Capacity |
| r/min         | Rotation per minute   | —   | Engine speed       |




LUBRICATION DIAGRAMS

- ① Camshaft
- ② Oil cleaner
- ③ Main axle
- ④ Drive axle
- ⑤ Crankshaft
- ⑥ Oil filter
- ⑦ Oil cleaner element



LUBRICATION DIAGRAMS

- ① Camshaft
- ② Crankcase
- ③ Oil pump






CABLE ROUTING

- ① Engine stop switch lead
- ② Fuel tank breather pipe
- ③ Band
- ④ Taillight lead
- ⑤ Clamp
- ⑥ C.D.I. magneto lead
- ⑦ Carburetor ventilation pipe
- ⑧ Carburetor breather pipe
- ⑨ Cable holder
- ⑩ Clutch cable
- ⑪ Pass the clutch cable through the cable guide
- ⑫ Cable guide
- ⑬ Brake cable
- ⑭ Throttle cable

**CAUTION:**


**Proper cable and lead routing is essential to insure safe vehicle operation.**



# CABLE ROUTING




- ① Regulator
- ② C.D.I. unit
- ③ Pass through the ventilation hose between the air filter case and mud guard.
- ④ Mud guard
- ⑤ Taillight
- ⑥ Air filter case
- ⑦ Ventilation hose
- ⑧ Clutch cable
- ⑨ Brake cable
- ⑩ Fuel tank breather pipe
- ⑪ Throttle cable
- ⑫ Band






- ① Ignition coil
- ② Headlight lead
- ③ Headlight switch lead
- ④ Wire harness
- ⑤ Clamp the decompression wire
- ⑥ Band
- ⑦ Carburetor ventilation pipe
- ⑧ Decompression wire
- ⑨ High tension cord



BW200N WIRING DIAGRAM





**YAMAHA**

**BW200ES**

**Supplementary  
Service Manual**



---

## **FOREWORD**

This Supplementary Service Manual has been prepared to introduce new service and new data for the BW200ES. For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with following manual.

**BW200N Service Manual (LIT-11616-04-63)**

### **BW200ES**

#### **SUPPLEMENTARY SERVICE MANUAL**

**©1985 by Yamaha Motor Corporation, U.S.A.**

**1st Edition, November 1985**

**All rights reserved. Any reprinting or  
unauthorized use without the written  
permission of Yamaha Motor Corporation,  
U.S.A. is expressly prohibited.**

**Printed in U.S.A.**

**P/N LIT-11616-05-21**

---

## NOTICE

This manual was written by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to put an entire mechanic's education into one manual, so it is assumed that persons using this book to perform maintenance and repairs on Yamaha machines have a basic understanding of the mechanical concepts and procedures inherent in machine repair technology. Without such knowledge, attempted repairs or service to this model may render it unfit to use and/or unsafe.

Yamaha Motor Company, Ltd. is continually striving to improve all models manufactured by Yamaha. Modifications and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha dealers and will, where applicable, appear in future editions of this manual.

TECHNICAL PUBLICATIONS  
SERVICE DIVISION  
MOTORCYCLE OPERATIONS  
YAMAHA MOTOR CO., LTD

## HOW TO USE THIS MANUAL

### PARTICULARLY IMPORTANT INFORMATION

This material is distinguished by the following notation.

**NOTE:** A **NOTE** provides key information to make procedures easier or clearer.

**CAUTION:** A **CAUTION** indicates special procedures that must be followed to avoid damage to the machine.

**WARNING:** A **WARNING** indicates special procedures that must be followed to avoid injury to a machine operator or person inspecting or repairing the machine.

### MANUAL FORMAT






















All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings  
Pitting/Damage → Replace.

### EXPLODED DIAGRAM

Each chapter provides exploded diagrams before each disassembly section for ease in identifying correct disassembly and assembly procedures.

|  |  |   |
|--|--|---|
| ①<br>GEN<br>INFO  | ②<br>INSP<br>ADJ  |   |
| ③<br>ENG          | ④<br>COOL         |   |
| ⑤<br>CARB         | ⑥<br>CHAS         |   |
| ⑦<br>ELEC         | ⑧<br>APPX         |   |
| ⑨                | ⑩                |   |
| ⑪               | ⑫               |   |
| ⑬               | ⑭               |   |
| ⑮               | ⑯               | ⑰  |
| ⑱               | ⑲               | ⑳  |
| ㉑               |  |   |

## ILLUSTRATED SYMBOLS (Refer to the illustration)

Illustrated symbols ① to ⑧ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Periodic inspection and adjustment
- ③ Engine
- ④ Cooling system
- ⑤ Carburetion
- ⑥ Chassis
- ⑦ Electrical
- ⑧ Appendices

Illustrated symbols ⑨ to ⑭ are used to identify the specifications appearing in the text.

- ⑨ Filling fluid
- ⑩ Lubricant
- ⑪ Tightening
- ⑫ Wear limit, clearance
- ⑬ Engine speed
- ⑭  $\Omega$ , V, A

Illustrated symbols ⑮ to ㉑ in the exploded diagram indicate grade of lubricant and location of lubrication point.

- ⑮ Apply engine oil
- ⑯ Apply gear oil
- ⑰ Apply molybdenum disulfide oil
- ⑱ Apply wheel bearing grease
- ⑲ Apply lightweight lithium-soap base grease
- ⑳ Apply molybdenum disulfide grease
- ㉑ Apply locking agent (LOCTITE®)

---

# CONTENTS

|   |    |
|---|----|
| <b>PERIODIC INSPECTIONS AND ADJUSTMENTS</b> ..... | 1  |
| <b>INTRODUCTION</b> .....                         | 1  |
| <b>PERIODIC MAINTENANCE/LUBRICATION</b> .....     | 1  |
| <b>CHASSIS</b> .....                              | 2  |
| AIR FILTER CLEANING .....                         | 2  |
| <b>ELECTRICAL</b> .....                           | 3  |
| BATTERY INSPECTOIN .....                          | 3  |
| FUSE INSPECTION .....                             | 6  |
| <b>ENGINE OVERHAUL</b> .....                      | 8  |
| <b>ENGINE REMOVAL</b> .....                       | 8  |
| REMOVAL .....                                     | 8  |
| DISASSEMBLY .....                                 | 9  |
| <b>INSPECTION AND REPAIR</b> .....                | 11 |
| STARTER DRIVES .....                              | 11 |
| <b>ENGINE ASSEMBLY</b> .....                      | 13 |
| ENGINE MOUNTING .....                             | 14 |
| <b>ELECTRICAL</b> .....                           | 15 |
| <b>BW200ES CIRCUIT DIAGRAM</b> .....              | 15 |
| <b>ELECTRICAL COMPONENTS</b> .....                | 17 |
| <b>ELECTRICAL STARTING SYSTEM</b> .....           | 19 |
| CIRCUIT DIAGRAM .....                             | 19 |
| STARTING CIRCUIT OPERATION .....                  | 21 |
| TROUBLESHOOTING .....                             | 22 |
| STARTER MOTOR .....                               | 29 |
| <b>IGNITION SYSTEM</b> .....                      | 37 |
| CIRCUIT DIAGRAM .....                             | 37 |
| TROUBLESHOOTING .....                             | 39 |
| <b>CHARGING SYSTEM</b> .....                      | 45 |
| CIRCUIT DIAGRAM .....                             | 45 |
| TROUBLESHOOTING .....                             | 47 |
| <b>LIGHTING SYSTEM</b> .....                      | 53 |
| CIRCUIT DIAGRAM .....                             | 53 |
| TROUBLESHOOTING .....                             | 55 |
| <b>SIGNAL SYSTEM</b> .....                        | 61 |
| CIRCUIT DIAGRAM .....                             | 61 |
| TROUBLESHOOTING .....                             | 63 |
| <b>APPENDICES</b> .....                           | 69 |
| <b>SPECIFICATIONS</b> .....                       | 69 |
| GENERAL SPECIFICATIONS .....                      | 69 |
| MAINTENANCE SPECIFICATIONS .....                  | 70 |
| <b>CABLE ROUTING</b> .....                        | 74 |
| <b>BW200ES WIRING DIAGRAM</b>                     |    |

## PERIODIC INSPECTIONS AND ADJUSTMENTS

### INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.


### PERIODIC MAINTENANCE/LUBRICATION

Unit: km (mi)

| Item                   | Remarks   | Initial               |                       |                       | Every                 |                       |
|------------------------|---|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|
|                        |   | 1 month               | 3 months              | 6 months              | 6 months              | 1 year                |
| Valve(s)               | Check valve clearance.<br>Adjust if necessary.                            | <input type="radio"/> |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Cam chain              | Check chain tension.<br>Adjust if necessary.                              | <input type="radio"/> |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Spark plug             | Check condition.<br>Clean or replace if necessary.                        | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Air filter             | Clean. Replace if necessary.  |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Carburetor             | Check idle speed/starter operation. Adjust if necessary.                  |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Fuel line              | Check fuel hose for cracks or damage. Replace if necessary.               |                       |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Engine oil             | Replace<br>(Warm engine before draining.)                                 | <input type="radio"/> |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Engine oil filter      | Clean. Replace if necessary.  | <input type="radio"/> |                       | <input type="radio"/> |                       | <input type="radio"/> |
| Engine oil strainer    | Clean. Replace if necessary.  | <input type="radio"/> |                       | <input type="radio"/> |                       | <input type="radio"/> |
| Brake                  | Check operation.<br>Adjust if necessary.                                  | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Clutch                 | Check operation.<br>Adjust if necessary.                                  | <input type="radio"/> |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Drive chain            | Check operation/Adjust as required/Replace as required.                   | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | 1 Month               |                       |
| Decompression system   | Check operation.<br>Adjust if necessary.                                  |                       |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Wheels                 | Check balance/damage/runout.<br>Repair if necessary.                      | <input type="radio"/> |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Wheel bearings         | Check bearings assembly for looseness/damage.<br>Replace if damaged.      | <input type="radio"/> |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Rear arm pivot         | Apply grease lightly every 12 months.**                                   |                       |                       |                       |                       | <input type="radio"/> |
| Middle sprockets shaft | Lubricate every 6 months.**   |                       |                       | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Steering bearing       | Check bearing assembly for looseness. Moderately repack every 12 months.* | Check                 |                       | Check                 | Check                 | <input type="radio"/> |
| Fittings/Fasteners     | Check all chassis fittings and fasteners. Correct if necessary.           | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Battery                | Top-up/Check specific gravity and breather pipe.                          | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |

\* Medium weight wheel bearing grease.


\*\* Lithium soap base grease.



## CHASSIS AIR FILTER CLEANING


1. Remove:
  - Side cover (Right)
  - Air filter case cover (Right) ①

**NOTE:** \_\_\_\_\_  
Do not remove air filter case cover (Left).



2. Remove:
  - Air filter element ①

**CAUTION:** \_\_\_\_\_  
The engine should never be run without the air filter element; excessive piston and/or cylinder wear may result.



3. Remove:
  - Filter guide ①

4. Wash the element gently, but thoroughly, in solvent.

**WARNING:** \_\_\_\_\_  
Never use low flash point solvents such as gasoline to clean the air filter element. Such solvent may lead to a fire or explosion.

5. Squeeze the excess solvent out of the filter and let dry.

**CAUTION:** \_\_\_\_\_  
Do not twist the filter element when squeezing the filter element.

6. Pour a small quantity of foam-air-filter oil or Yamalube 2-cycle oil onto the filter element and work thoroughly into the porous foam material.

**NOTE:** \_\_\_\_\_

In order to function properly, the element must be damp with oil at all times, but not dripping with oil.

---


7. Install:

- Air filter element
- Filter element guide
- Air filter case cover (Right)
- Side cover (Right)

**NOTE:** \_\_\_\_\_

Fit the filter element on the filter case and coat the sealing edge of the element with light grease to provide an airtight seal.

---



## ELECTRICAL BATTERY INSPECTION


1. Remove:
  - Cover ①


2. Remove:
  - Band ①
  - Battery ②

**NOTE:** \_\_\_\_\_

Disconnect the negative lead first, and then disconnect the positive lead.

---





### 3. Check:


- Fluid level

Incorrect → Refill.

Fluid level should be between upper ① and lower ② level marks.

### CAUTION:

Normal tap water contains minerals which are harmful to a battery; therefore, refill only with distilled water.



### 4. Inspect:

- Battery fluid specific gravity
- Out of specification → Charge.

**Charging Current:**

**0.7 Amps/10 Hrs.**

**Specific Gravity:**

**1.280 at 20°C (68°F)**

### WARNING:

Battery electrolyte is dangerous; it contains sulfuric acid and therefore is poisonous and highly caustic.

Always follow these preventive measures:

- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.
- Wear protective eye gear when handling or working near batteries.

Antidote (EXTERNAL):

- SKIN – Flush with water.
- EYES – Flush with water for 15 minutes and get immediate medical attention.

Antidote (INTERNAL):

- Drink large quantities of water or milk follow with milk of magnesia) beaten egg, or vegetable oil. Get immediate medical attention.







## BATTERY INSPECTION

---

Batteries also generate explosive hydrogen gas, therefore you should always follow these preventive measures:

- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks, or open flames (e.g., welding equipment, lighted cigarettes, etc.)
- **DO NOT SMOKE** when charging or handling batteries.

**KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.**

---

5. Inspect:

- Battery breather pipe  
Obstruction → Remove.  
Damage → Replace.


6. Install:

- Battery

**NOTE:** \_\_\_\_\_

Connect the positive lead first, and then connect the negative lead.

---




7. Connect/Inspect:

- Battery breather pipe ①  
Be sure the pipe is properly attached and routed.

② Pass through clamp

**CAUTION:**


When inspecting the battery, be sure the breather pipe is routed correctly. If the breather pipe touches the frame or exits in such a way as to cause battery electrolyte or gas to exit onto the frame, structural and cosmetic damage to the machine can occur.



## FUSE INSPECTION

1. Remove:

- Seat



2. Inspect:

- Fuse ①  
Defective → Replace.  
Blow fuse (New) → Inspect circuit.

**Blown fuse procedure steps:**

- Turn off ignition and the circuit.
- Install a new fuse of proper amperage.
- Turn on switches to verify operation of electrical device.
- If fuse blows immediately again, check circuit in question.

**WARNING:**

Do not use fuses of higher amperage rating than recommended. Extensive electrical system damage and fire could result from substitution of a fuse of improper amperage.



# FUSE INSPECTION

---

| Description | Amperage | Quantity |
|-------------|----------|----------|
| Main        | 10A      | 1        |
| Reserve     | 10A      | 1        |



## ENGINE OVERHAUL


### ENGINE REMOVAL

#### REMOVAL

1. Remove:


- Side covers (Left and right)
- Seat
- Fuel tank
- Exhaust pipe
- Carburetor

Refer to "ENGINE REMOVAL" in BW200N  
(LIT-11616-04-63) SERVICE MANUAL.




2. Disconnect:

- CDI magneto leads
- Neutral switch lead



3. Remove:

- Frame earth lead ①  
(at starter motor)



4. Remove:

- Starter motor lead ①  
(at starter relay)
- Engine assembly

Refer to "ENGINE REMOVAL" in BW200N  
(LIT-11616-04-63) SERVICE MANUAL.

**DISASSEMBLY**

## 1. Remove:


- Cylinder head
- Cylinder
- Piston

Refer to "DISASSEMBLY" in BW200N  
(LIT-11616-04-63) SERVICE MANUAL.



## 2. Remove:

- Starter motor ①



## 3. Remove:

- Bolt (CDI magneto) ①



## 4. Remove:

- CDI magneto
- Use the Rotor Puller (YM-01080) ①.



## 5. Remove:

- Starter idle gear ①
- Idle gear axle ②
- Starter wheel gear ③






6. Remove:

- Cam chain and guide
- Clutch
- Kick starter
- Oil pump
- Balancer gears
- Shifter
- Crankcase
- Crankshaft

Refer to "DISASSEMBLY" in BW200N  
(LIT-11616-04-63) SERVICE MANUAL.



## INSPECTION AND REPAIR


### STARTER DRIVES

#### 1. Check:

- Roller operation

Push the roller to arrow direction.

Unsmooth operation → Replace starter clutch.




#### 2. Inspect:

- Starter wheel gear teeth ①

- Starter idle gear teeth ②

Burrs/Chips/Roughness/Wear → Replace.



#### 3. Inspect:

- Contacting surfaces

Pitting/Wear/Damage → Replace.



#### 4. Check:

- Starter clutch operation

#### Clutch operation checking steps:

- Install the starter wheel gear to the starter clutch, and hold the starter clutch.

- When turning the wheel gear clockwise, the starter clutch and the wheel gear should be engaged.

If not, the starter clutch is faulty. Replace it.

- When turning the wheel gear counterclockwise, the wheel gear should turn freely.

If not, the starter clutch is faulty. Replace it.






## STARTER DRIVES

- ① Starter idle gear
- ② Idle gear axle
- ③ Starter wheel gear
- ④ Starter clutch

Ⓐ AFTER INSTALLING THE STARTER CLUTCH, CALK THE BOLT END, AS SHOWN.







## ENGINE ASSEMBLY

### 1. Install:

- Crankshaft
- Crankcase
- Shifter
- Balancer gears
- Oil pump
- Kick starter
- Clutch
- Cam chain and guide

Refer to "ENGINE ASSEMBLY AND ADJUSTMENT" in BW200N (LIT-11616-04-63) SERVICE MANUAL.



### 2. Install:

- Starter wheel gear ①
- Idle gear axle ②
- Starter idle gear ③

### 3. Apply:


- Molybdenum disulfide oil (to the starter clutch roller)

### 4. Install:

- CDI magneto

### NOTE:

When installing the CDI magneto, make sure the woodruff key is properly seated in the key way of the crankshaft. Apply a light coating of lithium soap base grease to the tapered portion of the crankshaft end.




5. Tighten:
- Bolt (CDI magneto) ①



50 Nm (5.0 m•kg, 36 ft•lb)



6. Apply:
- Lithium soap base grease (to O-ring)



7. Install:
- Starter motor ①

8. Install:
- Piston
  - Cylinder
  - Cylinder head
- Refer to "ENGINE ASSEMBLY AND ADJUSTMENT" in BW200N (LIT-11616-04-63) SERVICE MANUAL.


#### ENGINE MOUNTING

Refer to "ENGINE MOUNTING" in BW200N (LIT-11616-04-63) SERVICE MANUAL.



ELECTRICAL

BW200ES CIRCUIT DIAGRAM





- ① Main switch
- ② CDI magneto
- ③ "ENGINE STOP" switch
- ④ CDI unit
- ⑤ Ignition coil
- ⑥ Spark plug
- ⑦ Rectifier/Regulator
- ⑧ "LIGHTS" switch
- ⑨ Headlight
- ⑩ Taillight
- ⑪ Fuse
- ⑫ Starter motor
- ⑬ Starter relay
- ⑭ Battery
- ⑮ Starting circuit cut-off relay
- ⑯ Clutch switch
- ⑰ "START" switch
- ⑱ Neutral light
- ⑲ Neutral switch


**COLOR CODE**

|          |              |
|----------|--------------|
| R.....   | Red          |
| W.....   | White        |
| B.....   | Black        |
| Br.....  | Brown        |
| G.....   | Green        |
| Y.....   | Yellow       |
| L.....   | Blue         |
| Sb.....  | Sky blue     |
| O.....   | Orange       |
| B/R..... | Black/Red    |
| B/W..... | Black/White  |
| Y/R..... | Yellow/Red   |
| R/W..... | Red/White    |
| L/W..... | Blue/White   |
| B/Y..... | Black/Yellow |
| R/B..... | Red/Black    |



## ELECTRICAL COMPONENTS

- ① Wire harness
- ② Main switch
- ③ Starting circuit cut-off relay
- ④ Ignition coil
- ⑤ Neutral switch
- ⑥ CDI unit
- ⑦ Battery
- ⑧ Rectifier/Regulator
- ⑨ Fuse
- ⑩ Starter relay



---



**MEMO**




**NOTE:**

For the color codes, see page 16.

- ① Main switch
- ⑪ Fuse
- ⑫ Starter motor
- ⑬ Starter relay
- ⑭ Battery
- ⑮ Starting circuit cut-off relay
- ⑯ Clutch switch
- ⑰ "START" switch
- ⑲ Neutral switch










**STARTING CIRCUIT OPERATION**

The starting circuit on this model consists of the starter motor, starter relay and starting circuit cut-off relay. If the "ENGINE STOP" switch and the main switch are both on, the starter motor can operate only if:

- The transmission is in neutral (the neutral switch is on).
- The clutch lever is pulled in (clutch switch is on).



- ① Battery
- ② Starter motor
- ③ Starter relay
- ④ Main switch
- ⑤ "START" switch
- ⑥ Starting circuit cut-off relay
- ⑦ Clutch switch
- ⑧ Neutral switch






### TROUBLESHOOTING

#### STARTER MOTOR DOES NOT OPERATE.

**NOTE:** \_\_\_\_\_

Before this troubleshooting, remove side covers, seat and fuel tank.





#### 1. Fuse inspection

- Remove fuse.
- Connect Pocket Tester (YU-03112) to fuse and check it for continuity.


**NOTE:** \_\_\_\_\_


Set tester selector to " $\Omega \times 1$ " position.



#### 2. Battery fluid level inspection



- Fluid level should be between upper ① and lower ② level mark.





3. Battery terminal inspection

- Inspect battery terminal and connections.



4. Battery fluid specific gravity inspection

- Remove caps.
- Inspect specific gravity of all cell using Battery Hydrometer ①.

**Specific Gravity:**  
 $1.280 \pm 0.01$  at 20°C (68°F)

**WARNING:** \_\_\_\_\_



Battery electrolyte is poisonous and dangerous, causing severe burns, etc. It contains sulfuric acid. Avoid contact with skin, eyes or clothing. Antidote: EXTERNAL-Flush with water. INTERNAL-Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call a physician immediately.

Eyes: Flush with water for 15 minutes and get prompt medical attention. Batteries produce explosive gases. Keep sparks, flame, cigarettes etc., away. Ventilate when charging or using in an enclosed space. Always shield your eyes when working near batteries.

**KEEP OUT OF REACH OF CHILDREN.**



OK

Low specific gravity


- Recharge battery

**Charging Current:**  
0.7 amps/10 hrs

**NOTE:**

Replace the battery if:

- Battery voltage will not rise to a specific value or bubbles fail to rise even after many hours of charging.
- Sulfation of one or more cells occurs, as indicated by the plates turning white, or an accumulation of material exists in the bottom of the cell.
- Specific gravity readings after a long, slow charge indicate on cell to be lower than the rest.
- Warpage or buckling of plates or insulators is evident.



5. Connect battery positive (+) lead and starter motor lead; use heavy duty jumper lead.


**WARNING:**

This test should be performed within a few seconds to prevent further damage. Also, there should be no flammables close to the starter relay.

Starter motor runs.

Starter motor does not run.


Inspect and repair the starter motor. Refer to "STARTER MOTOR" section.



6. Starter relay conduct check


- Disconnect starter relay leads (Blue/White, Red/White) and connect them to battery positive and negative lead use a jumper leads.

- ① Positive lead
- ② Negative lead




7. Starting circuit cut-off relay conduct check


- Remove starting circuit cut-off relay from headlight stay.
- Connect 12V battery and Pocket Tester (YU-03112) to starting circuit cut-off relay terminals as shows.



**NOTE:** \_\_\_\_\_

- Use full charge battery.
- Set tester selector to "Ω × 1" position.





### 8. Main switch conduct check



- Disconnect main switch coupler (Brown, Red, Black/Red, Black/White leads).
- Connect Pocket Tester (YU-03112) to main switch leads (Brown, Red).

**Tester (+) lead → Red lead**  
**Tester (-) lead → Brown lead**

**NOTE:** \_\_\_\_\_

Set tester selector to “Ω × 1” position.

- Turn main switch to “ON” position and check it for continuity.



### 9. “START” switch conduct check

- Disconnect handlebar switch coupler (Yellow/Red, Blue, Red/White, Brown leads).
- Connect Pocket Tester (YU-03112) to handlebar switch leads (Red/White, Brown).

**Tester (+) lead → Brown lead**  
**Tester (-) lead → Red/White lead**

**NOTE:** \_\_\_\_\_

Set tester selector to “Ω × 1” position.

- Push on “START” switch and check it for continuity.




Continuity  
(0Ω)



No continuity  
(∞)

Handlebar switch is faulty, replace it.



10. Clutch switch conduct check

- Disconnect clutch switch leads (Black/ Yellow, Black).
- Connect Pocket Tester (YU-03112) to clutch switch leads.

**Tester (+) lead → Black/Yellow lead**  
**Tester (-) lead → Black lead**

**NOTE:**

Set tester selector to "Ω × 1" position.


- Clutch lever is pulled and check clutch switch for continuity.

Continuity  
(0Ω)



No continuity  
(∞)

Clutch switch is faulty, replace it.



11. Neutral switch conduct check


- Disconnect neutral switch lead (Sky blue).
- Connect Pocket Tester (YU-03112) to neutral switch lead and frame earth lead.

**Tester (+) lead → Sky blue lead**  
**Tester (-) lead → Frame earth lead**


**NOTE:**

Set tester selector to " $\Omega \times 1$ " position.

- Transmission is in neutral and check neutral switch for continuity.



12. Check entire electrical starting system for connections. Refer to "WIRING DIAGRAM" section.







**STARTER MOTOR**

- ① Starter motor lead
- ② O-ring
- ③ Yoke assembly
- ④ Armature coil assembly
- ⑤ Brush assembly


|          |   |
|----------|---|
| <b>A</b> | <b>COMMUTATOR UNDER CUT:</b><br>1.5 mm (0.06 in)          |
| <b>B</b> | <b>COMMUTATOR DIAMETER WEAR LIMIT:</b><br>21 mm (0.87 in) |
| <b>C</b> | <b>BRUSH WEAR LIMIT:</b><br>3.5 mm (0.14 in)              |





## Removal


1. Remove:
  - Side cover (Left)
  - Seat




2. Remove:
  - Change pedal ①
  - Drive sprocket cover ②



3. Disconnect:
  - Starter motor lead ①





4. Remove:
  - Starter motor ①




## Disassembly


1. Remove:
  - Starter motor lead ①



2. Remove:
  - Yoke assembly



3. Remove:
  - Armature coil assembly



#### Inspection and repair

1. Measure:
  - Brush length (each)
  - Out of specification → Replace brush.




**Minimum Brush Length:**  
3.5 mm (0.14 in)


2. Inspect:
  - Brush spring
  - Damage → Replace.



3. Inspect:
  - Commutator (Outer surface)
  - Grooved wear/Burning/scratches → Smooth out using a sandpaper (#500 ~ 600).

**NOTE:** \_\_\_\_\_  
Sand the commutator outer surface lightly and evenly.






4. Measure:

- Commutator diameter  
Out of specification → Replace.



**Outside Diameter Limit:**  
21 mm (0.87 in)



5. Measure:


- Mica undercut (a)  
Out of specification → Scrape mica using a hacksaw blade.



**Mica Undercut (a):**  
1.5 mm (0.06 in)

**NOTE:**

The mica insulation of the commutator must be undercut to ensure proper operation of the commutator.



6. Measure:

- Armature coil resistance  
Out of specification → Replace.



**Armature Coil Resistance:**  
0.02Ω at 20°C (68°F)




7. Check:

- Armature coil insulation  
Set the pocket tester selector to "Ω × 1K" position.  
Continuity → Replace.

**Assembly**


Reverse the "Removal" and "Disassembly" procedure.

Note the following points.

**1. Install:**

- Brushes
- Brush springs


Using a thin screw driver.

**2. Install:**

- Armature coil assembly

**3. Install:**


- O-rings (New) ①

**4. Install:**


- Washer ①

**NOTE:**

Fit the washer on the bracket as shown.



5. Apply:
- Lithium soap base grease (to oil seal and bearing)




6. Install:
- Yoke assembly ①


**NOTE:** \_\_\_\_\_  
 Install the yoke assembly ① with its short skirt (a) forward.

- (a) : Short skirt
- (b) : Long skirt

**NOTE:** \_\_\_\_\_  
 Align the match marks ① on the bracket with the match marks ② on the housing.




7. Install:
- Bolts ①
  - O-rings (New) ②



8. Install:
- O-ring (New) ①

**NOTE:** \_\_\_\_\_  
 Apply a grease lightly.





**Installation**

- 1. Install:
  - Starter motor ①



---

**MEMO**






IGNITION SYSTEM

CIRCUIT DIAGRAM

Below circuit diagram shows ignition circuit.







**NOTE:** \_\_\_\_\_

For the color codes, see page 16.

- ① Main switch
- ② CDI magneto
- ③ "ENGINE STOP" switch
- ④ CDI unit
- ⑤ Ignition coil
- ⑥ Spark plug






## TROUBLESHOOTING

**IF IGNITION SYSTEM SHOULD BECOME INOPERATIVE (NO SPARK OR INTERMITTENT SPARK).**

**NOTE:**

Before this troubleshooting, remove side covers, seat and fuel tank.



## 1. Spark plug inspection

- Remove spark plug.
- Clean spark plug with spark plug cleaner, if necessary.
- Inspect electrode, insulator and plug gap. Refer to "CHAPTER 2—SPARK PLUG INSPECTION" section in BW200N SERVICE MANUAL (LIT-11616-04-63).

**Plug Gap:**

**0.6 ~ 0.7 mm (0.024 ~ 0.028 in)**

OK

No good

Replace or regap spark plug.

## 2. Ignition spark test

- Install spark plug to plug cap.
  - Ground spark plug to cylinder head.
  - Turn main switch to "ON".
- Then, kick starter or start starter motor (Push on "START" switch).



# IGNITION SYSTEM

**ELEC**




No spark

Spark

Ignition circuit is good.

6 mm (0.24 in)




### 3. Ignition spark gap test

- Remove spark plug and plug cap.
- Hold spark plug lead 6 mm (0.24 in) from cylinder head.
- Kick starter or start starter motor (Push on "START" switch).

No spark

Spark

Replace spark plug and/or plug cap.



### 4. Main switch conduct check

- Disconnect main switch coupler (Brown, Red, Black/Red, Black/White leads).
- Connect Pocket Tester (YU-03112) to main switch leads (Black/Red, Black/White)

**Tester (+) lead → Black/Red lead**  
**Tester (-) lead → Black/White lead**

#### NOTE:

Set tester selector to " $\Omega \times 1$ " position.

- Turn main switch to "ON" position and check it for continuity.




Continuity  
(0Ω)

No continuity  
(∞)



Main switch is faulty, replace it.



5. "ENGINE STOP" switch conduct check
- Disconnect handlebar switch leads (Black/White, Black).
  - Connect Pocket Tester (YU-03112) to handlebar switch leads.

Tester (+) lead → Black/White lead  
Tester (-) lead → Black lead

**NOTE:** \_\_\_\_\_  
Select tester selector to "Ω×1" position.


- Turn "ENGINE STOP" switch to "RUN" position and check it for continuity.

No continuity  
(∞)

Continuity  
(0Ω)



Handlebar switch is faulty, replace it.



6. Ignition coil resistance test
- Disconnect ignition coil lead (Orange).
  - Connect Pocket Tester (YU-03112) to ignition coil lead (Orange) and ignition coil base.

Tester (+) lead → Orange lead  
Tester (-) lead → Ignition coil base



**NOTE:** \_\_\_\_\_

Set tester selector to " $\Omega \times 1$ " position.

- Measure primary coil resistance.



**Primary Coil Resistance:**  
1.44 ~ 1.76  $\Omega$  at 20°C (68°F)

- Connect Pocket Tester (YU-03112) to ignition coil lead (Orange) and spark plug lead.

**Tester (+) lead** → Orange lead  
**Tester (-) lead** → Spark plug lead


**NOTE:** \_\_\_\_\_

Set tester selector to " $\Omega \times 1K$ " position.

- Measure secondary coil resistance.




**Secondary Coil Resistance:**  
5.28 ~ 7.92 k $\Omega$  at 20°C (68°F)



### 7. Source coil resistance test

- Disconnect CDI magneto leads.
- Connect Pocket Tester (YU-03112) to CDI magneto leads (Black, Red).


**Tester (+) lead** → Red lead  
**Tester (-) lead** → Black lead






- Measure source coil (1) resistance.

**NOTE:** \_\_\_\_\_  
 Set tester selector to " $\Omega \times 100$ " position.

 **Source Coil (1) Resistance (R–B):**  
 396 ~ 484 $\Omega$  at 20°C (68°F)






- Connect Pocket Tester to CDI magneto leads (Brown, Black).

**Tester (+) lead** → Brown lead  
**Tester (-) lead** → Black lead

- Measure source coil (2) resistance.

**NOTE:** \_\_\_\_\_  
 Set tester selector to " $\Omega \times 10$ " position.

 **Source Coil (2) Resistance (Br–B):**  
 27.9 ~ 34.1 $\Omega$  at 20°C (68°F)



8. Pick-up coil resistance test
- Disconnect pick-up coil leads (White, Green).
  - Connect Pocket Tester (YU-03112) to pick-up coil leads.

**Tester (+) lead** → White lead  
**Tester (-) lead** → Green lead





- Measure pick-up coil resistance.

**NOTE:** \_\_\_\_\_

Set tester selector to " $\Omega \times 100$ " position.



**Pick-up Coil Resistance (W–G):**  
**648 ~ 792 $\Omega$  at 20°C (68°F)**






CHARGING SYSTEM

CIRCUIT DIAGRAM

Below circuit diagram shows charging circuit.








**NOTE:**

For the color codes, see page 16.

- ② CDI magneto
- ⑦ Rectifier/Regulator
- ⑪ Fuse
- ⑭ Battery






TROUBLESHOOTING

**THE BATTERY IS NOT CHARGED.**

**NOTE:** \_\_\_\_\_

Before this troubleshooting, remove side covers and seat.





1. Fuse inspection

- Remove fuse.
- Connect Pocket Tester (YU-03112) to fuse and check it for continuity.


**NOTE:** \_\_\_\_\_


Set tester selector to "Ω x 1" position.



2. Battery fluid level inspection

- Fluid level should be between upper ① and lower ② level mark.






3. Battery terminal inspection

- Inspect battery terminal and connections.

|  |   |                          |
|--|---|--------------------------|
| OK   | ↓ | Dirty or poor connection |
| <ul style="list-style-type: none"> <li>• Clean battery terminals using wire brush.</li> </ul> <p><b>NOTE:</b> _____</p> <p>After cleaning terminals, apply grease lightly to both terminals.</p> <p>_____</p> <ul style="list-style-type: none"> <li>• Connect battery leads correctly.</li> </ul> |   |                          |



367-003

4. Battery fluid specific gravity inspection

- Remove caps.
- Inspect specific gravity of all cell using Battery Hydrometer ①.

**Specific Gravity:**  
 $1.280 \pm 0.01$  at 20°C (68°F)



**WARNING:** \_\_\_\_\_

Battery electrolyte is poisonous and dangerous, causing severe burns, etc. It contains sulfuric acid. Avoid contact with skin, eyes or clothing. Antidote: **EXTERNAL**-Flush with water. **INTERNAL**-Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call a physician immediately.

**Eyes:** Flush with water for 15 minutes and get prompt medical attention. Batteries produce explosive gases. Keep sparks, flame, cigarettes etc., away. Ventilate when charging or using in an enclosed space. Always shield your eyes when working near batteries. **KEEP OUT OF REACH OF CHILDREN.**



OK

Low specific gravity




- Recharge battery

**Charging Current:**  
0.7 amps/10 hrs

**NOTE:** \_\_\_\_\_

Replace the battery if:

- Battery voltage will not rise to a specific value or bubbles fail to rise even after many hours of charging.
- Sulfation of one or more cells occurs, as indicated by the plates turning white, or an accumulation of material exists in the bottom of the cell.
- Specific gravity readings after a long, slow charge indicate on cell to be lower than the rest.
- Warp or buckling of plates or insulators is evident.



## 5. Charging voltage test

- Connect Inductive Tachometer (YU-08036) to spark plug lead.
- Connect Pocket Tester (YU-03112) to battery.

**NOTE:** \_\_\_\_\_

Set tester selector to "DC20V" position.

**Tester (+) lead → Battery (+) terminal**  
**Tester (-) lead → Battery (-) terminal**

- Start engine and accelerate to about 5,000 r/min.
- Measure charging voltage.

**Charging Voltage:**

14 ~ 15 V at 5,000 r/min

# CHARGING SYSTEM


**ELEC**



Out of specification

Charging voltage meets specification.

Battery is faulty, replace it.



## 6. Charging coil resistance test

- Disconnect CDI magneto leads (Yellow, White, Black).
- Connect Pocket Tester (YU-03112) to CDI magneto leads.

### NOTE:

Set tester selector to " $\Omega \times 1$ " position.

Tester (+) lead → White lead

Tester (-) lead → Black lead

- Measure charging coil resistance.



**Charging Coil Resistance (W—B):**


**0.36 ~ 0.44 $\Omega$  at 20°C (68°F)**

Resistance meets specification.

Out of specification

Charging coil is faulty, replace it.

7. Check entire charging system for connections. Refer to "WIRING DIAGRAM" section.





---


**MEMO**



**LIGHTING SYSTEM**

**CIRCUIT DIAGRAM**

Below circuit diagram shows lighting circuit.








**NOTE:** \_\_\_\_\_

For the color codes, see page 16.

\_\_\_\_\_

- ② CDI magneto
- ⑦ Rectifier/Regulator
- ⑧ "LIGHT" switch
- ⑨ Headlight
- ⑩ Taillight





## TROUBLESHOOTING

**HEADLIGHT AND/OR TAILLIGHT DOES NOT COME ON.**
**NOTE:**


Before this troubleshooting, remove side covers and seat.

## 1. Headlight bulb conduct check

- Disconnect headlight leads (Green, Yellow, Black) and remove headlight unit.
- Remove headlight bulb.

**WARNING:**

Keep flammable products or your hands away from bulb while it is on, it will be hot. Do not touch bulb until it cools down.




- Connect Pocket Tester (YU-03112) to bulb terminals and check bulb for continuity.


Tester (+) lead → Terminal 1  
Tester (-) lead → Terminal 3

Tester (+) lead → Terminal 2  
Tester (-) lead → Terminal 3

**NOTE:**

Set tester selector to " $\Omega \times 1$ " position.






2. Headlight bulb socket conduct check
- Install bulb to headlight socket.
  - Connect Pocket Tester (YU-03112) to headlight leads and check it for continuity.

Tester (+) lead → Green lead  
 Tester (-) lead → Black lead

Tester (+) lead → Yellow lead  
 Tester (-) lead → Black lead

**NOTE:** \_\_\_\_\_

Set tester selector to “Ω × 1” position.



3. Taillight bulb conduct check
- Remove taillight lens and bulb.

**WARNING:** \_\_\_\_\_


Keep flammable products or your hands away from bulb while it is on, it will be hot. Do not touch bulb until it cools down.


- Connect Pocket Tester (YU-03112) to bulb terminals and check bulb for continuity.

Tester (+) lead → Terminal 1  
 Tester (-) lead → Terminal 2

**NOTE:** \_\_\_\_\_

Set tester selector to “Ω × 1” position.







4. Taillight bulb socket conduct check
- Install bulb to taillight socket.
  - Disconnect taillight leads (Blue, Black).
  - Connect Pocket Tester (YU-03112) to taillight leads and check it for continuity.

Tester (+) lead → Blue lead  
 Tester (-) lead → Black lead

**NOTE:** \_\_\_\_\_  
 Set tester selector to " $\Omega \times 1$ " position.



5. Lighting voltage test
- Connect Pocket Tester (YU-03112) to headlight leads (Green, Black).

Tester (+) lead → Green lead  
 Tester (-) lead → Black lead

**NOTE:** \_\_\_\_\_  
 Set tester selector "AC20V" position.



- Connect Inductive Tachometer (YU-08036) to spark plug lead.
- Turn "LIGHT" switch to "LO" position.
- Start engine and accelerate to about 5,000 r/min.



- Measure lighting voltage.



**Lighting Voltage:**  
**13 ~ 14 at 5,000 r/min**




6. "LIGHT" switch conduct check
- Disconnect "LIGHT" switch leads (Yellow/Red, Blue, Red/White, Brown).
  - Connect Pocket Tester to "LIGHT" switch leads and check it for continuity.


If switch is turned to "LO" position.  
Tester (+) lead → Yellow/Red lead  
Tester (-) lead → Green lead

If switch is turned to "HI" position.  
Tester (+) lead → Yellow/Red lead  
Tester (-) lead → Yellow lead

**NOTE:** \_\_\_\_\_

Set tester selector to " $\Omega \times 1$ " position.





**7. Lighting coil resistance test**


- Disconnect CDI magneto leads (Yellow, White, Black).
- Connect Pocket Tester (YU-03112) to CDI magneto leads.


**NOTE:** \_\_\_\_\_

Set tester selector to " $\Omega \times 1$ " position.


**Tester (+) lead → Yellow lead**  
**Tester (-) lead → Black lead**

- Measure lighting coil resistance.

 **Lighting Coil Resistance (Y – B):**  
**0.27 ~ 0.33 $\Omega$  at 20°C (68°F)**



**8. Check entire lighting system for connections.**  
 Refer to "WIRING DIAGRAM" section.





---

**MEMO**






**SIGNAL SYSTEM**

**CIRCUIT DIAGRAM**

Below circuit diagram shows signal circuit.







**NOTE:**

For the color codes, see page 16.

- ① Main switch
- ⑪ Fuse
- ⑭ Battery
- ⑱ "NEUTRAL" indicator light
- ⑲ Neutral switch






## TROUBLESHOOTING

**WHEN TRANSMISSION IS IN NEUTRAL, "NEUTRAL" INDICATOR LIGHT DOES NOT COME ON.**

**NOTE:**

Before this troubleshooting, remove side covers, seat and fuel tank.



## 1. "NEUTRAL" indicator light bulb conduct check

- Disconnect "NEUTRAL" indicator light leads (Sky blue, Black) and remove it.
- Remove bulb.
- Connect Pocket Tester (YU-03112) to bulb terminals and check bulb for continuity.

**Tester (+) lead → Terminal 1**

**Tester (-) lead → Terminal 2**


**NOTE:**

Set tester selector to " $\Omega \times 1$ " position.

Continuity

No continuity  
( $\infty$ )

Bulb is faulty, replace it.




## 2. "NEUTRAL" indicator light socket conduct check

- Install bulb to "NEUTRAL" indicator light socket.
- Connect Pocket Tester (YU-03112) to indicator light leads (Sky blue, Black) and check socket for continuity.




Tester (+) lead → Sky blue lead  
Tester (-) lead → Black lead

NOTE: \_\_\_\_\_  
Set tester selector to " $\Omega \times 1$ " position.





3. Fuse inspection
- Remove fuse.
  - Connect Pocket Tester (YU-03112) to fuse and check it for continuity.

NOTE: \_\_\_\_\_  
Set tester selector to " $\Omega \times 1$ " position.



4. Battery fluid level inspection
- Fluid level should be between upper ① and lower ② level mark.





|   |   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |     |
|---|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|
| + | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 |
|---|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|

Correct Incorrect

↓

- Refill battery fluid.

**CAUTION:** \_\_\_\_\_

Refill with distilled water only; tap water contains minerals harmful to a battery.

\_\_\_\_\_

5. Battery terminal inspection
- Inspect battery terminal and connections.

OK Dirty or poor connection

↓

- Clean battery terminals using wire brush.


**NOTE:** \_\_\_\_\_

After cleaning terminals, apply grease lightly to both terminals.

\_\_\_\_\_

- Connect battery leads correctly.

6. Battery fluid specific gravity inspection
- Remove caps.
  - Inspect specific gravity of all cell using Battery Hydrometer ①.



**Specific Gravity:**  
 $1.280 \pm 0.01$  at 20°C (68°F)




**WARNING:** \_\_\_\_\_

Battery electrolyte is poisonous and dangerous, causing severe burns, etc. It contains sulfuric acid. Avoid contact with skin, eyes or clothing. Antidote: EXTERNAL-Flush with water. INTERNAL-Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call a phy-



sician immediately.


**Eyes:** Flush with water for 15 minutes and get prompt medical attention. Batteries produce explosive gases. Keep sparks, flame, cigarettes etc., away. Ventilate when charging or using in an enclosed space. Always shield your eyes when working near batteries. **KEEP OUT OF REACH OF CHILDREN.**



7. Main switch conduct check

- Disconnect main switch coupler (Brown, Red, Black/Red, Black/White leads).
- Connect Pocket Tester (YU-03112) to main switch leads (Brown, Red).



**Tester (+) lead → Red lead**  
**Tester (-) lead → Brown lead**



**NOTE:**

Set tester selector to " $\Omega \times 1$ " position.

- Turn main switch to "ON" position and check it for continuity.



## 8. Neutral switch conduct check


- Disconnect neutral switch lead (Sky blue).
- Connect Pocket Tester (YU-03112) to neutral switch lead and frame earth lead.

**Tester (+) lead → Sky blue lead**  
**Tester (-) lead → Frame earth lead**


**NOTE:**

Set tester selector to " $\Omega \times 1$ " position.

- Transmission is in neutral and check neutral switch for continuity.



9. Check entire signal system for connections.  
Refer to "WIRING DIAGRAM" section.







## APPENDICES

## SPECIFICATIONS






## GENERAL SPECIFICATIONS

| Model   | BW200ES   |
|---|---|
| Model Code Number   | 1RL   |
| Vehicle Identification Number                             | JYA 1RL00*G000101   |
| Engine Starting Number                                    | 1RL-000101  |
| Basic Weight:<br>With Oil and Fuel Tank                   | 123 kg (271 lb)   |
| Engine:<br>Starting System                                | Electric and Kick Starter                                     |
| Spark Plug:<br>Type (Manufacturer)<br>Gap                 | D8EA (NGK), X24ES-U (N.D.)<br>0.6 ~ 0.7 mm (0.024 ~ 0.028 in) |
| Bulb Wattage (Quantity):<br>Headlight<br>Tail/Brake light | 12V 45W/45W (1)<br>12V 6W (1)                                 |





MAINTENANCE SPECIFICATIONS

Engine

| Model  | BW200ES  |   |                           |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
|--|--|---|---------------------------|---------------------------------------|--------------|---------|---------------------------------------|---------------------------|-----|---------------------|---------|-------------------|-------------------------------------|-----|-----|---------------------------------------|--|-----|--------------------|--|----------------------------------|--|--|--|--------------|-----|--|-------------------|--|-----|--|-------------------|--------------|-----|--|-------------------|--|-----|--|-------------------|--|
| <p>Cylinder Head:<br/>Warp Limit</p>    | <p>0.03 mm (0.0012 in)<br/>*Lines indicate straightedge measurement:</p>           |   |                           |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| <p>Camshaft:<br/>Cam Cap Inside Diameter<br/>Camshaft Outside Diameter<br/>Shaft-to Cap Clearance<br/>Cam Dimension</p> <table border="0"> <tr> <td data-bbox="267 756 349 787">Intake</td> <td data-bbox="462 735 665 997" rowspan="6">  </td> <td data-bbox="690 756 755 787">"A"</td> <td data-bbox="787 756 1274 787">36.538 ~ 36.638 mm (1.438 ~ 1.442 in)</td> </tr> <tr> <td></td> <td data-bbox="690 787 755 819">"B"</td> <td data-bbox="787 787 1274 819">30.152 ~ 30.252 mm (1.187 ~ 1.191 in)</td> </tr> <tr> <td></td> <td data-bbox="690 819 755 850">"C"</td> <td data-bbox="787 819 1047 850">6.588 mm (0.259 in)</td> </tr> <tr> <td data-bbox="267 861 349 892">Exhaust</td> <td data-bbox="690 861 755 892">"A"</td> <td data-bbox="787 861 1242 892">36.58 ~ 36.68 mm (1.440 ~ 1.444 in)</td> </tr> <tr> <td></td> <td data-bbox="690 892 755 924">"B"</td> <td data-bbox="787 892 1274 924">30.226 ~ 30.366 mm (1.190 ~ 1.195 in)</td> </tr> <tr> <td></td> <td data-bbox="690 924 755 955">"C"</td> <td data-bbox="787 924 1047 955">6.63 mm (0.261 in)</td> </tr> </table> | Intake   |  | "A"                       | 36.538 ~ 36.638 mm (1.438 ~ 1.442 in) |              | "B"     | 30.152 ~ 30.252 mm (1.187 ~ 1.191 in) |                           | "C" | 6.588 mm (0.259 in) | Exhaust | "A"               | 36.58 ~ 36.68 mm (1.440 ~ 1.444 in) |     | "B" | 30.226 ~ 30.366 mm (1.190 ~ 1.195 in) |  | "C" | 6.63 mm (0.261 in) | <p>25.000 ~ 25.021 mm (0.984 ~ 0.985 in)<br/>24.96 ~ 24.98 mm (0.982 ~ 0.983 in)<br/>0.021 ~ 0.016 mm (0.0008 ~ 0.0024 in)</p> |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| Intake   |   |   | "A"                       | 36.538 ~ 36.638 mm (1.438 ~ 1.442 in) |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
|  |  |   | "B"                       | 30.152 ~ 30.252 mm (1.187 ~ 1.191 in) |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
|  |  |   | "C"                       | 6.588 mm (0.259 in)                   |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| Exhaust  |  |   | "A"                       | 36.58 ~ 36.68 mm (1.440 ~ 1.444 in)   |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
|  |  |   | "B"                       | 30.226 ~ 30.366 mm (1.190 ~ 1.195 in) |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
|  |  | "C"   | 6.63 mm (0.261 in)        |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| <p>Valve Clearance (Cold):<br/>Intake<br/>Exhaust</p>  | <p>0.10 ~ 0.14 mm (0.0039 ~ 0.0055 in)<br/>0.16 ~ 0.20 mm (0.0063 ~ 0.0078 in)</p> |   |                           |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| <p>Valve Spring:</p> <table border="0"> <tr> <td colspan="2">Free Length</td> <td></td> <td></td> </tr> <tr> <td>Inner Spring</td> <td>IN.</td> <td></td> <td>36.2 mm (1.42 in)</td> </tr> <tr> <td></td> <td>EX.</td> <td></td> <td>36.2 mm (1.42 in)</td> </tr> <tr> <td>Outer Spring</td> <td>IN.</td> <td></td> <td>36.6 mm (1.44 in)</td> </tr> <tr> <td></td> <td>EX.</td> <td></td> <td>36.6 mm (1.44 in)</td> </tr> <tr> <td colspan="2">Compressed Length (Valve Closed)</td> <td></td> <td></td> </tr> <tr> <td>Inner Spring</td> <td>IN.</td> <td></td> <td>30.5 mm (1.20 in)</td> </tr> <tr> <td></td> <td>EX.</td> <td></td> <td>30.5 mm (1.20 in)</td> </tr> <tr> <td>Outer Spring</td> <td>IN.</td> <td></td> <td>32.0 mm (1.26 in)</td> </tr> <tr> <td></td> <td>EX.</td> <td></td> <td>32.0 mm (1.26 in)</td> </tr> </table>  | Free Length  |   |                           |                                       | Inner Spring | IN.     |                                       | 36.2 mm (1.42 in)         |     | EX.                 |         | 36.2 mm (1.42 in) | Outer Spring                        | IN. |     | 36.6 mm (1.44 in)                     |  | EX. |                    | 36.6 mm (1.44 in)  | Compressed Length (Valve Closed) |  |  |  | Inner Spring | IN. |  | 30.5 mm (1.20 in) |  | EX. |  | 30.5 mm (1.20 in) | Outer Spring | IN. |  | 32.0 mm (1.26 in) |  | EX. |  | 32.0 mm (1.26 in) |  |
| Free Length  |  |   |                           |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| Inner Spring   | IN.  |   | 36.2 mm (1.42 in)         |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
|  | EX.  |   | 36.2 mm (1.42 in)         |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| Outer Spring   | IN.  |   | 36.6 mm (1.44 in)         |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
|  | EX.  |   | 36.6 mm (1.44 in)         |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| Compressed Length (Valve Closed)   |  |   |                           |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| Inner Spring   | IN.  |   | 30.5 mm (1.20 in)         |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
|  | EX.  |   | 30.5 mm (1.20 in)         |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| Outer Spring   | IN.  |   | 32.0 mm (1.26 in)         |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
|  | EX.  |   | 32.0 mm (1.26 in)         |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| <p>Tilt Limit*</p> <table border="0"> <tr> <td>Inner Spring</td> <td>IN.&amp;EX.</td> <td></td> <td>2.5° or 1.6 mm (0.063 in)</td> </tr> <tr> <td>Outer Spring</td> <td>IN.&amp;EX.</td> <td></td> <td>2.5° or 1.6 mm (0.063 in)</td> </tr> </table>    | Inner Spring   | IN.&EX.   |                           | 2.5° or 1.6 mm (0.063 in)             | Outer Spring | IN.&EX. |                                       | 2.5° or 1.6 mm (0.063 in) |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| Inner Spring   | IN.&EX.  |   | 2.5° or 1.6 mm (0.063 in) |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |
| Outer Spring   | IN.&EX.  |   | 2.5° or 1.6 mm (0.063 in) |                                       |              |         |                                       |                           |     |                     |         |                   |                                     |     |     |                                       |  |     |                    |  |                                  |  |  |  |              |     |  |                   |  |     |  |                   |              |     |  |                   |  |     |  |                   |  |



| Model                           | BW200ES   |   |
|---------------------------------|---|---|
| Direction of Winding (Top view) | Inner Spring  | Outer Spring  |
|                                 |  |  |
| Carburetor:                     |   |   |
| Type/Manufacturer/Quantity      | Y24P-3P/TEIKEI/1  |   |
| I.D. Mark                       | 1RL00   |   |
| Main Jet (M.J.)                 | #120  |   |
| Main Air Jet (M.A.J.)           | φ1.4  |   |
| Jet Needle-clip Position (J.N.) | 4C813-2/5   |   |
| Needle Jet (N.J.)               | 2,600   |   |
| Pilot Jet (P.J.)                | #42   |   |
| Pilot Air Jet (P.A.J.)          | φ1.1  |   |
| Air Screw (turns out) (P.A.S.)  | 1 1/2 ± 1/8   |   |
| Valve Seat (V.S.)               | φ2.0  |   |
| Starter Jet (G.S.)              | GS <sub>1</sub> #70, GS <sub>2</sub> #70  |   |
| Fuel Level (F.L.)               | 7.0 ± 1.0 mm (0.27 ± 0.04 in)   |   |
| Float Height (F.H.)             | 25 ± 1.0 mm (0.98 ± 0.04 in)  |   |
| Engine Idling Speed             | 1,350 ± 50 r/min  |   |

**Chassis**



| Model  | BW200ES  |
|--|--|
| <b>Rear Suspension:</b><br>Shock Absorber Travel<br>Spring Free Length<br>Spring Rate (K1)<br>(K2)<br>Stroke<br>Optional Spring              | 62 mm (3.23 in)<br>187.5 mm (14.82 in)<br>44.1 N/mm (4.5 kg/mm, 247.9 lb/in)<br>78.4 N/mm (8.0 kg/mm, 440.6 lb/in)<br>0.0 ~ 62 mm (0.0 ~ 2.17 in)<br>No. |
| <b>Drive Chain:</b><br>Type/Manufacturer (Primary)<br>(Secondary)<br>Number of Links (Primary)<br>(Secondary)<br>Chain Free Play (Secondary) | 50 HDL/D.I.D.<br>52 OD/D.I.D.<br>42 Links<br>74 Links<br>25 ~ 40 mm (0.98 ~ 1.57 in)   |





## Electrical

| Model  | BW200ES  |
|--|--|
| C.D.I.:<br>Magneto Model/Manufacture<br>Source Coil Resistance (Color)<br><br>Pick-up Coil Resistance (Color)<br><br>C.D.I. Unit Model/Manufacture                   | F1RL/YAMAHA<br>396 ~ 484 $\Omega$ at 20°C (68°F)<br>(Black – Red)<br>27.9 ~ 34.1 $\Omega$ at 20°C (68°F)<br>(Black – Brown)<br>648 ~ 792 $\Omega$ at 20°C (68°F)<br>(White – Green)<br>1LR-M0/YAMAHA |
| Charging System:<br>Type<br>Charging Voltage<br>Charging Coil Resistance (Color)   | Flywheel Magneto<br>14 ~ 15V at 5000 r/min<br>0.36 ~ 0.44 $\Omega$ at 20°C (68°F)<br>(Black – White)   |
| Lighting System:<br>Type<br>Lighting Voltage<br>Lighting Coil Resistance (Color)   | Flywheel Magneto<br>13 ~ 14 V at 5000 r/min<br>0.27 ~ 0.33 $\Omega$ at 20°C (68°F)<br>(Black – Yellow)   |
| Voltage Regulator/Rectifier:<br>Type<br>Model/Manufacture<br>No Load Regulated Voltage   | Semi Conductor-Short Circuit Type<br>EHU-01TR18/MATSUSHITA<br>13 ~ 14 V  |
| Battery:<br>Model/Manufacture<br>Capacity<br>Specific Gravity  | GM7CZ-3D/G.S.<br>12 V 7AH<br>1.280 at 20°C (68°F)  |
| Electric Starting System:<br>Type<br>Model/Manufacture<br>Out Put<br>Armature Coil Resistance<br>Brush Wear Limit<br>Commutator Diameter/ < Limit ><br>Mica Undercut | Constant Mesh Type<br>1RL-M0/YAMAHA<br>0.4 kw<br>0.019 $\Omega$<br>3.5 mm (0.014 in)<br>22 mm (0.87 in)/ < 21 mm (0.83 in) ><br>1.5 mm (0.06 in)   |
| Starter Relay:<br>Model/Manufacturer   | A104-132/HITACHI   |
| Starting Circuit Cut Off Relay:<br>Model/Manufacturer  | ACA 1212-1/MATSUSHITA  |


CABLE ROUTING












# BW200ES WIRING DIAGRAM



- ① Clutch switch
- ② Ignition coil
- ③ Spark plug
- ④ CDI unit
- ⑤ CDI magneto
- ⑥ Neutral switch
- ⑦ Connector (For flag light)
- ⑧ Taillight
- ⑨ Starting circuit cut-off relay
- ⑩ Starter relay
- ⑪ Starter motor
- ⑫ Battery
- ⑬ Fuse
- ⑭ Frame earth
- ⑮ Rectifier/Regulator
- ⑯ "START" switch
- ⑰ "ENGINE STOP" switch
- ⑱ "LIGHTS" switch
- ⑲ Headlight
- ⑳ Neutral light
- ㉑ Main switch

**COLOR CODE**

|     |              |
|-----|--------------|
| R   | Red          |
| W   | White        |
| B   | Black        |
| Br  | Brown        |
| G   | Green        |
| Y   | Yellow       |
| L   | Blue         |
| Sb  | Sky blue     |
| O   | Orange       |
| B/R | Black/Red    |
| B/W | Black/White  |
| Y/R | Yellow/Red   |
| R/W | Red/White    |
| L/W | Blue/White   |
| B/Y | Black/Yellow |
| R/B | Red/Black    |