



# TouchChat User Guide

For wego A-D Speech-Generating Devices



![](_page_0_Picture_5.jpeg)

Find more resources online: talktometechnologies.com (click Support)

## Table of contents

Hardware, power buttons and features
Guided Access
User settings
Edit mode
Edit a button message and image 6
Create a new page from an existing template7
Link to a new page
Copy and paste a button 8
Edit word pronunciation
Hide speech display bar
Hide a button
Voice Settings
Change button access
Take photos to use in a vocabulary set
Import photos from a computer to your device
Saved phrases
Back up and recover vocabulary sets 13
Editing with Chat Editor
Pair the TTMT Speaker (SPKR) 16
Install communication software updates
User information, passwords and notes

![](_page_3_Picture_1.jpeg)

#### Power

Press and hold this button (plus a volume button on some models) to turn the device on or off.

Note: Press this button one time while the wego A is on to put it into "Sleep" mode. This feature will conserve battery life when the wego A is not in use.

![](_page_3_Picture_5.jpeg)

#### Volume

Press the volume toggle up or down to adjust volume levels.

![](_page_3_Picture_8.jpeg)

#### Home

Tap to return to the home screen. If your wego A model does not have a Home button, swipe up from the bottom of the screen.

![](_page_3_Picture_11.jpeg)

#### Charging the device

Pull down the tab to reveal the device charging port. Charge device and TTMT Speaker (SPKR) at night or when not in use. Please only use a TTMT-approved charger with your device.

![](_page_4_Figure_0.jpeg)

If your wego A model does not have a Home button, swipe up from the bottom of the screen.

## **Guided Access**

In addition to being a dedicated communication device, the wego A has Guided Access, which keeps the user locked into the vocabulary software. All dedicated devices come with Guided Access enabled, but you may disable Guided Access after receiving your device. The wego A will remain dedicated to communication even with Guided Access disabled.

1. Start Guided Access by quickly triple-clicking the home button. Note: if your wego A model does not have a home button, use the Power button as shown on page 2. Enter all 1's when prompted for password. It will open this screen.

![](_page_5_Figure_3.jpeg)

- 3. Press Resume to continue Guided Access (top right).
- 4. Press End to stop Guided Access (top left).
- Lock Menu (restrict use of the menu bar or specific buttons/pages): Open Guided Access > Use your finger to draw a circle around area/ buttons to restrict.

![](_page_5_Picture_7.jpeg)

## User settings

Within *Settings* there are several features that allow you to customize your device. Note: Access to some of these features may be in your customized vocabulary set instead of within *Settings*.

To access settings, select Menu > Settings

- Voice selection, rate, and pitch settings
- Touch sensitivity
- Font settings
- Hide/show Speech Display Bar

Tip: Find a detailed explanation for each function by selecting **Vocab** > **Choose New Vocab** > **Menu** > **Help**.

#### Edit mode

*Edit Mode* allows you to customize or modify vocabulary sets and buttons. Tasks performed in *Edit Mode* include: create or edit a vocabulary button, create and link new vocabulary sets, copy/paste buttons, hide buttons and more.

- Start *Edit Mode*: On the orange menu bar (top of the screen) select Menu > Edit Page. The menu bar will change to red when Edit Mode is turned on.
- 2. Turn off *Edit Mode*: select **Done** when editing is complete. The menu bar will turn back to orange.

![](_page_6_Picture_12.jpeg)

## Edit a button message and image

Easily customize your vocabulary sets and images so that it's personalized. Add favorite foods, places to go and family member names so that everyday communication is quick and easy.

1. **Menu** > **Edit Page** > tap button to edit > **Edit this button**. This opens a pop-up window allowing you to edit the button message and image.

![](_page_7_Figure_3.jpeg)

- 2. *Button Label*: In text box below *Button Label*, type the text to display on button.
- 3. *Button Message*: In text box below *Button Message*, type a message the button should speak aloud when pressed.
- 4. Button Image:

*Choose a Symbol:* **Select Image** > tap magnifying glass > type word to search > **Search** > select symbol > **Save** > **Done**.

*Import photo*: **Import Image** > **Image Library** > select picture from photo library > **Use** > **Save** > **Done**.

*Take a picture*: **Import Image** > **Camera** > press white circle on screen to take a picture > **Use photo** > **Save** > **Done**.

Tip: Need to add more buttons? Enter Edit Mode > **Menu** > **Edit Page Layout** > Choose to add additional buttons by selecting **Rows** or **Columns**.

## Create a new page from an existing template

If you want to create a new page that includes new vocabulary, simply copy an existing template so you do not have to start from scratch. After you create your page, you can then link it to a button (see Link to a New Page below).

- 1. Menu > Edit Page > Menu > Load Another Page > select file .template > Done.
- 2. Menu > Import/Copy Pages > Duplicate this Page.
- 3. Menu > Load Another Page > select .template (Copy) > Done.
- Menu > Edit Page Layout > under Page Name, type new page name > Save > Done.

![](_page_8_Picture_6.jpeg)

#### Link to a new page

Linking allows existing buttons to open up to a new page with more vocabulary. For example, a "snack" button can be linked to a new page that lists out different snack options.

- 1. Menu > Edit Page > tap button to edit > Edit This Button.
- 2. Scroll down to Button Actions > Add > Navigate.
- Select page to navigate to from menu > leave default as no animation or select animation type > Save > Done.

![](_page_8_Picture_12.jpeg)

## Copy and paste a button

Easily move a button and all its actions in just seconds!

- 1. Menu > Edit Page > tap to select button to copy > Copy Button.
- 2. Tap to select location to paste button > **Paste Button** > **Done**.

![](_page_9_Picture_4.jpeg)

Tip: You can copy button style only (background color, font, and label positioning). Follow above instructions but select **Paste Button Style** instead of **Paste Button**.

## Edit word pronunciation

If the device mispronounces a word, adjust the pronunciation within the settings and it will then always pronounce that word the way you programmed it to.

- 1. Menu > Edit Pronunciations.
- 2. Tap the + sign.
- 3. In the Word space, type the word to edit (e.g. fajita).
- 4. In the *Pronounce As* space, type the word's proper pronunciation (e.g. Fuheetah).
- 5. Select **Pronounce** to hear word pronounced.
- 6. **Save** > **Done**.

![](_page_9_Picture_14.jpeg)

Tip: Some words will require a bit of creativity to get a correct pronunciation. If this occurs, try using space between numbers, commas, hyphens, or apostrophes with letters.

## Hide speech display bar

The speech display bar is the box where the spoken text appears. If this is too distracting for the user, you can hide it from view.

Menu > Settings > scroll to Speech Display Bar > tap Hide Speech Display.

Done		Settings
Speech Display Bar		
Hide Speech Display	$\bigcirc$	
Allow Copy/Paste		
Auto Capitalization		
Show Icons	$\bigcirc$	
Hide Delete Button	$\bigcirc$	

## Hide a button

If the user appears overwhelmed by too many buttons on a page, consider hiding some of the buttons. Hide mode only hides buttons, it does not delete them. In the future, when the user is ready for more buttons on the page, simply unhide the buttons.

- 1. Menu > Edit Page > Menu > Hide Mode. The task bar will turn green.
- 2. Tap to select buttons to hide > **Done**.
- To unhide buttons: enter *Edit Mode* > Menu > Hide Mode > tap to select buttons to unhide > Done.

![](_page_10_Figure_9.jpeg)

Tip: You can hide multiple buttons across several vocabulary sets: start **Hide Mode** > **Menu** > **Load Another Page**.

### Voice settings

Adjust speech settings to create a highly-customized voice for your device.

1. Menu > Settings > scroll down to Speech.

Voice: Select one of the many different voices available.

*Rate*: Slide the bar to increase or decrease the speed of your speech. Voice Pitch: Adjust from highest to lowest to change your voice sound.

2. Done.

Done		Settings	
Speech			
Voice	Heather		>
Rate	0		
Voice Pitch			>
Pause Between Words	No Pause		>

#### Change button access

When touching the screen to make selections, some users may need to adjust how the screen accepts their touch. Follow the instructions below to adjust timing when touching buttons.

1. Menu > Settings > scroll down to Buttons.

Activate on release: button doesn't activate until your finger is lifted from screen.

Dwell time: the amount of time a button must be held before activating. *Release time*: the length of time that must pass before another button can be activated.

2. Done.

Done		Settings	
Buttons			
Activate on Release	$\bigcirc$		
Dwell Time	None		>
Release Time	None		>
Force Font Size	$\bigcirc$		
Highlight Touch			

## Take photos to use in a vocabulary set

The wego A gives you the option to take several pictures at once and add them to buttons later. You will need to access the Camera outside of Guided Access to accomplish this.

- 1. End Guided Access (see Guided Access section for directions) > exit *TouchChat.*
- 2. Touch the Camera icon. 🗖
- 3. Press white circle on screen to take photo. Take as many photos as you'd like.
- 4. Open TouchChat. 뎭
- 5. Resume *Guided Access* by quickly triple-clicking the home button (optional). Note: if your wego A model does not have a home button, use the Power button as shown on page 2.
- 6. When ready to add a photo, navigate to the page you'd like to add a photo.
- 7. Follow instructions for *Edit a button: Import Image* (pg. 5) to add a photo to your button.

## Import photos from a computer to your device

Import any picture you have saved to your personal computer onto your wego A by following the steps below. Once imported onto your device, you can then program it onto a button.

- 1. Create a folder on your computer desktop > add photos you want uploaded to your device to this folder.
- 2. Open *iTunes* on your computer.
- 3. Connect device to computer via USB charging cable.
- 4. In *iTunes*, select the device icon located on the top toolbar.

![](_page_12_Figure_15.jpeg)

- 5. Select **Photos** from left hand column.
- Check Sync Photos > Copy photos from Choose Folder > select folder containing the photos on your computer > Select folder > Apply.

![](_page_12_Picture_18.jpeg)

- 7. Once *iTunes* completes device sync, unplug USB cable from computer.
- 8. Open TouchChat on your wego A. 뎭
- 9. Follow instructions for *Edit a button: Import Image* (pg 5) to add a photo to your button.

## Saved phrases

If you are using an OnWord or Zoom file, the Saved Phrase function makes storing phrases extremely easy for the user to do independently. Typing and saving phrases to buttons is a quick and easy way to prepare in advance for anticipated conversations, such as doctor visits, shopping trips, or presentations at school or work.

- 1. Open the keyboard in your *OnWord* file > type phrase or message to save.
- 2. Select the **Home** button > navigate to page you want message stored.
- 3. Select the **Save** button **\*** > **Continue**.
- 4. Touch the button on your screen where you want to save your phrase.

Want to se	e a movie o	on Friday?		X
Back				
Yes	l use this computer to talk. Please be patient while l compose my message	That's not what I meant	That's interesting, tell me more	l am not sure about that
No	That is c Selection	Store Text to Buttor ct the button where you v ore your composed mess	<b>1?</b> vant to age	fantastic
Wow	С	ancel Cont	inue	
Save Clear		(:::::)^		Speak

#### Delete a saved phrase or message

- 1. Select **Clear** button to clear speech bar.
- 3. Select the **Save** button **The Continue**.
- 3. Select the button that you wish to delete.

Tip: Save over the top of existing phrases to delete and replace the existing phrase.

## Back up and recover vocabulary sets

You can back up your files in two different ways: on the device or on your computer. Back up files onto the device for a quick save, but it's recommended to occasionally back up files onto your computer as well.

#### Back up a vocabulary set on your device

Vocab > Choose New Vocab > Menu > Import/Export Vocab > Export to iTunes > select vocab to export > rename file to export > Save.

![](_page_14_Figure_4.jpeg)

![](_page_14_Picture_5.jpeg)

Cancel	Export Vocab	Save
Export File Name		
TTMT 4.11.17		
Source Title		
1 OnWord Qwerty v1		
Source Description		

Tip: Each time you back up a file, rename with the date at the end of the file name to help you keep track of the latest file. For example: John Doe 1.11.17.

#### Recover a vocabulary set backed up on your device

Vocab > Choose New Vocab > Menu > Import/Export Vocab > Import from iTunes > select vocab file to import > Save.

#### Back up a vocabulary set on your computer

- 1. Connect device to computer via USB charging cable.
- 2. Open *iTunes* on your computer.
- 3. Your computer and device may request access to each other. Select **Trust** on your wego A and **Continue** on your computer.
- On device: Vocab > Choose New Vocab > Menu > Import/Export Vocab > Export to iTunes > select vocab to export > rename file to export > Save.
- 5. In iTunes: select the device icon located on the top toolbar.

![](_page_15_Figure_6.jpeg)

- 6. Select **Apps** from left-hand menu.
- 7. Scroll down to the *File Sharing* section and select **TouchChat**.

*	- ()	<b>É</b>	Search
File Edit View Controls Account H	lelp		
<>		Guppy	
Guppy A 1608 945 -	File Sharing The apps listed below can transfer docu Apps	ments between your iPhone and this computer.	
yÅr Apps ∬ Music	Proloquo2Go	1 OnWord Alpha v1.6.ce	1.2 MB 1/29/2016 10:35 AM
Movies	TouchChatHD	1 Quickstep 4 v1.3.ce 1 Quickstep 8 v1.4.ce	488 KB 5/17/2015 7:45 PM 2 MB 8/26/2015 11:30 AM
Photos		1 Quickstep 12 Adult v1.3.ce 1 Quickstep 12 checkerboard 1.3.ce	740 KB 5/17/2015 7:45 PM 1.9 MB 5/17/2015 7:45 PM

- 8. Select vocabulary set you want to back up from the right-hand column.
- 9. Select **Save** to at bottom right > select location on computer to save file.

Apps	TouchChatHD Documents	
Prologuo2Go	1 OnWord Alpha v1.6.ce	1.2 MB 1/29/2016 10:35 AM
100	1 OnWord Qwerty v1.6.ce	1.2 MB 1/29/2016 10:33 AM
C Touch Chanting	1 Quickstep 4 v1.3.ce	488 KB 5/17/2015 7:45 PM
() IOUCINEIRINO	1 Quickstep 8 v1.4.ce	2 MB 8/26/2015 11:30 AM
-	1 Quickstep 12 Adult v1.3.ce	740 KB 5/17/2015 7:45 PM
	1 Quickstep 12 checkerboard 1.3.ce	1.9 MB 5/17/2015 7:45 PM
	1 Quickstep 12 v1.3.ce	1.9 MB 5/17/2015 7:45 PM
	1 Quickstep 15 v1.3.ce	4.2 MB 5/17/2015 7:45 PM
	1 Quickstep 24 Adult v1.3.ce	7.1 MB 5/17/2015 7:46 PM
	1 Quickstep 24 v1 1.13.17.ce	12.5 MB Today 10:33 AM
	1 Quickstep 24 v1.3.ce	12.3 MB 5/17/2015 7:46 PM
	1 Quickstep 40 v1.3.ce	14 MB 5/17/2015 7:47 PM
	1 Quickstep Max Adult v1.3.ce	5.9 MB 5/17/2015 7:58 PM
	1 Quickstep Max v1.5.ce	18.7 MB 5/17/2015 7:59 PM
	1 Zoom Alpha v1.6.ce	2.4 MB 1/29/2016 10:35 AM
	1 Zoom Basic v1.7.ce	1.3 MB 1/29/2016 10:36 AM
	1 Zoom Chat Alpha v1.6.ce	1.2 MB 1/29/2016 10:36 AM
	1 Zoom Chat Qwerty v1.6.ce	1.2 MB 1/29/2016 10:36 AM
	1 Zoom Core Alpha v16.ce	3.4 MB 1/29/2016 10:37 AM
	1 Zoom Core Qwerty v1.6.ce	3.4 MB 1/29/2016 10:37 AM
	1 Zoom Qwerty v1.6.ce	2.5 MB 1/29/2016 10:37 AM
	TTMT 1.13.17.ce	364 KB Today 12:59 PM
		Add Fie Save to

Tip: Saving your file to Chat Editor allows you to edit the file on your computer and transfer to your wego A later. Save file to Chat Editor Import folder on your desktop.

#### Recover a vocabulary set backed up on your computer

- 1. Connect **wego A** to computer via USB charging cable.
- 2. Open *iTunes* on your computer > select the device icon on the top toolbar.
- 3. Select **Apps** from the left-hand menu.
- 4. Scroll down to the File Sharing section and select TouchChat.
- 5. Select Add File and choose vocabulary set saved to your computer.
- 6. On your wego A: select Vocab > Choose new Vocab > Menu > Import/ Export Vocab > Import from iTunes > select vocab set to import > Save.

## **Editing with Chat Editor**

*Chat Editor* is a free application for windows/PC computers that allows a user to edit vocabulary sets on a computer and then transfer back to the wego A device.

#### Download and install Chat Editor to your computer

- 1. Go to **touchchatapp.com/support/software-updates** > click on the current version of *Chat Editor* to begin application download.
- 2. When the download is complete, double-click on the *Chat Editor* file > select Run to begin the installation.
- 3. When prompted, select preferred language > **OK** > **Next**.
- Read the License Agreement > select the button next to I accept the agreement > Next.
- 5. Select **Install** > **Finish**. The *Chat Editor* application and an Import folder will display on your desktop when the download is complete.

#### Create a TouchChat vocabulary set configuration

The first time you open *Chat Editor*, you will be prompted to configure the application to use for TouchChat vocabulary sets.

- 1. Open Chat Editor application.
- 2. Select TouchChat from the drop-down list of products.
- 3. Select preferred language from the drop-down.
- 4. Select SymbolStix from the drop-down list of symbol sets.

#### Editing a vocabulary set in Chat Editor

- 1. Follow steps 1-9 for Back up a vocabulary set on your computer to transfer the vocabulary set you want to edit to your computer. Select to save the file in the Import folder located on your desktop.
- 2. Open *Chat Editor* > select the *TouchChat* configuration.
- 3. Library > My resources > select the vocabulary set to edit.
- 4. Edit your vocabulary set (changes are automatically saved when complete).

#### Upload vocabulary set back to your wego A device

- 1. In *Chat Editor*, select **Library** > **Transfer** > **Vocab to file**.
- 2. Select file to export > Transfer
- 3. Select **Save As** > save the vocabulary set to your computer.
- 4. Follow steps 1-6 for *Recover a vocabulary set backed up on your computer* to upload the vocabulary set back to your wego A device.

![](_page_16_Picture_24.jpeg)

HAT

## Pair the TTMT Speaker (SPKR)

Your wego A's TTMT Speaker (SPKR) is already paired, but on occasion you may need to re-pair it.

1. Turn off *Guided Access*: quickly triple-click Home button to open *Guided Access*.

Note: if your wego A model does not have a home button, use the Power button as shown on page 2. Enter pass code (default pass code is all 1s) > press **End** (top left).

2. Press **Home** button to view device home screen.

Note: if your wego A model does not have a home button, use the Power button as shown on page 2.

3. **Settings** > **Bluetooth** > If off, tap the **Bluetooth** button to turn on.

	Settings		Bluetooth	
┝>	Airplane Mode	$\bigcirc$	Bluetooth	
Ŷ	Wi-Fi	TTMT Setup	Now discoverable as "Talk's iPad".	
*	Bluetooth	On	MY DEVICES	
			TTMT SPKR	Connected (i)
	Notifications		ZAGG Rugged Book	Not Connected (i)
8	Control Center			
C	Do Not Disturb			

4. Under My Devices, tap TTMT SPKR to pair.

	Settings			Bluetooth
▶	Airplane Mode	$\bigcirc$	Bluetooth	
Ŷ	Wi-Fi	TTMT Setup		
*	Bluetooth	On	MY DEVICES	
			TTMT SPKR	Not Connected (i)
C	Notifications		ZAGG Rugged Book	Not Connected (i)
8	Control Center			
C	Do Not Disturb			

5. Press **Home** button to return to device home screen.

Note: if your wego A model does not have a home button, use the Power button as shown on page 2.

- 6. Open vocabulary set.
- 7. Quickly triple-click the **Home** button to resume *Guided Access*.

## Install communication software updates

Your wego A is locked/dedicated and can only perform speech/ communication functions. It cannot connect to the internet for web-surfing, etc. However, the wego A can be connected to the *App Store* to download software updates for your communication software. Please note that once connected to the *App Store* you cannot download/install new apps to your wego A. This functionality is disabled.

#### Initial setup: turn on access to the App Store

- Turn off *Guided Access*: quickly triple-click **Home** button to open *Guided Access* > enter pass code (default pass code is all 1s) > press End (top left).
- 2. Press **Home** button to view device home screen.
- Connect to Wi-Fi if not already: Settings > Wi-Fi > connect to your network.
- Settings > Screen Time > Content & Privacy Restrictions > enter passcode: 9357.
- 5. At the top of the screen, toggle Off Content & Privacy Restrictions.
- 6. Press **Home** button. The *App Store* icon will display on device home screen.

#### Update software in the App Store

- 1. Select the App Store icon.
- 2. Select **Updates** on bottom menu bar to display applications with updates available.
- 3. Select **Update** button next to application.
- If prompted, enter your Apple user ID and password (located on pg 15 of this guide). If you cannot locate your user ID or password, please contact our Support team: 877-392-2299 Option 3, or support@talktometechnologies.com.

#### Update complete: turn off access to the App Store

- 1. Once update is complete: press **Home** button to return to home screen.
- Settings > Screen Time > Content & Privacy Restrictions > enter passcode: 9357.
- 3. At the top of the screen, toggle **On** *Content & Privacy Restrictions*.
- 4. Press **Home** button to return to device home screen.
- 5. Open vocabulary set.
- 6. Quickly triple-click the Home button to resume Guided Access.

## User information and notes

Apple ID:
Password:
Guided Access code:
Notes:



![](_page_23_Picture_0.jpeg)

## We bring speech to life™

# Need Help?

![](_page_23_Picture_3.jpeg)

877.392.2299 Option 3

![](_page_23_Picture_5.jpeg)

support@talktometechnologies.com

![](_page_23_Picture_7.jpeg)

talktometechnologies.com (click Support)

![](_page_23_Picture_9.jpeg)

Join in the conversation... Connect with us for resources, contests and more!