

User Manual

Portable, battery-powered solar water filter & pump



gosun.co/manuals

Manual de usuario en Espanol Manuel d'utilisation en Françias Gebruikershandleiding auf Deutsch 日本語のユーザーマニュアル 中文用户手册



Table of Contents

Best Practices When Traveling Abroad	4
Warnings and Limitations	5
Parts List	6
Available Accessories	7
Storage Case	8
Filter Parts	9
Filter Replacement	10

Usage modes

A – Filter only (sucking)	. 12
B – Filter only (bottle or bag)	. 13
C – Pump and filter water	14–15
D – Pump water without filter	16–17
E – Using faucet / sink / shower	18–19
F – Make hot water with GoSun Fusion	20-21
G - Make hot water with submersible heater	22-23
Maintananaa	
Maintenance	24–25
Powerbank	26-27
Troubleshooting	28-29
Warranty	30

(this page is intentionally blank)

Caution

Drinking untreated water may expose you to harmful microorganisms and increase your risk of gastrointestinal illness. Improper usage of GoSun Flow® increases your risk of exposure to harmful microorganisms and increases your risk of gastrointestinal illness. Reduce your risk of becoming sick by following these safety instructions and by educating yourself on backcountry water safety.

Never use GoSun Flow® to filter seawater or chemically contaminated water, including water from mining tailing ponds or from near large agricultural operations. **Rinse the bottle and top cap with safe water before first use.**

DO NOT DROP or place pressure on this product in any manner. The intentional or unintentional impact of this product on a solid surface may damage the filtration mechanism within the GoSun Flow® and render it inefficient and unusable. This product must not be used by children without the supervision of an adult.

Tips

Test your gear before you go! Follow the instructions to make sure your GoSun Flow® is operating as you expect it to.

Note: GoSun Flow[®] will no longer filter water when the product has reached the end of its working life. Inability to sip or pump water through GoSun Flow[®] indicates that the filter should be replaced.

Questions? Contact support@gosun.co we're here to help!

Warnings & Limitations

Read before use.


Water Filter

- Can only filter tap water or fresh water from natural water sources like rivers and lakes. Not appropriate for use on saltwater, drinks, or chemical sources.
- ⊘ To avoid damaging the filter cartridge, do not filter water outside the temperature range of 35°F (2°C) – 120°F (40°C).
- Please clean or replace the polyproplylene filter disc if it becomes dirty, to prevent bacterial growth.
- If the flow rate significantly drops, replace filter cartridge immediately.
- Flush filter cartridge with clean (or filtered) water after using. Drain well, then air-dry. Do not store filter cartridge in humid place where bacteria or mold may grow.
- On't expose the water filter cartridge to sunlight for too long. High temperature and long UV exposure can damage filter materials.

Water Pump

- \bigcirc USB Pump is not waterproof. Do not submerge in water.
- O not run air through the pump for a long time. Doing so may cause the motor to overheat and degrade.
- \bigcirc Do not pump water without using mesh pre-filter on Intake Hose.

Parts List



Storage Case

- Water Filter
- Water Pump

- Powerbank
- Water Pouch
- Extra Filters


- Long Hose
- Short Hose
- Intake Hose

Available Accessories





Storage Case

- 1. The Pump, Filter and Powerbank get stored in the Top half of the Storage Case (the half with the solar panel)
- 2. To secure a part, open the velcro strap. Place the part down onto the rubber pad and firmly close the velcro strap.
- 3. Position each part in the Case as shown below.



Filter Parts







Third Stage: Nano Alumina Fiber

Removes bacteria and small impurities from water.



Second Stage: High-Efficiency Carbon Filter

Absorbs odors, hazardous chemicals, and heavy metals



First Stage: Polypropylene Filter Disc

Removes suspended impurities such as dirt, sand and rust

Filter Replacement

There are a few situations that would indicate it is time to replace your filter cartridge:


- 1. The flow rate through the filter is reduced to roughly one half the original flow rate (Please make sure the intake hose pre-filter and sediment filter disk are not dirty/clogged before replacing the main filter cartridge).
- The filter is becoming clogged and is past its useful life. The filter is still functioning, but the flow rate is reduced to the point where the pump is under additional strain.
- 2. If filtering chlorinated water and the water maintains a strong chlorine taste after filtration.
- The activated carbon filter has been consumed and the filter cartrage should be replaced.
- 3. Water coming from the filter is not clear.
- The Alumina filter element has likely been physically damaged and must be replaced. Please note: The filter cannot remove some substances, like the pigment in brewed tea, even when fully functional.

(this page is intentionally blank)

Mode A

Filter only (sucking)


- 1. Open Storage Case
- 2. Remove the Filter from the case.
- 3. Attach the intake hose with the pre-filter screen to the input of the filter. Place the intake hose screen into the water.
- 4. Suck to filter water
- 5. (Optional) The filter input can be placed directly in the water without the intake hose and screen if needed.



Mode B

Filter only (bottle or bag)


- 1. Open Storage Case
- 2. Remove the Filter from the case.
- 3. Attach the included foldable water bag, or other standard 20 Oz or 2 liter plastic drink bottle that has been filled with unfiltered fresh water to the filter input. The bottle or bag should thread on by rotating the bottle clockwise.
- 4. Squeeze the bottle or bag as needed to filter the water.





Mode C

Pump and filter water


- 1. Open Storage Case
- 2. Locate the three hoses Short, Long and Intake
- 3. Insert end of intake hose through the Left port and connect to the Intake side of Pump
- 4. Attach one end of the Short hose to the Outtake side of Pump, and the other end to the Intake side of the Filter
- 5. Insert one end of the Long hose through the Right port and connect to the Outtake side of the Filter








- 6. Locate freshwater source (not salt water), and place the Intake screen into it. For optimal performance, please ensure that the screen is suspended fully in the water. You may need to adjust the float to achieve this.
- 7. Place the loose end of the Long hose into your desired collection vessel
- 8. Plug Pump USB cable into the Solar Panel or Powerbank and enjoy fresh, filtered water!







Mode D


Pump water without the filter


- 1. Open Storage Case
- 2. Locate the two hoses Long and Intake
- 3. Insert end of intake hose through the Left port and connect to the Intake side of Pump
- 4. Insert end of the Long hose through the Right port and connect to the Outtake side of the Pump
- 5. Locate water source, and place the Intake screen into it. For optimal performance, please ensure that the screen is suspended fully in the water. You may need to adjust the float to achieve this





- 6. If using for drinking water, please ensure that the water source is potable
- 7. Place the loose end of the Long hose into your desired collection vessel
- 8. Plug Pump USB cable into the Solar Panel or Powerbank and enjoy!







Mode E


Using the faucet / sink / shower

- 1. Follow Steps 1–6 in Mode C (pump and filter) or D (pump only). For the shower, we recommend not using prefiltered water and not having the filter in-line. This will provide the best flow rates.
- 2. Connect the loose end of the Long hose to the intake stem on the faucet housing
- 3. Ensure that the Faucet cable is connected to the Long Hose along its length with the small plastic connectors if desired.
- 4. Insert the faucet cable through the middle Port on the Storage Case.






- 5. Locate the three-part cable split and connect the components to it as shown below.
- 6. Pop up the Sink basin and attach the faucet clamp to the sink, table, or other desired location.
- 7. Press the button next to the faucet spout to turn the water on / off. You may need to wait a few seconds on first use for the water to come out.
- 8. Enjoy! (Optional): use heated water: please refer to Mode F & G



Mode F

Making hot water with the GoSun Fusion

- 1. Only use filtered or potable water (free of particulates which could clog the pump)
- 2. Locate GoSun Fusion and Vertical Tilt Leg Kit
- 3. Insert the Legs into the Bracket
- 4. Tilt the open end of the Fusion up, and insert the Bracket into the Fusion end as shown
- 5. Press the Bracket into the Fusion end as far as it goes, then lower the Fusion down onto the legs
- 6. Position the Fusion facing the Sun and fill with water. Open the Fusion to the Sun, and close end with the Cap, letting the water heat up inside.




- 7. To pump the water with Flow, follow steps 1–5 in Mode D.
- 8. Take the Intake Screen off the of Intake hose and insert that end of the Intake hose through the Fusion Lid.
- 9. (Optional): Attach the Intake Screen back onto the end of the Intake hose to weight the end of the hose down.
- 10. To use the heated water with the Sink or Shower, follow steps 2–7 in Mode E.



Caution

Do not let water exceed **120°F (40°C)** because that can scald skin and/or damage the pump. Use the GoSun Thermo or other thermometer to monitor.






Mode G

Making hot water with Submersible Heater

- 1. Only use filtered or potable water (free of particulates which could clog the pump)
- 2. Locate the Submersible Heater and Large Powerbank
- Place the Heater end of the Submersible Heater into your water source, without immersing the cord or housing. Please ensure that the water vessel can safely hold heated water. (Optional – for more efficient heating, you can use the **GoSun Fusion** as a vessel, by following steps 1–5 in Mode F)





Caution


Submersible Heater gets **very hot.** Only plug in when the heating element is fully submerged in water. Unplug heater before pumping water out of container.


- 4. Plug the Submersible Heater into the Powerbank and turn the Powerbank on.
- 5. To pump the water with Flow, follow steps 1–5 in Mode D.
- 6. To use the heated water with the Sink or Shower, follow steps 2–7 in Mode E.



Caution

Do not let water exceed **120°F (40°C)** because that can scald skin and/or damage the pump. Use the GoSun Thermo or other thermometer to monitor.





Maintenance

Filter cleaning and storage

Short term storage

Perform these steps when the filter will not be used for 2–3 days or after filtering 100–200 gallons of water

- 1. Filter a small amount (1–2 cups) of water into a clean container for flushing your filter assembly. If performing maintenance inside, tap water can be used.
- 2. Remove the pump and filter from the storage case and disconnect all attached hoses.
- 3. Drain the water from all hoses and store in the case.
- 4. Connect the pump to the powerbank or solar panel and run for 10-20 seconds to remove any water left in the pump.
- 5. Disassemble the filter housing and remove the filter cartridge, then disassemble the filter cartridge. (the filter housing and cartridge may still contain water in them)
- 6. Flush the pleated alumina filter, and the polypropylene filter with clean water run under tap water or gently stir the pleated filter in a cup of filtered water.*


* Do not handle the pleated alumina filter roughly, bend, or twist it, as you may physically compromise the filter element.

* Do not brush the alumina filter, only flush with clean water using low pressure.

- 7. Check the polypropylene filter. If the polypropylene filter is persistently dirty, replace it with a fresh filter.
- 8. Reassemble the filter cartridge, then reassemble the filter housing with filter cartridge installed.

Long term storage

Allow all three filter elements to air dry completely (this may take 2 days or more in some environments) before reassembly. Do not dry the filter in direct sunlight or in a heated enclosure, the UV rays from direct sunlight and excess heat can damage the filter materials.




Powerbank

How to charge and use the powerbank

Charge the Powerbank in several ways:

- 1. **Charge with any USB source:** to charge the powerbank with another USB source (a larger powerbank, wall charger, or other solar phone charger) simply connect the input of the power bank to the new charging source to start charging.
- 2. **Charge with solar panel:** to charge the power bank with solar, simply plug the charging cable into the power bank input and the solar panel output as shown below. Then, orient the solar panel at the Sun to power. The solar panel will perform best if it is directly facing the Sun.



Power the pump in several ways

- 1. **Power directly from the included solar panel:** Plug the pump's USB cable into the solar panel cable, and orient the solar panel at the Sun to power. The solar panel will perform best if it is directly facing the Sun.
- 2. **Power with the Powerbank:** Plug the pump's USB cable into the powerbank to run.
- 3. **Power with the Powerbank, while charging the solar panel:** If solar charging the powerbank, the Flow can still be used, but the flow will work at a reduced rate if in the shade. If the solar panel is not receiving enough sunlight for the Flow to function as desired, cover the solar panel or disconnect the powerbank from the solar panel to run fully off the powerbank.
- 4. **Power with any USB source:** Simply connect the pump cable to any USB power source such as a larger powerbank, wall charger, or other solar phone charger.

Troubleshooting

Problem	Probable Cause
Water flow rate from the Flow is reduced, but the pump is still running fine.	3 stage filter may be clogged
	Intake filter may be clogged
	Hose may be kinked
USB Pump seems to be running slowly, or is running rough.	Low light on solar panel
	3 stage filter may be clogged
	Hose may be kinked
USB Pump is not running when switched on at the faucet	Wire harness connected incorrectly
	Powerbank stuck in sleep mode
	Powerbank is depleated
Water coming out of filter does not look clean.	Filter physically damaged
	Contaminate is not filterable (chemical content, artificial or natural dye, etc.)

Solution

Please reference "Filter Replacement" on page 9 Clean the intake filter by flushing with clean water Check all hoses for kinks and straighten as needed

Move panel into full sun, facing the sun as best as possible Cover solar panel with opaque material Turn case upside down to fully block light from solar panel Please reference "Filter Replacement" on page 9 Check all hoses for kinks and straighten as needed

Check wire harness connections Press the button on the powerbank to manually turn it on Unplug the powerbank, wait 15 seconds, then reconnect Charge the powerbank for at least 1 hour, then reconnect

Replace the 3 stage filter assembly

Find an alternate water source

Unplug the powerbank, wait 15 seconds, then reconnect

Warranty

Warranty Policy

GoSun Inc. extends this One-Year Limited Warranty to the original end-use purchaser of GoSun products^{*} or the person receiving a Product as a gift, provided that the GoSun Product was purchased from an Authorized Dealer as defined below. The Limited Warranty does not extend to any other person or transferee. Statutory or common law may provide additional rights or remedies that vary from state to state, and country to country, which are not affected by this Limited Warranty.

Definitions

"Authorized Dealer" means any distributor, reseller or retailer that was duly authorized by GoSun at the time of the sale to sell authentic GoSun products in the jurisdiction where it sold the Product, and that sold the Product in new, unused condition in its original packaging.

"Fraud Misrepresentation" means misrepresenting any fact related to a warranty claim to GoSun, including the nature of the defect, whether the Product was purchased from an Authorized Dealer, and the authenticity of the Product. "Intended Use" means use of the Product (a) for food preparation, (b) for private (as opposed to commercial) purposes, (c) in conformity with all applicable local, state or federal law, code or regulations, (d) in accordance with GoSun recommendations and/or instructions in the materials and documentation that accompany the Product.

Scope of One-Year Limited Warranty

GoSun provides a One-Year Limited Warranty against Manufacturing Defects. If a Product contained a Manufacturing Defect when it was purchased from an Authorized Dealer, GoSun, at its sole discretion, will (i) repair, (ii) replace, or (iii) provide a Warranty Credit for the Product on the GoSun online store. The amount of the Warranty Credit shall be equal to the purchase price of the Product paid to the Authorized Dealer. GoSun reserves the right to inspect any Product subject to a warranty claim to determine, at its sole discretion, whether the claimed defect is a Manufacturing Defect or otherwise.

Disclaimer

Disclaimer

GoSun® Inc. shall be neither liable for any damages arising out of or as a result of the use of GoSun Flow[™] for any purpose other than for which it is clearly intended, nor for any malfunction resulting from the failure of the user of GoSun Flow[™] to strictly abide by the usage and safety information contained in this manual. Stated microbiological and longevity performance of GoSun Flow[™] is conducted under standard laboratory test conditions; more information regarding test results and conditions can be found at gosun.co/products/flow

GoSun Flow™ is a personal water filtration tool and should only be used for filtering water.

Preventing Recontamination

The effectiveness of GoSun Flow™ may be limited by environmental or hygienic conditions that could contribute to the recontamination of water after it has passed though the product's internal filter. These conditions include but are not limited to:

- 1. Handling the mouthpiece with dirty /contaminated hands.
- 2. Failure to maintain a clean moutpiece and exterior.
- 3. Failure to discontinue use of the product per manufacturer's recommendations.
- 4. Using the filter if the plastic is cracked.

5. Use in or exposure to extreme heat (higher temperature than 120°F/40°C) or near-freezing temperatures (below 35° F/2°C).

Read these usage and safety instructions carefully before using GoSun Flow®.

The quality of the filtered water is not guaranteed if the product is submitted to conditions other than those encountered during its normal use. Your use of GoSun Flow™ implies that you accept and agree to these terms, conditions, and disclaimer.

(this page is intentionally blank)

Need help?

- **%** +1 888.868.6154
- Support@gosun.co
- gosun.co/help-center



OgosunOgosun

Patent pending in USA & other countries. Copyright © 2022 GoSun Inc. All rights reserved +1 888.868.6154
 support@gosun.co