

# How To Adjust The Grinder Settings



## Step 1

Put your coffee beans in the designated opening.

## Step 2

Begin disassembling by unscrewing the top cap, next remove the handle, then remove the lock.

## Step 3

Use the disk to adjust the coarseness. If you want your coffee beans to be fine, tighten the disk (clockwise motion), for more coarse loosen the disk (counter clockwise motion).

## Step 4

Once you are happy with the settings – begin reassembling the parts. Starting with lock, then the handle, and lastly screw the top cap back on.

## Step 5

Start rotating the handle to start grinding.

