RadExpand[™] 5 Plus

Rider Quick Reference

Power Your Ride

Your RadExpand ebike has three ways to move you with ease:

Pedal Assist System (PAS)

Adjust the PAS level to the amount of motor help you want while you pedal.



Level 5 = Maximum help.Level $\mathbf{1} = A$ little help. Level **0** = PAS is off.

Throttle on Demand

Twist the throttle to get extra motor power with or without pedaling.

Get a quick boost to get started. Or cruise along without pedaling!




Gears

۲

Downshift to a low gear for easy pedaling (great for starting or for going uphill).

Upshift to a high gear for fast cruising once you're already up to speed.



Gears are a mechanical feature independent of the motor and work like the gears on a non-motorized bike.

Color Display Overview

в

С

D

Ε

Power button

Menu button

Increase PAS/

Headlight button

Right turn button

Decrease PAS/

Walk button

Left turn button



Remote

Turn Signals

 \bigcirc

Your RadExpand ebike is equipped with a taillight that includes integrated turn signals to help improve your visibility in low light conditions.



RAD POWER BIKES

Press the desired turn button on the remote before starting a turn, and press the button again when the turn is completed to turn off the signal.

WARNING: Do not substitute turn signals instead of using hand signals when riding your ebike. Always follow local guidelines requiring the use of hand signals when riding, and never assume that other vehicles on the road can see the turn signals when riding.

Folding and Unfolding

Your RadExpand ebike can be folded for storage and transport.

Turn the locking clasp up, pull the quick release lever away from the frame, and then disconnect the frame hinge lock. Carefully fold the front of the frame in a counter-clockwise motion toward the rear of the frame until the wheels are parallel to each other. Secure the frame with the velcro strap, if desired.




۲



Push the release button on the stem locking lever up and then pull the lever down to unlock the stem riser. Carefully fold down the handlebar until it rests against the frame.

Reverse these steps to unfold the ebike and secure the stem riser and frame hinge before riding.

WARNING: Use caution to keep fingers, clothing, and other objects away from the folding mechanisms and potential pinch points on your bike. Always check the folding mechanisms to ensure they're locked before you ride or move your bike.



- Wattage level G
- **Battery** level н
- Headlight indicator
- Left turn signal
- κ Speedometer
- Odometer L М
- USB charging indicator N Remaining battery or
- remaining range estimate 0

- Right turn signal
- **PAS** level

P



RadExpand[™] 5 Plus Safety First!





WARNING! Riding with any loose, improperly adjusted, or over-worn components can cause failure or loss of control, resulting in damage to your ebike, serious injury, or death.

۲



□ All accessories are attached and used according to manufacturers' instructions. □ Bike helmet, closed-toe shoes, and weather-appropriate, high-visibility clothing.

۲

WARNING: Ebike components like brakes, cables and tires may wear out faster than would be the case for non-motorized bicycles, requiring more service. You must check your ebike before each ride and according to the other checklists in your Owner's Manual, and have a professional, reputable bike mechanic perform a thorough tune-up following the service intervals described in your Owner's Manual, or sooner if you discover increased wear. Failure to do so could result in property damage, serious injury, or death.



rad-go.com/safety

© Copyright 2024 Rad Power Bikes Inc. All rights reserved. All trademarks are the property of Rad Power Bikes Inc. 2312211254

PART # 702-00030

۲