Rotate and lower handlebars,

and tighten quick release



## **HOW TO UNFOLD**

Before unpacking your scooter, you must read the User Manual, observe rider restrictions and read the returns policy and warranty overleaf.

Take care when unpacking your scooter, please keep all packaging until you are entirely satisfied with your purchase.

Follow the steps illustrated below to unfold your scooter and prepare for your first ride. Some parts may vary from the diagram, however the (un)folding process remains the same. You will need a pump with a standard 'Schrader' valve when inflating the tyres.

Please observe our safety recommendations in the User Manual before your first scoot.

Please note, a part of the scooter may have been disassembled by our packing team in order to fit accessories in the box (e.g. mudguards, kick-stand) you will find the tools required to reassemble these parts enclosed.

We have prepared video tutorials for you to watch on our YouTube channel Go to swiftyscooters.com/assembly-guides to find the direct links to our

If you have any problems, please contact your local dealer, or contact us:






keep fingers inside carry handle

when folding and unfolding






Turn footplate toggle, and lift folding stem


Secure folding stem lever

with toggle




Pull back pin and release to lock rear fork into place





Lower foot plate



Perform a basic safety check before each ride as described in the User Manual. Check brakes are working. Check bolts, wheel nuts and quick release levers are tightened fully.

Recommended tyre pressure 60-80 PSI.

You may wish to adjust the position of the handlebars or brake levers, using the tool provided.





## RETURNS and REFUNDS

Thank you for purchasing a SwiftyONE-e. If you are not entirely satisfied with your purchase, we're here to help. If you made your purchase from one of our registered dealers, please contact them directly. If you bought from swiftyscooters.com, please read our returns policy below:

#### **RETURNS**

We offer a no-hassle 30 day returns policy to any unused, full-priced items, with all original packaging. For sale items, you have 14 days to contact us.

You will also need to have the receipt or proof of purchase.

If you are not entirely satisfied with your scooter after riding it, you may still return your scooter to us, however, we reserve the right to make a deduction for wear and tear, once we have received and inspected your scooter.

### HOW TO RETURN YOUR ITEM

The first thing to do is to contact us.

email: support@swiftyscooters.com or call SwiftyHQ: +44 (0)161 848 8695

We will then explain how to return your item (depending on location). If you are a UK customer, we will arrange for our courier to collect it, once you have packed it back into its original box.

### **REFUNDS**

Once we receive your item, we will inspect it and notify that we have received your returned item. We will immediately notify you of the status of your refund after inspection. If your return is approved, we will initiate a refund to your credit card (or original method of payment). You will receive the credit within a certain amount of days, depending on your card issuer's policies.

### **SHIPPING**

The cost of shipping the product back to Swifty Scooters may not be covered (dependent on location and reason for return). If you receive a refund, the cost of the return shipping will be deducted from your refund. If you are returning an item because of our mistake, you will receive a full refund.



Scan me for video guides of assembly and maintenance!

or go to swiftyscooters.com/assembly-guides

## WARRANTY

Swifty Scooters is committed to producing the highest quality products in the industry and welcomes customer feedback that can assist us in achieving this goal. We warrant our products to their original owner with proof of purchase from authorised dealers against defects in manufacturing and materials.

The hub motor, battery and controller are covered for 1 year under warranty. Frame and forks have a warranty of 2 years for the original owner. If your scooter frame or forks fail due to manufacturing and materials we will repair or replace them free of charge. However, the cost of shipping the product or part back to and from Swifty Scooters may not be covered (dependent of location and reason of the return).

### THIS WARRANTY DOES NOT COVER

- 1. Normal wear and tear.
- 2. Improper assembly.
- 3. Improper maintenance and installation of incompatible parts and accessories.
- 4. Damage or failure due to accidents, misuse, abuse and neglect.

Any modification to the frame, fork or components voids this warranty entirely. This warranty is expressly limited to the repair or replacement of defective items, and said repair and replacements is the sole remedy of the warranty. Cost of shipping the product back to and from Swifty Scooters and any labour charges incurred may not be covered.

### WARRANTY PROCEDURES

- 1. Please contact us by email at support@swiftyscooters.com for a warranty claim form.
- 2. Please fill out the Swifty Scooters warranty claim form in full. Photos of the damage / issue and proof of purchase must be attached.
- 3. Return the form and attachments to us via email (support@swiftyscooters.com).
- 4. Swifty Scooters will determine the defects based on the information provided, then we will require you to send back the original items.
- 5. After we examine the part and determine that your product is defective or faulty, your product will be replaced free of charge. Shipping costs may apply.

#### VALIDATE YOUR WARRANTY

You can register your warranty by scanning the QR code below or by visiting

www.swiftyscooters.com/warranty and completing our quick online warranty form.




### Scan me!

or go to swiftyscooters.com/warranty for the online form











## Swifty ONE ?

## **POWER IT UP**


Your scooter should now be unfolded and ready to go. You can now take the following steps to give electric power to your Swifty.

These are the basic steps to get you started, please read the Swifty e-scooter User Manual in full before you start your first journey.

If you have any problems, please contact your local dealer, or contact us:

SwiftyHQ Tel: +44 (0)161 848 8695 Email: support@swiftyscooters.com








2

You can charge your battery whether it's on or off the scooter. To take your battery off the scooter, you'll first need to unlock the battery with the keys provided



#### WARNING!

You are supplied with 2 keys to secure the battery. It is advisable to seperate the keys and keep the spare in a safe place.









### How to Charge:

- 1. Plug your charger into a mains socket, the LED light on the charger will illuminate GREEN
- 2. Peel open the yellow cover on the side of the battery. Connect the charger to the battery using the lead provided, the LED light on the charger will then change to RED which indicates its charging.
- 3. A full charge takes up to 6 hours. To prolong the life of the battery, charge it after every trip.
- 4. Once fully charged the LED light on the charger will switch back to GREEN, indicating the battery is fully charged.



## Swifty ONE !

## TIME TO RIDE


If you have any problems, please contact your local dealer, or contact us:

SwiftyHQ Tel: +44 (0)161 848 8695 Email: support@swiftyscooters.com



power button for 1 second.





To turn on your headlight, short press the middle button औ, the ■D icon should appear on the top right of the display interface. You should also turn on your rear light manually to increase your visibility.



Press the **M** button to switch among the 4 acceleration modes.

Blank Kick scooter mode, motor will not start

Slow acceleration, for inexperienced new riders

MID Medium acceleration, for a balanced riding experience

HIGH Max acceleration, for maximum torque and scooting uphill

To set off, take the following steps:

- 1. Place one foot on the footplate and push off with your other leg. Balance both feet on the scooter when you have enough momentum.
- 2. After you've pushed off, twist the grip throttle towards you gently to start the motor.
- 3. Hold the throttle halfway to maintain the desired speed.
- 4. Twist the throttle all the way to get the maximum speed of 25 km/h or 15.5 mph.

To stop - Always release throttle before applying brakes.



To perform an emergency stop, release throttle, bend knees, brace arms and use both brakes together.




Scan me for video guides of assembly and maintenance!

swiftyscooters.com/assembly-guides





## **DISPLAY INTERFACE DIAGRAM:**





## **KICK-STAND**

If you have any problems, please contact your local dealer, or contact us:

SwiftyHQ Tel: +44 (0)161 848 8695 Email: support@swiftyscooters.com

# **HOW TO USE** Flip both legs out to the side. Using your toe to pivot the kickstand down to the ground, roll the scooter backwards until the kickstand The final standing position, the rear wheel is lifted,


snaps into place underneath the rear wheel.

Lift the footplate and rotate the rear wheel.

## HOW TO FOLD THE **Swifty** ONE REAR WHEEL

the legs closed as shown above.





with the stand underneath.

The kickstand will rotate through the frame into the fully folded position as shown above.

