




MADE BY ZEN<sup>®</sup>



ALINA

Lantern style Aroma Diffuser  
with a soft ambient light

# **TABLE OF CONTENTS:**

**A. ABOUT THE ALINA**

**B. TECHNICAL SPECIFICATION**

**C. OPERATING INSTRUCTIONS**

**D. FEATURES**

**E. MAINTENANCE**

**F. TROUBLESHOOTING**

**G. WARRANTY**

**Congratulations on purchasing your MADE BY ZEN® Alina Aroma Diffuser. Please keep this manual to help you get the most out of your Alina and for maintenance.**

# A - ABOUT THE ALINA

Minimal yet beautiful in design, the Alina Aroma Diffuser releases a cool scented mist, fragancing your home and creating a tranquil sanctuary.

Alina's lantern style cover emits a soft warm glow, casting subtle patterns of light and shadow, instantly creating calm and relaxation.

Unwind and set the perfect mood, filling the room with scent and light.



Warm, ambient LED lighting with a variety of settings to help you relax.

- Soft glow, fixed ambient light



Sleep mode (no light) option



The Alina Aroma Diffuser also has an intermittent mist setting, which automatically controls the scent diffusion, by intermittently switching the mist on and off every 30 seconds. This is ideal for using stronger scents/oils, or when scent is desired for a longer period of time.



Suitable for use with any essential or fragrance oils  
(MADE BY ZEN® oils recommended)

**Thank you for purchasing the MADE BY ZEN® Alina Aroma Diffuser.**

# B - TECHNICAL SPECIFICATIONS

**Model Name: Alina Aroma Diffuser**

**Model No: EW021**



**Product Size: Ø115 x 146.2mm**

**Voltage: DC 24V**

**Power: 12W**

**Water Capacity: 80ml**

**Run Time: 4 hours**




01. Mist Output

02. Cover

03. Max. Water Level Line

04. Water Discharge Groove

05. Ceramic Disc



06. Water Tank


07. Vent Hole

08. Mist Button

09. Light Button

10. DC Jack

11. Adaptor



# IMPORTANT NOTES BEFORE

The Aroma Diffuser **MUST** be cleaned before and after each use. When stored the unit should **always** be kept clean and dry. **NEVER** leave stagnant oil and water in the water tank for any prolonged period.

Whilst using your diffuser, you **MUST** clean the water tank every 3 days:



**Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can develop in the water reservoir, and expelled into the air when next used causing very serious health risks. To prevent this the water tank **MUST** be cleaned properly every 3 days.**

Der Aromadiffuser **MUSS** vor und nach jeder Verwendung gereinigt werden. Das Gerät sollte immer in einem sauberen und trockenen Zustand gelagert werden. Lassen Sie **NIE** über einen längeren Zeitraum Öl und Wasser im Wassertank stehen.

Während der Verwendung Ihres Diffusers **MÜSSEN** Sie den Wassertank **alle** drei Tagen reinigen:



**Eventuell im Wasser oder der Umgebung, in der das Gerät verwendet bzw. gelagert wird, vorhandene Mikroorganismen können sich im Wassertank weiterentwickeln, bei der nächsten Verwendung in die Luft austreten und somit äußerst ernsthafte Gesundheitsrisiken hervorrufen. Zur Vermeidung dessen **MUSS** der Wassertank alle drei Tage ordentlich gereinigt werden.**

يجب تنظيف الفواحة العطرية قبل وبعد كل استعمال. في حال حفظ وتخزين الجهاز، يجب دومًا المحافظة عليه نظيفًا وجافًا. لا تترك بقايا الزيت والماء الراكد أبدًا في خزان الماء لمدة طويلة جدًا.

أثناء استعمال الفواحة العطرية، يجب عليك تنظيف خزان الماء كل ٣ أيام.



يمكن للكائنات الدقيقة التي قد تكون موجودة في الماء أو في البيئة في حال استخدام الجهاز أو تخزينه أن تنمو في خزان الماء، وتنتشر في الهواء، وسوف يتسبب الاستعمال التالي للجهاز بأخطار صحية كبيرة جدًا. لحماية خزان الماء، يجب تنظيفه على نحو مناسب كل ٣ أيام (٧٢ ساعة).

1. Place the aroma diffuser on a flat surface, at least 60cm away from the floor and at least 10cm away from the wall. DO NOT place the aroma diffuser on wooden or polished furniture that may be damaged by water moisture.

2. Always unplug the aroma diffuser from the mains electrical supply when cleaning or filling with water. Always use the power adaptor supplied. Ensure the cable is secure to avoid tripping or knocking over the aroma diffuser. If the power adaptor is damaged, it must be replaced with a suitable adaptor provided by the manufacturer or its agent. Alternatively, a new adaptor can be purchased from your retailer.

3. Use a suitable measuring cup to fill the water into the water tank. Never attempt to fill water under a running tap or whilst plugged in. Do not fill the water beyond the max water level line. Carefully remove the excess water from the tank, if overfilled from the water tank from the water discharge arrow - away from the vent hole.

4. The aroma diffuser must be kept out of reach from children and pets to avoid risk of injury. Children should be supervised at all times to ensure they do not play with the appliance.

5. The aroma diffuser is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.


6. Keep the aroma diffuser in a clear space to allow the mist to freely spread and away from appliances especially those sensitive to water to avoid unnecessary accidents.

7. The aroma diffuser must be cleaned after each use and should always be kept clean and dry when not in use. Never leave stagnant oil and water in the water tank for prolonged periods.


8. Never attempt to disassemble your aroma diffuser or repair the product, as this will void your warranty and create a shock hazard. Contact your retailer if an internal inspection is required.

9. In case of abnormal observations such as smoke, peculiar smells or noise, stop using the aroma diffuser immediately and contact the retailer from where you purchased it. Never wrap the adaptor with cloth or paper as blocking ventilation could increase the risk of fire.
10. Always handle the aroma diffuser with care – accidental damage is not covered under the warranty.
11. Always use water at room temperature and use only fresh, clean water from a reliable source. Do not fill the water tank with other chemicals or liquids other than water and a few drops of fragrance or essential oils.
12. Never touch the water within the water tank when the aroma diffuser is in operation as the water may become warm. It is perfectly normal for the water temperature to increase over time. Especially if it has been running for a few hours. This is caused by the energy created from the vibrating disc. The water should not exceed 40°C but for some models it can increase to 50°C (+/- 5°C). However, as the mist dissipates from the mist outlet, the water temperature cools rapidly due to the large surface area of each droplet, hence the mist is referred to as a 'cool mist'.
13. Always plug the adaptor into the DC jack before plugging into the mains.
14. Do not remove the covers during operation.
15. NEVER touch the ultrasonic ceramic disc while the diffuser is plugged in as this could cause serious injury.
16. Do not immerse the unit in water or other liquids and do not attempt to clean in a dishwasher.
17. When using the light only mode, the standby mode will not operate. Switch off the light as per the instructions in this manual.

# C - OPERATING INSTRUCTIONS




1. Place the diffuser upright on a firm and flat surface. Remove the cover upward carefully as shown. Plug in the DC jack.



2. Add water to the water tank with a suitable measuring cup until the water reaches the max. water level line as shown.





3. Add 3-5 drops of your favourite fragrance or essential oil into the water.



4. Replace the cover.





5. Plug in the power adaptor and press the MIST button to switch on the unit.

**Note: Do not lean or move or attempt to empty or refill the diffuser during operation.**

## BUTTON FUNCTIONS

### MIST CONTROL

> **Press MIST once**

Aroma Diffuser will mist continuously. When on this mode, the CONT. light indicator will be lit.

> **Press MIST three times**

The Aroma Diffuser will now stop misting.



### LIGHT CONTROL

> **Press LIGHT once**

An ambient will activate.

> **Press MIST twice**

Aroma diffuser will mist intermittently; 10 seconds on / 10 seconds off. When on this mode, the 10 SEC. light indicator will be lit.



> **Press LIGHT twice**

Light will switch off.


## D - FEATURES

The Alina ultrasonic Aroma Diffuser provides a revolutionary way to fragrance your surroundings. It works by creating high frequency vibrations that breaks down the water and oil into minute particles which are then effectively diffused into the immediate surroundings.

- Unique patented design
- Aroma Diffuser: can be used with ambient lighting or without, ideal for night-time use
- Night Lamp: Can be used without the mist, ideal as a night light
- Low energy LED ambient lights
- Mini humidifier
- Quiet operation
- Auto-shut off when water runs out for an additional safety
- Easy to clean and use


Note: Auto shut off does not operate when using light only mode.

# E - MAINTENANCE




1. Press the MIST and LIGHT button to switch off the diffuser and unplug the power adaptor from the mains.


**DO NOT EMPTY WATER FROM THE SIDE OF THE VENT HOLE**



3. Empty water via the discharge groove



2. Remove the cover as shown



4. Use a clean swab or cloth to clean the unit.

**Caution:** Always switch off the appliance and disconnect the power source from electrical outlet before cleaning.

Always keep your Aroma Diffuser clean and dry when not in use. Never leave stagnant oil and water inside the tank for prolonged periods. If the aroma diffuser stops generating mist (or generates little mist), clean the ceramic disc as indicated above. For stubborn oil build up, use sanitary alcohol on a cotton bud if required.

When cleaning, always take extra care to ensure water does not enter DC Jack power port. Allow the unit to dry thoroughly as advised below if water accidentally enters the electrical port.

**Accidental Leakage:** In the event of the aroma diffuser being knocked over during use, please follow the steps below to avoid malfunction.

- Unplug the diffuser from the mains and remove the cover carefully.
- Pour out any remaining water from the tank.
- Shake the diffuser gently to drain any water from inside, then leave for 24 hours for the diffuser to dry thoroughly in a well-ventilated area.

# F - TROUBLESHOOTING

Problem	Possible Cause	Solution
No Mist or mist volume significantly reduced	Power supply is not connected	Plug in the power adaptor and press the button on the base.
	Water is lower than the water level sensor	Refill the tank with ordinary tap water. Take care not to fill past the max water level line
	Water is exceeding the max water level line	Carefully pour out excess water in the direction of the water discharge groove
	There may be a build-up of oil on the ceramic disc	Clean the ceramic disc with water and a clean cloth
	Mist outlet is blocked	Clean the mist outlet by thoroughly cleaning the inside of the cover with clean water
Unit will not switch on	There is an insufficient amount of water in the tank	Fill the water tank with water up to the max water level line. Do not over fill
	The power cable may not be connected properly	Disconnect the cable and try connecting properly
Water is leaking from the product	The cover is not positioned correctly	Remove the cover and replace correctly allowing mist to release correctly
	The unit has been tipped or knocked over	Follow the accidental leakage instructions
	The temperature is low or there is high humidity	Under these conditions the mist can sometimes condense into water droplets
	Water moisture has built up inside the cover	Remove the inner cover and dry off excess water from the inside of the cover

**The intensity and amount of mist may vary, but this is not unusual and should not be considered as a fault. Factors that may affect this include water type, humidity, temperature, air currents etc.**

## G - WARRANTY

This product carries a 12-month warranty for proper use in accordance with this manual against any manufacturing defects.

Accidental damage is not covered under the warranty. The warranty period is 12 months from the date of purchase. In case of any problems arising during the warranty period, please contact your retailer for maintenance or claims. Proof of purchase will be required, so it is vital that you keep your receipt of purchase with this safety manual.

Corrosive oils such as Citronella may cause damage to the unit if left in the water tank. This type of damage is not covered under the warranty. This Aroma Diffuser must be cleaned after each use.



**IMPORTANT!**

MADE BY ZEN® Ultrasonic Aroma Diffusers comply with the WEEE Directive (Waste from Electrical and Electronic Equipment Directive) 2019/19/EU.

Electrical equipment is a large source of waste and if not properly recycled could have damaging effects on the environment, whereas if it is recycled, the resources could be used again.

Electronic waste needs to be separated from other waste to be recycled properly. When the Alina Aroma Diffuser reaches the end of its working life, please deposit at an appropriate collection point for recycling of electrical products. You can also recycle used electronics at Household Waste Recycling Centres.

Caring for our planet is important to us, so please help us by disposing of the Alina correctly. Thank You.



MADE BY ZEN®