

#11 Percussion Cap Maker

PRODUCES A #11 ALUMINUM CAP

READ ALL INSTRUCTIONS AND CAUTIONS BEFORE USING

Using scissors or a pocket knife remove the top and bottom from an undamaged aluminum beverage can. (The can must be aluminum. Check with a magnet if you are unsure.) Cut the can down the middle and run it over a table edge to flatten it into a sheet. Clean both sides to remove residue and cut it into strips approximately 3/4" wide. Insert the aluminum strip in the feeding slot of the #11 Percussion Cap Maker body with the unpainted side up. Insert the punch carefully into the guide hole. Place it on a solid base and tap the punch downward with a plastic hammer or soft mallet. Use light taps to begin with until you get the feel required. Be sure to hold the strip squarely against the back of the slot. Extract the punch and invert it. The finished aluminum cap will fall from the exit passage. Reposition the aluminum strip for each successive cap. Avoid cutting into a previously cut hole. After repeated use, paint, aluminum or other residue may collect in the punch teeth and should be brushed out.

CHARGING YOUR CAP

1. Mix *Prime All* per instructions.
2. Fill #11 Cap flush with *Prime All*.
3. Place 1 drop of acetone on top of *Prime All*.
4. Let dry for 24 hours.
5. You are ready to shoot.

CAUTION

Always wear eye protection.

Always wear gloves.

**Use caution when cutting and handling aluminum cans,
they can be very sharp.**

The punch must be handled with care.

Damaged cutting edges will greatly reduce cap quality.

Do NOT slam Cap on Nipple.

#11 Percussion Cap Maker

PRODUCES A #11 ALUMINUM CAP

READ ALL INSTRUCTIONS AND CAUTIONS BEFORE USING

Using scissors or a pocket knife remove the top and bottom from an undamaged aluminum beverage can. (The can must be aluminum. Check with a magnet if you are unsure.) Cut the can down the middle and run it over a table edge to flatten it into a sheet. Clean both sides to remove residue and cut it into strips approximately 3/4" wide. Insert the aluminum strip in the feeding slot of the #11 Percussion Cap Maker body with the unpainted side up. Insert the punch carefully into the guide hole. Place it on a solid base and tap the punch downward with a plastic hammer or soft mallet. Use light taps to begin with until you get the feel required. Be sure to hold the strip squarely against the back of the slot. Extract the punch and invert it. The finished aluminum cap will fall from the exit passage. Reposition the aluminum strip for each successive cap. Avoid cutting into a previously cut hole. After repeated use, paint, aluminum or other residue may collect in the punch teeth and should be brushed out.

CHARGING YOUR CAP

1. Mix *Prime All* per instructions.
2. Fill #11 Cap flush with *Prime All*.
3. Place 1 drop of acetone on top of *Prime All*.
4. Let dry for 24 hours.
5. You are ready to shoot.

CAUTION

Always wear eye protection.

Always wear gloves.

**Use caution when cutting and handling aluminum cans,
they can be very sharp.**

The punch must be handled with care.

Damaged cutting edges will greatly reduce cap quality.

Do NOT slam Cap on Nipple.