



MAUCH - TECHNOLOGY CO., LTD

Nanling Technology Park, Lixiang Street, No. 600
110000 Shenyang, Hunnan District, China

Email: Christian.mauch@hotmail.com

Phone: +86 1513 4182 360


PL – Series Sensor Hub X8




Installation:

The Sensor Hub X8 can be either installed via double side tape, or screwed down to the main frame, by removing the 4 bottom M3 screws and drilling holes into the frame. Then reinstall the screws trough the frame. -> The original screws will be too short, so please replace them with longer ones according to your frame thickness.

Wiring Schematic:




Connection to external equipment:



01: Connection To BEC:

The Hub X8 is compatible to any PL or PC / BEC.

Please connect the special cable here with 2x 4p and 2x 4p. connectors



1st 4p -> To PL or PC / BEC

1st 3p -> Hub X8 power port

2nd 3p -> Hub X8 sensor 1 input

2nd 4p -> PL-xxx sensor board 1

The supply voltage is 4.95-5.05V and the max. current should not exceed 0.5A.

The current draw of the Hub X8 (with active OLED) is 50mA, plus 8x 15mA (current sensors) = 170mA (0.17A)
So even if we connect 2pcs X8 with 16 current sensors, plus a Hub X2 (15mA), we're still below the 0.5A.
 $(2 \times 0.17A) + 0.015A = 0.335A$


02: Sensor Connectors:



Please connect here any of PL-xxx sensors. However, all sensors must be of the same current rating!
If you use less than 8 sensors, then it doesn't matter where you connect the sensors. However, sensor 1 must be always connected, via the 4p cable for voltage measurement.
For more details, please check Pos. (9).

The 7 cables to connect the PL-xxx sensor boards (4p <-> 3p), come together with the Hub X8 (L=200mm)

Only PL-xxx sensors can be used. The Hub X8 is not compatible with HS-xxx-xx sensors!



If all 8 possible sensors are installed, but you want to fly your UAV with only 4 LiPo's, then you can deactivate the unused current sensors, by either disconnecting them from the Hub X8, or installing a switch into the GND wire of the sensor board.

Do not install the switch into the + 5V or I-out cable!
Do not install the switch into the cable of sensor 1!

If the sensor is disconnected, or the GND wire is switched off, then the Hub X8 will deactivate the sensor input during boot up or restart.

03. Reset / Restart:

In case of any alarm (over current or under current), then you can perform a reset, by either re-powering the Hub X8, or press the reset switch for a short time.

If you press the reset switch longer than 2 seconds, then the Hub X8 will restart. This is helpful if you deactivate installed sensors after switching on the system.

It is possible to install an external reset / restart switch (not included), the necessary 5p cable with connector is included.

2x red for external switch + 3x white for alarm relays output.

4: Status LED:

RED = During startup / Any alarm is active and the alarm relays is ON / If the Reset - Restart switch is pressed.
GREEN = After booting up and all connected sensors are initialized / No active alarm

05: Alarm Out:

Pin 3 = P -> The middle contact of the relays.

Pin 4 = NO (normal open)

Pin 5 = NC (normal closed)

Any power LED or buzzer can be connected here, but the max. current should not exceed 1A.

The necessary 5p cable with connector is included. -> 2x red for external switch + 3x white for alarm relays output.

06: External LCD / OLED display:



If the Hub X8 is installed in a place where the display is no more visible, then you can connect here a standard 2x16 LCD display (4-bit data bus), but please do not use any LCD displays with back LED light, as these lights can draw easily more than 200mA and the supplied power from the Power-Cube might be not enough.

You also can install an 2x16 / OLED display. The current draw of these displays is minimal (30mA). Therefore, Internal and External display can be active.

REM: External OLED displays with CFK cover and reset switch might be available soon.

Please check Pos. (7), for how to activate / deactivate the internal and external display.

07: Setup DIP switch:

S1	S2			
OFF	OFF	Internal and external display OFF		
OFF	ON	Internal display ON and External display OFF		
ON	OFF	Internal display OFF and External display ON		
ON	ON	Internal and external display ON		
S3	S4	S5	S6	
ON	OFF	OFF	OFF	PL - 050 Sensors
ON	ON	OFF	OFF	PL - 100 Sensors
ON	ON	ON	OFF	PL - 200 Sensors
ON	ON	ON	ON	PL - 400 Sensors (PL-400 Sensors / release Q2-2024)

08: I2C connector:



Only for maintenance use to read out the log files.

This connector can not be used for flight controllers who only support I2C mower modules. For example, Pixhawk 6x or equivalent.

