

- GM 60 to 80 amp alternator
- Use Loctite® removable threadlocker 242 (blue) on all fasteners. 1.
- Bolt alternator back bracket [A] to alternator front bracket [B] 2. using bolt [D] 1/4-20 x 1-1/4" SHCS. Tighten. (May be preassembled).
- Bolt alternator bracket [A-B] to drivers side head using bolt [E] 3/8-3. 16 x 1" SHCS and bolt [G] 3/8-16 x 2-1/4" SHCS. Tighten.
- 4. Install stainless load washer [K] into counterbore on inside of bracket [B].
- Bolt alternator adjustment arm [C] to backside of alternator top 5. boss using bolt [I] 5/16-18 x 1" BHCS and stainless flat washer [J]. Be sure and hook adjustment arm under alternator lower pivot boss. Tighten.
- Bolt alternator with adjustment arm to bracket [A-B] using bolt [H] 6. 3/8-16 x 2-3/4" SHCS. Do not fully tighten.
- Install bolt [F] 3/8-16 x 1-1/4" SHCS into bracket [A-B]. Do not fully 7. tighten.
- 8. Install alternator belt on rear groove when using 2-groove pulleys. Goodyear: #15495 Gates: #7490XL Belt: 7/16" x 49"
- Apply tension on alternator belt and tighten bolts [F] 3/8-16 x 1-1/4" 9. SHCS and [H] 3/8-16 x 2-3/4" SHCS.

BILL OF MATERIALS			
ITEM	QTY.	DESCRIPTION	SIZE
Α	1	Alternator Back Bracket	
В	1	Alternator Front Bracket	
С	1	Alternator Adjustment Arm	
D	1	1/4"-20 Socket Head Cap Screw	1-1/4"
E	1	3/8"-16 Socket Head Cap Screw	1"
F	1	3/8"-16 Socket Head Cap Screw	1-1/4"
G	1	3/8"-16 Socket Head Cap Screw	2-1/4"
Н	1	3/8"-16 Socket Head Cap Screw	2-3/4"
I	1	5/16"-18 Button Head Cap Screw	1"
J	1	Stainless Flat Washer	9/16" x .060"
К	1	Stainless Load Washer	3/4" x 3/16"