

ComLink TL/TL-NET Owner's Manual

Version 1.6, Aug 2014



Copyright © 2012 BY
Bridge Embedded Systems, Inc
Version 1.5, January 2012

All rights reserved.
Printed in the United States of America.

LTR® is a registered trademark of EF Johnson Corporation
Windows® is a registered trademark of Microsoft Corporation

For Technical Support, please contact:
BridgeCom Systems, Inc.
617 Liberty Road
Smithville, MO 64089
Tel: (816)-532-8451
techsupport@BridgeComSystems.com

TABLE OF CONTENTS


CHAPTER 1: INTRODUCTION	4
WELCOME	4
CHAPTER 2: INSTALLATION	5
CHAPTER 3: CONTROLLER AND SYSTEM CONNECTIVITY	12
CHAPTER 4: VALIDATION AND AIR-TIME	13
CHAPTER 5: REMOTE MANAGEMENT	14
OVERVIEW.....	14
APPENDIX A: TRUNKING CONTROLLER TROUBLESHOOTING.....	15
WARRANTY AND SERVICE	16
FCC STATEMENTS	17

CHAPTER 1: INTRODUCTION

Welcome

Thank you for purchasing the ComLink TL/TL-NET local and wide-area LTR repeater controller.

This Owner's Manual will acquaint you with the features and show you how to program and interface the TL-NET LTR controller to your repeater system. Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, please note that one of the many features of the TL-NET includes upgradable firmware. Firmware upgrades may modify existing features and/or introduce new features not available at the time of this manual's publication. Please read the accompanying documentation with any firmware upgrade for any changes to this manual's content.



Front View of three controllers in 1U chassis



Rear View of three controllers in 1U chassis

As you read this document, here are KEY POINTS To REMEMBER:

In order for the TL-NET LTR controller designated as the Network Master to operate correctly, it must have TL-NET mode enabled when connected to a TL-NET Gateway. However, TL-NET mode must be disabled when programming the controller using the TL Control Manager software. Also, only the Network Master needs to be in TL-NET mode. If more than one controller is used in the system, a second controller can be used to program all the controllers while leaving the network master connected to the TL-NET Gateway. When initializing a controller to a repeater number it must be connected to the PC and have TL-NET mode disabled.

Only one controller CAN BE the SYNC Master for reliable communications between controllers and the PC.

In the event you want to adjust a controller not on the repeater bus and does not have termination jumpers installed, for that controller you'll need to use a CAT-5e Network cable to loop the two repeater bus ports back to itself.

CHAPTER 2: INSTALLATION

Step 1: Repeater Connection


Build a cable to connect the controller to your repeater. The following table indicates the pins for repeater connector J32.

J32 – DSUB9 MALE - Repeater Connector Pin-out

- Pin 1- GND
- Pin 2- COR/COS Input (Active Low) +5V Pull-up
- Pin 3- RX Discriminator In – From Repeater RX
- Pin 4- TX Audio Out – To Repeater TX Audio
- Pin 5- No Connection
- Pin 6- 13.8Volts DC Input
- Pin 7- TX Data Out – To Repeater TX Data
- Pin 8- PTT Out +5V (Active Low)
- Pin 9- PTT Out Open Drain – Active Low – Rev C PCB or later.


Step 2: Program the controller

1. Connect the PC to the connector designated as COMPUTER or J31.
2. If you haven't done so, install the TL-NET Control Manager software. The software is supported on all Windows operating systems WIN 95, WIN XP, Win 7 and 8.
3. Run the TL-NET Control Manager software.
4. Disable TL-NET mode. This is done by selecting TL-NET from the menu list and selecting DISABLE.
5. If the controller has yet to be assigned a repeater number, select INIT CTRL button from the task bar. The snapshot below is what you should see.



Init CTRL Repeater Number and SYNC Status Assignment

6. Select the Repeater Number and SYNC status. The Controller must be programmed to be either MASTER or SLAVE. **NOTE:** For proper stable communications between controllers and the PC, the terminating jumpers (J15-J20) must be installed on at least one controller attached to the repeater bus. It is also necessary that at least one controller be assigned the SYNC Master. However, keep in mind, it's not necessary to have the PC connected to the SYNC master in order to talk to the repeater controller system. Press Close when done.
7. Select the Read System Icon from the task bar. Enter "1234" as the default password. The following screen is seen. Note: Certain settings may be different on your controller.



Controller Settings Tab Sheet

8. Program the settings as required by your system. The following list describes each parameter:
 1. Sync Status – Designates this controller as either MASTER or SLAVE
 2. Area – 0 or 1
 3. TX Data Polarity – Normal or Inverted
 4. RX Data Polarity – Normal or Inverted
 5. System Operator –
 1. Password – protects unauthorized attempts when reading controller from the Control manager software
 2. Remote PIN – DTMF sequence prior to sending Over the AIR programming commands
 3. HOME and IDENT – SYSOP home and ident used when sending Over the Air programming commands.
 6. De-Emphasis – Selects whether internal deemphasis is enabled or disabled.
 7. TL Status – Selects whether the TL-LTR controller is enabled or disabled.
 8. CW Broadcast ID – Enter the channel ident to be sent via Morse code. Also enter how often the channel ident is to be sent.
 9. Timers:

1. Idle Update interval – Duration the controller sends a free repeater telegrams when the controller is not busy.
 2. Fade Timer – Duration the controller will continue to send LTR telegrams after it fails to decode valid LTR telegrams from the active mobile.
 3. TX Timeout – Duration the controller will transmit continuously before keying down.
 4. TX Lead In – How long the controller waits after engaging the repeater PTT before sending LTR telegrams. Provides a wait time to ensure repeater is on frequency and can send full LTR telegrams without missing preamble of the LTR telegram. Check your repeaters requirements.
10. Conventional CSQ/CTCSS – Select the RX and TX tone and Ident Mask Number.
11. Valid Repeater Array: This check box array tells this controller what other controllers in the system it has permission to trunk calls to. It might be that even though another controller is in the system, you may not want this particular controller to trunk calls to it. This feature is good for mixing networked and non-networked repeaters. You may not want a networked repeater trunking calls off to non-networked channels. Also, this feature is nice when you are adding repeater controllers to the site and have yet to upgrade the mobiles in the field.
12. Network Options:
1. Network Master – Select this checkbox if this controller is to function as the network master. The network master will be the controller connected to the TL-NET Gateway's serial port. Check the only the one controller connected to the TL-NET Gateway.
 2. Network Array – This is a network master feature only. Check each box of all the TL-NET controllers connected to the TL-NET Gateway's audio ports. These will be your network repeaters/controllers.
13. TX Audio Settings: Press the UPDATE CONTROLLER after adjustment is made.
1. Course – adjusts the TX Audio in 2.5 dB step increments.
 2. Fine – adjust the TX Audio in 0.5 dB step increments.
 3. CW ID – adjust the broadcast ID tone deviation.
 4. TX Data – adjusts the TX LTR Data in 0.5 dB step increments.
14. Operating Mode – Sets mode of operation as either Repeater or Base
15. COS (Carrier Operated Switch) Polarity Output – Active Hi or Active LO
16. UPDATE CONTROLLER – Once changes are made, press this button to update the controllers.

STEP 3: ALIGN THE CONTROLLER


For the next steps, reference the PCB layout Figure (see Figure on next page). You will need to remove the unit's cover to access the PCB.

There can be two different sources for the receive audio. One is the local audio coming from the repeater's receiver and the other is the Gateway connecting the audio from the other sites. **The local audio from the repeater's receiver must be tuned first.**


Adjust local receive audio first:

1. Program the service monitor for the repeater RX frequency. Inject a full-quieting 1kHz tone deviating at 3.0 kHz (wide – 25kHz) 2.0 kHz (narrow – 12.5 kHz). Place voltmeter on DC and put voltmeter probe on TP1. Adjust P1 until TP1 reads 2.5 Volts.

2. ADJUST RX AUDIO GAIN: P4 adjust the RX Audio Gain from 0 to 1. The purpose of this adjustment is to reduce the gain in the event the receiver supplies too much signal for the controller. In most cases, this POT should be set full CW for unity gain (1). If more gain is needed, the internal audio signal processor will allow for increasing the signal. If the incoming signal is large, use P4 to adjust the signal measured at TP4 to 1V P-P.
3. RX DATA AC GAIN: Remove the 1 kHz tone from the service monitor. Program the service monitor to generate a full-quieting 100 Hz tone or LTR Data deviating at 1kHz (wide – 25 kHz) or 800 Hz (narrow – 12.5 kHz). Place voltmeter on AC and probe on TP2. Adjust P2 until 1.5-1.8 Volts P-P is achieved. See plot of Received LTR Data as viewed on TP2.



4. RX DATA DC Adjust: Place voltmeter on DC. With probe remaining on TP2, Adjust P1 until ~ 2.5Volts is achieved. Then place probe on TP6 and confirm the DC voltage is between 2.0 and 3.0 volts



PCB Layout


5. Gateway audio – Each gateway supports adjustment of the audio volume to/from other sites. To adjust the audio for a specific channel, you will need to log on to the gateway’s web site and adjust the RECORD volume.

Adjust Local TX audio:

AC or DC coupling to repeater: J1 and J2 are three terminal jumpers that control the signal coupling to the transmitter. J1 sets the audio coupling to the transmitter. When the audio is AC coupled, a 10-uF capacitor is placed in series with the audio. When the audio is DC coupled it is biased to 2.5Volts. To AC couple the audio to the repeater, place the jumper on the J1’s two pins towards the repeater connector (J32). J2 sets the data coupling to the transmitter. When the LTR data is AC coupled, a 220-uF capacitor is placed in series with the LTR data. When the LTR data is DC coupled it is biased to 2.5Volts. To AC couple the TX Data to the repeater, place the jumper on J1’s two pins away from the repeater connector (J32).

- J1 – AC or DC couple TX Audio To Transmitter
- J2 – AC or DC couple TX Data To Transmitter

1. Using the TL Control Manager software press the TL-Setup button. The following screen shot will be displayed.



TL CONTROLLER SETUP FORM

2. TX DATA ADJUST - With the transmitter connected to the service monitor and on the proper TX frequency, press the START button under TX Data Adjust. Increase or decrease the TX Data level until 1 kHz (wide) or 800Hz (Narrow) is achieved. Press STOP. In the event data cannot go low enough, place shorting block across pins 2 and 3 of J4. Then increase Data level accordingly. Pin1 is towards front of PCB.
3. TX AUDIO ADJUST – Make sure the audio source is Local. With the service monitor in duplex mode, inject a 1 kHz tone deviating at 3.0 kHz (wide) or 2.0 kHz (narrow). Press the START button. Adjust the audio setting until 2.0 kHz (wide) or 1.5 kHz (narrow) achieved on the transmit frequency. Press STOP.
4. CWID Adjust – Press START. Increase/Decrease the setting until 2.5 kHz (wide) or 1.5 kHz (narrow) deviation. Press STOP.
5. AUDIO to Gateway – With the audio source on LOCAL, press the START button under TX Audio Adjust. With the service monitor, inject a 1 kHz tone deviating at 3 kHz (wide) or 2 kHz (narrow). Using a voltmeter on the AC setting, place the probe on TP3. Adjust P3 until 200mV is achieved. Press STOP.
6. AUDIO From Gateway – All other controllers at other sites should be sending audio to their respective gateways at 200mV. Therefore, it is recommended the audio from the gateway to the controller be adjusted from the gateway’s web server.

Alignment is now complete. Using a radio programmed for the controller, attempt to handshake with the repeater. If handshake attempts are unsuccessful, check the following symptoms and possible solutions:

Repeater fails to respond to handshake attempts:

- Make sure you have the selected channel programmed for COS output enabled active low.
- Make sure controller and radio’s Repeater Number and Area Bit are the same.
- Also, make sure the controller is aligned to ‘see’ the data. Inspect TP2.
- Make sure the controller is ‘SYNCED’

Radios won't complete handshake:

- Make sure TX Data polarity is correct for radios in the system.
- Make sure TX Data levels are adequate for the respective channel spacing.

Once a successful handshake is complete, check to confirm the Local and Network audio levels are all correct to your liking. **REMEMBER: If a controller is the Network Master it must be in TL-NET mode for the system to properly communicate with other sites. The Network Master must be connected to the Gateway's serial port.**

In summary, here is a list of the adjustment pots (P) and test points (TP)

Potentiometers:	Description
P1	RX DC Data Adjust (0-5Volts DC)
P2	RX Data Level Adjust (0-20)
P3	Audio to Gateway Level Adjust (0-10)
P4	RX Audio Level Adjust (0-1)


Test POINTS:	Description
TP1:	RX Data/Tone AC and DC Level
TP2	RX Data/Tone AC gain
TP3	Audio to Gateway
TP4	Audio level from Receiver
TP5	Audio from Gateway
TP6	Dynamic DC RX Data Adjust

JUMPERS	Description
J1	AC or DC coupling selector for Voice
J2	AC or DC coupling selector for DATA
J3	PTT Test Point - Active High
J4	TX Data Attenuator - Rev C PCB and later
J6 & J12	REPEATER BUS
J15-J20	Bus Terminator shorting block header
J21	AUDIO connector to TL-NET Gateway
J31	COMPUTER Connection
J32	REPEATER Connection

Chapter 3: Controller and System Connectivity

In a trunking system the TL controllers communicate to each other through the repeater bus. The repeater bus uses the RS-485 standard to communicate. RS-485 requires terminating resistors. Terminating resistors reduce the transmission line effects caused by the signals propagating over long distances. To enable the terminating resistors, place shorting blocks across Jumpers J15-J20 on at least one controller in the system. Daisy-chain the controllers using straight-through cat-5e networking cable or RJ-11 8 conductor telephone cable. It's advisable to keep the cabling between controllers as short as possible. See system example below.

REMEMBER: Jumpers must be installed on the ends of the bus in the system. For the system example below, jumpers would be placed on controller 1 and controller 16. For proper communication between PC and the controller, the controller must have jumpers installed, be in a system with a controller that has jumpers installed, or have a CAT5e network cable looped back to both repeater bus connectors.




SYSTEM EXAMPLE

Each controller's audio port is connected to a Gateway audio port. In the above example, the audio from Repeater 1 would connect to Gateway audio port 1, Repeater 4 to Gateway audio port 2, etc. The controller designated as the network master is to be connected to the Gateway's RS-232 COM port. In the above graphic, Repeater 1's controller is the network master.

Chapter 4: Validation and Air-Time

Each controller's group idents can be validated/invalidated from three different sources: The TL Control Manager software, remotely through DTMF key sequences, and through the TL-NET Gateway from the TL-NET Gateway's web server. This section deals with managing group idents from the TL Control Manager software.

Place the cursor in the Treeview on the left of the form. Right-click the mouse to bring up the pop-up menu or press F2. Depending on whether a controller node or group idents node is selected will indicate which options are available. While on a controller node, you have the option of validating/invalidating all idents for this channel. When on a group idents node, you have the option of validating or invalidating the group idents. It is not possible to invalidate the SYSOP Home-Ident used for remote programming. In addition, you can view that particular group idents's air time and reset it. **NOTE:** When validating/invalidating idents, you must perform this option when all the controllers are attached to the repeater bus. This will ensure all controllers in the system are made aware of the validation status. After performing the operation, you can read the system to confirm the results. The TL LTR controller validates a call as the handshake attempt is made. This means the idents is checked the moment a radio attempts to access the controller. If the idents is invalid, no access is granted.



TL Control Manager with TreeView pop-up menu options

CHAPTER 5: REMOTE MANAGEMENT

Overview

The TL-NET LTR controller supports the remote management of IDENTs and repeater controllers. IDENTs can be validated and invalidated over the air. Repeater Controllers can be validated/invalidated over the air. You can also reset a particular controller over the air. You must set up a specific HOME-ID combination for system operator usage in the TL Control Manager Software. All controllers in the system must be programmed with the same HOME-ID combination, and 4-digit PIN. As long as all controllers in the system have the same 4-digit PIN and SYSOP HOME-IDENT, it does not matter what controller you handshake with.

- **VALIDATING/INVALIDATING IDENT:** Upon successful handshake with the system using the system-operator HOME-ID, the command sequence is as follows: First 4 digits are the PIN followed by two digit HOME, followed by three digit IDENT, followed by a 1 for Validate or 0 for Invalidate. A '#' is then pressed to cause the task to execute:

For Example: You've chosen 2135 as the PIN and your selected HOME-ID is 05-002. You want to enable a new customer by given them ID 140 and HOME them on repeater 12. Once handshake is complete using 05-002, key in the following:

```
[2][1][3][5] [1][2] [1][4][0] [1] [#]
```

The HOME-ID should now be validated. Verify by handshaking with the system.

To invalidate HOME-ID 12-140, upon successful handshake, key in the following:

```
[2][1][3][5] [1][2] [1][4][0] [0] [#]
```

Confirm by observing the radio is now unable to handshake with the system.

- **VALIDATE/INVALIDATE ALL IDENTs:** You can validate or invalidate all ident's for a particular controller. For Example, to invalidate all ident's on controller 12, key in the following:

```
[2][1][3][5] [1][2] [0][0][0] [4] [#]
```

To validate all ident's of controller 12:

```
[2][1][3][5] [1][2] [0][0][0] [5] [#]
```

- **VALIDATING/INVALIDATING REPEATERS - VALID REPEATER ARRAY:** The CS-540TL supports a feature called: valid repeater array. This feature allows you to set up a controller to only trunk calls off to specific 'valid' repeaters. This feature comes in handy for the following reasons: Lets say you have just added a fourth channel to your trunking system and you have yet to update all the radios using this system. During operation it might be these radio's home channel will trunk them off to this new fourth channel. Unfortunately, the radios don't know about this new channel and will this prevent the call indicating a busy system. To prevent this from happening, the home channel can exclude this new channel by making it invalid. Once you've upgraded the fleet, you can 'validate' this new channel by permitting the controllers to trunk to it.

For example, you've added repeater 15 to the system. Repeater 5 doesn't have repeater 15 in its valid repeater array and so won't trunk calls to it. To make repeater 5 aware of repeater 12, enter the following after successful handshake with the system:

```
[2][1][3][5] [0][5] [0][1][2] [2] [#]
```

To take repeater 12 out of 5's valid repeater array, key in the following:

```
[2][1][3][5] [0][5] [0][1][2] [3] [#]
```

Bear in mind, the repeater to be validated/invalidated is a three-digit field.

- **RESET A PARTICULAR CONTROLLER:** For example, to reset controller 12

```
[2][1][3][5] [1][2] [0][0][0] [6] [#]
```

Appendix A: Trunking Controller Troubleshooting

1. Repeater fails to respond to handshake attempts:

- Make sure you have the selected channel programmed for COS output enabled active low.
- Make sure controller and radio's Repeater Number and Area Bit are the same.
- Also, make sure the controller is aligned to 'see' the data. Inspect TP2.

2. Radios won't complete handshake:

- Make sure TX Data polarity is correct for radios in the system.
- Make sure TX Data levels are adequate.

3. My PC is not communicating with the controller:

- Make sure you have first assigned a repeater number to the controller.
- Make sure at least one controller in the system has repeater bus terminating resistors installed.
- Make sure the controller is not in TL-NET mode.
- Make sure the system has SYNC.

4. Controller won't SYNC:

- Make sure at least one controller in the system is programmed as the MASTER.
- Make sure controller TL-STATUS is not in BYPASS mode.
- Check Cat5e cable quality.
- Check to see if at least one controller in system has the repeater bus resistor terminating jumpers installed.

5. Home channel is not trunking calls off to the GOTO channels:

- Make sure the home channel has the GOTO channels checked in the valid repeater array. Also, make sure the proper controller is has its check box checked.

6. Controller is not Powering up:

- Check cable to repeater or power source.
- Open unit and check internal fuse. If blown, replace with 1.5A fuse.
- Check reverse polarity protection Diode D6.

WARRANTY AND SERVICE

Limited Warranty

This product is warranted by BridgeCom Systems, Inc. to be free of defects in materials and workmanship for a period of **two years** from the date of purchase. If a defective part causes this product to operate improperly during the two-year warranty period, we will service it to the original owner free of charge if shipped to BridgeCom Systems at the owner's expense. This warranty does not apply to any parts damaged due to improper use or violation of instructions. It does not extend to damage incurred by misuse or abuse, unauthorized modifications, natural causes such as lightning, fire, floods, and other such catastrophes; nor to damage caused by environmental extremes, such as power surges and/or transients, theft, or accidents.

All warranties must be performed at BridgeCom Systems, Inc. No credit will be given for unauthorized repair work attempted by the customer.

BridgeCom Systems, Inc. will repair or replace the equipment and return to the customer freight pre-paid, within the continental United States. Equipment found not to be defective will be returned at the customer's expense, and it will include the cost to ship, test, and return the equipment.

Equipment returned for repair must have a return merchandise authorization (RMA) number. To obtain an RMA contact our Technical Support Department at (816)-532-8451 or email techsupport@BridgeComSystems.com. All returned equipment must have the RMA number listed on the outside of the shipping container.

Ship all returns to BridgeCom Systems, Inc. 617 Liberty Rd. Smithville, MO 64089 Attn:Repair

Out of warranty repairs and service charges are billed at the current hourly rate plus parts.

PRICES ARE SUBJECT TO CHANGE WITHOUT NOTICE.

This document contains information proprietary to Bridge Embedded Systems, Inc. and BridgeCom Systems, Inc. Its contents may not be reproduced, in whole or in part, without express written permission from either Bridge Embedded Systems, Inc. or BridgeCom Systems, Inc.. The information is provided "AS IS" without warranty of any kind, either expressed or implied. Bridge Embedded Systems, Inc. or BridgeCom Systems, Inc. does not assume any liability for damages. Technical information and specifications in this document are subject to change without notice.

FCC Statements

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.