



Ventilation controller

Version 116

Section 1 – Electrician’s Guide for The CAPTAIN System

Thank you for purchasing the CAPTAIN System. It is designed for easy installation and operation. The system is designed to control vents, heaters, and fans

Main Features

The CAPTAIN System is designed for the unique challenges of greenhouse facilities.

- Temperature DIFs with manual overrides
- Wind speed sensor option
- Humidity option
- Battery backed Clock
- 6 or 10 relay outputs
- Adjustable temperature settings
- Touch screen display
- Manual overrides

- Installing the CAPTAIN

Consider the following before installing the Captain:


- Protect the enclosure from moisture—mount it in a secure and dry place.
- Important: Only drill holes in the bottom of the enclosures.
- Condensation runs downhill. Drilling holes into the top or upper sides of the enclosure voids the warranty.

- Wiring the Temperature Sensor

Place the temperature sensor in the middle of the building or in a location that represents the building's average temperature.

- It is important to not allow sensors to come into contact with direct sunlight

Connect the temperature sensor to sensor #1 terminals. Polarity is not important.




Extending the temperature sensor:

1. Run 18-22 AWG wire (twisted or shielded wire if possible) from the sensor to the Captain. Keep the sensor wire away from high voltage wire by at least 1 foot. Specifically, keep it away from the VFD output wires.
2. Solder or use gel-filled crimps to connect your wires to the temperature sensor.
Pro – a Probe can be connected to Sensor #4 if jumper #1 is put to position T

Connecting wind meter

The windmeter is used to close vents in high wind conditions.



Captain wind meter connections:

The red wire connects to 24v+

The white wire connects to terminal #99

The black wire connects to terminal #98

Mounting the windmeter

Locate the sensor outside.

Have it exposed to the wind from all directions.

Mount it upright. .. stem down, rotating cups on the top.



Connecting a rain sensor



You can connect a rain sensor to the system. The rain sensor closes select vent motors when it's raining. The system supports 1 rain sensor.

If you connected a rain sensor the controller needs to know it. Setup parameters P40 & P41 assign the sensor to the vent motors.

Installing the rain sensor

When you are installing the wires, keep the rain sensor cord 6 inches away from high voltage wires.

The vent motor's close signal is activated when the sensor is wetted. The position of the sensor versus the sky dictates the response.




Rain sensor #1

The wire colors are marked on the board and match the sensor's cord. Wire by connecting the colors.

Rain sensitivity

The rain sensitivity can be adjusted. However, it does require that you take the rain sensor apart. Take the 4 screws out that hold the sensor together to access the switches inside. Adjust the switches as noted below. Be careful to keep the gasket in place when reassembling.

Dip switch table	
8	-must be off
7	-must be off
6	-must be off
5	-must ON
4	-must be off
3	- off-
2	-sensitivity -default ON
1	-sensitivity default off



Sensitivity settings:

The sensor has 4 sensitivity settings. Dip switches 1&2 set the rain detect threshold..

First drop detection:

1 & 2 off -very sensitive will be on at first drop of rain. Our experience is this might close a vents too quickly. Potential exists for False alarms.

.1 inch per hour setting

1 on, 2 off . Sensitive-about right for some buildings.

.25 inch per hour setting

1 off, 2 on – Moderate response. This works well for most general applications.

1 inch per hour setting

1&2 on – This will have everything soaked before closing

15 minute delay after it stopped raining:

Normally the vent needs to reopen after it stopped raining.

If you want it to stay closed for a while after the rain, Set dip switch 3 on.

Normally we want #3 off ,so vents re- open sooner..

Connecting a humidity sensor

The humidity sensor allows you to monitor and control the humidity. If humidity is too high a vent can open or a fan can start.


If you connect a humidity sensor, it needs to be activated. Activate it by selecting humidity for Setup parameter P10

Location of the humidity sensor

Mount in a central location. Keep the sensor away from heaters or you will get a low reading when the heater is running.

Installing the humidity sensor

Route humidity sensor wires 6 inches away from high voltage wires.



To use a Humidity sensor:

Connections:


The blue wire connects to Power 24v+

Powering the Captain

AC versions come with a power cord. Plug it into a 120v outlet. Requires 120V 5amp

DC versions are either 12 or 24vdc. Check the voltage labeled on your unit.

Controller relay outputs



There are 8 output relays on the Captain8

The first 6 are replaceable and have NO & NC contacts. Max of 0.3hp or 7.5 amps whichever is less. They also have a green mechanical test button . This is used to manually activate the contacts.


The last pair 7&8, are smaller, only NO contact and not field replaceable. Max of 3 amps. No motor loads.

Each button on the screen and output terminals are associated the corresponding relays above.

Please search YouTube for AutoVent Captain for videos to better explain the process.

Motor connector bus bars

The motor connector bars are for low voltage motors only. By default the Captain8 includes busbars for the first 6 relays / 3 vents. If you want to repurpose any of the 6,5,4,3, 2 or 1 outputs for another app (remapping), the busbars must be removed from the remapped outputs. This is done by removing the busbar entirely, snipping with a pliers and reinstalling it on the correct outputs.



Bus can be reduced or removed to allow fans, heaters, or lights to be connected instead of vent motors. To shorten them, remove the connector completely then use pliers to snip it to length.


With the bus bar removed, the outputs become dry contact.



Connecting fans


Fans can be controlled but you need contactors to switch the fans' electricity. Outputs 7&8 are dry contact.

AutoVent contactor boxes are available for easy wiring.



Connecting 2 vents, 1 cooling, 2 heat.


Relays 6 or less can be remapped from their default of low voltage vents. If remapping #6 or less, the aluminum busbar must be shortened.



Grounds not shown.
Always wire per NEC or authority having jurisdiction

Connect to heaters


Several zones of heaters can be connected. Use output relays 7&8 for heaters or fans. Connect the heater's signal wires can be wired to the controller as shown below.



Connecting DC motors

If the controller has a PS suffix on the part number, it includes a 24v motor supply. PS models are prewired to run several DC vents motors. Connect motors directly to the board as shown. (Connector bars installed).

Pro tip! If the vent motor rotates in the wrong direction, swap the vent motor's blue & brown wires.



Configuration needed to match this diagram:

P0 - Number of vents =3


P1 - Curtain starting relay =1

P2 - Number of fans =0

P4 - Number of heaters =0


Vent motor circuit breakers

There are several vent motor breakers. Each of them protects a motor. If a motor's amps go too high, the center tab trips out. Press tab in to reset.



Overview of the Controller screen

The screen shows you what is happening. You can see the temperature and the status of the relays.



Press on the temperature to go to your settings

Press the bottom row of buttons to manually overrides

Overrides




The overrides allow you to force an output. In Auto, it will operate automatically. Selecting Off or Forced allows you to avoid the control system. The app's temperature is shown. All contributing probes are highlighted.

To exit press the blank space on the sides.


Temperature DIFs

Temperature DIFs allow you to change the setpoint of the heating/cooling equipment thought the day. DIFs are used to drop the humidity in the mornings or trap heat late in the day.

The DIF status is displayed below. The screen will show you the status and if you left it forced on. Press on the clock to change the DIF settings.




DIF override buttons allow you to manually override any clock settings.



Parameters

There are parameters that you can change. The parameters are labeled P1, P2 These parameters are the temperature setpoints and values you can adjust.



Vent Parameters

ID	Description	Default	Min	Max
P101- P110	Open temperature for Vent#1 – Vent#10	60°	1°	99°
P111- P120	Vent #1 – Vent#10 's DIF1 temperature	61°	1°	99°
P121- P130	Vent#1 – Vent#10 's DIF2 temperature	62°		
P131- P140	Vent#1 – Vent#10 's run seconds. How many seconds the vent will run per interval.	15		
P141- P150	Vent#1 – Vent#10, pause minutes. The time the vent waits between intervals	50		
P151- P160	Vent#1 – Vent#10 ventilation temperature gap. The difference between open and shut temperature	50		
P170	Vent Motor's max humidity, Humidity at which the vent will open to dry things	95		
P171	How many seconds the vent will open for the humidity event	10		
P172	Humidity limits temperature. Humidity will be disregarded if it's too cold	32		
P173	Which Vent is used for humidity?			

ID	Description	Default	Min	Max
P181- P190	Vent#1 – Vent#10 sequence. If vent should wait on another vent to close first from rain or high wind.	0		
P191- P200	Vent#1 – Vent#10 How long does it take for the vent to shut. Closing seconds for rain or high wind events.	100		
P201	High wind Vents- which Vents should shut from wind	0		
P202	High wind MPH	53		
P203	Wind override clear MPH	50		
P500	DIF1 start time. When DIF1 starts.	0		
P501	DIF1 end time. When DIF1 ends	0		
P502	DIF1 “2 nd ” start time. When DIF1 “2 nd ” starts.	0		
P503	DIF1 “2 nd ” end time. When DIF1”2 nd ” ends.	0		
P504	Dif2 on time. When Dif2 starts.	0		
P505	Dif2 off time. When DIF2 ends.	0		
P506	DIF2 “2 nd ” start time. When DIF2 “2 nd ” starts.	0		
P507	DIF2 “2 nd ” end time. When DIF2”2 nd ” ends.	0		

Fan temperature Parameters

The temperature parameters control the starting temperature.

The fans are used for cooling. They will turn on above the temperature setpoint.

If humidity is connected, fan # 1 can be set to clear out the high humidity.

ID	Description	Default	Min	Max
P301- P310	Start temperature for Fan#1 – Fan#10	0°	1°	99°
P311- P320	Fan#1 – Fan#10 ‘s DIF1 start temperature	0°		
P321- P330	Fan#1 – Fan#10 ‘s DIF2 start temperature	70°	1	99°
P331	Fan temperature Gap. Difference between on and off	0.3		
P341	Fan Max MPH- If a wind sensor is connected, MPH at which fans will stop	0		
P342	MPH dead span	0		
P350	Fan #1 Max humidity. If a humidity sensor is installed, when fan #1 will start to dry out the building. Set to 101% to disable humidity function)	99%RH		

ID	Description	Default	Min	Max
P351	Fan humidity hysteresis –	5%		101
P352	Fan humidity low-temperature limit	32°		
P354	Fan assigned to humidity. If Humidity is high these fans will activate. Green-fan activated	none	none	8
P361- P370	Fan#1 – Fan#10 's high-temperature limit	0		

Variable fan Parameters

ID	Description	Default	Min	Max
P401	Low-speed temperature for variable fans	50°	1°	99°
P402	High-speed temperature for variable fans	85°		
P403	Low speed for variable fans	20		
P404	Manual speed for variable fans	11	1	99°

Heater Parameters

The parameters control the starting temperature. The heaters can be controlled by the DIF function.

ID	Description	Default	Min	Max
P601- P610	Heater 1 – Heater 10 's setpoint°	60°	1°	100°
P611- P620	Heater 1 – Heater 10 's DIF1 setpoint°	61°	1	100°
P621- P630	Heater 1 – Heater 10 's DIF2 setpoint°	62°	1	100°
P631	Heater Hysteresis	2.0°		

Dehumidifier Parameters

ID	Description	Default	Min	Max
P440	Dehumidifier start temperature	60°	1°	100°
P441	Dehumidifier hysteresis	61°	1	100°

Light Dep Parameters

The parameters control the light Deprivation settings

The light DEP logic allows you to close shades and vents when DEP is activated. Afterward, the vents will wait 2 minutes in the reopen sequence.

ID	Description	Default	Min	Max
P530	Light Dep on Time	5:00	0:00	23:59
P531	Light Dep off time	14:00	0:00	
P532	Light Dep 2 nd on time	0:00	0:00	
P533	Light Dep 2 nd off time	0:00	0:00	

Configuration parameters related to Light DEP.

Light DEP /shades only move when the shade time has elapsed. If the vents are set to respond with the light DEP, they will close as well.

ID	Description	Default	Min	Max
P8	Light DEP enabled?	No	No	Yes
P50	Light DEP motor activation minutes,	150	1	20
P51- P59	Is vent #1 – vent #9 affected by Light DEP, (Does it need to close so light DEP can close)	No	No	

Grow Light Parameters

The parameters control the grow light settings

ID	Description	Default	Min	Max
P560	Grow Light on Time	5:00	0:00	23:59
P561	Grow Light off time	14:00	0:00	
P562	Grow Light 2 nd on time	0:00	0:00	
P563	Grow Light 2 nd off time	0:00	0:00	

Sensor Share- Developer feature as of 1/20/22

Sensor sharing is a when multiple Captain controllers use the Master’s wind and rain sensors. This is allows you to have multiple houses operating without putting weather sensors on each house.

Master configuration:


Set P38 to 1. This will cause the master to talk once per second with it’s data. You still must enable wind sensor P29 if you want to transmit the wind. Rain status is always transmitted.

Slave configuration:

Set P38 to 2. This will cause the slave to listen. You still must enable wind sensor P29 if you want to hear the wind. Rain status is always heard if its listening.

Controller connections

Connect radios as shown. The controllers talk via radios once per second. The TX and RX lights will blink accordingly.



Connections

Controller	Radio
B -----brown----	3
A ----- white ---	4
+V ----- red -----	2
0v ---- black -----	1

Diagnostics

PWR led needs to be on all the time
RX is when radio hears something
TX is when it talks.

If a slave never hears anything, check if
Master TX light comes on once per
seconds

Wireless channels

The radio has a channel and power level selector.

Channel selection

Dip switches 1 thru 4 sets which channel you are on. The default is 0, which is all switches off. But if you have more than 1 system within range, select an alternate channel for the new system.

Push a dipswitch to the ON position to select any of the first 4 channels.

If 4 channels are not enough, any combination of on/off switches is unique. Just use the same combination across the fans you want in the system. There is a maximum of 16 combinations.

Boost

The boost switch increases the radio power. Don't use boost unless it is required for consistent communication. Boosted power increases the chances of interference with other devices. Boosted power may reduce the total possible life of the radio. The only time you would need the power boosted is if a unit seems to be out of range. Range should be approx 800ft line of sight. Metal siding or screens will block the signal.



Slave connectivity indicator

Red “!!!” means it’s a slave and no messages were heard in the last 3 seconds

“TX” means it’s the master.

“.:|” Mean its receiving messages



Setup configurations

The setup allows you to change which apps are used within the controller.

Changing the apps is called remapping.

Remapping is done withing the setup menu and is an advanced function.

Search Youtube for AutoVent LLC Captain for videos on DIY remapping.

ID	Description	Default	Min	Max
P0	Number of vents	2	0	5
P1	Vent Starting Relay	1	0	1
P2	Number of fans in the systems	1	0	6
P3	Fan Starting Relay	5	0	10
P4	Number of heaters	2		9
P5	Heater Starting Relay	8		9
P6	Number of Grow lights	0	1	10
P7	Grow lights Starting Relay	25		10
P8	Number of light DEP circuits	0		1
P9	DEP Starting Relay	0		
P10	Dehumidifier output	0	0	10
P15	Is 2 nd Temperature sensor enabled	0		
P16	Is the Humidity sensor enabled	0		
P24	Fahrenheit or Celsius	F		
P25	Is DIF enabled 0=no 1= 1 DIF 2= 2 DIFs	0		
P26	Is HVLS enabled 0-10v enabled	0		
P27	Wind response time	3		
P28	Anemometer calibration	25		2
P29	Windmeter enabled	0		
P30	Revert controller to defaults	3	1	5
P38	Direct Share wind& rain. 0=no, 1= Master 2=Recipient	0	0	2
P39	Is Voltage Monitor enabled (solar)0=no 1=yes	0		
P41-P49	Vent #1 – Vent #9 rain sensor uses input # You select which input a vents rain sensor is connected to.	0		
P60	Fan high-temperature shutoff enabled?	0=no		1=yes
P61-P70	Turn fan 1 – fan 10 input off	0		
P71-P80	Per vent, which Temperature probes the vents use. If you want to average. Selecting none uses probe 1	0		
P81-90	Per heater, probes used – see above	0		

ID	Description	Default	Min	Max
P91-99	Per fan, probes used – see above	0		

Specifications

Size of enclosure	7" x10"x6"
Input voltage	120VAC
Output	(6) NO/NC relays. 7.5 amps max 120v motor .25 hp max (2) NO 3 amp outputs. Not rated for use with motors.
Temperature sensor	The 3-foot cord can be extended to 100 ft.
Warranty	1 year