

Note: A 15" STEEL RIM WITH A GOOD TIRE MUST BE USED TO CALIBRATE

1. A 15" STEEL RIM WITH A GOOD TIRE MUST BE USED TO CALIBRATE
2. ENTER PARAMETERS
3. PRESS THE HOUSE BUTTON
4. PRESS THE DIS + BUTTON (SCREEN WILL SAY "SET" ON THE LEFT AND "UP" ON THE RIGHT)
5. PRESS THE HOUSE BUTTON (THE SCREEN WILL SAY "IN" ON THE LEFT AND "TES" ON THE RIGHT)
6. PRESS THE HOUSE BUTTON (THE SCREEN WILL SAY "POS" ON THE LEFT AND "###" ON THE RIGHT)
7. MANUALLY ROLL THE TIRE UNTIL YOU GET TO 110 ON THE RIGHT, HOLD IT AND HIT THE PEOPLE BUTTON
8. MANUALLY ROLL THE TIRE UNTIL YOU GET TO 120 ON THE RIGHT, HOLD IT AND HIT THE PEOPLE BUTTON
9. SCREEN WILL SAY "ADD" ON THE LEFT AND "0.00" ON THE RIGHT
10. PRESS START TO SPIN THE TIRE
11. WHEN THE TIRE STOPS IT WILL SAY "ADD" ON THE LEFT AND "3.50" ON THE RIGHT
12. LINE UP THE INDICATOR LIGHTS AND ADD THE WEIGHT TO OUTSIDE
13. PRESS START
14. WHEN THE TIRE STOPS IT WILL SAY "3.50" ON THE LEFT AND "ADD" ON THE RIGHT
15. TAKE THE WEIGHT OFF THE OUTSIDE, LINE UP THE INDICATOR LIGHTS AND PUT IT ON THE INSIDE
16. PRESS START
17. WHEN IT STOPS SPINNING IT WILL SAY "SAV" ON THE LEFT AND "DAT" ON THE RIGHT
18. BALANCER IS CALIBRATED

Note: We reference the button key that has the shape of the House on it as the "Confirm" Button

1. Press confirm button
2. Press DIS/+ button
3. Display should read "Set / Up"
4. Press confirm twice
5. Rotate main shaft so that outer window reads number 111
6. Press "C" button
7. Rotate until outer window reads 55
8. Press C button
9. Rotate until outer window reads 111
10. Press C button
11. Display should read "COD / SET"
12. Press confirm
13. Display should read 46 - 48 in the inner window, number in outer window is irrelevant
14. Press confirm
15. Display should read "B-A / XXX" (The number in the outer window is the distance to the edge of the shaft flange when measuring with the pull out scale.)
16. Press confirm
17. Display should read "EL1 / XXX" (The number in the outer window is the tolerance that you can set. We recommend it set for 007)
18. Press confirm
19. Display should read "TUR / OFF"
20. Press confirm
21. Display will read "SAV / FAC" and the machine will beep 3 times. You are done.