

SOUTHERN CROSSBOW



REBEL 350

USER MANUAL
SC73003

WARNING:
Before operating the crossbow read and understand the safety procedures outlined in the manual. Hands and fingers must remain on the fore-grip and below the flight deck to prevent injury!

WHO WE ARE

Southern Crossbow is built on the idea of integrating age-old American resourcefulness and perseverance with modern equipment. These one-of-a-kind, tactical crossbows are different than the typical genre of the traditional crossbow market. With a matte black finish instead of a camouflage print, Southern Crossbows incorporate the style and customizable traits of a tactical weapon's platform with an innovative crossbow structure.

Southern Crossbows are equipped with a state-of-the-art, customizable AR platform, allowing users to mount flashlights, lasers, night vision riflescopes or any other tactical accessory that can be applied to an AR platform. Along with collapsible stocks, swinging stocks, and ergonomic grips, Southern Crossbow offers a modular crossbow system users can customize to their needs. The crossbows include arrows, a scope and a detachable quiver, everything needed for an ultimate crossbow experience.



**ENGINEERED IN TEXAS
MADE FOR ALL**

WWW.SOUTHERNCROSSBOW.COM

REBEL 350

Southern Crossbow was created to integrate the features of a tactical weapons platform with the modern compound crossbow. The Southern Crossbow Rebel 350's compound levering system and quiet cams make the 155lb draw weight and 350 fps arrow speed sure to turn heads on the range or in the field. The composite, ultra-stiff, split limb design offers exceptional power and durability. The Rebel 350 has an adjustable vertical grip, allowing the shooter better stability and accuracy. The Rebel 350's stock is modeled similar to that of a tactical weapon's system helping shooters easily transition from gun to bow without a substantial adjustment period; it is a composite stock with a rubber grip finish. The Rebel 350 comes packaged with: a 4x32 crossbow scope, a foot stirrup, four field tip arrows, a quick detach quiver, a sling, string wax and safety glasses. It has everything the shooter needs, right out of the box, to pick up and start shooting in minutes. Targets and prey not included.

WARNING! READ FIRST!

To prevent injury to yourself and others or damage to the crossbow, read the entirety of the manual and its safety and operating instructions before assembling, cocking or using the crossbow.

TABLE OF CONTENTS

Safety Instructions and Proper Handling.....	2-5
Specification and Features.....	6-7
Assembly.....	8-11
Accessory mounting.....	11-12
Installing the scope.....	12-13
Cocking and Loading.....	14-15
Shooting and Unloading.....	16
Recommended Arrows.....	17
Sighting.....	17-18
String specification.....	18
Maintenance.....	19-20
Troubleshooting.....	21-22
Warranty.....	22-24

SAFETY INSTRUCTIONS

WARNING! READ FIRST!

To prevent serious injury or death to yourself and others or damage to the crossbow, read the entirety of the manual and its safety and operating instructions before assembling, cocking, or using the crossbow.

Strictly follow these instructions at all times when operating the crossbow.

Crossbows are deadly weapons and should be used in a safe and cautious manner.

- Keep the crossbow out of reach of children and individuals with pathological conditions when not in use.
- Always point your crossbow in a safe direction. Never point it at or toward another person. Never point it at or toward anything you do not intend to shoot.
- Confirm and identify your intended target and what lies behind it before shooting. Arrows can travel a far distance and could injure others or damage property beyond your target.
- DO NOT move the trigger safety switch to FIRE position until you are ready to shoot.
- DO NOT put your finger on the trigger until you are ready to shoot.
- The crossbow is designed for hunting and target shooting only. DO NOT use the crossbow for any other purpose beyond its original intent. Doing so could cause serious injury or death.
- DO NOT modify the crossbow or its accessories other than what maintenance or

operating instructions are discussed herein.

- DO NOT transport or store the crossbow while it is cocked and/or loaded. The crossbow could accidentally discharge causing serious injury or death.
- DO NOT carry the crossbow while climbing up or down a tree or shooting/hunting stand. Hoist and lower the unloaded crossbow with durable rope. Carrying a crossbow while climbing could create a loss in balance and cause you to fall. ALWAYS wear a safety belt or harness when hunting from a tree stand. Falling from tree or shooting/hunting stands could cause serious injury or death.
- Follow the proper cocking instructions herein to prevent injury to your back and/or body.
- DO NOT fire your crossbow if obstructions (tree branches) block the limb's release path. Doing so could cause damage to the crossbow limbs or string causing serious injury or death.
- DO NOT fire the weapon with bystanders standing beside the crossbow. Bystanders are subject to serious injury in the rare case a string, cable, or limbs were to break.
- Make sure all arrows (field tips and broadheads) are properly placed in the quiver when transporting or storing the crossbow. Mishandling any arrow could cause serious injury.
- ONLY use the cocking rope when cocking the crossbow. DO NOT use hands or other objects when cocking the crossbow. Doing so could cause serious injury to your hands or fingers.
- Before each use, carefully examine your crossbow and arrows for worn, loose, damaged or missing parts. Using a damaged crossbow or arrow could cause serious

injury or death to yourself or others.

- DO NOT attempt to adjust the crossbow's draw weight, change its cable, limbs, or string without proper tools and instruction. Have a qualified archery/crossbow pro-shop perform these tasks. Improper adjustments and installation could cause serious injury or death, and void the crossbow's warranty.
- DO NOT use arrows that do not meet the required specifications of recommended arrows. Using incorrect lightweight arrows can have the same effect as dry-firing, thus causing damage to the crossbow, injury to yourself or others.

PROPER HAND GRIP OF THE CROSSBOW

NEVER allow your fore-grip hand or fore-grip hand's fingers or thumb to move above the flight groove or into the path of the bowstring or cable. All hands and fingers should remain below the flight groove and string/cable path to prevent serious injury. Not following this safety instruction will cause serious injury to your hand and fingers when the crossbow is fired. Hands must remain below this area at all times. Prior to shooting, hands should be properly kept on the crossbow's foregrip.



IMPROPER HAND GRIP METHODS! The methods above will cause serious injury to your hands and fingers upon firing.




PROPER HAND METHODS! The methods above are the proper ways to hold the crossbow.



DIAGRAM

- | | |
|------------------|------------------------|
| 1. Stock | 12. Stirrup |
| 2. Safety switch | 13. Quiver |
| 3. Sight bridge | 14. Picatinny Rail |
| 4. Optical sight | 15. Barrel |
| 5. Flight groove | 16. Fore grip |
| 6. Serving | 17. Vertical fore grip |
| 7. String | 18. Trigger |
| 8. Cables | 19. Sling |
| 9. Limb | 20. Cocking rope |
| 10. Cam/wheel | 21. Retention spring |
| 11. Riser | |



Draw weight	155 lbs
Arrow speed	350 fps
Power stroke	14.2"
Length	40.5"
Width	25.6"
Weight	10.8 lbs
Arrow length	20" and 22"
Arrow weight	400-425 grain / 350 grain min.

FEATURES:

350 FPS arrow speed
Compound levering system
Quick and quiet cams
Composite, ultra-stiff split limb design
Composite stock with black rubber grip finish
Picatinny accessory mounting rail
Quick detach quiver

INCLUDES:


Crossbow
Foot strirrup
4x32 crossbow scope
4 field tip arrows
Quick detach quiver
Vertical fore-grip
Sling
String wax
Safety glasses

ASSEMBLY

The Rebel 350 requires minor assembly out of the packaging. Follow strictly to the instructions herein to prevent damage to the crossbow or yourself.

The following should be included:

- A. Limb assembly
- B. Stirrup
- C. Stirrup screw (M8x50)
- D. Crossbow stock
- E. Sling
- F. 4 field tip arrows (20")
- G. Quiver
- H. Cable slide
- I. Quiver screws (M5x12)
- J. Quiver bracket
- K. Allen set (5mm, 4mm, 3mm)
- L. 4x32 crossbow scope




Step 1: Attach each of the cables into the grooves of the cable slide (H). The two cables must remain in the individual grooves of the cable slide once assembled.



Step 2: Attach the limb assembly (A) to the stock (D) by placing the cables into the cable slot of the stock. The cable slide must match the groove in the slot to attach correctly.



Step 3: Insert the barrel of the stock into the limb assembly and connect together.



Step 4: Attach the stirrup (B). Make sure the concave surface of the stirrup faces up and meets flush with the edge of the limbs. Fix the stirrup into place with the stirrup screw (C). Do not over tighten.

The main components of the crossbow are now assembled. Make sure the cables in the cable slide are separated in their grooves and not stacked together. If so, repeat steps 1 through 4.



Step 5: Install the quiver bracket onto the side of the crossbow body and fasten the two quiver screws (I). The quiver bracket will face away from the shooter to allow for easy access to arrows.

If right handed shooter, place the quiver bracket on the right side of the body. If left handed shooter, the quiver bracket will be attached to the left side of the body but the quiver bracket must be reversed. Using needle nose pliers unscrew both cap nuts, be careful to not lose both sets of washers. Remove and reverse the bracket, attaching washers and tightening both cap nuts.

Step 6: Insert the quiver (G) into the slot of the bracket (J). Engage the lever on the quiver to fasten the quiver to the bracket.



Step 7: Attach the sling (E) to each of the sling bolts attached to the crossbow. One is located on the stock of the crossbow and one located on the underside of the front of the crossbow.

To attach, loosen the screw bolts.



Press down on the screw bolt and rotate the clip off the attachment pin.



Insert the pin into the sling bolts on the crossbow. Press down on the screw bolt, rotate the clip to attach to the pin. Fasten the screw to secure the sling in place.



ACCESSORY MOUNTING

The Rebel 350 includes a picatinny rail (14) located under the bottom-front of the crossbow. This rail allows for mounting accessories such as grips, lasers, flashlights, etc. The Rebel 350 comes equipped with an adjustable vertical foregrip (17). To attach the foregrip:

Step 1: Loosen and remove the mounting screw from the foregrip's mount.

Step 2: Align the foregrip's mount with the picatinny rail. Note that the grip of the foregrip should be facing forward or towards the front of the crossbow.



Step 3: Slide the foregrip onto the picatinny rail. Align the space for the mounting screw with a slot on the picatinny rail.

Step 4: Insert the mounting bolt into the foregrip and through the slot on the picatinny rail. Next tighten the mount to secure the foregrip in place. **DO NOT** overtighten.

WARNING! If mounting other accessories, **DO NOT** attach any accessory that will interfere with the mechanism of the string or limbs! Doing so will cause damage to the crossbow and possibly personal injury.

INSTALLING THE SCOPE

The scope rings are pre-installed onto the crossbow scope. Follow the instructions below to properly mount the crossbow scope.

Step 1: Loosen the mounting screws on the scope rings.

Step 2: Align the rings with the grooves on the crossbow's mount. If the rings are not aligning properly with the grooves on the crossbow mount, the rings placement on the scope should be adjusted. To do so, loosen the two screws on the scope ring. Move the ring forward or backward to match the placement needed to mount to the crossbow mount. Retighten the screws on the scope ring.



Step 3: Tighten the mounting screws on the scope ring.

Step 4: At this time, check for correct eye relief by holding the crossbow in the shooting position. If adjustment is needed to obtain a full field of view through the scope, loosen the scope's two screws and reset the scope to the correct position.

Step 5: Once eye relief is established, check to see if the crosshair alignment is level by pointing the scope at an object that is level. If alignment is needed, loosen the rings, then rotate the scope to align the crosshair.

COCKING THE CROSSBOW

Warning: In order to prevent injury to your back, arms, or hands **ONLY** use the cocking rope instructions below to cock the crossbow. Accurately and properly cocking the crossbow will ensure the crossbow shoots straight and accurate. When cocking the bow, never release the cocking rope as this can result in a dry fire effect. If the string must be released during the cocking process, slowly lower the handles to gently return the bowstring to its resting position.

Step 1: Before cocking the crossbow, the safety switch (2) must be in the "FIRE" position. Hold the crossbow with the stirrup (12) sitting on a level surface and the underside facing you. Place your foot into the stirrup to provide stability.

Step 2: Place the hooks of the cocking rope (20) onto the crossbow string (7) on each side of the flight groove (5).



Step 3: Then place the middle of the rope in the groove in the stock located behind the mount and safety switch.



Step 4: Grasp the molded handle and pull the string back until it latches in the trigger. Once latched move the safety switch to the safety, "S", location marked in green.

Step 5: Place a recommended crossbow arrow in the flight groove. Make sure a fletching or vane is slipped into the flight groove and slide the arrow back under the arrow retention spring (21) until it rests against the serving. The arrow is now loaded and ready to fire.

WARNING! Even with the safety engaged, proper crossbow and shooting safety must be followed to prevent damage to property, serious injury or death.

SHOOTING AND UNLOADING

WARNING! DO NOT attempt to shoot the crossbow before reading the entirety of this manual. Proper handgrip should be used (read “Proper Handgrip of the Crossbow” under safety instructions section). Proper crossbow and shooting safety must be followed to prevent damage to property, serious injury or death.

When ready to fire the crossbow, flip the safety switch (2) up to the FIRE position marked by letter “F” in red. Gently squeeze the trigger until the string is released.



The safest method for unloading your crossbow is to fire an arrow into an arrow training (foam) target or soft, rock-free ground. When firing into the ground, fire at least 3 feet in front of you. **DO NOT** attempt to un-cock your crossbow by hand nor with the cocking rope. Doing so could cause injury to your hands or back and possibly result in a dry fire. It is recommended to carry a field tip in your quiver while hunting and use the field tip to unload the crossbow before storage or being transported.

RECOMMENDED ARROWS

To achieve accurate shooting and to maintain safety, Southern Crossbow recommends the following arrow types be used. Field tips, fixed and mechanical broadheads may be used with the Rebel 350. There is no recommended fletching style of specification. Aluminum and carbon arrows may also be used as long as the length and weight correspond to the following recommendations:

The recommended arrow weights are 400 and 425 grain.

The recommended lengths are 20" and 22".

The minimum arrow weight is 350 grains. Using arrows weighing less can produce a dry-fire effect with the crossbow.

Failure to follow the arrow recommendations may result in damaging the crossbow, personal injury, and voiding warranty.

SIGHTING THE CROSSBOW SCOPE

After installing the scope, the scope must be sighted in. Before sighting in, make sure the scope is in focus. If needed, the diopter adjustment can be adjusted to focus the image to your eye. To do this, rotate the entire eyepiece assembly (rear bell). Once focus is

achieved, rotate the locking ring until it is flush with the eyepiece assembly. This will lock the focus adjustment in place. If the user of the crossbow changes, the focus may need to be re-adjusted.

To sight in:

It is recommended to place the crossbow in a shooting vice that does not interfere with the operation of the string and limbs. Having the crossbow stable in a shooting vice will eliminate human error making it easier to line the sight's crosshair with the impact point of the arrow. Sight in the crossbow scope at 20 yards using the top line. If the impact of the arrow is offset from the aiming point, make adjustments to the elevation or windage adjustments. Adjust the top crosshair to align with the impact point of the arrow. Continue to shoot the crossbow and adjust the scope until the impact and aiming point coincide.

For the Rebel 350 (350fps), once zeroed at 20 yards the lower four lines correspond to 35, 45, 60, and 70 yards.

STRING SPECIFICATION

The Rebel 350 requires a 28 strand 39.6" length string (does not include loops) and 16.85" length cable with 12" yoke.

MAINTENANCE AND CARE

WARNING! Each time before you shoot the crossbow inspect the crossbow for worn, loose, damaged or missing parts.

Replace worn, damaged, or frayed strings and cables immediately. Keep strings and cables moist with string wax. DO NOT apply string wax to the serving, barrel or trigger. Doing so will collect wax in the latching/trigger mechanism and possibly prevent the string from cocking properly. Under normal shooting conditions, it is recommended to have your string replaced every other year by a professional at an archery/crossbow pro shop.

Regularly clean the crossbow to maintain top performance.

Keep the trigger/latching assembly dry. After use in wet conditions, dry the crossbow with a small cloth or blow dryer on the *no heat* setting. Occasionally apply lube to the latching assembly to prevent rust.

Occasionally apply lube to the safety switch, with the switch is located in the SAFE (green) position and then in the FIRE (red) position.

Barrel/rail lubrication can be used on the flight rail to reduce friction between the string

and rail. This will prolong the life of the serving and maintain proper arrow speed. Apply a small amount of lubrication to the rail every 100 shots. Too much lubrication can soak into the string and serving, causing the material to break down.

Regularly apply a small amount of lubrication to the axles and cams/wheels to maintain proper mechanics.

DO NOT use heavy oils, greases, or petroleum based jelly as lubricant. These substances will attract dust and dirt that will collect in the mechanical parts of the crossbow.

DO NOT store your crossbow in hot environmental conditions. Crossbow must be stored in a cool, dry place to prevent degradation of strings and cables.

DO NOT loosen bolts on the riser or limbs when the crossbow is not in use.

Southern Crossbow is only authorized to repair or replace mechanical parts, triggers, mounts and limbs. If repairs are needed, contact the Quality Assurance Department at 1-817-225-0310 or email request through the website www.southerncrossbow.com

TROUBLESHOOTING

Crossbow will not cock

- The safety switch is not set in the “FIRE” position. Set the safety switch from the “SAFE” position to “FIRE” position.
- The latching mechanism has not been properly maintained. Add small drops of oil to the latching mechanism and safety switch (in “fire” and “safe” position).
- Heavy grease or jelly was used during maintenance and has caused collection of debris to prevent proper latching. Attempt to clean the device with proper oils. The crossbow may need to be sent to the factory in order to be properly cleaned.

Trigger safety tension is too tight or loose

- Add small drops of oil to the latching mechanism and safety switch (in “fire” and “safe” position).
- The crossbow may need to be sent to the factory in order to be properly cleaned.

Arrow groupings are inaccurate

- The string was improperly cocked. Review section “cocking and loading” for proper technique to load the crossbow.
- Check that all assembly screws for the crossbow are tight (stirrup, limbs, sight bridge, scope rings, etc.)
- The scope rings may be loose and not holding zero. Retighten the rings and re-zero the scope

- The scope may have parallax and be defective.
- The arrow shaft may be out of tune. Rotate the arrow on its tip to see if the arrow bows or wobbles on its axis. If so, have your arrows re-tuned at a pro shop.

The string and cables are fraying

- Apply wax to the string and cables and rub the wax into the strings with your fingers.
- DO NOT use the crossbow if the cables are cut. Have the string/cable replaced before use.

The serving has degraded or come apart

- Applying too much oil to the rail of the crossbow will saturate the serving and cause the serving to come apart. Replace the string before use.

LIMITED LIFETIME WARRANTY

Your Southern Crossbow product is warranted free of defects in materials and workmanship that affect the proper operation of the crossbow for the lifetime of the original owner except for bow limbs, cams/wheels/axles, protective glasses, strings, and cables. Bow limbs and cams/wheels/axles are warranted for five (5) years from the date of purchase. Strings, cables, and protective glasses are not covered under warranty. This warranty is non-transferable is only deemed effective if purchaser registers product within 30 days after purchase through completing the online warranty registration at www.southerncrossbow.com. Southern Crossbow reserves the right at its discretion to accept valid proof of purchase upon request for Return Authorization (RA) number.

In the event of a defect under this warranty, Southern Crossbow will, at our option, repair or replace the product. This warranty does not cover damages caused by misuse or improper handling. Also, this warranty is null and void if modification or maintenance is provided by someone other than Southern Crossbow, excluding string/cable replacement in which consumer should consult a archery/crossbow pro shop or Southern Crossbow for service.

Warranty will be void for the following reasons:

1. Owner did not follow proper procedure of operation or proper maintenance provided in owner's manual.
2. The crossbow was altered from its original state or used outside of its intended use.
3. Damage caused by misuse, abuse, or neglect.
4. Damage caused by dry-firing or by using a non-recommended or underweight arrow as specified in the owner's manual.
5. The safety was disabled or altered from its original state.

To receive a RA number for warranty service or out-of-warranty repair, you will need to:

1. Fill out the online document labeled Warranty RA Form, or call 1-877-431-3579. If you are outside the US, call 1-817-225-0310.
2. Once the request has been received you will either receive a reply email that contains all necessary return information, or a customer service representative will contact you and give you an RA number over the phone.

If you are sending in a product for a warranty repair, you will be required to fill out a RA

request form. Once the form has been received and processed, you will receive a confirmation email containing your RA number and a PDF Return Form. The Return Form must be filled out completely and mailed in with your product. In order for your repair to be successfully fulfilled, be sure to closely follow all instructions outlined by the Return Form. If any of the aforementioned instructions are not properly followed, your request cannot be processed and the product will be held until you are contacted, and proper documentation is received.

To send in the product, you will be required to include the following items:

1. The filled out Repair Form.
2. The defective product.
3. If product was not registered online, a copy of the original receipt showing when and where the product was purchased must be included.
4. The RA number printed on the box, with a return address.

To view this manual in other languages or for more information, visit www.southerncrossbow.com

REBEL 350
USER MANUAL