

MR ENTERTAINER



MKP100


Multi-Format Karaoke Player



INSTRUCTION MANUAL

For your protection, please read these instructions in full and keep this manual handy for future reference. Carefully observe and comply with all warnings, cautions and instructions placed on the equipment or outlined in this manual to guard against injury.

SAFETY INSTRUCTIONS



The lightning flash & arrowhead symbol within a triangle is intended to alert you to the presence of danger.




The exclamation point within a triangle is intended to alert you to the presence of important operating & servicing instructions.

1. **Read Instructions** – All the safety and operating instructions should be read before the appliance is operated.
2. **Retain Instructions** – These should be retained for future reference.
3. **Heed Warnings** – All warnings on the appliance and in the operating instructions should be adhered to.
4. **Follow Instructions** – All operating and usage instructions should be followed.
5. **Attachments** – Do not use attachments that are not recommended by the product manufacturer as they may cause hazards.
6. **Water & Moisture** – Don not use this unit near water, for example near a bathtub or in a wet basement.
7. **Carts & Stands** – The appliance should be used only with a cart or stand that is recommended by the manufacturer. An appliance and cart combination should be removed with care. Quick stops, excessive force and uneven surfaces may cause an overturn.
8. **Ventilation** – The appliance should be situated so its location does not interfere with its proper ventilation. For example the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation slots.
9. **Heat** – The appliance should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
10. **Power Sources** – The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
11. **Grounding or Polarization** – Precautions should be taken so that the grounding or polarization means of an appliance is not defeated.
12. **Power-cord Protection** – Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles and the point where they exit from the appliance.
13. **Cleaning** – Unplug this unit from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning and ensure the appliance is totally dry before reconnecting.
14. **Power Lines** – An outdoor antenna should be located away from power lines.
15. **Non-use Periods** – The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
16. **Object & Liquid Entry** – Care should be taken so that objects do not fall and liquids are not spilled into the enclosure though openings.
17. **Damage Requiring Service** – The appliance should be serviced by qualified service personnel when:
 - A. The power supply cord or plug has been damaged.
 - B. Objects have fallen into the appliance.
 - C. The appliance has been exposed to rain.
 - D. The appliance does not appear to operate normally or exhibits a marked change in performance.
 - E. The appliance has been dropped or the enclosure is damaged.
18. **Servicing** – The user should not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified personnel.

NOTE: To CATV system installer's (U.S.A): This reminder is provided to call the CATV system installers attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected as close to the point of cable entry as practical.

Descriptions and Functions


Front Panel



1. **POWER** – Turns karaoke player on or off
2. **DISC TRAY** – Press EJECT to open/close the disc tray
3. **LCD DISPLAY**– Displays player status such as time, disc format and song number
4. **EJECT** – Open/Close the disc tray
5. **PLAY/PAUSE** - Play or pause the track
6. **STOP** - Stop playing the track
7. **PREVIOUS** - Previous track
8. **NEXT** - Next track.
9. **RECORD**- Starts/Stops Recording. Please see ‘Record Singing’ under ‘Basic Operation’ for more details.
10. **MIC INPUT 1** – Plug microphone in here
11. **MIC INPUT 2** – Plug microphone in here
12. **SD CARD** – Use this SD CARD input to connect SD CARD’S and MMC cards allowing playback of MP3, MP3G, MP4 audio/video files. Also allows ripping of CDG disc to MP3+G and recording of performances. Supports FAT32 only
13. **USB** – Use this USB input to connect USB devices such as flash drives or external hard drives allowing playback of MP3, MP3G, MP4 audio/video files. Also allows ripping of CDG disc to MP3+G and recording of performances. Supports FAT32 only.

Descriptions and Functions

Rear Panel



1. **SURROUND SOUND.** Only for use with surround sound system
2. **RIGHT AUDIO (RED).** Right audio output. Connect RED RCA Cable
3. **LEFT AUDIO (WHITE).** Left audio output. Connect WHITE RCA Cable
4. **HDMI –** HDMI Output
5. **OPTICAL –** Optical output socket for digital audio
6. **VIDEO (YELLOW) –** Video output. Connect YELLOW RCA Cable

FOR BEST RESULTS, CONNECT TO TV USING INCLUDED RED/WHITE/YELLOW RCA CABLES

**IF YOUR TV DOES NOT HAVE RED/WHITE/YELLOW RCA INPUTS THEN USE HDMI,
AND SEE SECTION BELOW ABOUT REDUCING MIC DELAY WHEN USING HDMI**

**Need Help? Contact our UK Support
Team via Whatsapp for Immediate Help..**




wa.link/3u39k6

scan qrcode on your phone,
or message 07536 915468

Please also check our Troubleshooting page...
www.mrentertainershop.co.uk/pages/troubleshooting

Remote Control Functions



Remote Control Functions

1. **POWER** – Turns the MKP100 on, or into standby mode, to turn completely off please use the button on the front of the player.
2. **OSD** – Cycles through the different onscreen display options.
3. **ANGLE** – Cycles through the available viewing angles on DVD's with multiple viewing options available
4. **SUBTITLE** – Cycles through the available subtitle languages on a DVD with subtitles available.
5. **PROG** – to program tracks press STOP then press PROGRAM. Enter your track selections and press PROGRAM again to accept. Press the PLAY button to start the programmed tracks.
6. **SETUP** – Use this button to access the MKP100 setup page on the video screen. Select options using the directional buttons and make changes using the ENTER button on the remote.
7. **DIRECTIONAL BUTTONS – MIC VOLUME & MIC ECHO**

The **UP** and **DOWN** buttons allow you to navigate through the menu screens, and adjust the volume of the microphone volume.

The **LEFT** and **RIGHT** buttons allow you to navigate through the menu screens, and adjust the amount of microphone echo..

Please note the microphone and echo controls work in disc mode only. If you want to adjust during USB/SD playback please do so via SETUP.
8. **RETURN** – accesses the main menu on a VCD 2.0 disc, NOTE, PBC must be turned on and the VCD must be a VCD 2.0 disc.
9. **PLAY/PAUSE** – start to play the disc or temporarily suspend playback. Press again to resume playback.
10. **PREV** – Skip to the previous track when playing a CDG disc
11. **FWD & REV** – Scans through a track when in disc mode, **FWD** scans forwards through a track, **REV** scans backwards through a track. **NOTE: This function will not work with CDG discs.**
12. **RIPPING** – For ripping CDG discs to MP3+G, please see 'RIP MP3+G from CD+G discs' under 'Basic Operation'
13. **RESUME** – Resumes playback from exact spot where a disc has been stopped in standby mode.
14. **A-B** – Loop button, allows you to set a section on a disc for continuous looping.
15. **REPEAT** – Cycles through the available repeat options.
16. **MUTE** – Mutes the sound from the disc
17. **KEY CONTROL** – Lower or raise the key of the track, b button to lower, # button to raise.
18. **OPEN/CLOSE** – This button is used to open or close the disc tray.
19. **NUMBER/PRESET** – Use these buttons to jump directly to a specific track in disc mode.
20. **TIME** – Accesses the time menu which allows you to jump directly to a specific time on a disc.
21. **TITLE** – Access the title screen on a DVD disc, will only work on DVD's that have title screens.
22. **ENTER** – used to make selections in menus and the OSD when an entry is highlighted.
23. **MENU** – Accesses the main menu on a DVD and other discs with main menus.

24. **STOP** – Stops disc playback.
25. **NEXT** – Skip to the next track when playing a CDG disc.
26. **VOLUME +/-** – Adjusts the music volume
27. **RECORD** – For recording performances to MP3, Please see ‘Record Singing’ under ‘Basic Operation’
28. **EQ** – Switch between available EQ pre-sets.
29. **MPX** – Multiplex button, used to turn the lead vocal on/off on multiplex tracks. Pressing this button cycles through the different audio output settings to turn the vocals on/off.
30. **N/P** – Switches between NTSC and PAL video modes
31. **DISC/USB** – Selects the playback mode, DISC / USB / SD CARD
32. **SLOW** – cycles through the different slow motion options when in disc mode.
33. **RESET** – Restores the player to factory defaults.

IMPORTANT NOTICE ABOUT SETTING UP MICROPHONES

Common problem 1...

“The microphones are too quiet compared to the music ” – this can usually be easily solved by adjusting the music & microphone levels, please follow the steps below...

1. Turn the microphones volume up to full using the remote
2. Turn the music down to volume 6 (this is roughly 50% of max volume)
3. Increase the volume on your TV, you may have to turn it up higher than you normally would to allow for the reduced music volume level on the MKP100.

Hopefully your microphones should now appear much louder compared to the music, you can keep adjusting the music, microphone & TV volumes to get the perfect balance between all three. If your microphones are not working at all or the cables are broken, please contact us and we will send you a replacement microphone/cable.

Common problem 2...

“I’m getting an echo / delay / latency on the microphones”

Some modern TV’s have simulated surround sound features such as movie mode, sports mode etc, which whilst great for movies & watching TV, can cause problems when processing the sound from a microphone as it causes a delay between when you sing, and when that sound comes out of your TV. To solve this you need to access the sound settings on your TV and disable any surround sound modes. You can also try turning the echo down via the MKP remote. We also recommend if possible connecting the MKP100 (or any karaoke player) to your TV using the red/white/yellow RCA cables included rather than HDMI, as HDMI is a digital signal which takes TV’s some time to process, often causing a delay from the microphones. This delay can be exaggerated if your TV is connected to a soundbar or surround sound system due to the processing time required to receive the audio signal from the MKP100, through the TV and out to the soundbar. This is a pitfall with digital connections to TV’s, and not a fault with the Karaoke Player.

The only way to remove this delay entirely is to have a separate soundbar/speakers purely for karaoke, which connect directly to the MKP100 therefore removing the TV processing delay. Check our website for dedicated karaoke soundbars & speakers, www.mrentertainershop.co.uk

Before Operation

Playable Media

This player supports the following disc formats, DVD, CD, CD+G, MP3, MP3+G and MP4 on the following disc types, DVD, DVD±R, CD, CD±R. Any other form of disc media may cause the player to display NO DISC on the display window. Future media and disc formats maybe supported with firmware updates when available. Dirty, scratched, warped and defective discs may cause a considerable time delay during the loading and reading of the disc. In some cases this may result in the disc being totally unreadable by the player.

Video Signal Formats

This player supports NTSC and PAL colour systems with automatic detection and override settings.

Audio Formats

This player accommodates stereo, surround, analogue and a few digital hi-fi audio signals. If required these can be configured under SETUP.

Handling and cleaning discs

When handling discs always hold them from their edges and/or by the circle in the centre. Never write or stick labels to any surface of the disc as this can unbalance, scratch or damage the disc. Do not bend or press the disc or expose it to direct sunlight. Store discs in a clean and dry environment. After use return the disc to its packaging, do not transport or move the player with discs still inside, as they can dislodge and/or damage the reader. Discs can be cleaned using a soft cloth, always wipe from the centre towards the edge, do not clean with any other cleaning solutions unless it's specifically made for CD's.

Power Cord

Handle the power cord by its plug only. Do not unplug the power cord by yanking or pulling on the cord. Touching or unplugging the cord with wet hands may lead to an electric shock or a short circuit. If the cord becomes damaged or its wires become exposed, please replace as soon as possible in order to prevent an electric shock or fire. It is advised that you regularly check the cord to ensure its functioning properly.

Contents



MKP-100 Unit (1)



Remote Control(1)

Items	Quantities
MKP-100 Unit	(1)
Remote Control	(1)
A/V RCA Cable	(1)
AAA Batteries	(2)
Manual	(1)



A/V RCA Cable(1)



AAA Batteries(2)



Manual(1)

Basic Operation

Basic Playback

Turn the machine on using the power button

Loading and navigating a disc

1. Press EJECT to open the disc tray.
2. Place a disc in the disc tray.
3. Press EJECT to close the disc tray
4. The disc will start playing automatically
5. To end playback press STOP
6. To resume playback press PLAY
7. To stop playback completely press the STOP button twice. Now when you press PLAY it will play from the beginning of the disc.
8. To pause playback press the PLAY/PAUSE button, to resume press PLAY/PAUSE
9. To skip a track press NEXT to go to a previous track press PREVIOUS. Alternatively if you know the track number you can enter it on the remote.

If a menu is shown on the TV screen

When inserting a DVD disc a menu may be displayed before playback, from the menu you can select a desired track, scene or any other displayed options using the directional arrows on the remote control, once your selection has been highlighted press enter to commence playback.

IMPORTANT

Please do not insert a damaged disc. If a disc takes more than usual to read or the display window shows LOAD for a prolonged period of time please EJECT the disc and check the disc for any dirt, fingerprints, scratches or other defects.

Playback from USB/SD

Select USB or SD Card pressing the Disc/USB button on the remote. You will then need to use the up and down navigational buttons to select the desired mode, press ENTER to confirm selection.

IMPORTANT

This player is not a computer; it cannot support large external self-powered hard drives or any device containing more than 2000 files. It is also recommended that your USB flash drive is formatted to FAT32. We cannot guarantee every USB flash drive will work, please try another brand if you are experiencing compatibility issues.

Loading a track from USB/SD

Your karaoke player supports playback of MP3's, MP3+G's and MP4's via USB/SD. If no disc is being played when you insert the USB/SD it will automatically be selected and playback will start. Otherwise if you need to switch to USB/SD you'll need to press STOP and then switch the input, details of how to do this are explained under '**Playback from USB/SD**'.

Please use the navigational buttons on the remote to navigate around the USB/SD card menu, once you have highlighted the track you want to play press ENTER to start playback. Pressing STOP will return you to this menu.

****Please Note**** If you are getting an "UNSUPPORTED FORMAT" error when trying to play an MP4 file, this could be a codec issue. We recommend using a file converter program to change the codec used in the MP4 file, or even easier is to convert your MP4 files to AVI format. This is an easy process that can be done using free software. Do a Google search for "ANY VIDEO CONVERTER" which is a great little tool for converting files.

Using the Microphones

The karaoke player has two microphone inputs. The microphone volume can be increased or decreased using the remote control. To get the best balance between the microphones and the music you may also need to adjust the music volume, this can be increased or decreased on the remote control. To enhance the vocal you may wish to add more or less echo, this can be done via the remote.

Using the Remote Control

The battery compartment is located on the back of the remote control, the remote requires 2 x AAA batteries, please ensure these are inserted with the positive (+) and negative (-) terminals in the correct direction.

Recording Singing

1. Insert your favourite CDG karaoke disc and insert a USB stick into the USB port to record to.
 2. Select and play the song you want to record. Then press the Record button on the remote to start recording. The song will then re-play from the beginning and start recording at the same time.
 3. Press the STOP or RECORD button to stop recording or when the song has finished the recording will automatically end.
 4. Your performance will be saved to the USB stick.
-

RIP MP3+G from CD+G discs

1. Insert CDG disc into disc tray, insert USB stick for MP3+G storage.
2. Press RIPPING button on the remote control.
3. Under options select your desired ripping speed, either 1x or 4x and your desired MP3 compression bit rate, 320 recommended.
4. Choose the tracks you want to rip from the TRACKS menu.
5. After you have selected your tracks go to START to start ripping your tracks.
6. Once ripping has completed please exit the window by selecting QUIT. Your songs will now be stored on your USB stick.

****Please Note**** Your files will be assigned default filenames such as Track01, Track02 etc, making them difficult to recognise later on when browsing files. We recommend using a PC to rename the files to include the song titles and artists making them easier to use.