

# ecoharmony

charging ahead

**Modbus Testing and Configuration Guide (V1.0)**

[Ecoharmony.co.uk](http://Ecoharmony.co.uk)

[Team@ecoharmony.co.uk](mailto:Team@ecoharmony.co.uk)



## 1. Introduction

This guide lays out the steps to use the Modbus communication between a PC and a EPC2.0+


## 2. Hardware

You will need:

- PC running windows
- USB to RS485 converter ([Amazon Link Here](#))
- 240V power supply

The EPC must be powered with a 240v AC supply to test the RS485 communication. Isolate the supply before making any connections. The indicator light on the top will show when the EPC is powered correctly.

The Modbus communication has three lines. A, B & Ground signal lines must be connected for the communication to work correctly.



### 3. Software Setup

Modbus simulator install and setup


Download the Tester.exe file available on the below webpage:

<https://www.se.com/uk/en/faqs/FA180037/>

#### Attachment(s)



When the program is run it will display the below. All the fields that need to be filled in are listed below.



The screenshot shows the 'Generic Modbus/Jbus Tester' application window. The interface includes various configuration fields and buttons. Red boxes highlight the following fields:

- 1: Port (COM3)
- 2: Baud (19200)
- 3: Parity (Even)
- 4: Communications Wiring (Wiring with Echo (2-wire))
- 5: Sample Mode (Manual)
- 6: Timeout in ms (1000)
- 7: Slave ID (20834)
- 8: Starting Register (1)
- 9: # of Registers (9)

The 'Read' button is circled in green. Other visible fields include Display Mode (Decimal/Hex), TCP/IP Address or URL (254.254.254.254), Sample Rate in ms (1), Data Type (Holding Register (R03 / W16)), and transaction time settings (Maximum, Transaction, Minimum).



## Factory Communication Settings

1. Com Port – Select the com port used by your PC for the RS485 converter
2. Baud Rate - 19200
3. Parity - Even
4. Communication Wiring – Wiring with No Echo (4 Wire)
5. Sample Mode - 20
6. Timeout - 1000
7. Slave ID - 101
8. Starting Registered – 1-52 (this defines the register displayed in the top position on the tester)
9. No. of Registers – 1-10 (this defines how many registers are displayed by the tester)

Use the “Read” button to display the register values currently on the device. Once the values are displayed, they can be adjusted.

Use the “Write” button to write the register values back to the device.

Use the “Register Map” below to identify the settings on the unit you would like to read or change. Some Register locations are read only and cannot be changed via Modbus.

**Note:** The EPC2.0+ comes configured as RCM enabled, if a RCM is not fitted the unit will report an error on power up and not initiate a charge.

To change the configuration read register 40048, change the “1” to “0” and write to the EPC. The unit will no longer look for a RCM to be connected.

**Warning:** The values written to the device will supersede any DIP switch configuration.

Placing all DIP switches in the ON position and powering up the unit will restore factory settings to the EPC. This includes any settings that have been changed via Modbus.



### EPC 2 PLUS MODBUS Register Map V104

Register	Read	Write	Function	Values	Default Value	Length
40001	Y	Y	R	0-255	0	16-bit
40002	Y	Y	G	0-255	0	16-bit
40003	Y	Y	B	0-255	0	16-bit
40004	Y	Y	LED Control Register	0 = Default Automatic, 1 = Colour and Brightness set by RGB registers		0 16-bit
40005	Y	Y	Lock Control	0=Chargepoint controlled, 1=Latch on, 2=Latch off	40013 Register value	16-bit
40006	Y	Y	Charge Disable	0 = state C disabled, 1 = auto start charging, 2 = Writing 2 to this register in state B or A will allow charge point to enter State C once and value will automatically return to 0	40014 Register Value	16-bit
40007	Y	Y	Active Charging Current	0, 6A-32A, Alloted current to advertise to EV	fallback @ startup	16-bit
40008	Y	N	Measured Voltage L1 N	Measured Voltage L-N terminals. Displays Volts x 10, value includes 1 decimal place	N/A	16-bit
40009	Y	N	Measured Current CT1	Measured Current in Amps x 10, Value indicates 1 decimal place	N/A	16-bit
40010	Y	N	Measured Power		N/A	16-bit
40011						16-bit
40012	Y	N	Active State	0=A, 1=B, 2=C, 3=D, 4=F	N/A	16-bit
40013	Y	Y	Lock Behaviour on Power Loss	0=Chargepoint controlled, 1=Latch on, 2=Latch off		0 16-bit
40014	Y	Y	Charge Disable behaviour on power loss	0 = state C disabled		1 16-bit
40015	Y	N	Error Code	See error code table A	N/A	16-bit
40016	Y	N	Connected Cable Current Rating in Amps	PP Current Rating	N/A	16-bit
40017	Y	N	EVSE Advertised Current	The current being advertised to the EV at this moment in time.		16-bit
40022	Y	Y	Baud Rate	1200, 2400, 4800, 9600, 19200, 57600		19,200 16-bit
40023	Y	Y	Parity	0 = none, 1 = even, 2 = odd		1 16-bit
40024	Y	Y	Server Address	If address bits are set to 1,1 Server address is this value 1-255		102 16-bit
40029	Y	Y	Comms Timeout	If no data received within XmS default to Fallback Current, 0 = no timeout, Allowed Values 1,000 - 60,000		0 16-bit
40030						16-bit
40031	Y	Y	Fallback Current	0-32 - Current to advertise on comms loss		32 16-bit
40043	Y	Y	Property Fuse Rating	Property maximum fuse rating in Amps for Supply Optimisation		100 16-bit
40044						16-bit
40045	Y	Y	Maximum Charging Current	6-32 Maximum current EVSE is capable of based on wiring and components		32 16-bit
40046	Y	Y	Lock Feedback Enable	1 = Feedback Enabled, 0 = Feedback Disabled, 2 = Default behaviour (on for motor, off for solenoid)		2 16-bit
40047	Y	Y	Lock Feedback Switch Polarity	1 = Hella Actuator, 0 = Phoenix Contact socket		1 16-bit
40048	Y	Y	RCM Enabled	1 = RCM Enabled, 0 = RCM disabled		1 16-bit
40049	Y	N	Socket / Tethered	1 = Socket, 0 = Tethered	SW1 Position	16-bit
40050	Y	N	Solenoid / Motor	1 = Solenoid, 0 = Motor	SW2 Position	16-bit
40051	Y	N	PEN Loss Enabled / Disabled	1 = PEN Loss Enabled, 0 = PEN Loss Disabled	SW3 Position	16-bit
40052	Y	Y	PEN Loss Developer Mode	0 = PEN Loss limits locked, 1 = PEN Loss Limits writable	0 @ startup	16-bit
40053	See Note		PEN Loss Import Lower Voltage Limit	Lower Trip Threshold for Voltage Based PEN Loss Detection (Import) - Voltage x 10 (1 Decimal)	2065	16-bit
40054	See Note		PEN Loss Import Upper Voltage Limit	Upper Trip Threshold for Voltage Based PEN Loss Detection (Import) - Voltage x 10 (1 Decimal)	2535	16-bit
40055	See Note		PEN Loss Export Lower Voltage Limit	Lower Trip Threshold for Voltage Based PEN Loss Detection (Export) - Voltage x 10 (1 Decimal)	2065	16-bit
40056	See Note		PEN Loss Export Upper Voltage Limit	Upper Trip Threshold for Voltage Based PEN Loss Detection (Export) - Voltage x 10 (1 Decimal)	2595	16-bit
40057	Y	Y	Import / Export Register	Auto Detected Values (Requires connected CT): 0 = Import, 1 = Export. Manual Override 2 = Force Import Mode, 3 = Force Export Mode. Defaults to Import mode on power cycle.	0 @ startup	16-bit

### Error Code Register

MSB	8	7	6	5	4	3	2	1	LSB
Reserved	Reserved	Reserved	Supply CT Failure	Mains Voltage Outside Limits	Reserved	Failed Diode Check	DC Residual Current Fault	RCM Self Test Fail	

MODBUS Settings	Default Value
Baud Rate	19200
Stop Bits	1
Data Bits	8
Parity	Even

**Note:**  
PEN Loss Thresholds are readable at all times. Writing Values requires setting of PEN Loss Developer Mode after startup. Developer Mode will reset to disabled on power cycle.

