


01 Specifications				
Model	Cont. Current	Peak Current	Input	BEC Output
120A ESC	120A	140A	3-8S LiPo	5.2V/6V/7.4V Adjustable, Continuous/Peak Current of 8A/20A

02 User Guide

I. Connections




**Throttle Signal Cable (Long White/Red/Black Tri-color Cable):** plug it into the Throttle channel on the receiver or flight controller. The White wire is for transmitting throttle signals, the Red & Black wires are BEC output wires.


**Reverse Brake Signal Wire (Yellow Wire):** it must be plugged into any vacant channel on the receiver (when using the Reverse Brake mode) to control the ON/OFF of the Reverse Brake function.

**Programming Cable (Short W/R/B Cable):** connect it to a LED program box if users want to program the ESC.

II. ESC/Radio Calibration



III. Normal Start-up Process




03 ESC Programming

There are two ways to program the ESC. One way is to program it with a LED program box; the other way is to program it with the transmitter. The ESC has many programmable items, so we recommend using the LED program box to do the ESC programming.

I. Program your ESC with a LED Program Box

Wiring :



- Plug the programming cable (on your ESC) into the programming port on the LED program box.
- (With a battery connected to your ESC), after connected a LED program box to the ESC, you need to disconnect the battery first and then reconnect it to the ESC to enter the programming mode, check and set parameters.

The portable program box is an optional accessory applicable for field use. Its friendly interface makes the ESC programming easy and quick. Connect a battery to your ESC after connecting a LED program box to the ESC, all programmable items will show up a few seconds later. You can select the item you want to program and the setting you want to choose via "ITEM" & "VALUE" buttons on the program box, and then press the "OK" button to save all new settings to your ESC.

**Attention!** You need to power your ESC off and then on after adjusting parameters. Otherwise, new parameters won't take effect.

II. Program your ESC with the Transmitter

Wiring:

User Manual of Series Brushless Speed Controller

VI. Exit the Programming

Move the throttle stick to the bottom position within 3 seconds after you hear two long beeps and two short beeps (emitting from the motor) can get you exit the programming mode. The motor beeps "Number" beeps to indicate the number of LiPo cells you have plugged in, and then a long beep to indicate the power system is ready to go.

04 Programmable Items

Values		1	2	3	4	5	6	7	8
Items									
1	Brake Type	Disabled	Normal	Proportional	Reverse				
2	Brake Force	Disabled	Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Level 7
3	Voltage Cutoff	Soft	Hard						
4	LiPo Cells	Auto Calc.	3S	4S	5S	6S	8S		
5	Cutoff Voltage	Disabled	2.8V	3.0V	3.2V	3.4V	3.6V	3.8V	
6	BEC Voltage	5.2V	6.0V	7.4V					
7	Start-up Mode	Normal	Soft	Very Soft					
8	Timing	0°	5°	8°	12°	15°	20°	25°	30 °
9	Motor Direction	CW	CCW						
10	Freewheeling	Enabled	Disabled						

1. Brake Type

Normal Brake

After selected this option, the brake function will be activated when you move the throttle stick to the bottom position. In this mode, the brake amount equals to the brake force you've preset.

Proportional Brake

After selected this option, the throttle range of 20% to 100% (on the transmitter) will correspond to the ESC throttle output of 0% to 100% while the throttle range of 20% to 0% (on the transmitter) will correspond to the brake force of 0 to 100%.

Reverse Brake

After selected this option, the Reverse Brake signal wire (its signal range must be the same as the throttle range) must to be plugged into any vacant channel on the receiver, and you can control the motor direction via that channel. The channel range of 0-50% is the default motor direction, and the channel range of 50% to 100% will cause the motor to spin counterclockwise. The channel stick should be within the channel range of 0-50% (0 would be better) when the first time you power on the ESC. After the Reverse function is activated, the motor will stop first and then spin in the reversed direction and then increase to the speed corresponding to the throttle input. Either signal loss, no matter reverse brake signal loss or throttle signal loss during the flight, can cause the throttle signal loss protection to be activated. If this function is enabled, the reverse signal cable is not connected to any channel. This function is disabled.

2. Brake Force

This item is adjustable from level 1 to level 7. The higher the level, the stronger the braking effect. It's only effect in the "Normal brake" mode.

3. Voltage Cutoff Type

Soft Cutoff

After selected this option, the ESC will gradually reduce the output to 50% of the full power in 3 seconds after the low-voltage cutoff protection is activated.

Hard Cutoff

After selected this option, the ESC will immediately cut off the output when the low-voltage cutoff protection is activated.

**4. LiPo Cells:** The ESC will automatically calculate the number of LiPo cells you have plugged in as per the "3.7V/Cell" rule if "Auto Calc." is selected, or you can set this item manually.

5. Cutoff Voltage

This item is adjustable from 2.8V to 3.8V (they are the cutoff voltages for one cell), it's 3.0V by default; or you can disable it if necessary.

6. BEC Voltage

This item adjusts the switch-mode BEC output voltage , it can be adjustable among 5.2V, 6.0V and 7.4V.

7. Start-up Mode


Normal Start-up

After selected this option, the motor will immediately start spinning and then quickly reach to the corresponding speed when you move the throttle stick from bottom position to top position.

Soft Start-up

After selected this option, the motor will slowly start spinning and then quickly reach to the corresponding speed when you move the throttle stick from bottom position to top position.

Very Soft Start-up



ESC Programming via the Transmitter (Throttle Stick)

It consists of 4 steps: Enter the programming → Select parameter items → Select parameter values → Exit the programming

I. Enter the Programming

Turn on the transmitter, move the throttle stick to the top position, and connect a battery to the ESC, 2 seconds later, the motor will beep "B-B-" first, then emit 56712 5 seconds later to indicate that you are in the ESC programming mode.

II. Select Parameter Items

After entering the programming, you'll hear the following 12 kinds of beeps circularly. Move the throttle stick to the bottom position within 3 seconds after you hear some kind of beeps, you'll enter the corresponding parameter item.

1. "B-"	Brake Type	(1 Short B)	7. "B——B-B-"	Start-up Mode	(1 Long B & 2 Short Bs)
2. "B-B-"	Brake Force	(2 Short Bs)	8. "B——B-B-B-"	Timing	(1 Long B & 3 Short Bs)
3. "B-B-B-"	Voltage Cutoff Type	(3 Short Bs)	9. "B——B-B-B-B-"	Motor Direction	(1 Long B & 4 Short Bs)
4. "B-B-B-B-"	LiPo Cells	(4 Short Bs)	10. "B——B——"	Freewheeling	(2 Long Bs)
5. "B——"	Cutoff Voltage	(1 Long B)	11. "B——B——B-"	Factory Reset	(2 Long Bs & 1 Short B)
6. "B——B-"	BEC Voltage	(1 Long B & 1 Short B)	12. "B——B——B-B-"	Exit	(2 Long Bs & 2 Short Bs)

Note: A long "B——" equals to 5 short "B-", so a long "B——" and a short "B-" represent the 6th item in "Select Parameter Items".

III. Select Parameter Values

The motor will beep different kinds of beeps circularly, move the throttle stick to the top position after you hear some kind of beeps will get you to the corresponding parameter value, then you'll hear the motor emit "isis" to indicate the value is saved, then get back to "Select

Parameter Items" and continue to select other parameter items that you want to adjust.

Values (Bs)		1	2	3	4	5	6	7	8
Items		B-	B-B-	B-B-B-	B-B-B-B	B——	B——B-	B——B-B-	B——B-B-B-
1	Brake Type	Disabled	Normal	Proportional	Reverse				
2	Brake Force	Disabled	Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Level 7
3	Voltage Cutoff Type	Soft	Hard						
4	LiPo Cells	Auto Calc.	3S	4S	5S	6S	8S		
5	Cutoff Voltage	Disabled	2.8V	3.0V	3.2V	3.4V	3.6V	3.8V	
6	BEC Voltage	5.2V	6.0V	7.4V					
7	Start-up Mode	Normal	Soft	Very Soft					
8	Timing	0°	5°	8°	12°	15°	20°	25°	30 °
9	Motor Direction	CW	CCW						
10	Freewheeling	On	Off						

User Manual of Series Brushless Speed Controller

After selected this option, the motor will slowly (slower than in "Soft Start-up Mode") start spinning and then quickly reach to the corresponding speed when you move the throttle stick from bottom position to top position. We recommend selecting the "Soft Start-up" or "Very Soft Start-up" mode when you're using a big-sized ducted motor.

8. Timing

This item is adjustable from 0 degree to 30 degrees, and it is 15 degrees by default.

9. Motor Rotation

This item allows you to adjust the rotation direction of your motor between CW and CCW, and it is CW by default.

10. Freewheeling (DEO)

This item is adjustable between "Enabled" and "Disabled", and it is enabled by default. With it enabled, you can have better throttle linearity or smoother throttle response.

05 Troubleshooting & Multiple Protections

Troubleshooting			
Troubles	Warning Tones	Causes	Solutions
The ESC didn't work after it was powered on while the motor kept beeping.	"BB, BB, BB....."	The input voltage was beyond the operating voltage range of the ESC.	Adjust the power-on voltage and ensure it's in the operating voltage range of the ESC.
The ESC didn't work after it was powered on while the motor kept beeping.	"B-, B-, B-, B-....."	The ESC didn't receive any throttle signal from the receiver.	Check if the transmitter and receiver are well bound, if any poor connection exists between the ESC and receiver.
The ESC didn't work after it was powered on while the motor kept beeping.	"B, B, B, B, B....."	The throttle stick has not been moved to the bottom position.	Move the throttle stick to the bottom position and calibrate the throttle range.
The ESC didn't work after the throttle calibration while the motor kept beeping.	"B, B, B, B, B....."	The throttle range you set was too narrow.	Re-calibrate the throttle range.
The ESC output suddenly reduced to 50% during the flight, the motor kept beeping after the flight completed but the battery was still connected to the ESC.	"BB, BB, BB....." or "BBBB,BBBB,...."	The ESC thermal protection has been activated	Improve the heat dissipating condition (i.e. add a cooling fan) or reduce the ESC load.
The ESC output suddenly reduced to 50% during the flight, the motor kept beeping after the flight completed but the battery was still connected to the ESC.	"BBB, BBB, BBB....."	The low-voltage cutoff protection has been activated.	Change another pack; lower down the cutoff voltage or disable the LVC protection (we do not recommend this).

Multiple Protections

1. Start-up Protection:

The ESC will monitor the motor speed during the start-up process. When the speed stops increasing or the speed increase is not stable, the ESC will take it as a start-up failure. At that time, if the throttle amount is less than 15%, the ESC will try to restart automatically; if it is larger than 20%, you need to move the throttle stick back to the bottom position first and then restart the ESC. (Possible causes of this problem: poor connection/ disconnection between the ESC and motor wires, propellers are blocked, etc.)

2. ESC Thermal Protection:

The ESC will gradually reduce the output but won't cut it off when the ESC temperature goes above 110°C. For ensuring the motor can still get some power and won't cause crashes, so the maximum reduction is about 50% of the full power. The ESC will gradually resume its maximum power after the temperature lowers down. In addition, the ESC temperature cannot exceed 70°C when it's powered on. Otherwise, it cannot be started up. (Here we are describing the ESC's reaction in soft cutoff mode, while if in hard cutoff mode; it will immediately cut off the power.)

3. Throttle Signal Loss Protection:

When the ESC detects loss of signal for over 0.25 second, it will cut off the output immediately to avoid an even greater loss which may be caused by the continuous high-speed rotation of propellers or rotor blades. The ESC will resume the corresponding output after normal signals are received.

4. Overload Protection:

The ESC will cut off the power/output or automatically restart itself when the load suddenly increases to a very high value. (Possible cause to sudden load increase is that propellers are blocked.)

5. Over-current Protection:

The ESC will cut off the power when the current gets close to the short circuit current. This protection may be activated by the burnt motor or some others.



