

Before commencing assembly, Please read the instruction manual!



www.dynam-rc.com



Specification

● Wingspan:	1 400mm	● Battery:	11.1 v 2200mAh 20C Li-Po
● Fuselage Length:	965mm	● ESC:	40A
● Wing loading:	44g/dm ²	● Motor:	KV:11 00
● Flying weight:	880g		
● Servo:	9gX4		

SR22 *ITS*

INSTRUCTION MANUAL



Warning!

SAFETY PRECAUTIONS

This radio control model is not a toy!

- First-time builders should seek advice from people having building experience in order to assemble the model correctly and to produce its performance to full extent.
- Assemble this kit only in places out of children's reach!
- Take enough safety precautions prior to operating this model. You are responsible for this model's assembly and safe operation!
- Always keep this instruction manual ready at hand for quick reference, even after completing the assembly.

Shen Zhen Dynam Industry & Trade Co.,LTD

TEL:+86-769-87566018 FAX:+86-769-87555185 E-mail:sales@dynam-rc.com

CE 0678 Ⓢ FC 14+

MADE IN CHINA

Safety Precautions

- Never fly the Airplane where there are crowds of people ,power lines overhead, automobiles or near highways. give yourself plenty of room for flying, as the plane can travel at a high rate of speed. Remember you are responsible for the safety of others.
- Do not fly in strong winds.
- Do not attempt to catch the Airplane while flying.
- Children under the age of 16 should not have admission to the transmitter for the plane.
- Never leave this system unattended, with the batteries in the unit and around children. Injury can result by children turning on the transmitter or the plane.
- Keep away from the propeller at all times. The system can automatically start when the batteries are plugged in, regardless if the transmitter is in the on or off position. The propeller can cause injury!
- Before flying, always remember to turn on the transmitter first, before plugging in the battery pack. Stay clear of propeller.
- Always turn the speed controller all the way down and the switch on “OFF”.(left control stick in the down position) before starting; otherwise the propeller will start on full power when you plug the battery into the plane.
- After running the motor, disconnect the battery first before turning off the transmitter, otherwise the propeller may start at full power.
- Never leave the charger or battery near wet areas.
- Completely discharging a Li-poly battery can result in permanent damage to the cells of the battery. Therefore you must always remember to disconnect the battery after using the plane.

BEFORE YOU BEGIN

- Read through the manual before you begin, so you will have an overall idea of what to do.
- Check all parts. If you find any defective or missing parts contact your local dealer. Please DRY FIT and check for defects for all parts that will require CA or Epoxy for final assembly. Any parts you find to be defective after the gluing process may be difficult to remove for warranty replacement. The manufacturer will replace any defective parts, but will be difficult to extend to the good parts that are good before bluing to defective parts during assembly.
- Symbols used throughout this instruction manual comprise of following:



Apply epoxy glue



Assemble left and right sides the same way.



Pay close attention here!



Pliers



Ensure smooth non-binding movement while assembling.



Cut off shaded portion


RTF INCLUDING



RTF including: _____

- fuselage
- wing
- elevator
- landing gear
- Landing pole
- plastic parts set
- push rod
- glue
- decal
- balance charger
- LI-Po battery (11.1V 2200mAh 20C)
- transmitter
- Adaptor
- Propeller
- ESC

Assembly



- 1** As shown, coated adhesive foam rubber in the horizontal tail Office.



- 2** As shown, horizontal tail position in the corresponding bonding fuselage.



- 3** As shown, the rudder rod penetration quick connector, tighten with a screwdriver.

Indicate: this time steering the Huizhong state.




- 4** As shown, the elevator rod penetration quick connector, tighten with a screwdriver.

Indicate: this time steering the Huizhong state.




- 5** Z-end of the rod will turn into plastic pieces shown in the figure.



- 6** Fixed front wheel steering with PA2.5X6.

Assembly



- 7** The front wheel steering rod into quick connector fastened with a screwdriver.

Indicate: this time steering the Huizhong state.



- 8** As shown, Tear up the surface layer of the double-sided adhesive.



- 9** As shown, Install hood in the fuselage.



- 10** As shown in the installation of 9060 Clover paddle.




- 11** Phillips screwdriver fastening fairing.



- 12** As shown, Body antenna installation.

Assembly




13 Apply rubber cement to left and right wing halves



14 As shown, Left and right wing bonding.



15 As shown, Installation of plastic parts in the position of the wing mark.



16 As shown, Landing gear screws around with PA2.5X6.



17 As shown, The aileron cable with Y-cable



18 As shown, Installation of wing and fuselage, tighten with a screwdriver.




STICK OPERATION

MODE 1




MODE 2

MOVEMENT




THROTTLE






RUDDER



ELEVATOR





AILERONS




CG And Receiver Assembling


The ideal C.G. position is 30~35mm behind the leading edge measured at where the wing meets the fuselage. In order to obtain the C.G. specified, add weight to the fuselage or move the battery position. Check the C.G. before flying.




SUGGEST CONTROL THROW SETTING




ELEVATOR




AILERON



RUDDER



Decal




Battery Warning And Charging

Lithium-polymer batteries are a revolutionary new rechargeable battery technology for electric R/C flight, offering a variety of significant advantages over NiCd, NiMH and Li-Ion batteries. It is very important to have a good understanding of the operating characteristics of Li-Po batteries especially their exact rated voltage. Always read the specifications printed on the label of your Li-Po battery prior to use, and read this instruction sheet in its entirety.

WARNING! Lithium-Polymer batteries (Li-Po) are entirely different than NiCd and NiMH batteries and must be handled differently as well!! Failure to follow these care and handling instructions can quickly result in severe, permanent damage to the batteries and its surroundings and even start a FIRE!

- You must charge the Li-Po battery pack in a safe area away from flammable materials.
- Never charge the battery unattended. When charging the battery you should always remain in constant observation to monitor the charging process and react to potential problems that may occur.
- After flight, the battery cool down to ambient temperature before charging.
- Wire lead shorts can cause fire! If you accidentally short the wires, the battery must be placed in a safe area for observation for approximately 15 minutes.




- In the event of a crash, you must quickly and safely disconnect and remove the battery from observation, then place it in a safe, open area away from flammable materials to observe it for at least 15 minutes.
- Store the battery at room temperature for best results.
- Do not over-discharge the battery. Discharging the battery too low can cause damage to the pack resulting in reduced performance and duration.

Battery Warning And Charging

The charger requires up to 1.5 Amps of 10-15 Volt DC input power that can be supplied from a small 12V gel cell or car battery.




Input power for the charger can also be supplied through the use of an AC to DC adapter/power supply for convenient charging anywhere an AC outlet is available. We recommend the optional AC to 12V DC, 1.5 Amp Power Supply. **NEVER attempt to power the charger from an AC outlet without the use of a proper AC to DC adapter/power supply.**



Battery Warning And Charging

Once you have connected the charger to a power source, The red LED will turn on. Connect the Li-Po battery pack to the charger. When the pack is full charged. The green LED will turn on.




Install the Transmitter Batteries


Install 8 new "AA" batteries in the included transmitter. Check the power level of the batteries and operation of the transmitter by switching the power switch on (upward). The status LEDs at the top of the transmitter will indicate the power level of the batteries. If at any time the status LEDs no longer show green, it will be necessary to replace the batteries with new ones.



Parts List




SR22-01 Fuselage



SR22-02 wing



SR22-03 Canopy




SR22-04 Elevator




SR22-05 clean Blister




SR22-06 Propeller




DYM-0010 Brushless Motor




SR22-07 Plastic Part set



SR22-08 Landing gear



SR22-9 Landing Wheel




SR22-10 Fairing



SR22-11 push rod



DY-3001 quick-controller



DY-1007 9g Servo



DYA-000X Adaptor




DYE-1002 Balance Charger




DY-6006 11.1V 2200mAh 20C Li-Po Battery



DYT-2002 Transmitter




DY-3003 Glue



DYE-1004 40A ESC



DYR-2001 Receiver



DYAT-008 Servo horn



SR22-12 DECAL

visit our website
www.dynam-rc.com



HIGH QUALITY RC PRODUCTS

WWW.DYNAM-RC.COM
SALES: SALES@DYNAM-RC.COM
OEM PRODUCTS: OEM@DYNAM-RC.COM



GYRO

HOME | PRODUCTS | ABOUT US | NEWS | CONTACT US | DOWNLOAD

PRODUCTS

RC AIRPLANE

RC HELICOPTER

RC SYSTEM

SERVO

ESC

RECEIVER

BATTERY&CHARGER

ACCESSORIES

CRYSTAL

SIMULATOR

MOTOR

BLADE

**2009
CATALOG**

Dynam product list

NEWS

Airplane: SpitFire

HELI: E-RAZOR 450

HELI: Orbiter

HELI: Bell 47g

Airplane: Cessna EP

2 of 7



**2.4GHz
Radio Control System**

<p style="text-align: center;">SKYBUS</p> <p style="font-size: 0.8em;">NEW</p>  <p style="font-size: 0.7em;">Wingspan:1470mm Length:960mm Wing loading:48.8g/dm2 Flying weight:1200g Servo:9g*4 Battery:11.1V 2200mAh 15C</p>	<p style="text-align: center;">F-16</p> <p style="font-size: 0.8em;">NEW</p>  <p style="font-size: 0.7em;">Wingspan:670mm Fuselage length:1020mm Wing loading:47g/dm2 Flying weight:650g Servo:9g Battery:11.1V 2200mAh 15C ESC:60A</p>
<p style="text-align: center;">E-RAZOR 450 (B)</p>  <p style="font-size: 0.7em;">Length: 655mm Gross Weight:670g Main rotor diameter: 720mm Tail rotor diameter: 135mm Motor: Brushless 2750KV Battery:11.1V 2200mAh Li-Po Transmitter: FM 6-Channel</p>	<p style="text-align: center;">E-RAZOR 250</p>  <p style="font-size: 0.7em;">Length: 420mm Height:161mm Main rotor diameter: 438mm Tail rotor diameter: 105mm Motor: Brushless 4800KV Battery:7.4V 850mAh Li-Po</p>
<p style="text-align: center;">E-RAZOR 500</p>  <p style="font-size: 0.7em;">Main rotor diameter:951.5mm Tail rotor diameter:191mm motor: 800KV, 1100W Mainblade size:430mm FRP included</p>	<p style="text-align: center;">Radio Control System</p>  <p style="font-size: 1.2em; text-align: center;">2.4GHz</p> <p style="text-align: center;">4ch 6ch Radio</p>

- TEL:+86-769-87566018 • E-mail:sales@dynam-rc.cn
- FAX:+86-769-87555185 • Http:www.dynam-rc.com
- Add:No.C-02 Nanshan Industry Town Yantian Fenggang
City Dongguan Guangdong Province

Shen Zhen Dynam Industry & Trade co., Ltd