CRCN CRCA zCI RCR RCRO RCRO RCR RCR m RCI m RG om R com RCRCM.con



RCM.com RCRCIII.com RCM.com RCRCM.com RCRC RCRCM.com RCRCM.com RCRCM.com CRCM.com RCRCM.com RCRC Instruction Manual RCRCM.com RCR CCM.com RCRCM.com RCR CM.com RCR .com RCI .com RC n.com RC n.com RG n.com R M.com R M.com F **M**.com com I com cm CM.com

RCM.com RCRCM

om 🔼

RCM.com RCRCM

zcm

RCM

- RCRCM.com RCRCM Please unpack the plane carefully making sure that you have retrieved all of the small parts. com RCRCM.com RG RCRCM.com RCI
- Don't throw the box out until you are 100% sure it's empty!" Check that all the parts are supplied.
- **M**.com
- RCRCM.com RCRCM If any are missing please contact your vendor immediately.com **M**.com CM.com RCRCM.com RCRCM.com RCRCM.com





Wings

TWO WAYS TO INSTALL THE AILERON SERVOS

INTO THE FUSELAJE WITH PUSH ROD INSIDE USING INTERNAL CONTROL WING HORNS







ZC

for the aileron control horns use iron rod like the picrture show and bronce tube at the end.

1

make the pushrod using 3 mm carbon tube and iron rod





for the aileron control horns use iron rod like the picrture show make the pushrod using 2 mm carbon tube and iron rod

CM.com RCRCM.com RCRCM.com RCRCM.com RCRCM CM.com RCRCM.com RCRCM.



ELEVATOR AND RUDDER





ZCRCI

la

.com

RCRCM.com

RCI


RC

Using the 0.4mm push rod wire up 2 staple-shaped torsion springs

CUT THE ELEVATOR AND RUDDER FLAPS AS SHOWN ON THE PHOTOS USING ONE SIDE LIKE HINGE



CUT AND GLUE THE RUDDER SUPPORT AS SHOWN IN THE PHOTOS AND AFTER THAT, JOIN IT THE RUDDER AL FUSELAGE



m.com