



PEACOCK



PALE HONEY



Fearne

by Swan

3-IN-1

STICK BLENDER

CARE & USE INSTRUCTIONS

Model: SP21040 (all colours)



FEATURING
TEN DELICIOUS FAVOURITES



We love what we do



We're proud of our quality

TRUFFLE

www.fearnebyswan.co.uk



LILY





“I love making my own dips and hummus at home as well as vegetable mash and energy balls. All made so much easier with this incredible processor.

I love knowing what’s gone into my food so prepping as much as I can at home is important to me.”

“food processors are genius because they do so many jobs ... fast”
Feame

PEACOCK

PALE
HONEY

Fearne
by Swan

3-IN-1 STICK BLENDER CARE & USE INSTRUCTIONS

IMPORTANT SAFEGUARDS	04
WHAT'S IN THE BOX	05
HOW TO USE	06
CLEANING & MAINTENANCE	07
WARRANTY	08
BS PLUG	08
TECHNICAL INFORMATION	09
SPARE PARTS	09
DELICIOUS FAVOURITES	10
AFFIX YOUR RECEIPT	22
DISPOSAL OF THE PRODUCT	22

TRUFFLE

LILY



IMPORTANT SAFEGUARDS

When using your Fearne by Swan 3-in-1 stick blender especially when children are present, basic safety precautions should always be followed, including the following:

1. Read all instructions before using.
2. To protect against electrical shock, do not submerge the mixer or allow the AC cord or plug to come in contact with water or other liquids.
3. Unplug the appliance when not in use.
4. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
5. Do not use outdoors.
6. Do not let the cord hang over the edge of the table/counter or touch hot surfaces.
7. Always unplug the appliance before assembling, disassembling and cleaning the accessories.
8. Before plugging into a socket, check whether your voltage corresponds to the rating label of the appliance.
9. Don't plug the appliance into the power supply until it is fully assembled and always unplug before disassembling the appliance or handling the blade.
10. The appliance is constructed to process normal household quantities.
11. Short-time operating. Don't use the blender stick longer than 1 minute, and don't operate hard food longer than 10 seconds.
12. Always disconnect the appliance from the supply if it's left unattended.
13. Please handle with care to avoid injury, never misuse the appliance.
14. Please handle carefully cutting blades are sharp.
15. Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.





16. Keep hands and utensils out of the container while blending. A scraper may be used but must be used only when the unit is not running.
17. This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
18. The appliance should be cooled down to room temperature after each process.

WHAT'S IN THE BOX

- | | | |
|------------------------------------|-------------------------|------------------------------------|
| 1. Speed control dial | 6. Whisk holder | 11. Bowl slip mat / lid |
| 2. Low / variable speed switch (I) | 7. Whisk | 12. Cup slip mat / lid |
| 3. High speed switch (II) | 8. Chopping bowl lid | 13. Tall blending cup (max. 800ml) |
| 4. Motor unit | 9. Chopping blade | |
| 5. Blend head | 10. 500ml chopping bowl | |





HOW TO USE THE STICK BLENDER

The stick blender is perfectly suited for preparing dips, sauces, soups, mayonnaise and baby food as well as for mixing and milkshakes.

1. Turn the blender stick on the motor unit until it locks.
2. Introduce the hand blender in the vessel, and then press the switch (I) to operate it.
3. Don't use the hand blender longer than 1 minute.
4. **Caution:** The blade is very sharp.
5. **Caution:** Don't operate food without water.

HOW TO USE THE WHISK

Use the whisk only for whipping cream, beating egg whites and mixing sponges and Ready-mix desserts.

6. Inset the whisk into the whisk holder, and then turn the gear box on the motor unit until it locks.
7. Place the whisk in a vessel and then press the switch (I) to operate it.
8. Don't use the whisk longer than 2 minutes.

HOW TO USE THE CHOPPER

1. Chopper is perfectly suited for hard food, such as chopping meat, cheese, onion, herbs, garlic, carrots, walnuts, almonds, prunes etc.
2. Don't chop extremely hard food, such as ice cubes, nutmeg, coffee beans and grains.

Before chopping...

1. Carefully remove the plastic cover from the blade. Caution: the blade is very sharp! Always hold it by the upper plastic part.
2. Place the blade on the centre pin of the chopper bowl. Press down the blade and lock bowl. Always place the chopper bowl on the anti-slip base.
3. Place the food in the chopper bowl.
4. Place the chopping bowl lid on the chopper bowl.
5. Turn the motor unit on the chopping bowl lid until it locks.





6. Then press switch (I) to operate the chopper. During the processing, hold the motor unit with one hand and the chopper bowl with the other.
7. After use, turn the motor unit off the chopping bowl lid.

PROCESSING GUIDE

Food	Max	Running times	Prep	Speed
Meat	250g	15-20 Seconds	1~2cm	II
Nuts	100g	15-20 Seconds	/	II
Cheese	100g	15-20 Seconds	1~2cm	II
Bread	80g	8 Seconds	1~2cm	II
Onions	150g	8 Seconds	1~2cm	II
Biscuits	150g	8 Seconds	1~2cm	II
Flour	300g	10 seconds	/	II
Water	180g	10 seconds	/	II
Barm	8g	10 seconds	/	II
Sugar	8g	10 seconds	/	II
Salt	8g	10 seconds	/	II

CLEANING & MAINTENANCE

Cleaning the motor unit and chopping bowl lid with a damp cloth only. Do not immerse the motor unit in water.

1. Always unplug the appliance before cleaning.
2. All other parts can be cleaned in the dishwasher. However, after processing very salty food, you should rinse the blades right away.
3. When processing food with colour, the plastic parts of the appliance may become discoloured, wipe these parts with vegetable oil before placing them in the dishwasher.
4. The blades are very sharp, handle with care.



2 YEAR WARRANTY

This product is guaranteed for 2 years from the date of original purchase. If any defect arises due to faulty materials of workmanship the faulty products must be returned to the place of purchase. Refunds or replacement is at the discretion of the store.

The following conditions apply:

1. The product must be returned to the retailer with proof of purchase.
2. The product must be installed and used in accordance with the instructions contained in this instruction guide.
3. It must be used only for domestic purposes.
4. It does not cover wear and tear, damage, misuse or consumable parts.
5. Swan Products Ltd has limited liability for incidental or consequential loss or damage.
6. This guarantee is valid in the UK and Eire Only.



BS PLUG

The wires in the mains lead are coloured in accordance with the following code:

BLUE.....NEUTRAL
 BROWN.....LIVE

As the colours of the wire in the mains lead of this appliance may not correspond with the colour markings identifying the terminals on your plug, proceed as follows:

The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured red.

WARNING: DO NOT CONNECT ANY WIRE TO THE EARTH (E) TERMINAL





TECHNICAL INFORMATION

Model: SP21040
 220-240V ~50Hz 800W
 Distributed by Swan Products Ltd,
 PO Box 3117, Stoke-on-Trent,
 ST4 9GD
 © 2017 Swan Products Ltd
 Made in China

SPARE PARTS

When ordering spare parts, please use the references below:

Part No:	Description:
SP21040HON005	Blend head (Pale honey)
SP21040LYN005	Blend head (Lily)
SP21040PKN005	Blend head (Peacock)
SP21040TEN005	Blend head (Truffle)
SP21040HON006	Whisk holder (Pale honey)
SP21040LYN006	Whisk holder (Lily)
SP21040PKN006	Whisk holder (Peacock)
SP21040TEN006	Whisk holder (Truffle)
SP21040N007	Whisk
SP21040HON008	Chopping bowl lid (Pale honey)
SP21040LYN008	Chopping bowl lid (Lily)
SP21040PKN008	Chopping bowl lid (Peacock)
SP21040TEN008	Chopping bowl lid (Truffle)
SP21040N009	Chopping blade
SP21040N010	500ml chopping bowl
SP21040HON011	Bowl slip mat/lid (Pale honey)
SP21040LYN011	Bowl slip mat/lid (Lily)
SP21040PKN011	Bowl slip mat/lid (Peacock)
SP21040TEN011	Bowl slip mat/lid (Truffle)
SP21040HON012	Cup slip mat/lid (Pale honey)
SP21040LYN012	Cup slip mat/lid (Lily)
SP21040PKN012	Cup slip mat/lid (Peacock)
SP21040TEN012	Cup slip mat/lid (Truffle)
SP21040N013	Tall blending cup



“I get loads out of making food! The whole process brings me joy. From chopping, mixing, just that whole lovely cathartic process and then the best bit, eating it.”

Fearne





TEN

DELICIOUS FAVOURITES

Simple & easy to make recipes to help get you started.

CASHEW AND PECAN BUTTER	12
BETROOT DIP WITH CARROT AND RED PEPPER	13
SWEET POTATO HUMMUS	14
LENTIL WINTER WARMER SOUP	15
CORN FRITTERS WITH HONEY YOGHURT	16
SPELT AND SEED LOAF	17
NUT & SEED ENERGY BAR	18
BANANA BREAD	19
CHOCOLATE AND ALMOND CAKE	20
BLUEBERRY SCONES	21

FOR MORE INSPIRATION
AND ALL THINGS FEARNE, GO TO:

www.fearnebyswan.co.uk

BAKE HAPPY WITH FEARNE ONLINE:





MAKES 1 JAR OF 240g

CASHEW AND PECAN BUTTER

INGREDIENTS

150g raw unsalted cashew nuts
100g raw pecan nuts
Sea salt

PREP TIME: 10 MINS
PLUS COOLING TIME

METHOD

Preheat the oven to 180°C / 160°C fan / 350°F / gas mark 4.

Spread the nuts out on a baking tray and roast in the oven for 6-7 minutes, or until a shade darker and aromatic, taking care not to let them burn. Once roasted, remove the nuts and leave to cool completely.

Add the cooled nuts into the Fearnby by Swan food processor and blitz until the nuts transform into a creamy smooth butter. Depending on the strength of your processor, this can take anything from 3 – 6 minutes, as the natural oils within the nuts slowly release, aiding the process. Add in a good pinch of salt to taste and blitz to combine.

Transfer to an airtight container.





SERVES 4

BEETROOT DIP WITH CARROT AND RED PEPPER

INGREDIENTS

5 raw beetroot
3 tbsp Greek or soy yoghurt
2 tbsp tahini
Juice and zest of half a lemon
2 tbsp extra virgin olive oil,
plus more to serve
1 tsp fresh thyme leaves
Sea salt and pepper
1 tbsp coriander leaves,
to serve
Carrot and red pepper batons,
to serve

PREP TIME: 15 MINS

COOKING TIME: 60 MINS

METHOD

Preheat the oven to 200°C / 180°C fan / gas mark 6.

Wrap the beetroot in foil and roast for 50 - 60 minutes until completely tender. Remove, peel off the skin and leave to cool completely.

Add the cooled beetroot to the Fearnby by Swan food processor together with the yoghurt, tahini, lemon zest and juice, olive oil and thyme and blitz until smooth. Season to taste with salt and pepper. Thin with one tablespoon of water at a time until you reach your desired consistency.

Serve with the coriander leaves and olive oil drizzled over and the carrot and red pepper batons to dip into.





SERVES 4

SWEET POTATO HUMMUS

INGREDIENTS

1 large sweet potato
1 x 400g tin chickpeas, drained and rinsed
2 garlic cloves, peeled
100g tahini
Zest and juice of half a lemon
3 tbsp extra virgin olive oil, plus extra to drizzle over
½ tsp ground cumin, plus extra to sprinkle over
½ tsp ground coriander
1 tsp sea salt
1 tbsp flat leaf parsley leaves, roughly chopped

PREP TIME: 15 MINS

COOKING TIME: 45 MINS

METHOD

Preheat the oven to 200°C / 180°C fan / gas mark 6.

Wrap the sweet potato in foil and roast for 40 – 50 minutes until completely tender. Remove, cut in half lengthways, scoop out the flesh and leave to cool completely. Discard the skin.

In the Fearn by Swan food processor blitz together the sweet potato flesh and the remaining ingredients, apart from the parsley, until completely smooth. Thin with one tablespoon of water at a time until you reach your desired consistency.

Taste and adjust the seasoning if necessary with a little more salt. Serve in a bowl with a little ground cumin and parsley scattered over and some olive oil drizzled on top.





SERVES 4

LENTIL WINTER WARMER SOUP

INGREDIENTS

1 tbsp olive oil
2 onions, finely chopped
2 tsp ground cumin
4 garlic cloves, crushed
1 litre vegetable stock
2 potatoes, diced
1 carrot, peeled and diced
200g baby plum tomatoes
120g red lentils
Sea salt and pepper
1 tbsp extra virgin olive oil
1 tbsp flat leaf parsley,
roughly chopped

PREP TIME: 10 MINS

COOKING TIME: 40 MINS

METHOD

Put the oil into a large pot set over a medium heat. Add in the onion and cumin and sauté for 5 minutes. Add in the garlic and sweat out for another 5 minutes until the onion is translucent. Season well with salt and pepper.

Add in the stock, potato, carrot, tomatoes and lentils and bring to a boil. Skim off any foam that rises to the surface. Reduce the heat and simmer for 30 - 35 minutes until the vegetables and lentils are cooked through. Taste and adjust the seasoning with salt and pepper if necessary. This will depend on the quantity of salt in the vegetable stock you used, so make sure to add a little at a time, tasting as you go.

Using the Fearnby by Swan 3-in-1 stick blender, process the soup until completely smooth. Divide between bowls, drizzle over a little extra virgin olive oil and scatter with parsley.

Serve immediately with flaked almonds and a little sea salt.





MAKES 16

CORN FRITTERS WITH HONEY YOGHURT

INGREDIENTS

120g white spelt flour
½ tsp baking powder
100ml milk
1 egg, lightly beaten
100g onion, very finely chopped
400g corn, drained and rinsed
15g parsley, finely chopped
20g mint, finely chopped
1.5 tsp ground cumin
Sea salt and pepper
Olive or vegetable oil to fry
250g Greek yoghurt
2 tbsp honey

PREP TIME: 15 MINS

COOKING TIME: 10 MINS

METHOD

Place the flour and baking powder in a large bowl, using either the Fearnby by Swan hand mixer or stand mixer slowly whisk in the milk and beaten egg, until well combined with no lumps. Add in the onion, corn, parsley, half the chopped mint, ground cumin, 1 tsp sea salt and a few grindings of black pepper. Stir everything together to combine.

Place 1 tbsp of olive or vegetable oil in a large, non-stick frying pan and set over a medium-high heat. Once hot, add on 2 level tbsp's of batter for each fritter and flatten into little rounds. Fry in batches, without over crowding the pan, for about 3 minutes on each side, until they are golden brown and cooked through.

Combine together the yoghurt, honey and remaining mint and season with salt and pepper. Plate up a little stack of fritters (about 4 per person) and serve with the yoghurt on the side for dipping into.





SERVES 8 - 10

SPELT AND SEED LOAF

INGREDIENTS

500g wholegrain spelt flour
1 tsp baking powder
1 tsp bicarbonate of soda
1 tsp sea salt
100g sunflower seeds
20g chia seeds
60g raisins
1 tbs maple syrup
550ml tepid water

PREP TIME: 5 MINS

COOKING TIME: 60 MINS

METHOD

Preheat the oven to 200°C / 180°C fan / 400°F / gas mark 6. Lightly grease a 1kg loaf tin and line with baking parchment.

Add all the dry ingredients to the bowl of the Fearne by Swan stand mixer fitted with a dough hook, and mix everything together on a low speed. Add in the maple syrup and water and mix on a slightly higher speed until just combined.

Pour into the loaf tin and bake in the oven for 50 minutes, then carefully remove the loaf from its tin and continue to bake for a further 10 minutes.

Remove the loaf from the oven and leave to cool. Once cool cut into slices and enjoy with butter or coconut oil and jam.





SERVES 8 - 10

NUT & SEED ENERGY BAR

INGREDIENTS

300g dark chocolate, min 70%
130g jumbo oats
130g raw cashew nuts
200g pitted dates
4 tbsp brown rice syrup
60g almond, cashew
or peanut butter
3 tbsp pumpkin seeds
3 tbsp sunflower seeds
2 tbsp linseeds
3 tbsp coconut oil, melted

EQUIPMENT

24cm x 16cm baking tray
or Tupperware box, lined
with cling film.

PREP TIME: 15 MINS
PLUS COOLING TIME

METHOD

Preheat the oven to 180°C / 160°C fan / 350°F / gas mark 4.

Roast the oats and cashew nuts for 8 – 10 minutes until a shade darker and aromatic. Remove and leave to cool completely.

Place the dates, brown rice syrup and almond butter into the Fearne by Swan food processor and process down to a paste.

Add in the oats, cashew nuts, seeds and melted coconut oil and pulse on and off until the nuts and seeds are roughly chopped and all the mixture has come together.

Transfer the mixture to the lined baking tray and flatten out with the back of a wet spoon until well compacted and smooth. Cover and refrigerate for 2 hours or until very well chilled.

When ready to serve, slice into bars. Store in an airtight container for up to a week.





SERVES 8 - 10

BANANA BREAD

INGREDIENTS

120g coconut oil or unsalted butter, at room temperature
200g coconut palm sugar
2 eggs, beaten
4 very ripe bananas, peeled and mashed with a fork
2 tbsp rice milk
350g white or wholegrain spelt flour
½ tsp fine sea salt
1 tsp baking powder
1 tsp bicarbonate of soda
60g walnuts, roughly chopped

PREP TIME: 15 MINS

COOKING TIME: 70 MINS

METHOD

Preheat the oven to 180°C / 160°C fan / 350°F / gas mark 4. Grease a 20cm x 10cm loaf tin and line with baking parchment.

In the bowl of the Fearne by Swan stand mixer fitted with a paddle beater, cream together the coconut oil or butter and sugar until light and fluffy, then gradually beat in the eggs, mashed banana and milk until well combined.

In another bowl combine together the remaining ingredients. Gradually mix this in, until it has just come together.

Transfer the mixture to the lined loaf tin and bake for about 55-65 minutes, until a skewer comes out clean. If the top is browning too quickly, cover with tinfoil. Cool in the tin for 10 minutes, then turn out onto a wire rack to cool completely. Serve in slices as it is, or with a little butter.





SERVES 12

CHOCOLATE AND ALMOND CAKE

INGREDIENTS

300g dark chocolate, min 70% cocoa solids
225g coconut oil or unsalted butter
100g pitted medjool dates
6 eggs
100g ground almonds
200g coconut palm sugar
1 tsp vanilla extract
¼ tsp sea salt, plus extra to serve
Cocoa powder to dust
2 tbsp flaked almonds

PREP TIME: 15 MINS

COOKING TIME: 45 MINS

METHOD

Preheat the oven to 160°C / 140°C fan / gas mark 3 and grease and line a 22cm round spring form tin.

Melt 250g of the chocolate and coconut oil or butter in a heatproof bowl over barely simmering water.

Meanwhile, add the medjool dates and 2 of the eggs to the Fearnby Swan food processor and blitz until the dates are very finely chopped, transfer to the bowl of the Fearnby Swan stand mixer with a whisk attachment.

Whisk in the remaining 4 eggs, ground almonds, coconut palm sugar, vanilla and salt. Increase the speed to high and whisk in the melted chocolate and coconut oil until everything has come together, resulting in a thick, shiny mixture.

Pour the mixture into the cake tin and bake for 35-45 minutes, or until the cake is set but with a little wobble in the centre. Cover with foil if the top is browning too quickly. Leave the cake to cool completely, then remove from the tin.

To serve, dust the cake with cocoa powder and sprinkle over the flaked almonds and a little sea salt.





MAKES 8 - 10

BLUEBERRY SCONES

INGREDIENTS

350g white spelt flour, plus extra for rolling
½ tsp sea salt
1 tsp baking powder
1 tsp bicarbonate of soda
90g coconut oil
or unsalted butter
150g blueberries
50ml maple syrup
120ml rice milk
½ tsp apple cider vinegar
1 tsp vanilla extract
1 egg, beaten

TO SERVE

Salted butter or coconut oil
Jam or almond butter

EQUIPMENT

5cm plain or fluted pastry cutter

PREP TIME: 15 MINS

METHOD

Preheat the oven to 220°C / 200°C fan / gas mark 7 and line a baking tray with parchment paper.

In a bowl combine together the flour, salt, baking powder and bicarbonate of soda. Rub in the butter or coconut oil until it looks like breadcrumbs. Stir in the blueberries.

In a separate bowl combine together the maple syrup, rice milk, apple cider vinegar and vanilla extract. Add the dry and wet mixture to the Fearne by Swan stand mixer fitted with a dough hook and combine together quickly. Bring the dough together into a ball using your hands.

Turn the dough out onto a heavily floured work surface and roll or pat out (with floured hands) to a thickness of about 4cm. Dip the pastry cutter into flour and stamp out as many scones as possible. Gather up the remaining dough, roll out again and stamp out the remaining scones, you should have 8-10. Arrange on the baking tray, brush the tops with beaten egg and place in the centre of the oven, bake for 15 - 18 minutes until golden brown in colour and a skewer comes out clean. Cover with foil if browning too quickly.

Remove to a wire rack and leave to cool a little. Serve warm with your favourite jam, almond butter and some coconut oil or butter. Store in an airtight container and consume within 2 days.

Fearne By Swan 21





NOTES

Lined area for handwritten notes.

AFFIX
**YOUR
RECEIPT
HERE**

Affix your store receipt
for safe keeping.



We love
what we do



We're proud
of our quality



The device complies with the European Directives 2014/35/EU, 2014/30/EU and 2009/125/EC.



At the end of its service life, this product may not be disposed of in the normal household waste, but rather must be disposed of at a collection point for recycling electrical and electronic devices. The materials are recyclable according to their labelling. You make an important contribution to protecting our environment by reusing, recycling or utilising old devices in other ways. Please ask the municipal administration where the appropriate disposal facility is located.





FOR MORE INSPIRATION
AND ALL THINGS FEARNE, GO TO:

www.fearnebyswan.co.uk



BAKE HAPPY WITH FEARNE ONLINE:



