

BWC Manager ***Operation Guide***

R2.0_V2.0



Contents

Preface	1
1. Overview	2
1.1 Introduction.....	2
1.2 Homepage	3
1.3 Preparations.....	4
1.3.1 Install the Tool	4
1.3.2 Connect BWC	5
2. Main Operations.....	6
2.1 Operation Flow	6
2.2 Login	6
2.3 Manage a BWC	7
2.3.1 Read Device Configurations	7
2.3.2 Edit Device Configurations.....	8
2.3.3 Program Device Configurations	8
2.4 Batch Setting	9
2.4.1 Edit Device Information	9
2.4.2 Import Device Information	9
2.4.3 Edit Device Parameters.....	10
2.4.4 Program Device Configurations	10
2.5 Exit.....	11
3. Other Operations.....	12
3.1 Manage Template.....	12
3.1.1 Save Template.....	12
3.1.2 Import Template.....	12
3.2 Password Management.....	12
3.2.1 Retrieve Password.....	12
3.2.2 Change Password.....	12
3.3 Manage BWC Disk	14
3.3.1 Format Disk	14
3.3.2 Switch to Disk Mode	14
3.4 Upgrade Firmware	15
3.5 Factory Reset.....	15
3.5.1 Reset a Device	15
3.5.2 Reset Multiple Devices	15
3.6 View Version	16
3.7 Set Language.....	16




3.8 View Help	16
4. Appendix	17
4.1 Device Information Description	17
4.2 Device Parameters Description	17
4.3 Edit Permission of Device Parameters	20
Abbreviation	22

Preface

This chapter introduces the conventions and revision history of this document

Documentation Conventions

Icon Conventions

Icon	Description
 Tip	Information that helps you make better use of your product.
 Note	References that further describes the related topics.
 Caution	Situations that could cause data loss or equipment damage.

Notation Conventions

Notation	Description
“ ”	The quotation marks enclose the name of a software interface element. For example, click “OK”.
Bold	The text in boldface denotes the name of a hardware button. For example, press the PTT key.
->	The symbol directs you to access a multi-level menu. For example, to select “New” from the “File” menu, we will describe it as follows: “File -> New”.


Revision History

Version	Release Date	Description
R2.0	Aug, 2018	Update
R1.0	Aug, 2017	Initial release

1. Overview

1.1 Introduction


The BWC (Body Worn Camera) Manager is the PC software designed to manage BWCs. It enables users to read, edit and program the device configurations and upgrade firmware. Besides, it can configure BWCs by batch and supports template management to improve work efficiency.



Users only need to install the tool on the PC, and connect BWCs via data cable or hub, then use it to manage BWCs.

1.2 Homepage

The figure below shows the homepage.



Area	Description
1. Device List	<ul style="list-style-type: none"> ● Display the device number and user name; click the user name to view configurations. ● Format disk, switch disk mode and upgrade firmware ● Display the menu Batch Setting while connecting multiple BWCs to realize unified management.
2. Device Information	View and edit user name and ID, unit name and ID.
3. Device Parameters	<ul style="list-style-type: none"> ● View and edit device parameters, such as Screen Off Time, Pre-record Time, Post-record Time, resolution. ● Import and save template, reset to factory defaults.
4. Read/Program	<ul style="list-style-type: none"> ● Read: read configurations from BWC. ● Program: program configurations to BWC.
5. Menu Bar	View software version, set interface language and change password.

1.3 Preparations

1.3.1 Install the Tool


Currently the tool supports the following operating systems including Windows 7, Windows 8 and Windows 10.

This part takes the Windows 7 operating system as an example to simply introduce the installation steps.


After obtaining the installation package, please install the driver and software according to the installation wizard.

Step 1 Choose the language and continue.


Step 2 Select “I accept the terms of the license agreement” and click **Next**.



Step 3 The tool is installed in the C disk by default, click **Change** to change the installation path if necessary, and then click **Next**.



Step 4 Click **Install**, and the tool automatically starts installation.



Caution

During installing, if the tip dialogue box of driver installation pops up, please choose to install the driver, otherwise the tool cannot be used.

1.3.2 Connect BWC


Power on the BWC and connect it to the PC via data cable. You can use hub to connect multiple BWCs if necessary. When the BWC successfully connects to the PC, its screen shows “programming mode”.

Note

You can also purchase the multi-unit charger to connect multiple BWCs.

2. Main Operations

2.1 Operation Flow



Note

- Each BWC has two default user accounts: Admin and User. This chapter takes the Admin as an example to introduce the main operations of the tool.
- Both the Admin and User can manage single BWC. Only the Admin can manage multiple BWCs by **Batch Setting**.
- The configurations include device information and device parameters.

2.2 Login

Before login, please confirm that BWC has successfully connected to the PC, see [1.3.2 Connect BWC](#).


Step 1 Run the BWC Manager.

Step 2 Choose the Admin account and enter password.

Note

The default passwords of both the Admin and User are 99999999. See [3.2.2 Change Password](#) to modify if necessary.

After you successfully log in, the tool automatically enters the homepage as below.



2.3 Manage a BWC


This feature enables users to manage a BWC, including reading, edit and programming of device configurations.

2.3.1 Read Device Configurations

You can read the device configurations with any one of the following methods.

Method 1

Click the user name in the device list. The tool automatically reads and displays device information and parameters of the connected BWC



Note

The tool only reads once from BWC when you click the user name. After that, if you stay in the current edit page, this method is invalid.

Method 2

Step 1 Click **Read** on the bottom right of the edit page.

Step 2 Click **OK** in the popped dialogue box.

The edit page displays the device information and parameters read from the BWC.

2.3.2 Edit Device Configurations

2.3.2.1 Edit Device Information

Step 1 Click the user name in the device list to access the edit page.

Step 2 Edit user name, user ID, unit name and unit ID.

Device Information	
User Name	Chen Sir
User Number	168892
Group Name	XiaoHai
Group Code	910891089108



Note

Only Admin can edit device information. See [4.1 Device Information Description](#) for details.

2.3.2.2 Edit Device Parameters

Step 1 Click the user name in the device list to open the edit page.

Step 2 Edit device parameters.

Device Parameters		Reset	Import Template	Save Template
Screen Off	Never 10s 20s 30s			
Record Video Resolution	1920*1080(30fps) 1280*720(60fps) 1280*720(30fps) 848*480(30fps)			
Photo Resolution	16 million pixels 5 million pixels 3 million pixels			
Photo Quality	High Medium Low			
Pre Record Time	Off 10s 20s			
Post Record Time	Off 10s 20s 30s			
Realtime Video Resolution	1280*720(30fps) 1280*720(15fps) 848*480(30fps) 848*480(15fps)			
Watermark	Off Date/Time Date/Time+Device ID Date/Time+User Nu...			
Date/Time	2018/08/15 16:11:37 Auto Manual			
Volume	Silent Low Medium High			
Video Storage Segment	5min 10min 15min			
Language	English 简体中文			



Note

- See [4.2 Device Parameters Description](#) for details.
- For the edit permissions of Admin and User, see [4.3 Edit Permission of Device Parameters](#).

2.3.3 Program Device Configurations

After setting device information and parameters, you can program the configurations to the BWC.

Step 1 Click the user name in device list to open the edit page.


Step 2 Click **Program** on the bottom right of the edit page.

When the page shows “Programming succeeded”, the configurations are successfully programmed to the BWC.

2.4 Batch Setting

This feature enables users to manage multiple BWCs at the same time, such as the unified setting of device information and parameters.

When multiple BWCs are connected, the device list shows **Batch Setting**.



Note

- Only the Admin can conduct batch setting, and can manage 10 BWCs with the same model and version at most.
- The Admin password of all connected BWCs must be the same; otherwise the BWC verification will fail.
- Configurations cannot be read from BWC when batch setting is performed.
- Batch setting is unavailable when you connect BWCs with different models or versions.

2.4.1 Edit Device Information

For batch setting, all device information is set in Excel file. Please edit device information as below before importing the Excel file.

Step 1 Open the file “BWC Device Info.xlsx” in the installation package.

Step 2 Edit device information, such as user name and user ID.

Note

The WLAN and BT information are edited in the Excel file as well.

Step 3 Save and close the file.

2.4.2 Import Device Information

Step 1 Click **Batch Setting** in the device list to open the edit page.

Step 2 Click **Import Device Information**, and the window **Select File** pops up.

Step 3 Select the Excel file of device information and click **Open**.

After the file is imported to the tool, you can view the imported device information in the **Pending** column.

Device Information						
Pending (2)		Done (2)			Import Device Information	
User Name	User ID	Unit Name	Unit ID	WLAN Name	BT Name	Status
Chen Sir	168888	XiaoHai	910891089108	VM680	VM680	Successful
User	111111	XiaoHai2	910891089108	VM681	VM681	Successful

2.4.3 Edit Device Parameters

Step 1 Click **Batch Setting** in the device list to open the edit page.

Step 2 Edit device parameters.

Device Parameters					Reset	Import Template	Save Template
Screen Off	Never	10s	20s	30s			
Record Video Resolution	1920*1080(30fps)	1280*720(60fps)	1280*720(30fps)	848*480(30fps)			
Photo Resolution	16 million pixels	5 million pixels	3 million pixels				
Photo Quality	High	Medium	Low				
Pre Record Time	Off	10s	20s				
Post Record Time	Off	10s	20s	30s			
Realtime Video Resolution	1280*720(30fps)	1280*720(15fps)	848*480(30fps)	848*480(15fps)			
Watermark	Off	Date/Time	Date/Time+Device ID	Date/Time+User Nu...			
Date/Time	2018/08/15 16:11:37	Auto Manual					
Volume	Silent	Low	Medium	High			
Video Storage Segment	5min	10min	15min				
Language	English	简体中文					



Note

See [4.2 Device Parameters Description](#) for details.

2.4.4 Program Device Configurations


You can program the configurations to the BWC.

Step 1 Click **Batch Setting** in the device list to enter edit page.


Step 2 Click **Program** on the bottom right of the edit page.

The tool programs the configurations to all connected BWCs in the order of the device number 1~10.

After programming finishes, you can view the device information in **Done** column.

Device Information						
Pending (2)		Done (2)				
User Name	User ID	Unit Name	Unit ID	WLAN Name	BT Name	Status
Chen Sir	168888	XiaoHai	910891089108	VM680	VM680	Successful
User	111111	XiaoHai2	910891089108	VM681	VM681	Successful

2.5 Exit

Step 1 Click  in top right corner of the home page.

Step 2 Click **Exit** from the drop-down list.

3. Other Operations

3.1 Manage Template

You can save device parameters of a BWC as template, and then import the template to configure other BWC.

This feature can be applied to manage a BWC or multiple BWCs.

3.1.1 Save Template

Step 1 Click the user name in the device list to open the edit page.

**Note**

To use the template for multiple BWCs, click **Batch Setting** to open the edit page.

Step 2 Click **Save Template** in the edit page, the window **Save Template** prompts.

Step 3 Enter the template name and click **Browse** to select the file save path.

Step 4 Click **OK** to save template as TPL file.

3.1.2 Import Template

Step 1 Click the user name in the device list to open the edit page.

**Note**

To use the template for multiple BWCs, click **Batch Setting** to open the edit page.

Step 2 Click **Import Template** in the edit page, the window **Choose File** prompts.

Step 3 Choose the template file to be imported and click **Open**.

You can view the imported device parameters after importing finishes.

3.2 Password Management

3.2.1 Retrieve Password

**Note**

Only the Admin can retrieve password. Please choose the **Admin** account in the login page.

Step 1 Click **Forget Password** in the Admin login page to enter **Retrieve Password** page.


Step 2 Obtain the verification code according to the instructions in the page.

Step 3 Enter the correct verification code, and click **OK** to view the retrieved Admin password.


3.2.2 Change Password

3.2.2.1 Change Admin Password

Step 1 Use the Admin account and password to log in and enter the homepage.

Step 2 Click  in the top right corner and choose **Change Password**.

Step 3 Enter the Old Password, New Password and Confirm Password in the **Admin** tab page.



The screenshot shows a 'Change Password' dialog box with a dark blue header and a close button (X) in the top right. Below the header are two tabs: 'Admin' (highlighted in yellow) and 'User'. The form contains four input fields: 'User Name' with the value 'Admin', 'Old Password' with the placeholder '8 numbers only', 'New Password' with the placeholder '8 numbers only', and 'Confirm Password' with the placeholder '8 numbers only'. At the bottom are two buttons: a green 'OK' button and a grey 'Cancel' button.

Step 4 Click **OK** to save new password.



Note


You can set the Admin password of all connected devices to the same one. Please make sure all devices are successfully connected to the PC and the old password verification succeeded.

3.2.2.2 Change User Password


Change password by Admin

Step 1 Use the Admin account and password to log in and enter the homepage.

Step 2 Click the user name in the device list to choose a device.

Step 3 Click  in the top right corner and choose **Change Password**.

Step 4 Enter new password and confirm password in the **User** tab page.




The screenshot shows the same 'Change Password' dialog box, but the 'User' tab is now highlighted in yellow. The 'User Name' field contains the value 'User'. The 'Old Password' field contains seven asterisks (*****). The 'New Password' and 'Confirm Password' fields have the placeholder '8 numbers only'. The 'OK' and 'Cancel' buttons are at the bottom.


Step 5 Click **OK** to save new password.

Change Password by User

Step 1 Use the User account and password to log in and enter the homepage.

Step 2 Click  in the top right corner, and choose **Change Password**.

Step 3 Enter the Old Password, New Password and Confirm Password.



The image shows a 'Change Password' dialog box with a dark blue title bar and a close button (X) in the top right corner. The dialog contains four input fields: 'User Name' with the text 'User', 'Old Password' with the placeholder '8 numbers only', 'New Password' with the placeholder '8 numbers only', and 'Confirm Password' with the placeholder '8 numbers only'. At the bottom, there are two buttons: a green 'OK' button and a grey 'Cancel' button.

Step 4 Click **OK** to save new password.

3.3 Manage BWC Disk



Note

Only the Admin can manage disk.

3.3.1 Format Disk



Note

After disk formatting, all media files in the BWC will be cleared, including videos, photos and audios. Please be careful to format the disk.

Step 1 Click the user name in the device list.


Step 2 Click .

Step 3 Click **OK** in the popped dialogue box.

The page prompts “Formatting succeeded”.

3.3.2 Switch to Disk Mode

Step 1 Click the user name in the device list.

Step 2 Click  to switch to the disk mode.

The disk directory window automatically pops up. You can view and manage the BWC files, such as photos, videos.

3.4 Upgrade Firmware


Before upgrade, please contact the customer service to obtain the upgrade file.



Note

Only the Admin can upgrade the BWC.

Step 1 Click the user name in the device list.

Step 2 Click  and choose the upgrade file in the popped up window.

The upgrade file is automatically copied to the BWC, and the tool interface prompts “File copied to the device, disconnect the device to upgrade”.

Step 3 Disconnect the BWC.

The BWC detects the upgrade file and automatically execute upgrade task.

3.5 Factory Reset


This feature is for the Admin to reset the device parameters to default settings.


3.5.1 Reset a Device

Step 1 Click the user name in the device list to open the edit page.

Step 2 Click **Reset**.

Step 3 Click **OK** in the popped dialogue box.

A progress bar displays below the user name. After resetting is done, the  will display beside the user name.



3.5.2 Reset Multiple Devices

Step 1 Click **Batch Setting** in the device list to enter the edit page.


Step 2 Click **Reset**.

Step 3 Click **OK** in the popped dialogue box.


The tool executes resetting for all connected devices in the order of device number 1~10.

A progress bar displays below the user name. After resetting is done, the  will display beside the user name.


3.6 View Version

Click  in top right of the homepage, and choose **Version**.

3.7 Set Language

Click  in the top right corner of the homepage, choose **Language Setting**, and then choose the language type.

3.8 View Help

Click  in the top right corner of the homepage, and choose **Help**.

4. Appendix

4.1 Device Information Description

Name	Description
User Name	The user name of BWC, displaying the device list as well, such as police name.
User ID	The User ID of BWC, such as police ID.
Group Name	The unit name of the user, such as the name of the police station.
Group Code	The unit ID of the user, such as police station number.

4.2 Device Parameters Description

Name	Description	Applicable Models		
		VM550	VM550D	VM680
Screen Off	The screen auto-off time of BWC	√	√	√
Record Video Resolution	The resolution and transmission frame rate of local recording and stored video	√	√	√
Photo Resolution	The resolution of photos	√	√	√
Photo Quality	The quality level of photos	√	√	√
Video Quality	The video quality level.	×	×	√
Pre-record Time	The pre-record feature can help to capture the moments of critical incidents. When enabled, long press the video button for 3 seconds to enter pre-record mode.	√	√	√
Post-record Time	The post-record feature can prolong the recording time.	√	√	√
Realtime Video Resolution	The resolution and frame rate of remote transmitted video.	√	√	√
Watermark	The watermark content of photos and videos.	√	√	√
Date/Time	The date and time of BWC. Auto: automatically synchronize time with PC. Manual: manually set the time.	√	√	√

Name	Description	Applicable Models		
		VM550	VM550D	VM680
Volume	The volume of BWC, including button press tone, alert tone, video/audio file playing volume. The higher the level is, the greater the volume will be.	√	√	√
Video Storage Segment	The duration of video storage segment. During video recording, if the recording time exceeds the specified segment time, the video will be stored as multiple files. For example, the segment time is set as 5 minutes, the video recording time is 10 minutes, and then the video will be stored as 2 files.	√	√	√
Language	The display language of BWC	√	√	√
WLAN	When enabled, BWC can use WLAN.	√	×	×
WLAN Address	The WLAN address of BWC, which is read-only.	√	√	√
WLAN Mode	The connection mode of the broadband wireless network	√	√	√
WLAN AP SSID	The WLAN SSID of BWC in WLAN AP mode.	√	√	√
WLAN AP Password	The WLAN password of BWC in WLAN AP mode.	√	√	√
WLAN Device List	The WLAN SSID and password of connectable devices in WLAN STA mode.	√	√	√
BT	When enabled, BWC can use BT feature.	×	√	√
BT Name	The BT name of BWC.	√	√	√
BT Address	The BT MAC address of BWC, which is read-only.	√	√	√
Anti-flicker	During video recording or photo taking, the recorded videos may have stripe flashing or rolling or the photo may have stripe if BWC has flicker problem. This parameter is used to set the frequency of flicker calibration.	√	√	×
Loop Video	When enabled, BWC automatically deletes the earliest video files to release storage.	√	√	√

Name	Description	Applicable Models			
		VM550	VM550D	VM680	
File Replay Password	Set the password to replay files in BWC. The user can view videos, audios and photos only after entering the correct password on BWC.	×	×	√	
File Encryption	When enabled, all media files of BWC are encrypted, including videos, photos and audios.	×	×	√	
PTT Short Press	Set the feature triggered by short pressing PTT. This feature is valid only when BWC is not connected with multi-mode radio. <ul style="list-style-type: none"> ● None: no feature is triggered. ● Start/Stop Video Recording: press PTT to start or stop video recording. 	×	×	√	
P1 Short Press	Set the feature triggered by short pressing P1 key.	<ul style="list-style-type: none"> ● Mark/Unmark: press this key to mark or cancel marking files. ● Answer Call: press this key to quickly answer call. ● Hangup Call: when receiving a call, press this key to reject the call. During a call, press this key to end the call. ● Accept Video Upload: press this key to accept the video transmission request and transmit the live videos to the dispatch center. ● Reject Video Upload: when receiving the video transmission request, press this key to reject the request. During live video transmission, press this key to end transmission. 	√	×	×
P1 Long Press	Set the feature triggered by long pressing P1 key.		√	×	×
P2 Short Press	Set the feature triggered by short pressing P2 key.		√	×	×
P2 Long Press	Set the feature triggered by long pressing P1 key.		√	×	×

Name	Description	Applicable Models		
		VM550	VM550D	VM680
	<ul style="list-style-type: none"> ● Start/Stop Voice Recording: press this key to start or stop voice recording. ● Silent Mode On/Off: press this key enable or disable silent mode. 			

4.3 Edit Permission of Device Parameters

Name	Admin	User
Screen Off	√	√
Record Video Resolution	√	√
Photo Definition	√	√
Video Quality	√	×
Photo Quality	√	√
Pre-record Time	√	×
Post-record Time	√	×
Realtime Video Resolution	√	√
Watermark	√	×
Date/Time	√	×
Volume	√	√
Video Storage Segment	√	√
Language	√	√
WLAN	√	×
WLAN Address	×	×
WLAN Mode	√	×
WLAN AP SSID	√	×
WLAN AP Password	√	×

Name	Admin	User
WLAN Device List	√	×
BT	√	×
BT Name	√ (manage single BWC)	×
BT Address	×	×
Anti-flicker	√	×
Loop Video	√	×
File Replay Password	√	√
File Encryption	√	×
PTT Short Press	√	×
P1 Short Press	√	×
P1 Long Press	√	×
P2 Short Press	√	×
P2 Long Press	√	×

Abbreviation

Abbreviation	Full Name
BWC	Body Worn Camera

