



WWW.EPHCONTROLS.COM/EMBER

GATEWAY INSTRUCTIONS

Welcome

Thank you for choosing EMBER by EPH Controls. We hope you enjoy using it as much as we did developing it!

Controlling your heating anywhere, anytime is only a few simple steps away.

In this booklet, we will provide a step by step guide to setting up the EMBER heating control app and its associated hardware.

Again, thank you for choosing EMBER.

Index

- Page 4 Getting started
(Router requirements/Phone software etc)
- Page 5 LCD / Button legend
- Page 6 Pairing programmer to your gateway
- Page 7 Pairing thermostats to your programmer
- Page 8 Downloading your EMBER App
- Page 13 Pairing the gateway to your wireless internet
- Page 16 Home setup
- Page 18 Home screen diagram

Getting Started

WiFi Requirement

The SSID of your Wi-Fi should not be hidden when you are pairing the gateway to your router.

Please install the gateway in a place with a good Wi-Fi signal.

The gateway can only support 2.4 GHz wireless routers. It does not support 5 GHz wireless routers.

The MAC address of gateway should not be in the blacklist of the router.

Please restart your wireless router periodically or restart it before you are going on holiday to ensure that the connection is kept after long periods of inactivity.

Pay attention to the number of devices connected to your wireless router. Some routers may not work properly if too many devices are connected.

Device Operating System

- 1) Minimum IOS is 8.
- 2) Minimum Android OS is 4.2.
(Jellybean)

LCD / Button Legend








Figure (5-a): The gateway



Buttons to be used during gateway installation

Figure (5-b): The RF programmer

Pairing programmer to your gateway

1. Reset your router by switching it off and on.
2. On the Programmer, press  button for 5 seconds.
3. 'Wireless Connect' will appear on the screen. Figure (6-a)
4. Press the  button for 3 seconds. You will now enter the wireless connection screen.
5. A four digit code will appear on the screen. Figure (6-b)
6. On the Gateway, press the 'Function' button for 5 seconds.
7. Red and green lights on the gateway will both flash simultaneously every 1 second.
8. On the Programmer – R1 appears on the screen. Figure (6-c)
9. Press the  button.




Figure (6-a): 'Wireless Connection' screen




Figure (6-b): 'Gateway Connection' screen





Figure (6-c): 'Gateway Connection' screen

Pairing thermostats to your programmer


Lower the cover on the front of the RF programmer. Move the selector switch to the 'RUN' position.



On the RF programmer, press the  button for 5 seconds. Wireless Connect will appear on the screen. Figure (7-a)

On the RFR wireless room thermostat or RFC wireless cylinder thermostat, press the 'Code' button. This is located inside the housing on the Printed Circuit Board. Figure (7-b)

On the RF programmer, the available zones will begin to flash.

Press the  button for the zone you wish to connect the thermostat to.

The wireless symbol  appears on the screen.

The thermostat will count upwards to the number of the zone that it is paired with. When it reaches the number of the zone that it is paired with press the hand wheel on the thermostat.

The RF programmer is now operating in the wireless mode. The temperature of the wireless thermostat is now displayed on the programmer.

Repeat this process for the second, third and fourth zone if required.




Figure (7-a) 'Wireless Connection' screen



Reset button Code button

Figure (7-b) Printed Circuit Board






Figure (7-c) Zone screen


Downloading your EMBER App

1. Go to the Apple App Store on your iPhone or the Google Play Store on your Android device and download the EPH Ember App.
2. Once the app has been installed, open it.
3. Select to Sign up with your email address.

QR codes to the download links are available on the back cover.





4. Enter your Name.
5. Enter your Surname.
6. Enter your Email address.
7. Enter your Password (Minimum 6 characters – including lowercase, uppercase and number)
8. Confirm your Password.
9. Enter your telephone number. (optional)
10. Press Sign up.



Downloading your EMBER App (Continued)



11. Wait for a confirmation email from EMBER. (This could take 1 – 2 minutes)
12. Open the email and press the embedded button 'Click to activate your account'.
13. You will be directed to the EMBER app. Select 'Open' in Ember. If you are not automatically directed to the app, manually open it and complete step 14.



14. When the app opens, enter your email address and password.

15. Press 'Login'.

16. Press 'OK' to allow EMBER to send you notifications.



Downloading your EMBER App (Continued)

17. Ember opens in tutorial mode. Swipe left and right to view tutorial screens or press 'X' on top right of screen to continue the setup process.



Pairing the gateway to your wireless internet

1. **ON YOUR MOBILE DEVICE** - Press 'GO' on 'WiFi SETUP' and you will be directed to the WiFi Setup page.

If you have been given an invite code, Press 'GO' on the 'INVITE CODE' section, you may then enter the code to access the home you have been invited to.



Pairing the gateway to your wireless internet (Continued)

2. Ensure your mobile device is on the same network that the Gateway will be connected to. This will ensure that the SSID will be automatically populated with the correct information.
6. If pairing is unsuccessful, please repeat steps 4 & 5.
7. The Gateway now needs to be associated with your mobile device.

-- NOTE --

After entering router password, do not press continue button. Complete step 4 and then press continue button as per step 5.

3. Enter Wi Fi router password –
4. On the Gateway press the Function button once and within 1 second press the Smartlink button once.
Red and green lights on the gateway will both begin to flash.
5. On your mobile device, immediately press CONTINUE.

When successful the lights on the Gateway will be solid Green and you will progress to the Gateway Code screen (This can take up to 30 seconds).




8. Enter the ID WiFi code or scan the barcode which are both located on the gateway housing.
9. Press 'CONTINUE' once only.

Home setup appears on the screen – this may take a moment.

The number of zones connected to the programmer is detected and shown on the screen.

Press 'Home setup' to change home and zone names.



Home setup

1. Enter Home Name.
2. Enter Zone Names. It is not possible to rename the Hot Water zones.
3. Enter Location.
4. Press Save.
5. Invite user screen will appear.
6. Invite other users if needed or press 'Continue' to skip.

HOME SET UP

HOME NAME

Home

ZONE NAMES

Zone 1

Hot Water

LOCATION

eg. Dublin

SAVE >

INVITE USERS

Add emails by entering an email address and press 'Confirm'.
Invited users will receive an invite email with the invite code.

Enter email

CONFIRM


Invitation Code BA9A4

Generate Invite Code


CONTINUE >

7. You will receive a summary confirming the changes that you have made.
8. Press 'Continue'.
9. A summary will appear on the screen confirming the Home Setup is complete.

10. The Home screen will appear with the relevant number of zones now able to be controlled from your mobile device.



Home screen diagram



Notes

EPH Controls IE

Sitecast Industrial Estate,
Pouladuff,
Cork, T12 W665
Ireland

T +353 21 434 6238
F +353 21 454 5890

sales@ephcontrols.com
www.ephcontrols.com

EPH Controls UK

Unit E4, Welland Business Park,
Valley Way, Market Harborough,
Leicestershire, LE16 7PS
United Kingdom

T +44 1933 626 396
F +44 1933 626 218

sales@ephcontrols.co.uk
www.ephcontrols.co.uk

