WARNING

Failure to heed these Safety Precautions could result in accident and serious injury.

- 1) ONLY trained persons using proper equipment and procedures should mount tyres.
- 2) ALWAYS check tyre for cuts, cracks, foreign objects on interior and exterior surface, deformation damage, corrosion damage, and other damage or abnormalities, when fitting the tyre on the rim. NEVER use the tyre when the damage has reached the code layer.
- 3) NEVER use the rim with cuts, cracks, foreign objects on interior and exterior surface, deformation damage, corrosion damage, and other damage or abnormalities.
- 4) ALWAYS mount the tyre to the proper size of rim.
- 5) ALWAYS check the rotating direction on the sidewall and equip them accordingly to the indication. (Depending on the tyre, indication may not be marked on the sidewall).
- 6) ALWAYS lubricate the tyre beads and rim flange with an approved tyre lubricant when fitting the tyre onto the rim. Please leave more than ten minutes after mounting the tyre in order to dry the tyre lubricant.
- 7) ALWAYS inflate tyre / rim assembly in a safety cage or other restraining device using extension gauge and hose with clip-on air chuck. NEVER stand, lean on or reach over the assembly during inflation.
- 8) NEVER stand at either side of the tyre while inflating it because the rim may be propelled to the side if there is an explosive separation.
- 9) NEVER unplug the valve core while seating tyre to the rim.
- 10) NEVER inflate beyond 4.0 kgf/cm2 (57psi) pressure to seat beads. If beads are not properly seated when pressure reaches 4.0 kgf / cm2 (57psi), completely deflate and demount the assembly, re-lubricate the beads and re-inflate.
- 11) ALWAYS adjust the pressure regulating valve for air compressor below 5.0 kgf / cm2, due to the risk of rupture of the tyre.
- 12) ALWAYS remove the water in the compressor frequently, in order to avoid the water to enter in to tyre while inflating.
- 13) ALWAYS check tyre for proper seating and air leaks after inflation. Use soapy water when checking for air leaks, especially around value.
- 14) ALWAYS use the valve cap while driving.
- 15) ALWAYS adjust the wheel balance in order to prevent the abnormal vibration and irregular wear.
- 16) ALWAYS check whether there is a risk of tyre touching the vehicle after the equipment, in order to reduce the risk of rupture.
- 17) ALWAYS check for the air pressure before using the tyre when tyre is not heated. Air pressure may drop naturally.
- 18) ALWAYS take a great caution with accelerating, braking, and cornering immediately after mounting the tyre. It may take a while for the tyre wax to be removed from the tread surface and gain a stabilized grip.
- 19) ALWAYS check tyre for cuts, cracks, foreign objects and other damage or abnormalities. If tyre is used for racing, ALWAYS check it before each race.
- 20) NEVER use the tyre on public road
- 21) NEVER contact the sidewall of the tyre to the curb, nor run in to the projections in order to avoid the risk of tyre damage.
- 22) ALWAYS select the tyre in accordance with the usage and regulation of the competition, by referring the above mentioned table as reference.
- 23) NEVER use the tyre polisher nor tyre sealant in order to avoid harmful deterioration in the tyre.
- 24) NEVER adhere the tyre cleaner which contains silicon/ wax, or tyre lubricant on the tread surface. In any case that tyre cleaner or lubricant had been adhered, please make sure to remove them and take a great caution while driving.
- 25) NEVER store the tyre near the rain, water, heat, oil, direct sunlight, any instrument which could create an electricity / heat, or other factor that could lead to tyre damage.
- 26) ALWAYS take a great caution when storing the tyre under low temperature. Any excessive force or shock under low temperature could cause a cracking on the tread.



2017~ DUNLOP RACING KART TYRE CATALOGUE

for competition use


SLICK / KT3 / KT12 / KT14 RENTAL KART



SUMITOMO RUBBER INDUSTRIES, LTD.

Toyosu Center Building,3-3,3chome,Toyosu,Koto-ku,Tokyo 135-6005,Japan TELEPHONE: (+81)-3-5546-0126 FACSIMILE: (+81)-3-5546-0146

GRIP **ENDURANCE**



FRONT 11X5.00-6

REAR 11.5X7.10-6

■CIK-FIA HOMOLOGATION •CIK-FIA (Commission Internationale de karting-FIA) have established an homologation rule to reduce driver's burden for racing expenses.

CIK HOMOLOGATED

CIK HOMOLOGATED



CIK Homologated Tyre

DF M / PRIME **SLICK**

The compound focuses on anti-wear performance and this enables the powerful and flexible stability on steering even at the high temperature and high μ road surface.



CIK Homologated Tyre

DF H / OPTION **SLICK**

Enhanced a compatibility on high grip performance and high level wear resistance. Even shows a maneuverability arranged on a medium compound.



CIK Homologated Tyre

W13 , WET **KT14**

Shows great potential in wet condition with high grip and aquaplaning performance.



KT14

SL type

RS1 / SL TYPE **SLICK**

In addition to the excellent wear resistance, managed to improve the grip performance and achieved a stable running on a road.



SL type

SL W2 / WET

KT12

Enhanced a compatibility on wet performance and wear resistance. Even shows an improvement in sized up front tyre.



 \blacksquare = 6inch \blacksquare = 5inch

RENTAL KART

DF2 / SLICK

309949

4.5

309951 8.0 288

278

Controllable tyre for rental kart with long life.