

Cuisinart®



Deluxe Grind Conical Burr Mill


CBM-20C

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be taken, including the following:

1. Read all instructions.
2. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
3. To protect against risk of electrical shock, do not immerse cord, plug or grinder in water or other liquids.
4. Close supervision is necessary when any appliance is used by or near children, or individuals with certain disabilities.
5. Avoid contact with moving parts.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized Cuisinart service facility for examination, repair, or mechanical or electrical adjustment.
7. The use of attachments not recommended or sold by Cuisinart may cause fire, electrical shock, or risk of injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Before using, check hopper for the presence of foreign objects.
11. Use this appliance to grind roasted coffee beans only. Grinding other substances, such as nuts, spices or unroasted beans, may dull the blade and cause poor grinding or injury.
12. Do not use appliance for other than its intended use.
13. Do not place this appliance on or near a hot gas or electric burner, or in a heated oven.
14. Do not operate your appliance in an appliance garage or under a wall cabinet. When storing in an appliance garage, always unplug the unit from the electrical outlet. Not doing so could create a risk of fire, especially if the appliance touches the walls of the garage or the door touches the unit as it closes.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY



1. Hopper Lid
2. Bean Hopper
3. Conical Burr Grinder (not shown)
4. Grind Selector
5. LCD Display
6. Start/Stop Button
7. Cup Selector
8. Manual Button
9. Grind Outlet

10. Grind Chamber Lid
11. Grind Chamber
12. Shelf with Filter Clips (not shown)
13. Scoop Brush in holder (on back, not shown)
14. Cord Storage (not shown)
15. BPA Free (not shown)
All parts that come in contact with coffee are BPA free

NOTICE

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

INTRODUCTION

The next generation of coffee grinders has arrived to deliver the new standard in home-ground coffee! The conical burr grinds the beans with precise uniformity while maintaining the full flavor of the coffee bean. Whether you're using a French press, auto drip or espresso machine, you'll always start with the best, most precise grind. This grinder is fully automated – just choose your number of cups and grind setting, push Start, and the LCD with countdown timer lets you know how soon you'll have your perfectly ground coffee!

GETTING STARTED

When you open your new grinder, you will notice it must be assembled before use.

Take all the parts out of the box and remove plastic and packaging.

1. Place bean hopper on top of unit making sure it aligns correctly.
2. Remove lid from bean hopper and locate the lock/unlock knob and rotate clockwise into lock position and replace lid.
3. Place grind chamber lid on grind chamber and insert into unit (as pictured on page 3).
4. Insert scoop brush into holder on the base of the unit. Your unit is now ready to be used.

GRIND DIRECTLY INTO:

- Grind chamber (included)
- Gold-tone filter (cone or basket style)
- Paper filter (cone or basket style)
- Portafilter
- Cuisinart® HomeBarista™ Reusable Filter Cup or most single serve reusable capsules

OPERATING INSTRUCTIONS

1. Remove bean hopper lid.
2. Fill bean hopper, making sure that the lid closes securely. Maximum capacity is 16 oz (450 g); be sure you have enough beans to grind your desired amount of coffee.
3. Plug cord into outlet.
4. Select grind setting – rotate the grind selector dial to choose desired grind size. The higher the number, the coarser the grind. Use 1–6 for espresso, 7–12 for auto drip, 13–18 for French press. Your current selection will be displayed on the LCD.
5. Select cup setting – press the CUPS button repeatedly until your desired number of cups is displayed on the LCD, from 1 to 14 cups.
6. Place your preferred grounds container under grind outlet. (see page 4 for different grounds collection receptacles).

NOTE: Use care when grinding into filters as some grinds may escape to your counter. To help alleviate - we suggest always using the grind chamber lid as a guard (see photo page 7) except when using the HomeBarista™ or other single serve reusable capsule. See specific filter use directions on pages 7-8.

7. Press the Start/Stop button to begin grinding. A safety interlock system prevents the unit from operating unless the hopper is properly in place.

NOTE: If the grind chamber is overfilled, the chute can get clogged and the unit will not work. The LCD will flash. To unclog, first unplug your grinder and then use the scoop brush to clear out the chute of excess grounds.

Also note: If the grinder stops and displays EE in the LCD screen at any point, the motor has likely overheated. Unplug the grinder and wait for it to cool off (up to 30 minutes); when the EE is no longer displayed, resume use.

8. Grinding will automatically stop upon completion.
NOTE: To pause or cancel operation during use, see page 6.
9. Pull the grind chamber toward you or slide your preferred grounds container out to remove from unit.

To Pause or Cancel Grinding

1. To pause the grinding, press the Start/Stop button. The grinder will stop and the countdown timer will flash. Press the Start/Stop button again to resume.
2. To cancel the grinding, press and hold the Start/Stop button for 2–3 seconds.

NOTE: The unit will pause for up to 5 minutes before canceling the grind.

Manual Grind

If you prefer, after selecting your grind setting, you have the option of manually controlling how much coffee the unit will grind. To do so, follow steps 1–4 on previous page. Then press and hold the manual button until the desired amount of coffee has been ground. The LCD will display M.


NOTE: To avoid overflow when using the manual feature, the grinder will turn off automatically after approximately 1 minute.

Grinding Settings

When selecting your grind setting, remember that the higher the number the coarser the grind. Use 1–6 for espresso, 7–12 for auto drip, and 13–18 for French press.

NOTE: If you meet resistance when going from coarse to fine, a bean may be stuck. Re-insert grounds container or filter, then simply press the manual button while turning the grind dial towards fine.

Grinding Into Filters



Paper Filters

1. Flip shelf up to locate the two sets of clips.
2. Slide filter into the clips.
3. Slide the grind chamber lid into grind outlet.

NOTE: For cone shaped filters (a), use **top clips**. For basket style filters (b), use **bottom clips**.




TIP: When grinding over 10 cups of coffee into a paper filter, use hands to support filter to avoid the weight of the grinds from pulling the filter out of the clips.

Gold Tone Filters

1. Slide the grind chamber lid into grind outlet.
2. Place gold tone filter (c) into position under the grind outlet and proceed with grinding.

NOTE: For basket style filters you can pull down the shelf and rest filter on top for easy grinding.




Cuisinart® HomeBarista™ Reusable Filter Cup

1. Flip shelf down.
2. Slide filter cup onto shelf (d), lining up the top of the filter cup with the grinder spout, and guiding the bottom into the shelf's grooved opening.

TIP: Select either 1 or 2 cups on your grinder. Selecting a larger number may cause the filter cup to overflow. The recommended grind setting for auto drip coffee makers is 7-12, depending on preference of coarseness.

NOTE: When using a single-serve filter-cup other than a Cuisinart HomeBarista™ Reusable Filter Cup, you may need to hold the filter cup under the grinder spout to fill.



CLEANING/MAINTENANCE INSTRUCTIONS

NOTE: If your unit stops grinding, the chute may be clogged. To unclog, first unplug your grinder and then use the scoop brush to clear out the chute of excess grounds.

HOPPER

1. Unplug unit.
2. Beans can be removed from the hopper by lifting off the lid and rotating the knob to the "unlock" position. Once unlocked, the hopper can be removed to pour out remaining beans.

BURR GRINDER

1. After removing hopper, if some beans remain in the grinder, put hopper back on, re-insert the grind container or filter and run a grind cycle for 8 cups on any grind setting. Once finished, you can continue cleaning as instructed.
2. Rotate the grind selector dial counterclockwise until dial stops. OFF will be indicated on LCD.
3. Unplug unit.
4. Remove the bean hopper lid and turn the lock/unlock dial counterclockwise to release the bean hopper. **NOTE:** You will notice the release arrow and arrow on the burr on the inside of unit are now aligned. They must be aligned in order to re-insert the hopper.
5. Once the bean hopper has been removed, remove the burr grinder by grasping the metal handle and lifting up. Use the brush to remove grinds or wash by hand. Replace the burr grinder on the unit and rotate until the piece is fully inserted. Push handle down, replace and lock hopper.
Note: The hopper will not attach to the unit if the grinder has not been fully inserted. The brush on the measuring scoop is only for cleaning purposes.
6. Wipe body of grinder with a damp cloth.

NOTE: The bean hopper, bean hopper lid, grind chamber, and grind chamber lid can be washed by hand with hot, soapy water or placed in the top shelf of a dishwasher. Dry thoroughly.

MAINTENANCE

Any other servicing or maintenance should be performed by an authorized service representative.

WARNING: NEVER IMMERSE UNIT IN WATER.

WARRANTY

LIMITED THREE-YEAR WARRANTY (U.S. and CANADA only)

We warrant that this Cuisinart product will be free of defects in materials or workmanship under normal home use for 3 years from the date of original purchase. This warranty covers manufacturer's defects including mechanical and electrical defects. It does not cover damage from consumer abuse, unauthorized repairs or modifications, theft, misuse, or damage due to transportation or environmental conditions. Products with removed or altered identification numbers will not be covered.

This warranty is not available to retailers or other commercial purchasers or owners. If your Cuisinart product should prove to be defective within the warranty period, we will repair it or replace it if necessary. For warranty purposes, please register your product online at www.cuisinart.ca to facilitate verification of the date of original purchase and keep your original receipt for the duration of the limited warranty. This warranty excludes damage caused by accident, misuse or abuse, including damage caused by overheating, and it does not apply to scratches, stains, discolouration or other damage to external or internal surfaces that does not impair the functional utility of the product. This warranty also expressly excludes all incidental or consequential damages.

Your Cuisinart product has been manufactured to the strictest specifications and has been designed for use only in 120 volt outlets and only with authorized accessories and replacement parts. This warranty expressly excludes any defects or damages caused by attempted use of this unit with a converter, as well as use with accessories, replacement parts or repair service other than those authorized by Cuisinart.

If the appliance should become defective within the warranty period, do not return the appliance to the store. Please contact our Customer Service Centre:

Toll-free phone number:

1-800-472-7606

Address:

Cuisinart Canada
100 Conair Parkway
Woodbridge, Ont. L4H 0L2

Email:

consumer_Canada@conair.com

Model:

CBM-20C

To facilitate the speed and accuracy of your return, please enclose:

- \$10.00 for shipping and handling of the product (cheque or money order)
- Return address and phone number
- Description of the product defect
- Product date code*/copy of original proof of purchase
- Any other information pertinent to the product's return

* Product date code can be found on the underside of the base of the product. The product date code is a 4 or 5 digit number. Example, 90630 would designate year, month & day (2009, June 30th).

Note: We recommend you use a traceable, insured delivery service for added protection. Cuisinart will not be held responsible for in-transit damage or for packages that are not delivered to us.

To order replacement parts or accessories, call our Customer Service Centre at 1-800-472-7606. For more information, please visit our website at www.cuisinart.ca.

Cuisinart®



Coffeemakers



Blenders



Juicers

Cuisinart™ offers an extensive assortment of top quality products to make life in the kitchen easier than ever. Try some of our other countertop appliances and cookware, and Savor the Good Life®.

www.cuisinart.ca

©2016 Cuisinart Canada
100 Conair Parkway,
Woodbridge, ON L4H 0L2

Printed in China

16CC023518

Trademarks or service marks of third parties referred to herein are the trademarks or service marks of their respective owners.

IB-13463-CAN