

ELECTRONIC ANALYTICAL BALANCE



INSTRUCTION BOOK

(FA Model)

I About the Balance

Specification

Model	Range	Division	Repeatability	Linearity	Pan Size
FA1104	110g	0.1mg	0.2mg	0.5mg	∅ 80mm
FA1204	120g	0.1mg	0.2mg	0.5mg	∅ 80mm
FA2004	200g	0.1mg	0.2mg	0.5mg	∅ 80mm
FA2104	210g	0.1mg	0.2mg	0.5mg	∅ 80mm
FA2204	220g	0.1mg	0.2mg	0.5mg	∅ 80mm

Features

Stainless Steel Pan

Super bright LCD display with backlight

RS232 Interface

Mains adapter supplied as standard

Windshield supplied as standard

Height adjustable feet

Auto Calibration

Selectable measure units:mg, g, oz, ct

Memory for accumulated time

Applications

Weighing

Net weight / tare

Below balance weighing

Piece counting function

8.1 DATA OUTPUT

1	Model or a decimal point
2	A space or a decimal point
3	A space or *
4	+ or - or a decimal point
5	data
6	Data or a decimal point
7	Data or a decimal point
8	Data or a decimal point
9	Data or a decimal point
10	Data or a decimal point
11	Data or a decimal point
12	Data
13	Unit 1
14	Unit 2
15	Unit 3
16	Enter
17	Wrap

7.1 FAULT JUDGMENT

If you come across any problem, you can check it by you self and find the reasons.

07

FAULT	RESON	EXCLUDE
No display	Not connected to the power supply; Fuse is broken; Power transformer damage;	Plug in the power line; Replace the fuse; Replacement of power transformer; Contact factory
Weighing unstable	Bad working conditions; The wind screen is open ; Something between the table and balance ; The power unstable ; Weighing unstable ;	Keep the environment stable,close the windows and doors ; Close the glass door ; Take away the things ; Connect the stable power ;
The weighing digitsis wrong	The balance not calibration. Not tare before weighing. No adjust the level.	Calibration. Tare before weighing. Adjust the level feet.

IISETTINGS

TABLE OF CONTENTS

1.0 KNOW YOUR BALANCE

2.0 SPECIFICATIONS

3.0 UNPACKING THE BALANCE

4.0 LOCATING THE BALANCE

5.0 SETTING UP THE BALANCE

5.1 ASSEMBLING THE BALANCE

5.2 LEVELLING THE BALANCE

6.0 OPERATION SETTINGS

6.1 SENSITIVITY SETTING

6.2 SPEED SETTING

6.3 WEIGHING UNIT SETTING

7.1 FAULT JUDGMENT

8.1 DATA OUTPUT

1.0 KNOW YOUR BALANCE

Thank you for selecting the AE-FA Series Analytical Balance.

This Instruction Manual will guide you of the installation, accessories, trouble-shooting, after sales service information, general maintenance of the balance, etc. it will also guide you through the various applications.

Please read this Manual thoroughly before starting the operations. If you need any clarifications, feel free to contact us.

The FA balances are ideal for laboratory and general purpose weighing. The balances can also be used for some advanced weighing functions.

FEATURES:

Stainless Steel Pan

Super bright LCD display with backlight

RS232 Interface

Adapter supplied as standard

Windshield supplied as standard

Height adjustable feet, Bubble Level

Auto Calibration

Selectable measure units, g, oz, ct

Memory for accumulated time

Weighing function

Piece counting function

Below balance weighing

6. 4 COUNTING FUNCTION

There are counting functions in the balance, and you can use this for count the quantity. And please keep the products have the same weight, and the minimum weight must be $\geq 0.5\text{mg}$.

The details operation as blow :


1. Press "ON" key , enter the menu , then press "ON" key , until it show "COU" ;



2. Press "0/T" to enter the counting function , it show " COU 5pcs" ;



3. Press "ON" choose the quantity for sample , and put on the same weight , press "0/T" enter :



4. it will show the number after COU , then you can begin the counting ;




5. After the counting press "ON" and choose "weight" , press "0/T" back to the weighing .



06

6.2 SPEED SETTING


Keep pressing **ON**, when “**speed**” will show in the display,



press →0/T← to save setting

6.3 WEIGHING UNIT SETTING

Keep pressing **ON**, when **Unit** is shown ,Then operation as below:



05

2.0 SPECIFICATIONS

Model	FA1004	FA1104	FA1204	FA2004	FA2104	FA2204
Range	0-100g	0-110g	0-120g	0-200g	0-210g	0-220g
Division	0.1mg					
Repeatability	0.2mg					
Linearity	0.5mg					
Resp. Time	≤ 4 Sec.					
Pan Size	ø80mm					
Tare Range	Full					
Interface	RS-232 bi-directional					
Overall Dimensions	340 x 215 x 350mm					
Operating temperature	+10°C to 40°C					
Power Supply	Output voltage 5 VDC, 600mA through External Power Adapter as standard (Input Voltage 220 V, 50/60 Hz)					
Net Weight	7.5 kg					

3.0 UNPACKING THE BALANCE

Remove the balance from the packing by carefully lifting it out of the box.

Inside the box you will find everything needed to start using the balance

4.0 LOCATING THE BALANCE

- The balance should not be placed in a location that will reduce the accuracy.
- Avoid extremes of temperature. Do not place in direct sunlight or near air conditioning vents.
- Avoid unsuitable tables. The table or floor must be rigid and not vibrate.
- Avoid unstable power sources. Do not use near large users of electricity such as welding equipment or large motors.
- Do not place near vibrating machinery.
- Avoid high humidity that might cause condensation. Avoid direct contact with water. Do not spray or immerse the balances in water.
- Avoid air movement such as from fans or opening doors. Do not place near open windows or air-conditioning vents.
- Keep the balance clean. Do not stack material on the balances when they are not in use.

5.0 SETTING UP THE BALANCE

5.1 ASSEMBLING THE BALANCE

- Locate balance on solid surface, free from vibration
- Open the sliding door and gently place the stainless steel top.
- Level balance using the adjustable feet and the bubble level
- Connect the power to the balance
- For best performance, let the balance warm up for 30-60 min. and calibrate before using

5.2 LEVELLING THE BALANCE

After placing the balance in a suitable place, level it by using the bubble level. To level the balance turn the two adjustable feet at the rear of the balance until the bubble in the bubble level is centred.

6.0 OPERATION SETTINGS

6.1 SENSITIVITY SETTING

Keep pressing **ON**, when " **Stab** " is shown in the display,.

Then operation as blow:

 -----**Highest Sensitivity**

 -----**High Sensitivity**

 -----**Normal Sensitivity**

 -----**Poor Sensitivity**

press **→0/T←** to save setting

